

# OPERATION & MAINTENANCE

Paver Finisher  
F1200C / F1200CS  
Type 456 / 457



EN 02-0416  
4812023636



# Table of contents

<b>V</b>	<b>Preface .....</b>	<b>1</b>
1	General safety instructions .....	2
1.1	Laws, guidelines, accident prevention regulations .....	2
1.2	Safety signs, signal words .....	3
	"Danger"! .....	3
	"Warning" ! .....	3
	"Caution" ! .....	3
	"Note" ! .....	3
1.3	Other supplementary information .....	3
1.4	Warnings .....	4
1.5	Prohibitive symbols .....	6
1.6	Protective equipment .....	7
1.7	Environmental protection .....	8
1.8	Fire prevention .....	8
1.9	Additional information .....	9
2	CE identification and Declaration of Conformity .....	10
3	Guarantee conditions .....	10
4	Residual risks .....	11
5	Sensibly predictable incorrect usage .....	12
<b>A</b>	<b>Correct use and application .....</b>	<b>1</b>
<b>B</b>	<b>Vehicle description .....</b>	<b>1</b>
1	Application .....	1
2	Description of assemblies and functions .....	2
2.1	Vehicle .....	3
	Construction .....	3
3	Danger zones .....	6
4	Safety devices .....	7
5	Technical data, standard configuration .....	9
5.1	Dimensions (all dimensions in mm) .....	9
5.2	Permissible approach angle .....	10
5.3	Weights F1200C (all weights in t) .....	11
5.4	Weights F1200CS (all weights in t) .....	11
5.5	Performance data F1200C .....	12
5.6	Performance data F1200CS .....	12
5.7	Travel drive/traction unit .....	13
5.8	Engine EU 3A / Tier 3 - F1200C (o) .....	13
5.9	Engine EU 3B / Tier 4f - F1200C (t) .....	13
5.10	Engine EU 3A / Tier 3 - F1200CS (o) .....	13
5.11	Engine EU 3B / Tier 4f - F1200CS (t) .....	13
5.12	Material compartment (hopper) .....	14
5.13	Material transfer .....	14
5.14	Material distribution .....	14
5.15	Electrical system .....	14

5.16	Permissible temperature ranges .....	14
6	Identification points .....	15
6.1	Warning signs .....	18
6.2	Information signs .....	20
6.3	CE marking .....	22
6.4	Instructive symbols, prohibitive symbols, warning symbols .....	23
6.5	Further warnings and operating instructions .....	23
6.6	Identification label for the paver finisher (41) .....	24
6.7	Explanation of 17PIN serial number .....	25
7	EN standards .....	26
7.1	Continuous sound pressure level .....	26
7.2	Operating conditions during measurement .....	26
7.3	Measuring point configuration .....	26
7.4	Vibration acting on the entire body .....	27
7.5	Vibrations acting on hands and arms .....	27
7.6	Electromagnetic compatibility (EMC) .....	27

## **C10.12 Transportation ..... 1**

1	Safety regulations for transportation .....	1
2	Transportation on low-bed trailers .....	2
2.1	Preparations .....	2
3	Securing the load .....	4
3.1	Prepare the low-bed trailer .....	4
3.2	Driving onto the low-bed trailer .....	5
3.3	Lashing equipment .....	6
3.4	Loading .....	7
3.5	Preparing the vehicle .....	8
4	Securing the load .....	9
4.1	Securing at the front .....	9
4.2	Securing at the rear - screed with side board .....	10
4.3	After transportation .....	11
5	Transportation .....	12
5.1	Preparations .....	12
5.2	Driving mode .....	14
6	Loading by crane .....	15
7	Towing .....	17
8	Safely parking the vehicle .....	19
8.1	Lifting the vehicle with hydraulic lifts, lifting points .....	20

## **D10.12 Operation ..... 1**

1	Safety regulations .....	1
2	Controls .....	3
2.1	Operating panel .....	3
	Flame monitoring (o) .....	40
3	Remote control .....	44
4	Remote control .....	50
5	Malfunctions .....	58
5.1	Error code display and query for engine .....	58



5.2	Error code display and query for travel drive computer .....	60
-----	--	----

## **D30.12 Operation ..... 1**

1	Control elements on the paver finisher .....	1
1.1	Control elements on the operator's control station .....	1
	Control platform .....	2
	Running board extension (o) .....	3
	Fuse box .....	4
	Batteries .....	5
	Main battery switch .....	5
	Hopper transport safeguard .....	6
	Screed transport safeguard .....	6
	Speed controller Compacting elements .....	7
	Speed control, tamper (o) (A) .....	7
	Speed regulation for vibration (B) .....	7
	Conveying quantity controller Auger / conveyor .....	8
	Paving thickness indicator .....	8
	Auger lighting (o) .....	9
	LED working light (o) .....	9
	Auger height adjustment ratchet (o) .....	10
	Auger height displays .....	10
	Sensor rod / sensor rod extension .....	11
	Manual separator fluid spray (o) .....	13
	Separator fluid spraying system (o) .....	14
	Conveyor limit switches .....	15
	Auger limit switches .....	16
	24 volt sockets (o) .....	17
	Fire extinguisher (o) .....	18
	First-aid kit (o) .....	18
	Rotary beacon (o) .....	19

## **D40.12 Operation ..... 1**

1	Preparing for operation .....	1
	Required devices and aids .....	1
	Before starting work (in the morning or when starting paving) .....	3
	Check list for the vehicle operator .....	3
1.1	Starting the paver finisher .....	6
	Before starting the paver finisher .....	6
	"Normal" starting .....	6
	External starting (starting aid) .....	9
	After starting .....	12
	Observe indicator lamps .....	12
	Battery charge indicator (1) .....	12
	Error message (2) .....	12
1.2	Preparation for transportation .....	14
	Driving and stopping the paver finisher .....	16
1.3	Preparations for paving .....	17
	Separator fluid .....	17

	Screed heater .....	17
	Direction marks .....	18
	Loading/material transfer .....	20
	Filling function .....	20
1.4	Starting for paving .....	22
1.5	Checks during paving .....	23
	Paver function .....	23
	Quality of the layer .....	23
1.6	Interrupting/terminating operation .....	25
	During breaks (e.g. the material supply truck is late) .....	25
	During longer breaks (e.g. lunch break) .....	25
	When work is finished .....	27
1.7	Problems during paving .....	28
1.8	Malfunctions on the paver finisher or screed .....	30

## **E10.12 Set-up and modification ..... 1**

1	Special safety instructions .....	1
2	Distribution auger .....	3
2.1	Height adjustment .....	3
2.2	Auger width extension and material shaft with protective cover (Optional equipment) .....	4
3	Cut-off shoe installation instructions .....	6
	Push roller crossbar, adjustable .....	9
4	Connecting the automatic levelling system .....	10
	Connecting the slope controller / height controller .....	11
5	Working with the remote control (o) .....	12
	Changing over to normal control .....	13
6	Limit switch .....	14
6.1	Auger limit switches Mount (left and right) .....	14

## **F10 Maintenance..... 1**

1	Notes regarding safety .....	1
---	------------------------------	---

## **F2.12 Maintenance review ..... 1**

1	Maintenance review .....	1
---	--------------------------	---

## **F3.12 Maintenance - conveyor ..... 1**

1	Maintenance - conveyor .....	1
1.1	Maintenance intervals .....	3
1.2	Points of maintenance .....	4
	Chain tension, conveyor (1) .....	4
	Replace conveyor / conveyor drive - wear parts (2) .....	6

<b>F4.12</b>	<b>Maintenance - auger assembly .....</b>	<b>1</b>
1	Maintenance - auger assembly .....	1
1.1	Maintenance intervals .....	3
1.2	Maintenance points .....	4
	Drive chains of the augers (1) .....	4
	Auger box (2) .....	6
	Seals and sealing rings (3) .....	7
	Auger segments (4) .....	8
<b>F5.12</b>	<b>Maintenance - engine assembly .....</b>	<b>1</b>
1	Maintenance - engine assembly .....	1
1.1	Maintenance intervals .....	3
1.2	Maintenance points .....	6
	Engine fuel tank (1) .....	6
	Engine lube oil system (2) .....	7
	Engine fuel system (3) .....	9
	Engine air filter (4) .....	11
	Engine cooling system (5) .....	12
	Engine drive belt (6) .....	14
<b>F6.12</b>	<b>Maintenance - hydraulic system .....</b>	<b>1</b>
1	Maintenance - hydraulic system .....	1
1.1	Maintenance intervals .....	3
1.2	Points of maintenance .....	5
	Hydraulic oil tank (1) .....	5
	Suction/return flow hydraulic filter (2) .....	7
	High-pressure filter (3) .....	8
	Pump distribution gear (4) .....	9
	Bleeder .....	10
	Hydraulic hoses (5) .....	11
	Marking hydraulic hoses / storage 'period, period of use .....	13
	Auxiliary flow filter (6) .....	14
<b>F7.12</b>	<b>Maintenance - drive unit .....</b>	<b>1</b>
1	Maintenance - drive unit .....	1
1.1	Maintenance intervals .....	3
1.2	Maintenance points .....	6
	Chain tension (1) .....	6
	Checking / adjusting chain tension - grease tensioner version .....	6
	Checking / adjusting chain tension - spring loaded tensioner version ...	8
	Pre-tension of the tension unit. ....	9
	Adjusting tension: .....	9
	Relieving the chain: .....	9
	Bottom plates (2) .....	10
	Rollers (3) .....	11
	Planetary gear (4) .....	12

## **F8.12 Maintenance - electrical system ..... 1**

1	Maintenance - electrical system .....	1
1.1	Maintenance intervals .....	3
1.2	Maintenance points .....	4
	Batteries (1) .....	4
	Recharging the batteries .....	5
	Alternator (2) .....	6
	Insulation faults .....	8
	Cleaning the alternator .....	9
	Check belts .....	10
	Checking belt tension .....	10
	Adjusting belt tension .....	11
2	Electrical fuses .....	12
2.1	Main fuses (1) .....	12
2.2	Fuses in main terminal box (operating panel) .....	13
	Relays .....	15

## **F11.12 Lubricants and operating substances..... 1**

1	Lubricants and operating substances .....	1
1.1	Capacities .....	3
2	Operating substance specifications .....	4
2.1	Notes on diesel fuel .....	4
2.2	Drive engine TIER III (o) - fuel specification .....	4
2.3	Drive engine TIER IV (o) - fuel specification .....	4
2.4	Engine - lubricating oil .....	5
2.5	Cooling system .....	5
2.6	Hydraulic system .....	5
2.7	Pump distribution gear .....	5
2.8	Drive unit planetary gear .....	5
2.9	Auger box .....	6
2.10	Grease .....	6
2.11	Hydraulic oil .....	7

---

<b>F100</b>	<b>Tests, stopping .....</b>	<b>1</b>
1	Tests, checks, cleaning, stopping .....	1
1.1	Maintenance intervals .....	2
2	General visual inspection .....	3
3	Check that the bolts and nuts fit firmly .....	3
4	Inspection by an expert .....	4
5	Cleaning .....	5
5.1	Cleaning the hopper .....	6
5.2	Cleaning the conveyor and auger .....	6
6	Preserving the paver finisher .....	7
6.1	Shutdowns for up to 6 months .....	7
6.2	Shutdowns lasting from 6 months to 1 year .....	7
6.3	Recommissioning the machine .....	7
7	Environmental protection, disposal .....	8
7.1	Environmental protection .....	8
7.2	Disposal .....	8
8	Bolts - torques .....	9
8.1	Standard metric threads - strength class 8.8 / 10.9 / 12.9 .....	9
8.2	Fine metric threads - strength class 8.8 / 10.9 / 12.9 .....	10



---

# V Preface

Translation of the original operating instructions.

If the vehicle is to be operated safely, the information provided in these operating instructions will be required. The information is provided in a concise, clearly structured form. The individual chapters are arranged in alphabetical order, and every chapter starts with page 1. The individual pages are identified by the chapter letter and the page number.

Example: Page B 2 is the second page of chapter B.

These operating instructions cover various vehicle options. Make sure that during operation and maintenance work the description appropriate to the vehicle option is used.





In the interest of continued development, the manufacturer reserves the right to make changes to the vehicle (which will not, however, change the essential features of the type of vehicle described) without updating the present operating instructions at the same time.

Dynapac GmbH  
Wardenburg

Ammerländer Strasse 93  
D-26203 Wardenburg / Germany  
Telephone: +49 / (0)4407 / 972-0  
Fax: +49 / (0)4407 / 972-228  
[www.dynapac.com](http://www.dynapac.com)

## **1 General safety instructions**

### **1.1 Laws, guidelines, accident prevention regulations**

-  The locally applicable laws, guidelines and accident prevention regulations must always be observed, even if these are not expressly named here.  
The user himself/herself is responsible for compliance with the resulting regulations and measures!
-  The following warnings, prohibitive symbols and instructive symbols indicate dangers for persons, the vehicle and the environment due to residual risks when operating the vehicle.
-  Failure to observe this information, prohibitions and instructions can result in life-threatening injuries!
-  The "Guidelines for the Correct Use and Application of Paver Finishers" compiled by Dynapac must also be observed!



## 1.2 Safety signs, signal words

In the safety instructions, the signal words "Danger", "Warning", "Caution", "Note" are positioned in the coloured title block. They follow a certain hierarchy; in combination with the warning symbol, they indicate the severity of the danger or the type of note.

### "Danger"!



Danger of personal injury.

Indication of an immediately threatening danger that result in fatal or severe injuries unless the corresponding actions are taken.

### "Warning" !



Indication of a possible danger that can result in fatal or severe injuries unless the corresponding actions are taken.

### "Caution" !



Indication of a possible danger that result in moderate or minor injuries unless the corresponding actions are taken.

### "Note" !



Indication of a possible drawback unless the corresponding actions are taken, e.g. unwanted conditions or consequences can occur.

## 1.3 Other supplementary information

Other information and important explanations are identified by the following pictograms:



Precedes safety instructions that must be observed in order to prevent danger to personnel.



Precedes notes that must be observed to prevent damage to equipment.



Precedes general notes and explanations.

## 1.4 Warnings

Warning on a dangerous area or hazard!

Failure to observe the warnings can result in life-threatening injuries!



Warning on danger of being pulled in!



In this working area/on this element there is a danger of being pulled in by rotating or conveying elements!

Only carry out activities with elements switched off!



Warning on dangerous electrical voltage!



All maintenance and repair work on the screed's electrical system must always be carried out by an electrician!



Warning on suspended loads!



Never stand under suspended loads!



Warning on danger of crushing!



There is a danger of crushing when certain components are operated, or certain functions or vehicle movements are carried out. Always make sure that there are no persons within the endangered areas!



Warning on hand injuries!



Warning on hot surfaces or hot liquids!



Warning on danger of falling!



Warning on dangers posed by batteries!



Warning on hazardous or irritating substances!



Warning on substances which constitute a fire hazard!



Warning on gas bottles!




## 1.5 Prohibitive symbols

Opening/walking on/reaching in/carrying out/setting up are prohibited during operation or while the drive engine is running!



Do not start engine/drive!  
Maintenance and repair work may only be carried out with the diesel engine shut down!



Spraying with water is prohibited!



Extinguishing with water is prohibited!



Unauthorised maintenance is prohibited!  
Only qualified experts may conduct maintenance!




 Consult the Dynapac Service Department

Fire!, naked flames and smoking are prohibited!



Do not switch!



## 1.6 Protective equipment



Locally applicable regulations may require the wearing of various safety equipment!  
Always observe these regulations!

Wear safety goggles to protect your eyes!



Wear suitable head protection!



Wear suitable hearing protection to protect your hearing!



Wear suitable safety gloves to protect your hands!



Wear safety shoes to protect your feet!



Always wear close-fitting work clothing!

Wear a warning vest to be seen in time to avoid accidents!



Wear respiratory equipment if breathing air is contaminated!



## 1.7 Environmental protection



The locally applicable laws, guidelines and accident prevention regulations for the proper recycling and disposal of waste must always be observed, even if these are not expressly named here.

Water-endangering substances like:

- Lubricants (oil, grease)
- Hydraulic oil
- Diesel fuel
- Coolant
- Cleaning liquids

must not get into the soil or sewer system during cleaning, maintenance and repair work!

Substances must be caught, stored, transported and brought to professional disposal sites in suitable containers!



Environmentally hazardous substance!



## 1.8 Fire prevention



Locally applicable regulations may require suitable extinguishing agents to be carried on the vehicle!

Always observe these regulations!

Fire extinguisher!  
(optional equipment)



## 1.9 Additional information



Also observe the manufacturer's documentation and additional documentation!






For example, the maintenance instructions of the engine manufacturer



Description / depiction applicable when equipped with gas heater!



Description / depiction applicable when equipped with electric heater!



● Used to indicate standard equipment.

○ Used to indicate optional equipment.

## **2 CE identification and Declaration of Conformity**

(only applies to machines sold in the EU/EEC)

This machine has CE identification. This identification says that the machine fulfils the basic health and safety requirements pursuant to the Machinery Directive 2006/42/EC together with all other valid regulations. The scope of supply of the machine includes a Declaration of Conformity as specified in the valid regulations and amendments together with harmonised standards and other valid provisions.

## **3 Guarantee conditions**



The guarantee conditions are included in the scope of supply of the machine. This contains a complete specification of the valid conditions.

### **The guarantee becomes null and void if**

- damage occurs through malfunctions caused by improper use and incorrect operation.
- repairs or manipulations are carried out by persons who are neither trained nor authorised accordingly.
- accessories or spare parts are used that cause damage and which are not approved by Dynapac.



## **4 Residual risks**

These are risks that remain even if all possible measures and safety precautions have been taken to help minimise dangers (risks) or to reduce their probability and scope to zero.

### **Residual risks in the form of**

- **Danger to life and limb of persons at the machine**
- **Danger to the environment posed by the machine**
- **Damage to property and restricted output and functionality of the machine**
- **Damage to property in the operating range of the machine**

### **caused by:**

- wrong or improper use of the machine
- defective or missing safety devices
- use of the machine by untrained, uninstructed staff
- defective or damaged parts
- incorrect transport of the machine
- incorrect maintenance or repairs
- leaking operating substances
- emission of noise and vibrations
- impermissible operating substances

### **Existing residual risks can be avoided by complying and implementing the following:**

- warnings at the machine
- warnings and instructions in the safety manual for paver finishers and in the operating instructions of the paver finisher
- Operating instructions of the machine operator

## **5 Sensibly predictable incorrect usage**

Every kind of sensibly predictable incorrect usage of the machine constitutes misuse. Incorrect usage makes the manufacturer's warranty null and void: the operator bears sole responsibility.

Sensibly predictable incorrect usage of the machine includes:

- presence in the danger zone of the machine
- transporting persons
- leaving the operator's platform while the machine is operating
- removing protection or safety devices
- starting and using the machine outside the operator's platform
- operating the machine with the screed walkway plate hinged up
- failing to comply with the maintenance instructions
- omission or incorrect execution of maintenance or repair work
- spraying the machine with high pressure cleaners

---

# A Correct use and application



The "Guidelines for the Correct Use and Application of Paver Finishers" compiled by Dynapac are included in the scope of delivery for the present machine. The guidelines are part of the present operating instructions and must always be heeded. National regulations are fully applicable.

The road construction machine described in these operating instructions is a paver finisher that is suited for laying mixed materials, roll-down concrete or lean-mixed concrete, track-laying ballast and unbound mineral aggregates for foundations for paving.

The paver finisher must be used, operated and maintained according to the instructions given in the present operating instructions. Any other use is regarded as improper use and can cause injury to persons or damage to the paver finisher or other equipment or property.

Any use going beyond the range of applications described above is regarded as improper use and is expressly forbidden! Especially in those cases where the paver finisher is to be operated on inclines or where it is to be used for special purposes (construction of dumps, dams), it is absolutely necessary to contact the manufacturer.

**Duties of the user:** A "user" within the meaning of these operating instructions is defined as any natural or legal person who either uses the paver finisher himself, or on whose behalf it is used. In special cases (e.g. leasing or renting), the user is considered to be the person who, in accordance with existing contractual agreements between the owner and the user of the paver finisher, is charged with the observance of the operating duties.

The user must ensure that the paver finisher is only used in the stipulated manner and that all danger to life and limb of the operator, or third parties, is avoided. In addition to this, it must be ensured that the relevant accident prevention regulations and other safety-related provisions as well as the operating, servicing and maintenance guidelines are observed. The user must also ensure that all persons operating the paver finisher have read and understood the present operating instructions.

**Mounting of attachments:** The paver finisher must only be operated in conjunction with screeds that have been approved by the manufacturer. Mounting or installation of any attachments that will interfere with or supplement the functions of the paver finisher is permitted only after written approval by the manufacturer has been obtained. If necessary, the approval of local authorities must be obtained.


Any approval obtained from local authorities does not, however, make approval by the manufacturer unnecessary.




## B Vehicle description

### 1 Application

The Dynapac F1200C/CS paver finisher is a paver finisher with a caterpillar drive which is used for laying bituminous mixed material, roll-down or lean-mixed concrete and unbound mineral aggregates for foundations for paving.



## 2 Description of assemblies and functions



Item		Designation
1	●	Material compartment (hopper)
2	●	Truck push rollers
3	●	Tube for sensor rod (direction indicator) holder
4	●	Caterpillar drive
5	●	Levelling cylinder for paving thickness
6	●	Paving thickness indicator
7	●	Crossbeam
8	●	Travel drive of the caterpillar drive
9	●	Conveyor
10	●	Auger
11	●	Screed
12	●	Operator's platform
13	●	Operating panel
14	●	Working lights

● = Standard equipment

○ = Optional equipment

## 2.1 Vehicle

### Construction

The paver finisher has a welded steel frame on which the individual components are mounted.

The caterpillar drives are part of the frame structure; the suspension of the attached screed additionally helps to attain high paving precision.

The continuously adjustable hydrostatic travel drive allows the speed of the paver finisher to be matched to all work conditions.

The operation of the paver finisher is considerably facilitated by the independent travel drives and the clearly structured operating components and controls.

The following extra equipment (option) is available:

- ☐ Hydraulic front hopper flap
- ☐ Material chute / hinged material chute
- ☐ Remote control
- ☐ Additional headlights, warning lamps
- ☐ Emulsion spraying system
- ☐ Automatic levelling system
- ☐ Larger working widths
- ☐ Alternator for electric heater
- ☐ Further equipment and upgrade options on request

**Engine:** The paver finisher is equipped with a water-cooled 4-cylinder Deutz diesel engine. For further information please refer to the operating instructions for the engine.

**Drive unit:** Both caterpillar drives are directly driven by separate drives. They operate directly, without any drive chains which require maintenance or servicing. The tension of the caterpillar chains can be readjusted using tensioners.

**Hydraulic system:** The diesel engine drives the hydraulic pumps for all main paver finisher drives via the attached distribution gear and its auxiliary drive shafts.

**Travel drive:** The continuously adjustable travel drive pumps are connected to the travel drive engines by means of high pressure hydraulic hoses. These hydraulic motors drive the caterpillar chains via planetary gears that are mounted directly inside the drive units of the caterpillar chains.

**Steering system/operator's platform:** The independent hydrostatic travel drives allow the paver finisher to be turned on the spot. The adjustable synchronisation, controlled from the operating panel, ensures that the paver finisher runs straight ahead.

**Push roller crossbar:** The push rollers for material trucks are fastened to a cross bar that is pivoted at its centre. This crossbar allows different distances to the rear wheels of material trucks to be compensated. The paver finisher thus deviates less from its course and paving in curves is made easier. The push rollers and the hopper can be swivelled up together to reduce the transport width.

**Material compartment (hopper):** The hopper inlet is equipped with a conveyor system that empties the hopper and transfers the material to the auger. The hopper can hold approx. 5.0 t. To facilitate emptying and to improve material transfer, each of the lateral covers of the hopper can be hydraulically moved.

**Material transfer:** The paver finisher has a conveyor that brings the material from the hopper to the distribution augers. By scanning the filling height during the paving procedure, the transfer amount is regulated fully automatically.

**Augers:** The augers are driven and actuated independently from the conveyors. The left-hand and the right-hand half of the auger can be controlled separately. The drive system is fully hydraulic. The conveying direction can be changed towards the centre or towards the outside. This ensures that there is always a sufficient supply of material even if an excessive amount of material is required at one side. The auger speed is controlled by sensors that monitor the material flow.

**Height adjustment and extension of augers:** Height adjustment and extension of augers ensure optimum adaptation to a wide range of paving thicknesses and widths.



**Levelling/slope control system:** The standard paver finisher is prepared electrically and hydraulically to fit an automatic levelling system. The levelling system monitors the paving thickness and corrects any deviations from the nominal level automatically.

The system consists of optional combinations of:

- Height controllers
- Slope controller
- Digital controllers


The slope control system always operates in conjunction with the levelling cylinders on the opposite side.

By adjusting the height of the traction point of the crossbeam, the paving thickness of the material or the laying height of the screed can be controlled.

Actuation occurs electrohydraulically on both sides and can be controlled manually by means of toggle switches or automatically by means of an electronic grade control system.

**Screed lifting device:** The screed lifting device is used to lift the screed during transportation. This takes place by hydraulic means by actuating a hydraulic cylinder.

### 3 Danger zones



#### **WARNING**


#### **Danger for persons in the danger zone**

Persons in the danger zone can suffer severe or fatal injuries from movements and functions of the vehicle!

- Never stand in the danger zone of the vehicle!
- During operation, only the vehicle operator and the screed personnel are allowed on the vehicle or in the danger zone. The vehicle operator and screed personnel must keep to the respective driver's seats.
- Make sure that there is no-one in the danger zone before switching the vehicle on or starting it moving.
- The vehicle operator must ensure that no-one is in the danger zone!
- Sound the horn before driving away.
- Comply with all further information in these instructions and in the safety manual.



## 4 Safety devices



Item	Designation	
1	Hopper transport safeguard	
2	Screed transport safeguard	
3	Main switch	
4	Travel drive safety switch	
5	Emergency stop button	
6	Horn	
7	Ignition key	
8	Lights	**
9	Screed warning light	**
10	Covers, lateral flaps, coverings	**

\*\* Located on both sides of the vehicle



Safe operation is only possible if the control and safety devices are functioning perfectly and if the protective equipment is fitted correctly.






Check the function of these devices at regular intervals.




Functional descriptions for the individual safety facilities can be found in the following chapters.

## 5 Technical data, standard configuration

### 5.1 Dimensions (all dimensions in mm)



## 5.2 Permissible approach angle



### 5.3 Weights F1200C (all weights in t)

Paver finisher without screed	approx. 4.85
Paver finisher with screed: - V240V - V240V-E	approx. 5.8 approx. 5.8
With filled hopper Additionally max.	approx. 5.0



For the weights of the screed and the screed attachments, see the operating instructions for the screed.

### 5.4 Weights F1200CS (all weights in t)

Paver finisher without screed	approx. 4.85
Paver finisher with screed: - V240TV - V240TV-E	approx. 5.8 approx. 5.8
With filled hopper additionally max.	approx. 5.0



For the weights of the screed and the screed attachments, see the operating instructions for the screed.

## 5.5 Performance data F1200C

Screed used	Basic width (without cut-off shoes)	Minimum paving width (with cut-off shoe)	Continuously hydraulically adjustable up to	Maximum working width (with extension parts)	
V240V	1.20	0.30	2.40	3.10	m
V240V-E	1.20	0.30	2.40	3.10	m

Transport speed	0 - 3.3	km/h
Operating speed	0 - 27	m/min
Paving thickness	-150 - 200	mm
Theoretical paving performance	300	t/h

## 5.6 Performance data F1200CS

Screed used	Basic width (without cut-off shoes)	Minimum paving width (with cut-off shoe)	Continuously hydraulically adjustable up to	Maximum working width (with extension parts)	
V240TV	1.20	0.30	2.40	3.10	m
V240TV-E	1.20	0.30	2.40	3.10	m

Transport speed	0 - 3.3	km/h
Operating speed	0 - 27	m/min
Paving thickness	-150 - 250	mm
Theoretical paving performance	300	t/h



## 5.7 Travel drive/traction unit

Drive	Hydrostatic drive, continuously controllable
Drive unit	Two separately driven caterpillar drives with rubber grouser chains
Turning capacity	Turning on the spot
Speed	See above

## 5.8 Engine EU 3A / Tier 3 - F1200C (○)

Make/type	Deutz TD 2.9 L4
Version	4-cylinder diesel engine
Performance	49 KW / 66 PS (at 2200 rpm)
Fuel consumption, full load	14 l/h
Fuel consumption, 2/3 load	9.3 l/h
Fuel tank capacity	(See chapter F)

## 5.9 Engine EU 3B / Tier 4f - F1200C (●)

Make/type	Deutz TD 2.9 L4
Version	4-cylinder diesel engine
Performance	49 KW / 66 PS (at 2200 rpm)
Fuel consumption, full load	15.3 l/h
Fuel consumption, 2/3 load	10.2 l/h
Fuel tank capacity	(See chapter F)

## 5.10 Engine EU 3A / Tier 3 - F1200CS (○)

Make/type	Deutz TD 2.9 L4
Version	4-cylinder diesel engine
Performance	54 KW / 73 PS (at 2200 rpm)
Fuel consumption, full load	14 l/h
Fuel consumption, 2/3 load	9.3 l/h
Fuel tank capacity	(See chapter F)

## 5.11 Engine EU 3B / Tier 4f - F1200CS (●)

Make/type	Deutz TD 2.9 L4
Version	4-cylinder diesel engine
Performance	54 KW / 73 PS (at 2200 rpm)
Fuel consumption, full load	15.3 l/h
Fuel consumption, 2/3 load	10.2 l/h
Fuel tank capacity	(See chapter F)

## 5.12 Material compartment (hopper)

Volume	Approx. 2.3 m <sup>3</sup> = approx. 5.0 t
Input height	570 mm

## 5.13 Material transfer

Type	Simple conveyor belt
Width	620 mm
Conveyor operation	Automatic by means of mechanical limit switches

## 5.14 Material distribution

Augers	Ø 320 mm
Drive	Left and right auger separately controllable Hydrostatic central drive, continuously controllable
Conveying volume controller	Fully automatic via configurable switching points
Auger height adjustment	- continuously mechanical, 150mm
Auger extension	With extension parts (see auger extension chart)

## 5.15 Electrical system

On-board voltage	24 V
Batteries	2 x 12 V, 74 Ah
Alternator (○)	10 kVA / 400 V
Fuses	See chapter F, section 5



## 5.16 Permissible temperature ranges


Operation	-5°C / +45°C
Storage	-5°C / +45°C




For the filling volumes of the various lubricants and operating substances, see chapter F.






## 6 Identification points




 <b>CAUTION</b>	<b>Danger from missing or misunderstood vehicle signs</b>
	<p>Missing or misunderstood vehicle signs pose a danger of injuries!</p> <ul style="list-style-type: none"><li>- Never remove any warnings or information signs from the vehicle.</li><li>- Damaged or lost warning or information signs must be replaced immediately.</li><li>- Make yourself familiar with the meaning and position of the warning and information signs.</li><li>- Comply with all further information in these instructions and in the safety manual.</li></ul>












## 6.1 Warning signs








No.	Pictogram	Meaning
1		<ul style="list-style-type: none"> <li>- <b>Warning - Operating instructions!</b>            Danger due to improper operation. The machine personnel must have read and understood the safety, operating and maintenance instructions for the machine before the machine is put into operation! Failure to comply with the operating and warning instructions can cause severe or fatal injuries. Always replace lost operating instructions immediately! It is your personal responsibility to take due care and attention!</li> </ul>
2		<ul style="list-style-type: none"> <li>- <b>Warning - Switch off the engine and remove the ignition key before performing any maintenance and repair work!</b>            If the drive engine is left running or functions are switched on, this can cause severe or fatal injuries!            Switch the engine off and remove the ignition key.</li> </ul>
3		<ul style="list-style-type: none"> <li>- <b>Warning - Danger of crushing!</b>            Crushing points can cause severe or fatal injuries!            Maintain a safe distance from the danger area!</li> </ul>
4		<ul style="list-style-type: none"> <li>- <b>Warning - Hot surface - Danger of burning!</b>            Hot surfaces can cause severe injuries!            Keep your hands at a safe distance from the danger area! Use protective clothing or protective equipment!</li> </ul>
5		<ul style="list-style-type: none"> <li>- <b>Warning - Danger of being pulled in by the belt drive!</b>            Being pulled in by the belt drive can cause severe injuries to the hands and arms.            Keep your hands at a safe distance from the danger area!</li> </ul>



No.	Pictogram	Meaning
6		<ul style="list-style-type: none"> <li>- <b>Warning - Spring-loaded part!</b> Performing work incorrectly can cause severe to fatal injuries. Always observe the maintenance instructions!</li> </ul>
7		<ul style="list-style-type: none"> <li>- <b>Caution - Danger from incorrect towing!</b> Movements of the machine can cause severe or fatal injuries. The traction system brakes must be released before towing. Always observe the operating instructions!</li> </ul>
8		<ul style="list-style-type: none"> <li>- <b>Warning - Danger from running engine!</b> If the drive engine is left running, this can cause severe or fatal injuries. Never open the engine hood while the engine is running!</li> </ul>

## 6.2 Information signs


No.	Pictogram	Meaning
10	 D956045100	- <b>Operating Instructions</b> Position of the storage compartment.
11	 D990000215	- <b>Diesel fuel</b> Position of the filling point.
11	 4812041952	- <b>Diesel fuel, sulphur level &lt; 15 ppm</b> Position of the filling point, specification.
12	 D990000225	- <b>Lifting point</b> Lifting the machine is only permitted at these lifting points!
13	 D990000268	- <b>Main battery switch</b> Position of the main battery switch.
14	 4812025572	- <b>Lashing point</b> Lashing the machine is only permitted at these points!
15	 4812041941	- <b>Hydraulic oil</b> Position of the filling point.






No.	Pictogram	Meaning
16	 4812041943	- <b>Engine oil</b> Position of the filling and control point.
17	 4812002913	- <b>Engine oil drainage point</b> Position of the drainage point.
18	 4812002914	- <b>Gear oil drainage point</b> Position of the drainage point.
19	 4812043037	- <b>Gearbox oil</b> Position of the filling and control point.
20	 4812043018	- <b>Hydraulic oil drainage point</b> Position of the drainage point.
21	 4812043019	- <b>Fuel drainage point</b> Position of the drainage point.
22	 D455177801	- <b>Tamper speed adjuster</b> Position of the speed adjuster.

No.	Pictogram	Meaning
23		- <b>Vibration, speed adjuster</b> Position of the speed adjuster.
24		- <b>Auger and conveyor, speed adjuster</b> Position of the speed adjuster.


### 6.3 CE marking

No.	Pictogram	Meaning
30		- CE, sound output level


#### 6.4 Instructive symbols, prohibitive symbols, warning symbols

No.	Pictogram	Meaning
40		- Wear ear protection devices
41		- Warning on dangers posed by batteries!
42		- Do not spray the area or part with water!

#### 6.5 Further warnings and operating instructions

No.	Pictogram	Meaning
60		- <b>Engine start - All switches in neutral!</b> The engine cannot be started when functions are switched on. Always observe the operating instructions!

## 6.6 Identification label for the paver finisher (41)




No.	Designation
1	Paver finisher type
2	Year of construction
3	Operating weight, incl. all extension parts, in kg
4	Maximum permitted total weight in kg
5	Max. permissible load on the front axle, in kg (○)
6	Max. permissible load on the rear axle, in kg (○)
7	Maximum permissible axle load of the trailer axle in kg (○)
8	Rated performance in kW
9	Product identification number (PIN)



The punched vehicle identification number (VIN) on the paver finisher must match the product identification number (9).

## 6.7 Explanation of 17PIN serial number



A	- Manufacturer
B	- Family/Model
C	- Check letter
F	- Serial number

## 7 EN standards

### 7.1 Continuous sound pressure level



The operator always must use ear protection. The emission value at the ear of the driver varies depending on the materials used for paving and may even rise above 85 dB(A). If no ear protection devices are used, hearing can be impaired.

The noise emission level of the paver finisher was measured under free-field conditions according to the EN 500-6 draft dated March 1997, and ISO 4872.

**Sound pressure level at the operator's position  
(at the height of the head):**

$$L_{AF} = 83.6 \text{ dB(A)}$$

**Sound capacity level:**

$$L_{WA} = 104.0 \text{ dB(A)}$$

**Sound pressure level at the vehicle**

Measuring point	2	4	6	8	10	12
Sound pressure level $L_{AFeq}$ (dB(A))	70.4	69.8	70.6	71.1	68.6	68.6


### 7.2 Operating conditions during measurement

The diesel engine ran at maximum speed, conveyor at 40%, augers at 40%, tamper and vibration at minimum 50% of their maximum speed.

### 7.3 Measuring point configuration

Hemispherical measuring surface with a radius of 10 m. The machine was at the centre. The measuring points had been assigned the following coordinates:

	Measuring points 2, 4, 6, 8			Measuring points 10, 12		
Co-ordinates	X	Y	Z	X	Y	Z
	$\pm 7$	$\pm 7$	1,5	- 2,7 +2.7	+6,5 -6.5	7.1 7.1



---

#### **7.4 Vibration acting on the entire body**

When the machine is used properly, the weighted effective acceleration values at the driver's seat of  $a_w = 0.5 \text{ m/s}^2$  according to DIN EN 1032 are not exceeded.

#### **7.5 Vibrations acting on hands and arms**

When the machine is used properly, the weighted effective acceleration values at the driver's seat of  $a_{hw} = 2.5 \text{ m/s}^2$  according to DIN EN ISO 20643 are not exceeded.

#### **7.6 Electromagnetic compatibility (EMC)**

The following limit values are observed according to the stipulations of the EMC Directive 2004/108/EC:

- Interference emission according to DIN EN 13309:
  - < 35 dB  $\mu\text{V/m}$  for frequencies of 30 MHz - 1GHz measured at a distance of 10 m
  - < 45 dB  $\mu\text{V/m}$  for frequencies of 30 MHz - 1 GHz measured at a distance of 10 m
- Interference immunity against electrostatic discharge (ESD) according to DIN EN 13309:
  - The paver finisher did not show any discernible reactions to contact discharges of  $\pm 4 \text{ KV}$  and to air discharges of  $\pm 4 \text{ KV}$ .
  - The modifications according to test criterion "A" are being met, i.e. the paver finisher continues to work without malfunction during the test.

Electrical or electronic components and their arrangement may only be modified after written approval by the manufacturer has been obtained.





---

# C 10.12 Transportation

## 1 Safety regulations for transportation



Accidents can happen when the paver finisher and the screed are not properly prepared for transportation or when transportation is carried out improperly!

Reduce both the paver finisher and the screed to their basic widths. Remove all protruding parts (such as the automatic levelling system, auger limit switches, side shields, etc.).

Close the hopper lids and engage the hopper transport safeguards. Lift the screed and engage the screed transport safeguards.

Pack all parts that are not permanently fixed to the paver finisher and the screed into the appropriate boxes and into the hopper.

Close all coverings and check that they are securely seated.

In Germany, gas bottles must not be transported on the paver finisher or on the screed.

Disconnect the gas bottles from the gas system and protect them with their caps. Use a separate vehicle to transport them.

When loading via ramps, there is a risk that the machine will slip, tilt or overturn. Drive carefully! Keep people away from the danger area!

### **Additional stipulations for transportation on public roads:**



In Germany; caterpillar paver finishers **must not be driven as self-propelling vehicles** on public roads.

Note that in other countries different regulations may apply.





The operator must be in the possession of a valid permit for vehicles of this type.

The driving lights must be properly adjusted.

Only attachments and extension parts may be transported in the hopper, no material or gas bottles!

If necessary, the operator must be assisted by a second person when driving on public roads – especially at road crossings and junctions.

## 2 Transportation on low-bed trailers

-  Reduce the paver finisher and the screed to their basic widths; also remove any attached side shields.  
The maximum approach angle is indicated in the section entitled "Technical data"!
-  Check the fill level of the operating substances so that these do not escape when driving on an incline.
-  Attachment and loading equipment must meet the conditions of the applicable accident prevention regulations!
-  The weight of the paver finisher must be taken into consideration when selecting the attachment and loading equipment!

### 2.1 Preparations

- Prepare the paver finisher for transportation (see chapter D).
- Remove all overlaying or loose parts from finisher and screed (see also Screed operating instructions). Store these parts in a safe place.







-  Move the auger to the uppermost position to avoid collisions!



When the screed is operated with the optional gas heating system:








- Remove the gas bottle for the screed heater system:
  - Close main shut-off valve and bottle valve.
  - Turn off the bottle valve and remove the gas bottle from the screed.
  - Transport the gas bottle on a second vehicle, adhering to all safety regulations.




Operation	Switch
- Close the hopper lids.	
- Insert hopper transport safeguard.	
- Lift the screed.	
- Insert screed transport safeguard.	
- Extend levelling cylinders completely.	
- Retract the screed parts until the screed matches the basic width of the paver finisher.	




### 3 Securing the load

-  The following instructions for securing the load on the low-bed trailer consist merely in examples of how to secure the load correctly.
-  Always comply with the local regulations for securing the load and for correct use of load securing equipment.
-  Normal driving mode also includes emergency braking, evasive manoeuvres and poor road surfaces.
-  Use should be made of the different methods available for securing loads (positive fit, force connection, diagonal lashing, etc.) in accordance with the specific transport vehicle.
-  The low-bed trailer must have the necessary number of lashing points with lashing strength of LC 2,200 daN.
-  The total height and total width must not exceed the maximum permissible dimensions.
-  The ends of lashing chains and straps must be secured to prevent them working loose and falling down unintentionally!

#### 3.1 Prepare the low-bed trailer




-  The floor of the loading space must always be undamaged, free of oil and mud, dry (residual moisture is permitted without accumulations of water) and swept clean!

### 3.2 Driving onto the low-bed trailer



Make sure that there are no persons in the danger area during loading.



- Use the work gear and low engine speeds to drive onto the low-bed trailer.

### 3.3 Lashing equipment



Use the load securing equipment, lashing straps and chains belonging to the vehicle. Additional shackles, eyebolts, edge safeguards and non-slip mats may be needed, depending on the type of load securing equipment.



Always comply with the stated values for permitted lashing force and load rating!




Always tighten the lashing chains and straps handtight (100-150daN).

- Lashing chain permissible lashing force LC 2,200 daN	
- Non-slip mats	



Lashing equipment must be checked by the user for any signs of damage before use. On detecting any signs of damage that impact on safety, the lashing equipment must be withdrawn from any further use.

### 3.4 Loading




Pay attention to load distribution during loading!

In some vehicles, the kingpin load is too low so that the load has to be positioned further to the back of the vehicle (A).

Always heed the details regarding load distribution stipulated for the vehicle together with the centre of gravity of the paver finisher.

### 3.5 Preparing the vehicle




After the vehicle has been positioned on the low-bed trailer, the following preparations must be carried out:

- Close hopper, set hopper transport safeguards (1).
- Position the non-slip mats under the screed across the whole width of the vehicle (2) and lower the screed.
- Switch off the paver finisher.
- Attach and secure the protective hood (3) to protect the operating panel.



## 4 Securing the load

### 4.1 Securing at the front




Diagonal lashing secures the paver finisher at the front using the lashing points on the paver finisher and on the low-load trailer. Fasten the lashing chains as shown.



The lashing angles should be "β" between 6°-55° and "α" between 20°-65°!

## 4.2 Securing at the rear - screed with side board



Diagonal lashing secures the paver finisher at the rear using the lashing points on the paver finisher and on the low-load trailer. Fasten the lashing chains as shown.

### **4.3 After transportation**

- Remove the attachment devices.
- Lift the screed to the transportation position.
- Start the engine and drive from the trailer at a low engine/traction speed.
- Park the paver finisher in a secure spot, lower the screed and switch off the engine.
- Remove the key and/or cover the operating panel with the protective hood and secure it.

## 5 Transportation



Reduce the paver finisher and the screed to their basic widths; also remove any attached side shields.

### 5.1 Preparations







- Prepare the paver finisher for transportation (see chapter D).
- Remove all overlaying or loose parts from finisher and screed (see also Screed operating instructions). Store these parts in a safe place.



When the screed is operated with the optional gas heating system:









- Remove the gas bottle for the screed heater system:
  - Close main shut-off valve and bottle valve.
  - Turn off the bottle valve and remove the gas bottle from the screed.
  - Transport the gas bottle on a second vehicle, adhering to all safety regulations.



Operation	Switch
- Close the hopper lids.	
- Insert hopper transport safeguard.	
- Lift the screed.	
- Insert screed transport safeguard.	
- Extend levelling cylinders completely.	
- Retract the screed parts until the screed matches the basic width of the paver finisher.	





## 5.2 Driving mode

Operation	Switch
<ul style="list-style-type: none"> <li>- Set the fast/slow switch to "Hare" if necessary.</li> </ul>	
<ul style="list-style-type: none"> <li>- Turn the preselector to "zero".</li> </ul>	
<ul style="list-style-type: none"> <li>- Press the safety switch</li> </ul> <p> The safety switch must always be pressed when the drive lever is moved out of the neutral position. Otherwise the travel drive is blocked!</p>	
<ul style="list-style-type: none"> <li>- Swivel the drive lever to maximum.</li> </ul> <p> The vehicle already advances slightly on deflecting the drive lever!</p>	
<ul style="list-style-type: none"> <li>- Adjust required vehicle speed with the preselector.</li> </ul>	
<ul style="list-style-type: none"> <li>- To stop the vehicle, swivel the drive lever to the middle setting and set the preselector to "zero".</li> </ul>	



Press the emergency stop button when a dangerous situation arises!

## 6 Loading by crane

 <b>WARNING</b>	<b>Danger from suspended loads</b>
	<p>Crane and/or lifted vehicle can tip when lifted and cause injuries!</p> <ul style="list-style-type: none"> <li>- The vehicle may only be raised at the marked lifting points.</li> <li>- Heed the operating weight of the vehicle.</li> <li>- Do not enter the danger zone.</li> <li>- Use only lifting gear that can bear the load.</li> <li>- Do not leave any load or loose parts on the vehicle.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>



Use only lifting gear that can bear the load.  
 (See chapter B for weights and dimensions).









Attachment and loading equipment must meet the conditions of the applicable accident prevention regulations!



The vehicle's centre of gravity is dependent on the screed which is mounted.

Example:



-  Four lifting eyes (1, 2) are provided for loading the vehicle with a crane.
-  Depending on the type of screed which is used, the paver finisher's centre of gravity, with the screed mounted, is located in area (3) of the vehicle.
  - Secure vehicle wherever it is parked up.
  - Engage the transport safeguards.
  - Remove any attachments and extension parts from the paver finisher and the screed until the basic width has been attained.
  - Take off all protruding or loose parts and the gas bottles of the screed heater (see chapters E and D).
  - Attach lifting gear to the four attachment points (1, 2).
-  The max. permissible attachment point load is:  
Attachment point (1): 138 kN.  
Attachment point (2): 91 kN
-  The permissible load applies in the vertical direction!
-  Make sure that the paver finisher remains in a horizontal position during transportation!



## 7 Towing



Heed all regulations and apply all safety measures applicable for towing heavy construction machines.



The towing vehicle must be capable of securing the paver finisher, even on slopes.

Use only approved tow bars!

If necessary, remove any attachments and accessories from the paver finisher and the screed until the basic width has been attained.



A hand pump (1) is located in the engine compartment (left side); it must be actuated to be able to tow the machine.

Pressure for releasing the traction system brakes is built up with the hand pump.



- Release lock nut (2), screw threaded dowel (3) into pump as far as possible and secure with lock nut.
- Actuate lever (4) of hand pump until sufficient pressure has been built up and traction system brakes have been released.



On completion of the towing process, restore the initial status.



Only release the traction system brakes when the machine is sufficiently secured against accidental rolling or is already properly connected to the towing vehicle.






Two high-pressure cartridges (6) are located on both of the travel drive pumps (5). The following activities must be carried out to activate the towing function:

- Loosen lock nut (7) half a turn.
- Screw in the bolt (8) until increased resistance occurs. Then screw the bolt a further half turn into the high-pressure cartridge.
- Tighten the lock nut (7) to a torque of 22 Nm.



On completion of the towing process, restore the initial status.

- Attach the tow bar to the coupling (9) located in the bumper.



Now carefully and slowly tow the paver finisher out of the construction area.




Only ever tow the shortest distance to the means of transport or the next parking possibility.



The max. permissible towing speed is 10 m/min!  
In hazardous situations, a towing speed of 15 m/min is only permitted temporarily.



The max. permissible towing eye (9) load is: 91 kN





## 8 Safely parking the vehicle




When the paver finisher is parked at a location accessible to the public, it must be secured in such a way that unauthorised persons or playing children cannot damage the vehicle.

- Pull off the ignition key and the main switch (1) and take it with you – do not hide them somewhere on the machine.
- Protect the operating panel with the dust cover (2) and lock it.
- Store loose parts and accessories in a safe place.



## 8.1 Lifting the vehicle with hydraulic lifts, lifting points



The hydraulic lift must be rated for at least 8t.



Always choose a horizontal surface with adequate load rating as installation surface for the hydraulic lift!



Make sure that the hydraulic lift is securely and correctly positioned!



The hydraulic lift is only intended to lift a load and not as a support. Work should only be performed to and under raised vehicles when they have been secured and correctly supported to prevent them from tilting over and rolling or sliding away.



Roller-type jacks must not be moved when under load.



Chocks or supporting beams positioned so that they cannot be shifted or tilted must be adequately dimensioned and be able to take the corresponding weight.



There must not be anyone on the vehicle while it is being lifted.



All raising and lowering work must be carried out uniformly with all hydraulic lifts in use! Always check and observe horizontal alignment of the load!



Always carry out raising and lowering work with several people together, with an additional person monitoring progress!



Only positions (1) and (2) in the left and right side of the vehicle are permissible lifting points!



---

# D 10.12 Operation

## 1 Safety regulations



Starting the engine, the travel drive, the conveyor, the auger, the screed or the lifting devices can cause injuries or even the death of persons.

Make sure before starting any of these devices that no-one is working at, in or beneath the paver finisher or within its danger area!

- Do not start the engine or do not actuate any controls when this is expressly forbidden!  
Unless otherwise specified, the controls may only be actuated when the engine is running!







Never crawl into the auger tunnel or step into the hopper or onto the conveyor when the engine is running. Danger to life!



- Always make sure during work that no-one is endangered by the vehicle!
- Ensure that all protective covers and hoods are fitted and secured accordingly!
- Immediately rectify damage which has been ascertained! Operation must not be continued when the vehicle is defective!
- Do not let any persons ride on the paver finisher or the screed!
- Remove obstacles from the road and the work area!
- Always try to choose the operator's control station that is opposite to the flowing traffic! Lock the external control.
- Maintain sufficient safety clearance from overhanging objects, other vehicles and points of danger!
- Be careful when travelling on rough terrain to keep the paver finisher from slipping, tipping or turning over.



Always be the master over the vehicle; never try to use it beyond its capacities!

 <b>DANGER</b>	<b>Danger due to improper operation</b>
	<p>Improper operation of the vehicle can cause severe to fatal injuries!</p> <ul style="list-style-type: none"> <li>- The vehicle may only be used in the stipulated manner for its intended purpose.</li> <li>- The vehicle may only be operated by trained staff.</li> <li>- The vehicle operators must have made themselves familiar with the contents of the operating instructions.</li> <li>- Avoid jerky movements of the vehicle.</li> <li>- Do not exceed the allowed angle of rise and slope.</li> <li>- Keep hoods and covering parts closed during operation.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>

 <b>WARNING</b>	<b>Danger of being pulled in by rotating or conveying vehicle parts</b>
	<p>Rotating or conveying vehicle parts can cause severe or fatal injuries!</p> <ul style="list-style-type: none"> <li>- Do not enter the danger zone.</li> <li>- Do not reach into rotating or conveying parts.</li> <li>- Only wear close-fitting clothing.</li> <li>- Comply with the warning and information signs on the vehicle.</li> <li>- Stop the engine and remove the ignition key for any maintenance work.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>

 <b>WARNING</b>	<b>Danger of crushing from moving vehicle parts</b>
	<p>Vehicle parts performing movements can cause severe or fatal injuries!</p> <ul style="list-style-type: none"> <li>- Never stand in the danger zone of the vehicle!</li> <li>- Do not reach into the danger area.</li> <li>- Comply with the warning and information signs on the vehicle.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>





## 2 Controls



### 2.1 Operating panel









All detent switch functions that can pose a hazard when the diesel engine starts up (turning to the side, conveying function of auger and conveyor) prevent the engine from starting (start inhibit) when switched on or when set to "MANUAL" or "AUTO". These functions must be "Straight-ahead travel" or "OFF".












Pos.	Designation	Brief description
10	Lights	Lights up instrument panel A/B when the parking light is switched on
11	Emergency stop button	<p>In the case of an emergency (danger to persons, possible collision, etc.), press in the button!</p> <ul style="list-style-type: none"> <li>- Pressing the emergency stop button switches off the engine, the drives and the steering system. Making way, lifting the screed or other actions are then no longer possible! Danger of accident!</li> <li>- The emergency stop button does not shut off the gas heater system. Close the main shut-off valve and the valves on the bottles by hand!</li> <li>- To restart the engine, the button must be unlocked again.</li> </ul>
12	Engine speed adjuster	<p>Continuously variable engine speed setting (if drive lever is extended).  Min. setting: Idling speed  Max. position: Nominal speed</p> <p> For paving, select the rated speed; reduce the speed for transportation.</p> <p> The automatic speed control keeps the set speed constant even under a load.</p>
13	Straight-ahead travel synchronisation	<p>Using this potentiometer, both chains can be synchronised for straight-ahead travel while driving:</p> <ul style="list-style-type: none"> <li>- Set the steering to position "0"; then adjust the potentiometer until the paver finisher is travelling straight ahead.</li> </ul>







Pos.	Designation	Brief description
14	Ignition lock	<p>Switch positions:</p> <ul style="list-style-type: none"> <li>- P: Park position + warning lamps can be engaged when desired.</li> <li>- 0: Ignition OFF</li> <li>- 1: Ignition ON, lighting and separator fluid spray system can be activated</li> <li>- 2: No function</li> </ul> <p> The engine can start up if the drive lever is in the middle setting and no "AUTO" or "MANUAL" functions are switched on.</p> <p> Removal of the key is only possible in position 0.</p>
14a	Starter	<p>For starting the engine.</p> <p> Do not let the starter run continuously for more than 20 seconds; then allow for a break of 1 minute after every attempt!</p> <p> All emergency stop buttons (on the operating panel and the remote controls) must be pulled out when starting.</p> <p> The engine can only start up if the drive lever is in the middle setting and no "AUTO" or "MANUAL" functions are switched on.</p>









Pos.	Designation	Brief description
15 / 16	Drive lever (traction)	<p>For switching on the paver finisher functions and for continuously regulating the road speed – forward or reverse. Centre position: Engine in neutral; no travel drive;</p> <ul style="list-style-type: none"> <li>- To swivel the drive lever out, release by pulling the handle (16) up.</li> </ul> <p>If the drive lever is pushed out, then the following "AUTO" or "MANUAL" functions are activated:</p> <ul style="list-style-type: none"> <li>- Conveyor / auger</li> <li>- Tamper / vibration</li> <li>- Levelling</li> </ul> <p>as well as increasing the vehicle speed as far as it will go</p> <p> As well as pushing the drive lever out, the safety switch in the running board / on the handrail of the operator's control station must be pressed. Otherwise the travel drive is blocked.</p> <p> Use the preselector to set the maximum speed.</p> <p> The vehicle speed cannot be reduced to "0" with the preselector. The vehicle advances slightly with deflected drive lever, even if the travel drive preselector is set to "zero"!</p> <p> If the engine is started with the drive lever swivelled, the travel drive is inhibited. To start the travel drive, first the drive lever must be returned to the centre position.</p> <p> When changing over between forwards and reverse travel, the drive lever must remain briefly in neutral.</p>

















Pos.	Designation	Brief description
17	Travel drive preselector	<p>For setting the maximum speed that can be reached when the drive lever is at its stop.</p> <p> The scale roughly matches the speed in m/min (during paving).</p> <p> The vehicle speed cannot be reduced to "0" with the preselector. The vehicle advances slightly with deflected drive lever, even if the travel drive preselector is set to "zero"!</p>
18	Steering potentiometer	<p>The steering wheel movement is transferred electrohydraulically.</p> <p> For precise adjustments (position "0" = straight-ahead), see the straight-ahead travel synchronisation. For turning on the spot, see switch (Turning on the spot).</p>
19	Horn	<p>Press in the case of emergencies and to indicate when the vehicle starts to move!</p> <p> The horn can also be used to communicate acoustically with the truck driver for material loading!</p>









Pos.	Designation	Brief description
20	Left screed extend / retract	<p>Pushbutton function:</p> <ul style="list-style-type: none"> <li>- Left switch position: Extend left half of screed.</li> <li>- Right switch position: Retract left half of screed.</li> </ul> <p> On actuation, heed danger zones of moving parts of the vehicle!</p>
21	Right screed extend / retract	<p>Pushbutton function:</p> <ul style="list-style-type: none"> <li>- Left switch position: Retract right half of screed.</li> <li>- Right switch position: Extend right half of screed.</li> </ul> <p> On actuation, heed danger zones of moving parts of the vehicle!</p>
22	Left hopper open / close	<p>Pushbutton function:</p> <ul style="list-style-type: none"> <li>- Upper switch position: Close left hopper lid.</li> <li>- Lower switch position: Open left half of hopper.</li> </ul> <p> On actuation, heed danger zones of moving parts of the vehicle!</p>
23	Right hopper open / close	<p>Pushbutton function:</p> <ul style="list-style-type: none"> <li>- Upper switch position: Close right half of hopper.</li> <li>- Lower switch position: Open right half of hopper.</li> </ul> <p> On actuation, heed danger zones of moving parts of the vehicle!</p>










Pos.	Designation	Brief description
24	Left auger - Operating mode "AUTO" / "OFF" / "MANUAL"	<p>Detent switch function:</p> <ul style="list-style-type: none"> <li> -Operating mode "AUTO": The conveying function of the left half of the auger is switched on when the drive lever is swivelled out and is continuously controlled via the material limit switches.</li> <li> -Operating mode "OFF": The conveying function of the left half of the auger is switched off.</li> <li> -Operating mode "MANUAL": The conveying function of the left half of the auger is switched on continuously with full delivery capacity, without material control via the limit switches.</li> </ul> <p> On actuation, heed danger zones of moving parts of the vehicle!</p>
25	Right auger - Operating mode "AUTO" / "OFF" / "MANUAL"	<p>Detent switch function:</p> <ul style="list-style-type: none"> <li> -Operating mode "AUTO": The conveying function of the right half of the auger is switched on when the drive lever is swivelled out and is continuously controlled via the material limit switches.</li> <li> -Operating mode "OFF": The conveying function of the right half of the auger is switched off.</li> <li> -Operating mode "MANUAL": The conveying function of the right half of the auger is switched on continuously with full delivery capacity, without material control via the limit switches.</li> </ul> <p> On actuation, heed danger zones of moving parts of the vehicle!</p>







Pos.	Designation	Brief description
26	Reversing switch for left auger	<p>Pushbutton function:</p> <ul style="list-style-type: none"> <li>- Right switch position: The conveying direction of the left half of the auger can be reversed in order to slightly reverse paving material for example.</li> </ul> <p> The function can be triggered in all modes of the auger.</p> <p> On actuation, heed danger zones of moving parts of the vehicle!</p>
27	Reversing switch for right auger	<p>Pushbutton function:</p> <ul style="list-style-type: none"> <li>- Left switch position: The conveying direction of the right half of the auger can be reversed in order to slightly reverse paving material for example.</li> </ul> <p> The function can be triggered in all modes of the auger.</p> <p> On actuation, heed danger zones of moving parts of the vehicle!</p>
28	not used	












Pos.	Designation	Brief description
29	Conveyor Operating mode "AUTO" / "OFF" / "MANUAL"	<p>Detent switch function:</p> <ul style="list-style-type: none"> <li> -Operating mode "AUTO": The conveying function of the conveyor is switched on when the drive lever is swivelled out and is switched off via the material limit switches.</li> <li> -Operating mode "OFF": The conveying function of the conveyor is switched off.</li> <li> -Operating mode "MANUAL": The conveying function of the conveyor is switched on constantly, without material control via the limit switches.</li> </ul> <p> On actuation, heed danger zones of moving parts of the vehicle!</p>
30	Reversing switch for conveyor	<p>Pushbutton function:</p> <ul style="list-style-type: none"> <li>- Upper switch position: The conveying direction of the conveyor can be reversed in order to slightly reverse paving material for example which may be present in the material tunnel.</li> </ul> <p> The function can be triggered in all modes of the conveyor.</p> <p> The function can only be triggered in the "Auto" mode when the vehicle is moving.</p> <p> On actuation, heed danger zones of moving parts of the vehicle!</p>











Pos.	Designation	Brief description
31	Fill vehicle for paving process	<p>Pushbutton function:</p> <ul style="list-style-type: none"> <li>- Filling function for the paving process. The conveying functions set to "automatic" (conveyor and auger) are switched on.</li> </ul> <p> Once the set material height is reached at the limit switches, the conveying functions are switched off.</p> <p> On actuation, heed danger zones of moving parts of the vehicle!</p>
32	not used	









Pos.	Designation	Brief description
33	Screed lifting / lowering Screed stop (floating position OFF) / lower screed + floating position	<p>Pushbutton function:</p> <ul style="list-style-type: none"> <li>- Upper switch position: Lift the screed.</li> <li>- Switch position, central: Screed stop (floating position OFF): Screed is hydraulically locked in position.</li> <li>- Lower switch position: Lower screed + floating position: Screed is lowered and released in the floating position when the drive lever is swivelled out.</li> </ul> <p> To prevent the screed from lowering during an intermediate stop (drive lever in centre position), the screed is hydraulically held in position via relief pressure and the counter pressure of the material.</p> <p> Check whether the screed transport safeguard is inserted!</p> <p> On actuation, heed danger zones of moving parts of the vehicle!</p>








Pos.	Designation	Brief description
34	Tamper - Operating mode "AUTO" / "OFF" / "MANUAL" (○)	<p>Detent switch function:</p> <ul style="list-style-type: none"> <li> -Operating mode "AUTO": The screed tamper is switched on when the drive lever is swivelled out.</li> <li> -Operating mode "OFF": The screed tamper is switched off.</li> <li> -Operating mode "MANUAL": The screed tamper is switched on constantly.</li> </ul>
35	Vibration - Operating mode "AUTO" / "OFF" / "MANUAL"	<p>Detent switch function:</p> <ul style="list-style-type: none"> <li> -Operating mode "AUTO": Screed vibration is switched on when the drive lever is swivelled out.</li> <li> -Operating mode "OFF": Screed vibration is switched off.</li> <li> -Operating mode "MANUAL": Screed vibration is switched on constantly.</li> </ul>











Pos.	Designation	Brief description
36	Levelling Operating mode "AUTO" / "OFF"	<p>Detent switch function:</p> <ul style="list-style-type: none"> <li> -Operating mode "OFF": The automatic levelling function is switched off.</li> <li> -Operating mode "AUTO": height adjustment is carried out automatically via the connected grade control system.</li> </ul>
37	Left levelling cylinder extend / retract	<p>Pushbutton function:</p> <ul style="list-style-type: none"> <li>- Upper switch position: Retract left levelling cylinder.</li> <li>- Lower switch position: Extend left levelling cylinder.</li> </ul> <p> The "AUTO" and "OFF" mode are overridden when actuated.</p> <p> On actuation, heed danger zones of moving parts of the vehicle!</p>
38	Right levelling cylinder extend / retract	<p>Pushbutton function:</p> <ul style="list-style-type: none"> <li>- Upper switch position: Retract right levelling cylinder.</li> <li>- Lower switch position: Extend right levelling cylinder.</li> </ul> <p> The "AUTO" and "OFF" mode are overridden when actuated.</p> <p> On actuation, heed danger zones of moving parts of the vehicle!</p>





Pos.	Designation	Brief description
39	Travel drive fast/slow	<p>Detent switch function:</p> <ul style="list-style-type: none"> <li>- Upper switch position: Preselection of the speed level - transportation speed (fast).</li> <li>- Lower switch position: Preselection of the speed level - operating speed (slow).</li> </ul>
40	Turning on the spot	<p>Detent switch function:</p> <ul style="list-style-type: none"> <li>- Upper switch position: Straight-ahead travel / standard operation.</li> <li>- Lower switch position: Turning on the spot - The paver finisher turns on the spot (the caterpillar chains run in opposite directions) when the steering is turned to "10". <ul style="list-style-type: none"> <li>- Steering turned to the left = vehicle turns to the left</li> <li>- Steering turned to the right = vehicle turns to the right</li> </ul> </li> </ul> <p> If the "Turning on the spot" function has been inadvertently activated (and the steering is set to straight-ahead travel), the paver finisher does not move. This is often interpreted as a "malfunction".</p> <p> The function can only be activated in the working gear ("travel drive slow") speed.</p> <p> When the vehicle turns, persons and objects next to the paver finisher are in extreme danger. Note the danger area!</p>





Pos.	Designation	Brief description
41	Rotary beacon ON / OFF (○)	<p>Detent switch function:</p> <ul style="list-style-type: none"> <li>- Upper switch position: Rotary beacon ON.</li> <li>- Lower switch position: Rotary beacon OFF.</li> </ul> <p> Switch on for safety on roads and in the construction site area</p>
42	Working lights ON / OFF (○)	<p>Detent switch function:</p> <ul style="list-style-type: none"> <li>- Upper switch position: Working lights ON.</li> <li>- Lower switch position: Working lights OFF.</li> </ul> <p> Avoid dazzling other road users!</p>









Pos.	Designation	Brief description
43	Separator fluid spray system ON / OFF (○)	Detent switch function: <ul style="list-style-type: none"><li>- Upper switch position: Spray system "ON"</li><li>- Lower switch position: Hopper function "OFF"</li></ul>
44	Changeover Remote control / operator's platform (○)	Detent switch function: <ul style="list-style-type: none"><li>- Lower switch position: Machine control takes place at the paver finisher operator's platform</li><li>- Upper switch position: Machine control takes place at the remote control</li></ul>







Pos.	Designation	Brief description
45	Error / malfunction call up	<p>If a fault discovered on the drive engine is indicated by one of the warning lamps, a code assigned to a defined defect can be called up.</p> <p>Pushbutton function:</p> <ul style="list-style-type: none"> <li>- Upper switch position: Call the fault code.</li> </ul> <p> Press the switch until the three-digit code has been output by the warning lamp.</p> <p> Refer to the "Malfunctions" section for calling up error codes!</p>










Pos.	Designation		Brief description
50	Battery charge indicator (red)		Must go out after starting when the engine revs up. - If the indicator lamp does not go out, switch off the engine
51	Error message - vehicle (red)		Indicates that there is fault in the vehicle control system. Each fault should be checked and rectified as soon as possible!  ☞ Special equipment is needed to read out faults in the vehicle control system.  ☞ Please contact the technical customer service for your vehicle
52	Error message - drive engine (yellow)		Lights up when there is a fault in the drive engine. Depending on the type of fault, the drive engine may be switched off automatically for safety reasons.  ☞ The error code can be retrieved using the "Call up error/malfunction" switch.  ☞ Lights up for a few seconds once the ignition has been switched on for checking purposes.
53	Start inhibit (yellow)		Indicates that an enabled function stops the machine from starting.





51...56



Pos.	Designation		Brief description
54	Pre-heating indicator (yellow)		<p> Pre-heating is started with the ignition starter by switching the ignition on. (ignition key in position 1). Once pre-heating has finished, the indicator lamp goes off.</p> <p> Do not switch the ignition on until the pre-heating phase has finished!</p>
55	Indicator lamp Air filter (yellow)		<p>Lights up if the air filter needs replacing.</p> <p> Replace filter element acc. to maintenance instructions!</p>
56	Fuel reserve (yellow)		<p>Lights up when the fuel in the tank reaches the reserve level.</p> <p> Approx. 10% remains.</p>
57	Fuel gauge		Shows the level of fuel in the tank.
58	Operating hours counter		The operating hours are only counted while the engine is running. Heed the maintenance intervals (see chapter F).
59	Engine speed		Shows the actual speed of the drive engine (rpm).

## Flame monitoring (○)



---

Pos.	Designation	Brief description
70	Malfunction display	Left middle section malfunction display, red
71	Malfunction display	Left extendable part malfunction display, red
72	Malfunction display	Right middle section malfunction display, red
73	Malfunction display	Right extendable part malfunction display, red





Via the temperature sensor and flame monitoring system, the electronics monitor gas heater operation. If there is no stable flame at the ignition burner within 7 seconds, the electronics indicate a malfunction.




The gas supply is interrupted and the indicator lamps light up.




Please comply with further instructions for the flame monitoring function in the corresponding Operating Instructions for the screed.










Pos.	Designation	Brief description
74	Display	<ul style="list-style-type: none"> <li>- Shows the actual temperature of the screed heater.</li> <li>- Shows status reports of the screed heater.</li> </ul>  When the temperature is adjusted, the nominal temperature is displayed for a few seconds before the display reverts to the actual temperature.
75	"Plus" button	<ul style="list-style-type: none"> <li>- Pressing the button increases the nominal temperature.</li> </ul>  The temperature is adjusted in the range 20 - 180°C
76	"Minus" button	<ul style="list-style-type: none"> <li>- Pressing the button reduces the nominal temperature.</li> </ul>  The temperature is adjusted in the range 20 - 180°C
77	Button "ON / "OFF".	<ul style="list-style-type: none"> <li>- For switching the screed heater on and off.</li> </ul>


 Please comply with further instructions for the screed heater function and operation in the corresponding Operating Instructions for the screed.




### 3 Remote control





 Depending on the side of the machine (left/right), the function switches only control the corresponding function on the particular side of the machine.

Pos.	Designation	Brief description
80	Left remote control	<ul style="list-style-type: none"> <li>- for controlling paving-relevant paver and screed functions on the left side of the vehicle.</li> </ul>
81	Right remote control	<ul style="list-style-type: none"> <li>- for controlling paving-relevant paver and screed functions on the right side of the vehicle.</li> </ul>
82	Socket Left levelling system	<ul style="list-style-type: none"> <li>- for connecting the external levelling system to the left of the vehicle.</li> </ul>  When not needed, close the socket with the corresponding protective cap.
83	Socket Right levelling system	<ul style="list-style-type: none"> <li>- for connecting the external levelling system to the right of the vehicle.</li> </ul>  When not needed, close the socket with the corresponding protective cap.
84	Vandalism protection facility	<ul style="list-style-type: none"> <li>- Lock the vandalism protection facility at the end of work.</li> <li>- For attaching external levelling units.</li> </ul>  Remove the levelling unit before the vandalism protection facility is locked.





Pos.	Designation	Brief description
90	Emergency stop button	<p>In the case of an emergency (danger to persons, possible collision, etc.), press in the button!</p> <ul style="list-style-type: none"> <li>- Pressing the emergency stop button switches off the engine, the drives and the steering system. Making way, lifting the screed or other actions are then no longer possible! Danger of accident!</li> <li>- The emergency stop button does not shut off the gas heater system. Close the main shut-off valve and the valves on the bottles by hand!</li> <li>- To restart the engine, the button must be unlocked again.</li> </ul>
91	Horn	<p>Press in the case of emergencies and to indicate when the vehicle starts to move!</p> <p> The horn can also be used to communicate acoustically with the truck driver for material loading!</p>
92	Auger left/right Operating mode "AUTO" / "OFF" / "MANUAL"	<p>Detent switch function:</p> <ul style="list-style-type: none"> <li>- Left switch position: Operating mode "AUTO": The conveying function of the left / right half of the auger is switched on when the drive lever is swivelled out and is continuously controlled via the material limit switches.</li> <li>- Switch position, central: Operating mode "OFF": The conveying function of the left / right half of the auger is switched off.</li> <li>- Right switch position: Operating mode "MANUAL": The conveying function of the left / right half of the auger is switched on continuously with full delivery capacity, without material control via the limit switches.</li> </ul> <p> On actuation, heed danger zones of moving parts of the vehicle!</p>
93	Levelling cylinder left/right extend / retract	<p>Pushbutton function:</p> <ul style="list-style-type: none"> <li>- Upper switch position: Retract left / right levelling cylinder.</li> <li>- Lower switch position: Extend left / right levelling cylinder.</li> </ul> <p> On actuation, heed danger zones of moving parts of the vehicle!</p>






Pos.	Designation	Brief description
94	Screed left/right extend / retract	<p>Pushbutton function:</p> <ul style="list-style-type: none"> <li>- Switch position in the corresponding direction: extend or retract left / right screed half</li> </ul>  On actuation, heed danger zones of moving parts of the vehicle!
95	Screed warning light left/right	<ul style="list-style-type: none"> <li>- Flashes when the screed is extended and retracted.</li> </ul>






## 4 Remote control














Pos.	Designation	Brief description
100	Emergency stop button	<p>In the case of an emergency (danger to persons, possible collision, etc.), press in the button!</p> <ul style="list-style-type: none"> <li>- Pressing the emergency stop button switches off the engine, the drives and the steering system. Making way, lifting the screed or other actions are then no longer possible! Danger of accident!</li> <li>- The emergency stop button does not shut off the gas heater system. Close the main shut-off valve and the valves on the bottles by hand!</li> <li>- To restart the engine, the button must be unlocked again.</li> </ul>
101	Steering potentiometer	<p>The steering wheel movement is transferred electrohydraulically.</p> <p> For precise adjustments (position "0" = straight-ahead), see the straight-ahead travel synchronisation. For turning on the spot, see switch (Turning on the spot).</p>
102	Straight-ahead travel synchronisation	<p>Using this potentiometer, both chains can be synchronised for straight-ahead travel while driving:</p> <ul style="list-style-type: none"> <li>- Set the steering to position "0"; then adjust the potentiometer until the paver finisher is travelling straight ahead.</li> </ul>







Pos.	Designation	Brief description
103 / 104	Drive lever (traction)	<p>For switching on the paver finisher functions and for continuously regulating the road speed – forward or reverse. Centre position: Engine in neutral; no travel drive;</p> <ul style="list-style-type: none"> <li>- To swivel the drive lever out, release by pulling the handle (16) up.</li> </ul> <p>If the drive lever is pushed out, then the following "AUTO" functions are activated:</p> <ul style="list-style-type: none"> <li>- Conveyor / auger</li> <li>- Tamper / vibration</li> <li>- Levelling</li> </ul> <p>as well as increasing the vehicle speed as far as it will go</p> <p> As well as pushing the drive lever out, the safety switch in the running board of the operator's control station must be pressed. Otherwise the travel drive is blocked.</p> <p> Use the preselector to set the maximum speed.</p> <p> The vehicle speed cannot be reduced to "0" with the preselector. The vehicle advances slightly with deflected drive lever, even if the travel drive preselector is set to "zero"!</p> <p> If the engine is started with the drive lever swivelled, the travel drive is inhibited. To start the travel drive, first the drive lever must be returned to the centre position.</p> <p> When changing over between forwards and reverse travel, the drive lever must remain briefly in neutral.</p>




Pos.	Designation	Brief description
105	Travel drive preselector	<p>For setting the maximum speed that can be reached when the drive lever is at its stop.</p> <p> The scale roughly matches the speed in m/min (during paving).</p> <p> The vehicle speed cannot be reduced to "0" with the preselector. The vehicle advances slightly with deflected drive lever, even if the travel drive preselector is set to "zero"!</p>
106	Horn	<p>Press in the case of emergencies and to indicate when the vehicle starts to move!</p> <p> The horn can also be used to communicate acoustically with the truck driver for material loading!</p>
107	Left hopper open / close	<p>Pushbutton function:</p> <ul style="list-style-type: none"> <li>- Upper switch position: Close left hopper lid.</li> <li>- Lower switch position: Open left hopper lid.</li> </ul> <p> On actuation, heed danger zones of moving parts of the vehicle!</p>
108	Right hopper open / close	<p>Pushbutton function:</p> <ul style="list-style-type: none"> <li>- Upper switch position: Close right hopper lid.</li> <li>- Lower switch position: Open right hopper lid.</li> </ul> <p> On actuation, heed danger zones of moving parts of the vehicle!</p>




Pos.	Designation	Brief description
109 / 110	Safety switch	<p><b>Pull switch:</b></p> <p> The safety switch ensures that the travel drive is shut down when the operator leaves the working area.</p> <p> For safety reasons, it is prohibited to work with the remote control without fastening the safety cut-out belt to the operator!</p> <p>- Fasten the safety switch belt (110) to the operator.</p> <p> If the safety switch is pulled, the travel drive shuts down immediately.</p> <p> The travel drive is blocked after a safety shutdown. To release it again, the drive lever has to be put in neutral position first.</p>

## 5 Malfunctions

### 5.1 Error code display and query for engine




3



1

2






- If there is an error in the engine, a message appears with a flashing warning light (1). The corresponding error code (SPN/FMI) appears in the display (2).
- The error code goes off again after a defined period of time. The flashing warning light (1) remains active.
- To see the error display again, press the switch (3) briefly in the Info position until the error code appears in the display again.




If there are several errors, the error codes (SPN/FMI) appear one after the other. The warning light continues to flash until all errors have been rectified.

## 5.2 Error code display and query for travel drive computer





- If there is an error in the travel drive computer, a message appears with a flashing warning light (2).

NOTE	Service qualification necessary
	<p>The error messages can only be read out by a qualified Dynapac service partner.</p> <ul style="list-style-type: none"> <li>- Special equipment is necessary to read out the errors.</li> <li>- Particular skills and special instructions are required.</li> </ul>

## D 30.12 Operation

### 1 Control elements on the paver finisher

#### 1.1 Control elements on the operator's control station

 <b>WARNING</b>	<b>Danger of falling from the vehicle</b>
	<p>Entering and leaving the vehicle and the driver's seat during operation poses the danger of falling from the vehicle which can cause severe to fatal injuries!</p> <ul style="list-style-type: none"><li>- The operator must be at the intended driver's seat during operation.</li><li>- Never jump onto or off a moving vehicle.</li><li>- Keep accessible surfaces free of any soiling, e.g. operating substances, to avoid the risk of slipping.</li><li>- Use the steps provided and hold onto the handrail with both hands.</li><li>- Comply with all further information in these instructions and in the safety manual.</li></ul>

## Control platform


The control platform is designed for operating standing up.



- After work has been completed, place the vandalism protection facility (1) on the operating panel and secure with the lock (2).
- The vandalism protection facility can be kept in bracket (3) during operation.
- To operate with remote control (○), the handrail (4) can be removed so that the external control can be swivelled to the required side of the vehicle.
- Loosen the screws (5) and pull the handrail out of the holding tubes.
- Then insert the handrail again and tighten the screws (5) properly.
- There is a safety switch (6) in the running board respectively on the handrail.
- The switch must be pressed when the drive lever is moved out of the neutral position. Otherwise the travel drive is blocked.



Do not press the foot switch permanently. This also blocks the travel drive.

- The storage space (7) can be used to keep the on-board toolkit, operating instructions and other attachments.
- Keep the storage space closed after work has been completed.



 <b>WARNING</b>	<b>Danger due to damaged or missing operating instructions</b>
	<p>Failure to comply with the operating instructions can cause severe to fatal injuries!</p> <ul style="list-style-type: none"> <li>- Make yourself familiar with the contents of the operating instructions.</li> <li>- Always keep the operating instructions in the intended place at the vehicle.</li> <li>- Replace any missing or damaged operating instructions immediately.</li> <li>- Comply with all further information in the operating instructions and in the safety manual.</li> </ul>

### Running board extension (○)

The telescopic extension (1) is located on both sides of the running board for the operator's control station (2).

- Raise the extension gently in the opening and pull out to the required size.  
Ensure that the extension locks in one of the intended detent positions (3).




Extending the running board extension enlarges the basic width of the paver finisher.



Ensure that nobody or nothing is in the danger area!



Only adjust the operating position whilst the vehicle is stationary!




## Fuse box

The terminal box, which contains all fuses and relays, etc. is located beneath the operating panel.



An assignment plan for fuses and relays can be found in chapter F8.



## Batteries

The batteries (1) of the 24 V system are located in the engine compartment of the vehicle.



For the specifications, refer to chapter B, "Technical data". For maintenance, see chapter "F".



External starting must only be carried out according to the instructions (see section "Starting the paver finisher, external starting (starting aid)").

## Main battery switch

The main battery switch separates the current circuit from the battery to the main fuse.




For the assignment of all fuses, see chapter F.

- To interrupt the battery's current circuit, turn the key pin (3) to the left and pull it out.



Do not lose the key pin as in this case the paver finisher can no longer be moved!



## Hopper transport safeguard


Before parking or transporting the paver finisher, the hopper lids must be swung upwards and the transport safeguards for the hopper must be inserted.

- Insert snap hook (A) in the corresponding shackle of the opposite hopper lid.



Do not enter the hopper while the engine is running! Danger of being caught by the conveyor!

Without transport safeguards inserted, the hopper halves will slowly open; danger during transportation!




## Screed transport safeguard

It is used to protect the lifted screed from inadvertent sinking. The screed transport safeguard must be inserted before transportation and when work is finished.



Transportation with an unsecured screed leads to a risk of accidents!

- Lift the screed.
- Insert bolt (A) at the screed lifting in lock hole (B).



### ATTENTION!

Screed transport safeguard only for transportation!

Do not enter or work under screed only secured with screed lock for transportation!

**Danger of accident!**



## Speed controller Compacting elements

### Speed control, tamper (○) (A)


The tamper frequency (number of strokes per minute) is set fully variable using the rotary regulator (A).

### Speed regulation for vibration (B)

The vibration frequency (number of vibrations per minute) is set fully variable using the rotary regulator (B).




The tamper and vibration function is switched on and off at the vehicle operating panel.



## Conveying quantity controller Auger / conveyor

Use the knob (1) to adjust the conveying speed for conveyor and auger.

- Turn to the right - higher conveying speed
- Turn to the left - lower conveying speed




## Paving thickness indicator

Two scales (A), on which the currently set paving thickness can be read off, are located on the left and right sides of the vehicle.

- Pointer (B) shows the paving thickness.



In normal paving situations, the same paving thickness should be set on both sides of the vehicle!




## Auger lighting (○)



Two swivelling working lights (1) are provided to illuminate the auger compartment.



They are engaged together with the working lights.




## LED working light (○)

The working lights are fitted in any position on the machine using the magnetic foot.

- Connect the lead with the 24V socket on the vehicle.



Always align the working lights to avoid dazzling the operating personnel or other road users!




## Auger height adjustment ratchet (○)

For mechanical adjustment of the auger height

- Set the ratchet direction lever (1) to the clockwise or anti-clockwise direction. Turning anti-clockwise lowers the auger, turning clockwise lifts the auger.
- Actuate the ratchet lever (2)
- Set the desired height by alternatingly actuating the left and right ratchets.



The current height can be read on both auger height indicators.



Observe the notes on adjusting the auger height in the chapter "Set-up and modification"!


## Auger height displays

A scale (1), on which the currently set auger height can be read off, is located on the left and right sides of the ladder.




Display in cm

- Pointer (2) shows the auger height.



## Sensor rod / sensor rod extension



The sensor rod acts as an orientation aid for the vehicle driver during paving. Along the defined paving route, the vehicle driver can use the sensor rod to follow a tensioned reference wire or another marking.

The sensor rod runs along the reference wire or over the marking. Steering deviations can therefore be ascertained and corrected by the driver.



Use of the sensor rod increases the basic width of the paver finisher.



If the sensor rod or sensor rod extension are used, ensure that there is no one in the vehicle's danger area!



The sensor rod is adjusted when the vehicle is positioned, with its set working width, on the paving route and the reference marking running parallel to the paving route has been set up.

Adjusting the sensor rod:

- The sensor rod (1) is fitted to the head end of the vehicle on either the left or right.
  - Push the sensor rod into the mounting (2). Fasten by tightening the corresponding clamping bolts (3).
- After releasing the wing nuts (4), the end section of the sensor rod (5) can be set to the desired length; the angle can additionally be changed by swivelling on the joint (6).



The chain (7) can be used as a guide.



Tighten all assembly parts properly after setting up!

## Manual separator fluid spray (○)

Used to spray the parts coming into contact with asphalt with a separator emulsion.




Only use approved separator emulsion in the spray (1)!

- Build up pressure by actuating the pump lever (2).
- The pressure is indicated on the manometer (3).
- Actuate the manual valve (4) to spray.



Do not spray into open flame or on hot surface! Danger of explosion!



## Separator fluid spraying system (○)

Used to spray the parts coming into contact with asphalt with a separator emulsion.

- Connect the spray hose (1) with quick-action coupling (2).



Only switch on the spraying system when the diesel engine is running; otherwise, the battery will be discharged. Switch off after use.

- Pull the hose out of the device until a click is audible. When released, the hose automatically engages here. The hose is automatically retracted into the guide after pulling and discharging again.
- Actuate the manual valve (3) to spray.




Do not spray into open flame or on hot surface Danger of explosion!



The function is switched on and off at the vehicle operating panel.

- If the system is not in use, place the spray lance (4) in the provided holder (9).






## Conveyor limit switches

The conveyor is switched "ON" and "OFF" using the paddles (1) and (2).

- To set the deactivation point:
  - Loosen the screw (3) and turn the paddle (1) / (2) on the shaft until the required switching point is reached.

or

- Loosen the screw (4) and turn the switching cam (5) on the shaft until the required switching point is reached.
- After adjusting, retighten all mounting parts properly.



## Auger limit switches

The augers are controlled by sensors.

### Mounting the sensors:

Fasten the sensors to the side shield (1 sensor for each auger) in the provided clamp bracket (1) on the holding tube (2).



Always mount the sensors (3) to ensure that they are not damaged on extending and retracting the screed.


Align the ultrasound sensor (3) towards the mixed materials in front of the auger. The sound waves should impact on the mixed materials at right angles.

Adjust the deactivation point with the desired material height by regulating the potentiometer (4).

Repeat these tasks everyday before starting work.



Always keep the sensors free of impurities.



## 24 volt sockets (○)


There is one socket (1) on each side of the operating panel console.

Additional working lights can be connected here, for example.

- 24V socket



Voltage is present when the main switch is switched on.



### Fire extinguisher (○)



The paver finisher personnel must be familiarised with operation of the fire extinguisher (2).



Observe the inspection interval for the fire extinguisher!


### First-aid kit (○)



Any dressings that have been used must be replaced immediately!



Heed the expiry date of the first-aid kit!



## Rotary beacon (○)




The function of the rotary beacon must be checked daily before starting work.

- Place the rotary beacon onto the plug-in contact and secure with a wing bolt (1).
- Slide the rotary beacon with the tube (2) out to the desired height and secure with the clamping bolt (4).
- Activate the function on the operating panel as necessary.



The rotary beacon is easy to remove and should be stored securely at the end of work.







## **D 40.12    Operation**



### **1        Preparing for operation**

#### **Required devices and aids**

To avoid delays on site, check before starting work whether or not the following devices and aids are present:

- Wheel loader for transporting heavy extension parts
- Diesel fuel
- Engine oil and hydraulic oil, lubricants
- Separator fluids (emulsion) and manual injector
- Two filled propane gas bottles
- Shovel and broom
- Scraper (spatula) for cleaning the auger and the hopper infeed area
- Parts that may become necessary for extending the auger
- Parts that may become necessary for extending the screed
- Percentage spirit level + levelling rail, 4 m long
- Levelling wire
- Protective clothing, signal vest, gloves, ear protection

 <b>CAUTION</b>	<b>Danger due to restricted vision</b>
	<p>Restricted vision poses a risk of injury!</p> <ul style="list-style-type: none"> <li>- Before starting work, arrange the intended driver's seat so as to warrant adequate vision.</li> <li>- Signalmen must be used when vision is restricted, also to the sides and when reversing.</li> <li>- Only reliable persons may be used as signalmen who must have been received instructions about their task before taking up their activity. This refers in particular to the hand signals to be used. Standardised hand signals must be used.</li> <li>- Adequate lighting must be provided when working at night.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>

 <b>WARNING</b>	<b>Danger of falling from the vehicle</b>
	<p>Entering and leaving the vehicle and the driver's seat during operation poses the danger of falling from the vehicle which can cause severe to fatal injuries!</p> <ul style="list-style-type: none"> <li>- The operator must be at the intended driver's seat during operation.</li> <li>- Never jump onto or off a moving vehicle.</li> <li>- Keep accessible surfaces free of any soiling, e.g. operating substances, to avoid the risk of slipping.</li> <li>- Use the steps provided and hold onto the handrail with both hands.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>




## Before starting work


(in the morning or when starting paving)

- Heed the safety instructions.
- Check the personal protective equipment .
- Take an inspection walk around the paver finisher and check for leaks and damages.
- Install parts removed for transportation or for the night.
- When screed is operated with the optional gas heating system, open the closing valves and the main shut-off valve.
- Perform the check according to the "Checklist for the vehicle operator" given below.

## Check list for the vehicle operator

Check!	How?
Emergency stop button <ul style="list-style-type: none"> <li>- on the operating panel</li> <li>- on both remote controls</li> </ul>	Push in the button. The diesel engine and all running drives must stop immediately.
Steering	The paver finisher must immediately follow every steering wheel movement in a precise manner. Check straight ahead travel.
Horn <ul style="list-style-type: none"> <li>- On the operating panel</li> <li>- on both remote controls</li> </ul>	Briefly press the horn button. Horn signal must sound.
Lights	Switch on with the ignition key, walk around the paver finisher to check and switch off again.
Screed warning light (with vario screeds)	With the ignition switched on, press the switches for extending/retracting the screed parts. The warning lamps must flash.
Gas heater system (○): <ul style="list-style-type: none"> <li>- Bottle holders</li> <li>- Bottle valves</li> <li>- Pressure reducer</li> <li>- Hose break safety devices</li> <li>- Shut-off valves</li> <li>- Main shut-off valve</li> <li>- Connections</li> <li>- Indicator lamps of the switch box</li> </ul>	Check: <ul style="list-style-type: none"> <li>- Secure seat</li> <li>- Cleanliness and tightness</li> <li>- Working pressure 1.5 bar</li> <li>- Function</li> <li>- Function</li> <li>- Function</li> <li>- Tightness</li> <li>- All indicator lamps must light up when the system is switched on</li> </ul>

Check!	How?
Screed transport safeguard	When the screed is raised, it must be possible to insert the bolt in the lock hole.
Hopper transport safeguard	When the hopper is closed, it must be possible to insert the safety chain between the two hopper lids.
Miscellaneous: - Engine panels - Lateral flaps	Check that the hoods and flaps are securely seated.
Accessories: - First aid box	Equipment must be present on the vehicle!  Always observe the local regulations!



## 1.1 Starting the paver finisher

### Before starting the paver finisher

Before starting the diesel engine and beginning operation, the following steps must be performed:

- Daily maintenance of the paver finisher (see chapter F).



Check the operating hour counter to determine whether or not additional maintenance work (e.g. monthly or annual maintenance) must be performed.

- Check the safety devices and protective devices.

### "Normal" starting

Set the drive lever (1) to the centre position and the speed adjuster (2) to minimum

- Insert the ignition key (3) in position "0".



The lights should be switched off during starting to reduce the current drain on the battery.



The vehicle cannot be started if the "Start inhibit" (4) or "Error message" (5) indicator lamps are on.

The "Start inhibit" indicator lamps shows that the following states are present on the operating panel or remote control:

- Emergency stop button (6) pressed
- Auger function (7) switched to "AUTO" or "MANUAL"
- Conveyor function (8) switched to "AUTO" or "MANUAL"

The "Error message" indicator lamp shows that an engine fault prevents the starting process.

- Turn ignition key (3) to position 1 and wait for the preheat check (9) to go off.
- Press the starting button (3a) to start the engine.  
Do not let the starter run continuously for more than 20 seconds, then allow for a break of one minute after every attempt!



If the engine does not start and the Error message (5) indicator lamp flashes, then the electronic engine control system has activated the start inhibit.


To deactivate the start inhibit, turn the system off with the ignition key (3) for approx. 30 s.



If the engine still has not started after two attempts, ascertain the cause!



Do not use aerosol types such as ether as starting aid. This can cause an explosion and lead to personal injuries.



## External starting (starting aid)



The engine can be started with the help of an external power source if the batteries are empty and the starter no longer turns.

Suitable power sources are:

- Other vehicles with a 24V system
- Additional 24V battery
- Start device that is suitable for external starting (24 V/90 A).



Standard chargers or quick chargers cannot be used for external starting.

To externally start the engine:


Set the drive lever (1) to the centre position and the speed adjuster (2) to minimum

- Insert the ignition key (3) in position "0".



The starting aid cable must be connected to 24 V.

- First connect the positive terminal (1) to the start aid battery with the positive terminal (2) of the vehicle battery.
- Then connect the negative terminal (3) of the start aid battery to ground of the discharged vehicle, e.g. to the engine block or to a bolt (4) on the machine frame.



Do not connect the start aid cable to the negative terminal of the discharged battery! Danger of explosion!



Lay the start aid cable so that it can be disconnected once the engine is running.



The vehicle cannot be started if the "Start inhibit" (4) or "Error message" (5) indicator lamps are on.

The "Start inhibit" indicator lamps shows that the following states are present on the operating panel or remote control:

- Emergency stop button (6) pressed
- Auger function (7) switched to "AUTO" or "MANUAL"
- Conveyor function (8) switched to "AUTO" or "MANUAL"

The "Error message" indicator lamp shows that an engine fault prevents the starting process.

- Possibly start the engine of the vehicle supplying power and leave to run for a while.

Now try to start the other vehicle:


- Turn ignition key (3) to position 1 and wait for the preheat check (9) to go off.
- Press the starting button (3a) to start the engine.  
Do not let the starter run continuously for more than 20 seconds, then allow for a break of one minute after every attempt!



If the engine does not start and the Error message (5) indicator lamp flashes, then the electronic engine control system has activated the start inhibit.  
To deactivate the start inhibit, turn the system off with the ignition key (3) for approx. 30 s.

- If the engine still has not started after two attempts, ascertain the cause!
- If the engine starts up: disconnect the start aid cable again in reverse order.





## **After starting**



Let the paver finisher warm up for approx. 5 minutes if the engine is cold.

## **Observe indicator lamps**

The following indicator lamps must be observed under all circumstances:

For further possible faults, see Engine operating instructions.

### **Battery charge indicator (1)**

Must go out after starting.



If the lamp does not go out or lights up during operation: Briefly rev up the engine.



The engine speed can be increased by switching on a conveying function.

If the lamp remains on, turn the engine off and ascertain the fault.

For further possible malfunctions, refer to the section "Malfunctions".

### **Error message (2)**




Lights up for a few seconds once the ignition has been switched on for checking purposes.



If the lamp does not go out or lights up during operation: switch off engine immediately and determine fault.



Depending on the type of fault, the vehicle can temporarily continue to be operated or, in the case of serious faults, should be shut down immediately to prevent further damage from occurring.



## 1.2 Preparation for transportation


- Use switch (1) to close the hopper.
- Insert hopper transport safeguards.
- Lift the screed completely using switch (2), insert screed transport safeguard.
- Turn the travel drive preselector (3) to zero.
- Fully extend the levelling cylinders with the switch (4).
- Use switch (5) to adjust the screed to the basic width of the paver finisher.



Lift the auger if necessary!



If the engine is started with the drive lever(6) swivelled, the travel drive is inhibited. To start the travel drive, first the drive lever must be returned to the centre position.



## Driving and stopping the paver finisher

- Set the travel drive to the desired speed level, fast/slow (1).
  - Upper switch position: transport speed (hare)
  - Lower switch position: operating speed (tortoise)
- Turn the travel drive preselector (2) to medium speed.
- Press safety switch (3) in the running board or on the handrail.
- For driving, carefully tilt the drive lever (4) forward or backward according to the drive direction desired.
  - Adjust the speed with the preselector (2).
- Carry out steering movements by actuating the steering potentiometer (5).



In emergency situations, press the emergency stop button (6)!

- To stop, set the preselector (2) to "0" and move the drive lever (4) into its centre position.



The safety switch must always be pressed when the drive lever is moved out of the neutral position. Otherwise the travel drive is blocked.



Do not press the foot switch permanently. This also blocks the travel drive.


### 1.3 Preparations for paving

#### Separator fluid

Spray the parts coming into contact with asphalt (hopper, screed, auger, push roller) with a separator fluid.



Do not use diesel fuel as it dissolves the bitumen (prohibited in Germany!).




#### Screed heater

Switch on the screed heater approx. 15–30 minutes (depending on the ambient temperature) before paving begins. Warming up prevents the material from sticking to the screed plates.




## Direction marks

To ensure straight paving, a direction mark must be present or established (road edge, chalk lines or similar).

- Pull the direction indicator out of the bumper (arrow) and adjust it accordingly.







### **Loading/material transfer**

- Use switch (1) to open the hopper.  
Instruct the truck driver to dump the material.
- Set the switches for the auger (2) and the conveyor (3) to "auto".



The conveying function starts by deflecting the drive lever.



Check that the material is transferred properly.

Readjust the auger limit switches if conveying is not satisfactory. Adjust the conveyor limit switches with the vehicle turned off until sufficient material is conveyed in front of the screed.

### **Filling function**




The "filling function" can additionally be used to convey the material in front of the screed at the start of paving:

- Set the switches for the auger (2) and the conveyor (3) to "auto".
- Actuate switch (4):  
The engine speed is increased, the conveying functions (conveyor and auger) are switched on without deflecting the drive lever.



Once the set material height is reached at the limit switches, the conveying functions are switched off.



## 1.4 Starting for paving

Set the switches, levers and controls listed below to the specified positions when the screed has reached its operating temperature and a sufficient amount of material lies in front of the screed:

Pos.	Switch	Position
1	Drive lever	Centre position
2	Travel drive speed - fast/slow	Slow ("tortoise")
3	Travel drive preselector	Mark 6-7
4	Engine speed	Maximum
5	Screed position	Floating position
6	Vibration	Auto
7	Tamper (○)	Auto
8	Auger left/right	Auto
9	Conveyor	Auto
10	Levelling	Auto
11	Speed regulator, tamper(○)	adapted to the paving situation
12	Speed regulator, vibration	adapted to the paving situation

- Press safety switch (13) in the running board or on the handrail.
- Then push the drive lever (1) all the way to the front and start driving.
- Observe the distribution of the material and adjust the limit switches if necessary.
- Set the compacting elements (tamper and/or vibration) according to the required compaction ratio.
- Let the paving master check the paving thickness after 5–6 meters and correct if necessary.

Check the area of the caterpillar chains as uneven ground is levelled by the screed. The caterpillar chains act as reference points for the layer thickness.

The basic setting of the screed must be corrected when the actual layer thickness deviates significantly from the values indicated by the scales (see the operating instructions for the screed).



The basic setting is for asphalt material.

## 1.5 Checks during paving

The following points must be constantly observed during paving:

### **Paver function**

- Screed heater
- Tamper and vibration
- Engine oil and hydraulic oil temperature
- The screed parts must be retracted and extended in time when obstacles are in the way
- Uniform material transfer and distribution or supply to the screed; may require corrections to settings of the material switches for conveyor and auger.




See the section "Malfunctions" when paver finisher functions fail.

### **Quality of the layer**

- Paving thickness
- Slope
- Evenness in the driving direction and at right angles to it (check with 4 m levelling rod)
- Surface structure/texture behind the screed.



See section "Malfunctions, problems during paving" if the paving quality is poor.



## 1.6 Interrupting/terminating operation

**During breaks** (e.g. the material supply truck is late)

- Determine the approximate duration.
- When cooling down of the material below the minimum paving temperature must be expected, run the paver finisher empty and create an edge like the end of a layer.
- Set the drive lever (1) to the centre position.


**During longer breaks**

(e.g. lunch break)

- Set the drive lever (1) to the centre position and the speed adjuster (2) to minimum.
- Switch the screed heater system off.
- Switch off the ignition.
- When the screed is operated with the optional gas heating system (○), close the valves of the bottles.



The screed must be heated up to the correct paving temperature before paving may be restarted.





---

## When work is finished

- Run the paver finisher empty and stop it.
- Move the drive lever (1) to the central position, set preselector (2) to "0" and set the speed adjuster (3) to minimum.
- Switch the auger (4), conveyor (5), tamper(○) (6), vibration (7) and levelling (8) functions to "OFF".
- Use switch (9) to lift the screed.
- Insert the screed transport safeguard.
- Retract screed to basic width with switch (10).  
Where applicable, completely extend the levelling cylinders using switch (11).
- Use switch (12) to close the hopper lids.
- Insert the hopper transport safeguards.
- Set tampers (○) (6) to "manual"; while operating the tampers at a low speed, let any material residues drop out.
- Switch tampers (○) (6) "OFF".
- Switch off screed heater (13).
- Switch the working and warning lights (14) to "OFF".
- Read and check the operating hour meter (15) to determine whether maintenance work must be performed (see chapter F).
- Switch off the ignition (16).
- Close the main shut-off valves and the bottle valves for the screed gas heater system.
- Remove the levelling units and stow them away in the boxes, close all flaps.
- Remove all parts that extend beyond the paver finisher contour or secure them if the paver finisher is to be transported over public roads on a low-bed trailer.



Do not turn off main switch until 15 seconds after the ignition has been turned off!



The engine electronics need this length of time to back up data.

- Cover and lock the operating panel.
- Remove material residues from the screed and the paver finisher and spray all parts with separator fluid.

## 1.7 Problems during paving

Problem	Cause
Wavy surface ("short waves")	<ul style="list-style-type: none"> <li>- change in the material temperature, demixing</li> <li>- wrong material composition</li> <li>- incorrect operation of the roller</li> <li>- incorrectly prepared foundation</li> <li>- long standstill times between loads</li> <li>- grade control reference line is not suitable</li> <li>- grade control jumps to the reference line</li> <li>- grade control toggles between up and down (inertia setting is too high)</li> <li>- bottom plates of the screed are loose</li> <li>- bottom plates of the screed are warped or not uniformly worn</li> <li>- screed does not work in the floating position</li> <li>- too much play in the mechanical screed link/suspension</li> <li>- paver finisher speed is too high</li> <li>- augers are overloaded</li> <li>- changing material pressure against the screed</li> </ul>
Wavy surface ("long waves")	<ul style="list-style-type: none"> <li>- change in the material temperature</li> <li>- demixing</li> <li>- roller has stopped on the hot material</li> <li>- roller has turned or roller speed has been changed too fast</li> <li>- incorrect operation of the roller</li> <li>- incorrectly prepared foundation</li> <li>- truck brake is applied too tight</li> <li>- long standstill times between loads</li> <li>- grade control reference line is not suitable</li> <li>- incorrect installation of the grade control</li> <li>- limit switch is not correctly set</li> <li>- screed is empty</li> <li>- screed has not been switched to the floating position</li> <li>- too much play in the mechanical screed link</li> <li>- auger is set too deep</li> <li>- auger is overloaded</li> <li>- changing material pressure against the screed</li> </ul>
Cracks in the layer (over the entire width)	<ul style="list-style-type: none"> <li>- material temperature is too low</li> <li>- change in the material temperature</li> <li>- moisture on the foundation</li> <li>- demixing</li> <li>- wrong material composition</li> <li>- wrong paving thickness for maximum grain size</li> <li>- cold screed</li> <li>- bottom plates of the screed are worn or warped</li> <li>- paver finisher speed is too high</li> </ul>

Problem	Cause
Cracks in the layer (centre strip)	<ul style="list-style-type: none"> <li>- material temperature</li> <li>- cold screed</li> <li>- bottom plates are worn or warped</li> <li>- wrong crowning</li> </ul>
Cracks in the layer (outer strip)	<ul style="list-style-type: none"> <li>- material temperature</li> <li>- screed extendable parts are incorrectly installed</li> <li>- limit switch is not correctly set</li> <li>- cold screed</li> <li>- bottom plates are worn or warped</li> <li>- paver finisher speed is too high</li> </ul>
Layer composition is not uniform	<ul style="list-style-type: none"> <li>- material temperature</li> <li>- change in the material temperature</li> <li>- moisture on the foundation</li> <li>- demixing</li> <li>- wrong material composition</li> <li>- incorrectly prepared foundation</li> <li>- wrong paving thickness for maximum grain size</li> <li>- long standstill times between loads</li> <li>- vibration is too slow</li> <li>- screed extendable parts are incorrectly installed</li> <li>- cold screed</li> <li>- bottom plates are worn or warped</li> <li>- screed does not work in the floating position</li> <li>- paver finisher speed is too high</li> <li>- auger is overloaded</li> <li>- changing material pressure against the screed</li> </ul>
Marks in the surface	<ul style="list-style-type: none"> <li>- truck hits too much against the finisher while aligning to the finisher</li> <li>- too much play in the mechanical screed link/suspension</li> <li>- truck brake is applied</li> <li>- vibration is too high while standing on a spot</li> </ul>
Screed does not react to corrective measures as expected	<ul style="list-style-type: none"> <li>- material temperature</li> <li>- change in the material temperature</li> <li>- wrong paving thickness for maximum grain size</li> <li>- incorrect installation of the grade control</li> <li>- vibration is too slow</li> <li>- screed does not work in the floating position</li> <li>- too much play in the mechanical screed link</li> <li>- paver finisher speed is too high</li> </ul>

## 1.8 Malfunctions on the paver finisher or screed

Malfunction	Cause	Remedy
At the diesel engine	Various	See operating instructions for the engine
Diesel engine does not start	Batteries empty	See "External starting" (start assistance)
	Various	see "Towing"
Tamper or vibration is not functioning	Tamper is obstructed by cold bitumen	Properly heat the screed
	Hydraulic oil level in the tank is too low	Top up oil
	Pressure limiting valve is defective	Replace the valve; if necessary, repair and adjust the valve
	Leak in the suction line of the pump	Seal or replace the connections
		Tighten or replace the hose clamps
	Oil filter is soiled	Clean the filter; if necessary, replace the filter
Conveyor or augers run too slowly	Hydraulic oil level in the tank is too low	Top up oil
	Power supply is interrupted	Check fuses and cables; replace if necessary
	Switch is defective	Replace the switch
	One of the pressure limiting valves is defective	Repair or exchange the valves
	Pump shaft broken	Replace the pump
	Limit switch does not switch or regulate correctly	Check the switch; replace and adjust the switch if necessary
	Pump is defective	Check the high pressure filter for dirt particles; replace if necessary
	Oil filter is soiled	Replace the filter

Malfunction	Cause	Remedy
Hopper cannot be swung open	Engine speed is too low	Increase the speed
	Hydraulic oil level is too low	Top up oil
	Leak in the suction line	Tighten the connections
	Flow rate regulator defective	Replace
	Leaking seals of the hydraulic cylinder	Replace
	Control valve is defective	Replace
	Power supply interrupted	Check fuse and cables; replace if necessary

Malfunction	Cause	Remedy
Hoppers lowers inadvertently	Control valve is defective	Replace
	Leaking seals of the hydraulic cylinder	Replace
Screed cannot be lifted	Oil pressure too low	Increase the oil pressure
	Leaking seal	Replace
	Power supply is interrupted	Check fuse and cables; replace if necessary
Crossbeams cannot be lifted or lowered	Switch on the remote control is set to "Auto"	Set the switch to "Manual"
	Power supply is interrupted	Check fuse and cables; replace if necessary
	Switch on the operating panel defective	Replace
	Excess pressure valve defective	Replace
	Flow rate regulator defective	Replace
	Seals defective	Replace
Crossbeams lower inadvertently	Control valves defective	Replace
	Pilot-controlled non-return valves defective	Replace
	Seals defective	Replace

Malfunction	Cause	Remedy
Traction does not work	Travel drive fuse defective	Replace (fuse strip on the operating panel)
	Power supply is interrupted	Check potentiometer, cables, connectors; replace if necessary
	Travel drive monitoring (type-specific) defective	Replace
	Electro-hydraulic servo unit of the pump defective	Replace the servo unit
	Insufficient supply pressure	Check and adjust if necessary
		Check the suction filter; replace the supply pump and the filter if necessary
	Drive shaft of hydraulic pumps or engines broken	Replace pump or engine
Irregular engine speed, engine stop function does not work	Fuel level too low	Check the fuel level; refill fuel if necessary
	Fuse "engine speed control" defective	Replace (fuse strip on the operating panel)
	Electrical power defect (line break or short circuit)	Check potentiometer, cables, connectors; replace if necessary





---

## E 10.12 Set-up and modification

### 1 Special safety instructions



Danger to personnel by inadvertent starting of the engine, travel drive, conveyor, auger, screed or screed lifting devices.

Unless otherwise specified, work may only be performed when the engine is at a standstill!



- To protect the paver finisher against inadvertent starting:  
Move drive lever into centre position and turn preselector controller to zero, remove ignition key and battery main switch.
- Protect lifted vehicle parts (e.g. screed or hopper) against lowering by means of mechanical safeguards.
- Replace parts or have them replaced as stipulated.



When connecting or disconnecting hydraulic hoses and when working on the hydraulic system, hot hydraulic fluid may spurt out at high pressure.


Switch off the engine and depressurise the hydraulic system! Protect your eyes!

- Mount all protective devices before re-commissioning the paver finisher.

 <b>DANGER</b>	<b>Danger due to changes at the vehicle</b>
	<p>Structural changes to the vehicle make the operating licence null and void and can cause severe to fatal injuries!</p> <ul style="list-style-type: none"><li>- Only use original spare parts and approved accessories.</li><li>- After maintenance and repair work, ensure that any dismantled protective and safety devices are all completely fitted again.</li><li>- Comply with all further information in these instructions and in the safety manual.</li></ul>

## 2 Distribution auger

### 2.1 Height adjustment



Depending on the material, the height of the auger (1) – measured from its lower edge – should be at least 50 mm (2 inches) above the height of the material layer.


Example: Paving thickness 10 cm

Adjustment: 15 cm from the ground

An incorrect height setting can result in the following problems during paving:

- Auger too high:  
Too much material in front of the screed; material overflow. When operating with larger working widths, demixing and traction problems may occur.
- Auger too low:  
Not enough material that can be precompacted by the auger. Irregularities resulting from this cannot be completely compensated by the screed (wavy surface).  
In addition, increased auger segment wear occurs.
- Loosen the 4 mounting screws (2).
- Set the ratchet direction lever (3) to the clockwise or anti-clockwise direction.
- Adjust the required height by actuating the ratchet (4).
- The current height can be read at the scale (5).
- Retighten the mounting screws (2) properly.

## 2.2 Auger width extension and material shaft with protective cover (Optional equipment)



To fit auger extensions, an additional auger segment (1) is fitted to the auger shaft.

Assembly:

- Remove outermost screw connection (2) from the basic auger.
- Remove plug (3).
- Fit the auger extension (1) to the corresponding side.
- Fit screw connection (2).
- Fit plugs (3) to the auger extension.

The relevant material shaft must be fitted to each auger extension.

Material shaft, protective cover


Suspend the material shaft (4) in the provided bracket on the basic unit and secure with the rod (5).

- Remove original shaft (4)
- Fit extension shaft (6)
- Secure original shaft (4) to extension shaft (6).




Switch off engine and secure the device before carrying out any work on equipment.


### 3 Cut-off shoe installation instructions

 The cut-off shoe enables smaller paving widths.

- The cut-off shoe (1) used to reduce the paving width first has to be equipped with the compensation part (2) corresponding to the height of the layer.




- These compensation parts (2) are inserted into the cut-off shoe mounting. The compensation parts' bolts are inserted into the bores on the mounting.



- Position the cut-off shoe laterally on the paver finisher and press the side plates together. Move the screed in and lower it.
- Slide the cut-off shoe in between the tamper deflector plate and the rear wall of the paver finisher.




The cut-off shoe's spring tension prevents the ingress of material between the cut-off shoe and the screed/vehicle.




- Then move the side shield in.



Ensure that nobody is located in the danger area!



- Align the side shield with the securing bore using the crank and the hydraulic system.
- Secure the cut-off shoe to the side shield using the bolt, washer and nut (3, 4, 5).




- Raise the screed and carry out a visual inspection.



Make sure that the cut-off shoe lies on the bottom plate.

Ensure that nobody is located in the danger area!





## Push roller crossbar, adjustable

For adaptation to various truck design types, the push roller crossbar (1) can be shifted to two positions.




The adjustment travel is 100 mm.

- Possibly close the hopper halves to raise the hopper flap (○) .
- Remove hopper rubber (2).
- Dismantle retaining pin (3) using a suitable bolt extractor.
- Bring the push roller crossbar into the front / rear position.



Shift the push roller crossbar at the towing eye (4) or use a suitable assembly lever in its guide (left and right) to push it into the corresponding position.

- Put the retaining pin (3) correctly back into the intended position.



#### 4 Connecting the automatic levelling system

The paver finisher has two control circuits for levelling.

One for the right side of the paver finisher and one for the left side.




The automatic levelling system can be suspended in the opened vandalism protection facility on the remote control.

Connect the coiled cable of the automatic levelling system with the sockets on the remote controls:

- for the right side of the paver finisher (1)
- for the left side of the paver finisher (2)

Always make sure that you connect the cables up correctly!



## Connecting the slope controller / height controller

The slope controller (3) and height controller (4) are connected to either the left or right automatic levelling system. Connect the coiled cables of the controllers with the corresponding sockets (5) of the automatic levelling system.


- Slope controller to left automatic levelling system - socket (5)
- Slope controller to right automatic levelling system - socket (6)
- Connect the height controller (4) to the automatic levelling system on the corresponding side of the vehicle.




If the connections are confused, the automatic levelling system works in reverse.



Route the supply lines so as to rule out any risk of stumbling or damage to the lines.




## 5 Working with the remote control (○)



 Heed the following points when operating the paver finisher from the remote control:

- Swivel the remote control into the required position and secure with retaining brackets (1) and (2).

 To operate with remote control (○), the driver's platform handrail can be removed so that the remote control can be swivelled to the required side of the vehicle.

- Set switch (3) to the "Remote control" position (to the right).
- Fasten the safety cut-out belt (4) to the operator.



If the safety switch is pulled, the travel drive shuts down immediately.



For safety reasons, it is prohibited to work with the remote control without fastening the safety cut-out belt to the driver!



The travel drive is blocked after a safety shutdown. To release it again, the drive lever (6) has to be put in neutral position first.

- Set the speed to working gear (5).



The travel drive is blocked automatically in travel gear.

### **Changing over to normal control**

- Swivel the arm of the remote control into the "Park position" and secure with retaining brackets (1) and (2).
- Set switch (3) to the "0" position (down).

## 6 Limit switch

### 6.1 Auger limit switches Mount (left and right)

The auger's ultrasonic limit switch is mounted on both sides on the side board's handrail.

- Position the sensor bracket (1) on the bracket at the side board of the screen, align, and tighten with lock nut (2).
- Align the sensor (3) and secure with a clamping lever (4).
- Possibly adjust height of bracket (5). Loosen lock nut (6) to this end.
- Connect the left or right sensor's connection cable to the intended remote control bracket sockets.



The connection cables are connected to the relevant sockets on the remote control bracket.

- Adjust the deactivation point with the desired material height by regulating the potentiometer (7).




The sensors should be adjusted so that 2/3 of the augers are covered with the paving material.



The paving material must be conveyed over the full working width.







We recommend adjusting the limit switch positions during material distribution.







# F 10 Maintenance

## 1 Notes regarding safety

 <b>DANGER</b>	<b>Danger due to changes at the vehicle</b>
	<p>Structural changes to the vehicle make the operating licence null and void and can cause severe to fatal injuries!</p> <ul style="list-style-type: none"> <li>- Only use original spare parts and approved accessories.</li> <li>- After maintenance and repair work, ensure that any dismantled protective and safety devices are all completely fitted again.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>

 <b>DANGER</b>	<b>Danger due to incorrect vehicle maintenance</b>
	<p>Incorrectly performed maintenance and repair work can cause severe or fatal injuries!</p> <ul style="list-style-type: none"> <li>- Ensure that maintenance and repair work is always only carried out by trained, specialist staff.</li> <li>- All maintenance, repair and cleaning work should only be carried out with the engine turned off. Remove ignition key and main switch.</li> <li>- Affix a sign "Do not start" to the vehicle.</li> <li>- Perform a visual inspection and check all functions every day.</li> <li>- Proceed with all maintenance tasks according to the maintenance schedule.</li> <li>- Proceed with expert inspection every twelve months.</li> <li>- Eliminate all ascertained faults straight away.</li> <li>- Do not restart the vehicle until all ascertained faults have been eliminated.</li> <li>- Failure to comply with the prescribed inspection and maintenance work renders the operating licence null and void!</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>

 <b>CAUTION</b>	<b>Hot surfaces!</b>
	<p>Surfaces including those behind covering parts, together with combustion fuels from the engine or screed heater can be very hot and cause injuries!</p> <ul style="list-style-type: none"> <li>- Wear your personal safety gear.</li> <li>- Do not touch hot parts of the vehicle.</li> <li>- Only perform maintenance and repair work after the vehicle has cooled down.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>

 <b>CAUTION</b>	<b>Danger due to electric shock</b>
	<p>Injuries can be caused by touching live parts directly or indirectly!</p> <ul style="list-style-type: none"> <li>- Do not remove any protective safeguards.</li> <li>- Never spray water on electric or electronic components.</li> <li>- Maintenance work to the electric system should only be carried out by trained specialist staff.</li> <li>- When equipped with electric screed heater, check the insulation monitoring every day according to the instructions.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>



**Cleaning:** Do not use any inflammable substances (such as petrol). Avoid directly cleaning electrical parts and insulation material with a steam jet; cover them up beforehand.



**Working in enclosed environments:** Exhaust fumes must be conducted into the open air. Propane gas bottles must not be stored in closed rooms.



In addition to these maintenance instructions, the maintenance instructions issued by the engine manufacturer must be adhered to under all circumstances. All maintenance work and service intervals itemised here are binding in nature.




Information on how to maintain the optional equipment can be found in the individual sub-sections of this chapter!



# F 2.12 Maintenance review

## 1 Maintenance review



Assembly	Chapter	Maintenance required after the following service hours									
		10	50	100	250	500	1000 / annually	2000 / every 2 years	5000	20000	If necessary
Conveyor	F3.12	■									■
Auger	F4.12			■			■				■
Engine	F5.12	■			■	■	■	■			■
Hydraulic system	F6.12	■	■	■		■	■	■			■
Drive units	F7.12	■	■	■	■	■	■				■
Electrical system	F8.12	■	■	■	■		■				■
Checking/stopping	F100.02	■					■				■


Maintenance required	■
----------------------	---







In this overview, you will find the maintenance intervals for optional machine equipment!



## F 3.12 Maintenance - conveyor

### 1 Maintenance - conveyor



 <b>WARNING</b>	<b>Danger of being pulled in by rotating or conveying vehicle parts</b>
	<p>Rotating or conveying vehicle parts can cause severe or fatal injuries!</p> <ul style="list-style-type: none"> <li>- Do not enter the danger zone.</li> <li>- Do not reach into rotating or conveying parts.</li> <li>- Only wear close-fitting clothing.</li> <li>- Comply with the warning and information signs on the vehicle.</li> <li>- Stop the engine and remove the ignition key before any maintenance work.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>

 <b>WARNING</b>	<b>Danger from heavy loads</b>
	<p>The raised machine can slide away and cause severe to fatal injuries!</p> <ul style="list-style-type: none"> <li>- The vehicle may only be raised at the marked lifting points.</li> <li>- Heed the operating weight of the vehicle.</li> <li>- Do not enter the danger zone.</li> <li>- Only use approved ramps and adequately dimensioned ramps or pits.</li> <li>- Use only lifting gear that can bear the load.</li> <li>- Do not leave any load or loose parts on the vehicle.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>

 <b>CAUTION</b>	<b>Hot surfaces!</b>
	<p>Surfaces including those behind covering parts, together with combustion fuels from the engine or screed heater can be very hot and cause injuries!</p> <ul style="list-style-type: none"> <li>- Wear your personal safety gear.</li> <li>- Do not touch hot parts of the vehicle.</li> <li>- Only perform maintenance and repair work after the vehicle has cooled down.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>

## 1.1 Maintenance intervals

Pos.	Interval							Maintenance point	Note
	10	50	100	250	500	1000 / annually	2000 / every 2 years		
1	■							- Conveyor chain - Check tightness	
								■ - Conveyor chain - Adjust tension	
								■ - Conveyor chain - Replace chain	
2								■ - Replace conveyor / conveyor drive - wear parts	

Maintenance	■
Maintenance during the running-in period	▼

## 1.2 Points of maintenance

### Chain tension, conveyor (1)

#### Check chain tension:



To check and adjust the chain tension, the paver finisher must be located over a pit, on ramps or on a platform.




When the conveyor chain is tensioned correctly, there is a sag of approx. 65 mm between the upper edge of the chain and the side member (A).



The conveyor chains should not be too tight or too slack. An excessively taut chain can cause the chain to be stopped or to break when material falls into the space between the chain and the sprocket.

An excessively slack chain may catch on protruding objects and be destroyed.




#### Adjustment of chain tension:



The adjusting screws (B) are located at the front of the vehicle on the cross-beam.

- Dismantle the locking plates (C) of the adjusting screws.
- Adjust the chain tension using the adjusting screw (B).
  - Increase chain tension: turn clockwise
  - Reduce chain tension: turn counterclockwise.



Adjust the chain tension evenly at both adjusting screws.

- Remount the locking plates (C) again properly.

### Check / replace chain:



The conveyor chain must be replaced at the latest when:

- the conveyor webs (A) are worn or
- the chain has lengthened to such an extent that it can no longer be retightened.



Chain links must not be removed to shorten the chain!  
Incorrectly dividing the chains would lead to the destruction of the drive wheels!



Your Dynapac customer service will be happy to provide support during maintenance, repair and the replacement of wearing parts!



## Replace conveyor / conveyor drive - wear parts (2)



Check the following wear parts in the material tunnel and replace if necessary:



- Drive chain cover (A)
- Bottom plate (B):
- Wear plates (C):



These must be replaced if the system is no longer sealed or there are holes in the parts.



The conveyor chain is not offered protection by worn cover!




Check the following wear parts in the conveyor drive section and replace if necessary:

- Conveyor chain reversing roller
- Conveyor drive chain sprocket




Your Dynapac customer service will be happy to provide support during maintenance, repair and the replacement of wearing parts!









## F 4.12 Maintenance - auger assembly

### 1 Maintenance - auger assembly



 <b>WARNING</b>	<b>Danger of being pulled in by rotating or conveying vehicle parts</b>
	<p>Rotating or conveying vehicle parts can cause severe or fatal injuries!</p> <ul style="list-style-type: none"> <li>- Do not enter the danger zone.</li> <li>- Do not reach into rotating or conveying parts.</li> <li>- Only wear close-fitting clothing.</li> <li>- Comply with the warning and information signs on the vehicle.</li> <li>- Stop the engine and remove the ignition key before any maintenance work.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>

 <b>CAUTION</b>	<b>Hot surfaces!</b>
	<p>Surfaces including those behind covering parts, together with combustion fuels from the engine or screed heater can be very hot and cause injuries!</p> <ul style="list-style-type: none"> <li>- Wear your personal safety gear.</li> <li>- Do not touch hot parts of the vehicle.</li> <li>- Only perform maintenance and repair work after the vehicle has cooled down.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>

## 1.1 Maintenance intervals

Pos.	Interval								Maintenance point	Note
	10	50	100	250	500	1000 / annually	2000 / every 2 years	5000		
1			■						- Auger drive chains - Check tension	
								■	- Auger drive chains - Adjust tension	
								■	- Auger drive chains - Chains and chain sprockets Replace	
2						■			- Auger box - Check grease fill	
								■	- Auger box - Top up grease	
								■	- Auger box - Change grease	
3						■			- Seals and sealing rings - Check wear	
								■	- Seals and sealing rings - Replace seals	
4			■						- Auger segments - Check wear	
								■	- Auger segments - Replace auger segments	

Maintenance	■
Maintenance during the running-in period	▼

## 1.2 Maintenance points

### Drive chains of the augers (1)

To check the chain tension:


- Manually turn both augers to the right and left. In this case, movement clearance (C) at the augers' outer circumference should be 3-4 mm.



Risk of injury due to sharp-edged parts!

To **re-tension** the chains

- Release the mounting screws (A).
- Set the chain tension correctly using the threaded pins (B):
- Retighten the bolts (A).



### Check / replace chain:



The drive chains (A) must be replaced at the latest when:


- The sprockets (B) on the auger shaft or drive are worn.
- The chains (A) have lengthened to such an extent that they can no longer be retightened.



Chains and chain sprockets must always be replaced in sets.



Your Dynapac customer service will be happy to provide support during maintenance, repair and the replacement of wearing parts!



## Auger box (2)

### Check grease fill

To **check** the grease fill:

- Remove side cover (A)



No reduction in the quality and quantity of the grease fill is normally expected. However, the grease fill must always be replaced if there is a considerable change in colour or any lumps have formed.



When grease is present in the correct quantity and quality, a film of grease adheres to the full length of both chains (B).

- Top up with grease if necessary.
- Reinstall cover (A).

### Change grease




The grease should be changed regularly when proceeding with wear-related change of the chains and chain sprockets.

- After dismantling the worn parts, clean the auger box on the inside.
- Once all parts have been mounted, fill with new grease, then fit cover (A).



Your Dynapac customer service will be happy to provide support during maintenance, repair and the replacement of wearing parts!




### Seals and sealing rings (3)



After reaching operating temperature, check the gearbox for leaks.



In case of visible leaks, e.g. between the flange surfaces (A) of the drive, auger shaft (B) or at the side cover (C), replacement of the seals and sealing rings is necessary.



### Auger segments (4)




If the surface of the auger segment (A) becomes sharp-edged, the diameter of the auger is reduced and the auger shafts (B) have to be replaced.



Risk of injury due to sharp-edged parts!




Your Dynapac customer service will be happy to provide support during maintenance, repair and the replacement of wearing parts









# F 5.12 Maintenance - engine assembly

## 1 Maintenance - engine assembly



In addition to these maintenance instructions, the maintenance instructions issued by the engine manufacturer must be adhered to under all circumstances. All maintenance work and service intervals itemised here are binding in nature.

 <b>WARNING</b>	<b>Danger of being pulled in by rotating or conveying vehicle parts</b>
	<p>Rotating or conveying vehicle parts can cause severe or fatal injuries!</p> <ul style="list-style-type: none"> <li>- Do not enter the danger zone.</li> <li>- Do not reach into rotating or conveying parts.</li> <li>- Only wear close-fitting clothing.</li> <li>- Comply with the warning and information signs on the vehicle.</li> <li>- Stop the engine and remove the ignition key before any maintenance work.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>

 <b>CAUTION</b>	<b>Hot surfaces!</b>
	<p>Surfaces including those behind covering parts, together with combustion fuels from the engine or screed heater can be very hot and cause injuries!</p> <ul style="list-style-type: none"> <li>- Wear your personal safety gear.</li> <li>- Do not touch hot parts of the vehicle.</li> <li>- Only perform maintenance and repair work after the vehicle has cooled down.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>

## 1.1 Maintenance intervals

Pos.	Interval								Maintenance point	Note
	10	50	100	250	500 / annually	1000 / annually	2000 / every 2 years	If necessary		
1	■								- Fuel tank Check filling level	
								■	- Fuel tank Refill with fuel	
							■		- Fuel tank Clean the tank and system	
2	■								- Engine lube oil system Check oil level	
								■	- Engine lube oil system Top up oil	
					■				- Engine lube oil system Change oil	
					■				- Engine lube oil system Change oil filter	
3	■								- Engine fuel system Fuel filter (drain the water separator)	
					■				- Engine fuel system Replace fuel pre-filter	
					■				- Engine fuel system Replace fuel filter	
								■	- Engine fuel system Bleed fuel system	

Maintenance	■
Maintenance during the running-in period	▼

Pos.	Interval								Maintenance point	Note
	10	50	100	250	500 / annually	1000 / annually	2000 / every 2 years	If necessary		
4	■								- Engine air filter Check air filter	
	■								- Engine air filter Dust collector Emptying	
						■		■	- Engine air filter Air filter cartridge Replace	
5	■								- Engine cooling system Check radiator fins	
				■				■	- Engine cooling system Clean radiator fins	
				■					- Engine cooling system Check level of the coolant	
								■	- Engine cooling system Top up coolant	
					■				- Engine cooling system Check coolant concentration	
								■	- Engine cooling system Coolant concentration Adjust	
							■		- Engine cooling system Change coolant	

Maintenance	■
Maintenance during the running-in period	▼

Pos.	Interval							Maintenance point	Note
	10	50	100	250	500 / annually	1000 / annually	2000 / every 2 years		
6					■			- Engine drive belt Check drive belt	
							■	- Engine drive belt Tighten drive belt	
					■		■	- Engine drive belt Replace drive belt	

Maintenance	■
Maintenance during the running-in period	▼

## 1.2 Maintenance points

### Engine fuel tank (1)

- Check the **filling level** on the gauge on the operating panel.




Fill the fuel tank each time before starting work so that the fuel system cannot "run dry" and time-consuming venting (bleeding) can therefore be avoided.

For **filling in** the fuel:

- Open lateral flap.
- Remove cap (A).
- Fill in fuel through the filling port until the required fill level is achieved.
- Replace the cap (A).


**Clean the tank and system:**


- Unscrew the drain plugs (B) of the tank and drain about 1 l fuel into a collection pan.
- When returning the screw, make sure to use a new seal.




## Engine lube oil system (2)

### Check oil level

 In case of correct oil level, the oil is between the two notches of the sensor rod(A).



 Only check the oil level when the finisher is in a horizontal position!

 The sensor rod is located at the front end of the engine.

 Too much oil in engine damages gas-kets; too little oil results in overheating and engine destruction.

For **filling in** the oil:

- Remove cap (B).
- Fill up oil to correct level.
- Return cap (B).
- Use sensor rod to check level again.




## Oil change:



Change the oil when the engine is at operating temperature

- Place the end of the oil drain port hose (C) in the collection container.
- Remove the screw cap with a wrench and allow the oil to drain completely.
- Replace the screw cap and tighten properly.
- Fill in the specified quality of oil through the filler opening (B) on the engine until the oil level rises to the correct mark on the sensor rod (A).



## Changing the oil filter:




The new filter is inserted during an oil change once the used oil has been drained out.



The oil filter is located at the front end of the engine.

- Loosen the filter (D) using a filter wrench or filter strap and unscrew. Clean the contact surface.
- Apply light coating of oil to the gasket on the new filter and fill filter with oil before installing it.
- Tighten filter by hand.



After installing the oil filter, attention must be paid to the oil pressure display and good sealing during the test run. Check oil level again.




## Engine fuel system (3)




 The fuel filter system consists of two filters:

- Prefilter (A) with water separator
- Main filter (B)

### Prefilter - draining of water

 Drain the collecting vessel at regular intervals, or in response to an error message from the engine control unit.


- Put a suitable drip pan underneath.
- Disconnect the electrical connection/cable connection.
- Loosen drain plug (C).
- Drain off liquid until pure diesel fuel emerges.
- Tighten the drain plug (C) again.
- Restore the electrical connection/cable connection.




### **Changing the prefilter:**

- Put a suitable drip pan underneath.
- Disconnect the electrical connection/cable connection.
- Loosen drain plug (C) and drain off liquid.
- Untighten the filter cartridge (A) using a pair of oil filter tongs or oil filter strap and unscrew it.
- Clean any dirt from the sealing face of the new filter cartridge and the opposite side of the filter head.
- Lightly coat the oil filter cartridge seal with fuel and screw hand-tight under the bracket (17-18 Nm).
- Restore the electrical connection/cable connection.
- Tighten the drain plug (C).
- Bleed the fuel system

### **Bleed the fuel system:**


 The fuel system is bled using the electric fuel feed pump. Do not attempt to start the vehicle while the fuel system is being bled to ensure that no error message is generated.

- Ignition "ON"

 The electronic fuel feed pump switches on for 20 seconds to bleed the fuel system and build up the necessary fuel pressure.

 Wait until the electric fuel feed pump is switched off by the control unit.

- Ignition "OFF"

 Repeat at least twice until the fuel system is bled.

### **Replacing the main filter:**


- Untighten the filter cartridge (B) using a pair of oil filter tongs or oil filter strap and unscrew it.
- Clean any dirt from the sealing face of the new filter cartridge and the opposite side of the filter head.
- Lightly coat the oil filter cartridge seal with fuel and screw hand-tight under the bracket (17-18 Nm).

 After fitting the filter, ensure good sealing action during the test run.

## Engine air filter (4)

### Emptying the dust collector

- Empty the dust removal valve (B) on the air cleaner housing (A) by pressing the discharge port in the direction of the arrow.
- Remove any baked on dust by pressing together the upper valve section.




- ☞ Clean the discharge port from time to time.

### Cleaning / replacing the air filter cartridge

- ☞ Pollution of the combustion air filter depends on the dust content of the air and the mesh size of the filter selected.

- ☞ Filter maintenance becomes necessary if:

- Maintenance interval or
- Engine electronics service indicator
- Open the air filter lid.
- Pull out the filter cartridge (D) and the safety cartridge (E).



- ☞ Clean the filter cartridge (D) and replace after one year at the latest.

- Blow out with dry pressure air (max. 5 bar) from inside out or tap it (in case of emergency only).

- ☞ Do not damage cartridge when doing so.

- Check the soundness of the filter papers of the filter cartridge (by exposing to light) and the soundness of the seals. Replace them as required.

- ☞ Replace the safety cartridge (E) together with the filter cartridge (D)

## Engine cooling system (5)

### Checking / topping up coolant

The cooling water level must be checked when the system is cold. Make sure that the anti-freeze and anti-corrosive liquid is sufficient (-25°C).



When hot, the system is under pressure. When it is opened, there is danger of scalding!



The filler neck is accessed via the service flap (A) on top of the vehicle:



If necessary fill in a sufficient amount of coolant through the open port (B) of the compensating tank.

### Change coolant



When hot, the system is under pressure. When it is opened, there is danger of scalding!



Use only approved coolants!




Observe the instructions in the chapter entitled "Operating substances"!

- Remove the drain screw (B) on the radiator and let the coolant drain completely.
- Reinstall the drain screw (B) and tighten properly.
- Fill in coolant through the filling opening (A) on the compensation tank until the coolant level rises to the centre of the sight glass (C).



The air is only able to escape completely from the cooling system once the engine has reached its operating temperature (at least 90°C). Check the fluid level again, top up if necessary.



### **Checking and cleaning the radiator fins**

- If necessary, remove leaves, dust or sand from the radiator.



Observe engine's operating instructions

### **Check coolant concentration**

- Check the concentration using a suitable tester (hydrometer).
- Adjust the concentration if necessary.



Observe engine's operating instructions!

## Engine drive belt (6)

### Check drive belt

- Check the drive belt for damage.



Small transverse cracks in the belt are acceptable.



In the event of longitudinal cracks which intersect with transverse cracks and damaged material surfaces, belt replacement is necessary.




Observe engine's operating instructions!

### Replace drive belt






Observe engine's operating instructions!





## F 6.12 Maintenance - hydraulic system

### 1 Maintenance - hydraulic system



 <b>WARNING</b>	<b>Danger from hydraulic oil</b>
	<p>Hydraulic oil under high pressure can cause severe to fatal injuries!</p> <ul style="list-style-type: none"> <li>- Only competent staff should work on the hydraulic system!</li> <li>- Any hydraulic hoses that are cracked or soaked through must be replaced immediately.</li> <li>- Depressurise the hydraulic system.</li> <li>- Lower screed and open hopper.</li> <li>- Stop the engine and remove the ignition key before any maintenance work.</li> <li>- Secure the vehicle to prevent it being switched on again.</li> <li>- Consult a doctor immediately if injured.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>

 <b>CAUTION</b>	<b>Hot surfaces!</b>
	<p>Surfaces including those behind covering parts, together with combustion fuels from the engine or screed heater can be very hot and cause injuries!</p> <ul style="list-style-type: none"> <li>- Wear your personal safety gear.</li> <li>- Do not touch hot parts of the vehicle.</li> <li>- Only perform maintenance and repair work after the vehicle has cooled down.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>



## 1.1 Maintenance intervals

Pos.	Interval								Maintenance point	Note
	10	50	100	250	500	1000 / annually	2000 / every 2 years	If necessary		
1	■								- Hydraulic oil tank - Check filling level	
								■	- Hydraulic oil tank - Top up oil	
							■		- Hydraulic oil tank - Change oil and clean	
						■			- Hydraulic oil tank - Ventilation filter (sensor rod) Replace	
2	■								- Hydraulic oil tank - Check maintenance indicator	
						■		■	- Hydraulic oil tank - Intake / return hydraulic filter; change, vent	
3		▼			▼	■		■	- High-pressure filter - Replace filter element	

Maintenance	■
Maintenance during the running-in period	▼

Pos.	Interval							Points of maintenance	Note
	10	50	100	250	500	1000 / annually	2000 / every 2 years		
4	■							- Pump distribution gear - Check oil level	
								■ - Pump distribution gear - Top up oil	
			▼			■		- Pump distribution gear - Change oil	
	■							- Pump distribution gear - Check bleeder	
								■ - Pump distribution gear - Clean bleeder	
5	▼ ■							- Hydraulic hoses - Visual inspection	
	▼ ■							- Hydraulic system Leak test	
								■ - Hydraulic system Retighten screw connections	
							■	■ - Hydraulic hoses - Replace hoses	
6					■			■ - Auxiliary flow filter- Replace filter element	(○)

Maintenance	■
Maintenance during the running-in period	▼

## 1.2 Points of maintenance

### Hydraulic oil tank (1)

- **Oil level** check on sensor rod (A).



The paver finisher must be positioned horizontally with all hydraulic cylinders retracted.



If all the cylinders are extended, the level can fall below the sensor rod marking.



The sensor rod (A) should be coated with oil up to the upper marking.

For **filling in** the oil:

- Fill oil in at the filler neck (B) until the oil level on the sensor rod reaches the upper marking.
- Screw in the sensor rod (B) again.



Use only the recommended hydraulic oils - see section "Recommended hydraulic oils".



When filling for the first time, all hydraulic cylinders should be extended/retracted at least 2x for ventilation!

To **change** oil:




- To drain the hydraulic oil unscrew the drain plug (D) at the bottom of the tank.
- Collect the oil in a container using a funnel.
- When returning the screw, make sure to use a new seal.
- Fill in the specified quality of oil through the filler opening (B) on the engine until the oil level rises to the correct mark on the sensor rod (A).



The oil should be changed when at operating temperature.



When changing the hydraulic oil also change the filter.




## Ventilation filter



The ventilation filter is integrated in the sensor rod.  
The sensor rod must be replaced according to the maintenance interval.

## Suction/return flow hydraulic filter (2)

Replace the filter element when the **service indicator** (A) turns red at a hydraulic oil temperature of more than 80° or the interval has been reached.



- Place an oil collecting vessel under the filter housing (B), unscrew the drain plug (C) and let the oil drain out.
- Tighten the drain plug (C) properly again.
- Loosen the filter housing (B) at hex (D).
- Unscrew the filter housing (B) and push approx. 10 cm down.
- Loosen the filter cartridge (E) from the filter head and take out of the engine compartment together with the filter housing.




To avoid impurities, do not let the filter cartridge fall back into the housing again!

- Remove the filter cartridge (E).
- Empty and clean the filter housing (B), clean the sealing faces in the filter head.
- Replace the O-ring (F) on the filter housing.
- Insert new filter cartridge and fill filter housing with oil up to the top edge.
- Coat sealing face (G) and O-ring (F) with oil.



Only use hydraulic oils of the prescribed specification!

- Screw the filter housing (B) hand tight into the filter head, then tighten gently with a wrench.
- Start trial operation and check the tightness of the filter.



### High-pressure filter (3)

The filter (B) is in the engine compartment on the left of the vehicle.



During the run-in time, the filter element can be cleaned with cleaning solvent, later it will have to be changed.

- Loosen the fittings (C) and remove the filter housing (B).
- Fix the filter in a vice.
- Loosen and unscrew the screw-in neck (D) with a screw wrench.




Put a vessel underneath to collect the draining oil.

- Remove the screw-in neck with strainer element (D).
- Shake any remaining oil out of the housing (E) into a vessel for used oil, then clean the filter housing with cleaning solvent.
- Check that the O-ring (F) at the screw-in neck is in perfect condition, replace if necessary.
- Push the screw-in neck with strainer element (D) carefully into the housing (E) and screw in as far as it will go. Tighten with a screw wrench (torque 120 +/- 5 Nm)
- Start trial operation and check the tightness of the filter.



Replace the seal ring whenever the filter cartridge is replaced.




## Pump distribution gear (4)

- Check **oil level** on the viewing glass (A) (at the side of the distribution box).



The oil level must be up to the centre of the viewing glass.



For **filling in** the oil:

- Unscrew the filler screw (B).
- Fill in oil through the filling port until the required filling level is achieved on the viewing glass (A).
- Screw in the filler screw (B) again.




Make sure to clean the screw and the vicinity of the drain bore!

## Oil change:

- Place the end of the oil drain port hose (C) in the collection container.
- Remove the screw cap with a wrench and allow the oil to drain completely.
- Replace the screw cap and tighten properly.
- Fill in the oil of specified quality through the filling port on the gearbox (B) until the oil level rises to the centre of the viewing glass (A).




The oil should be changed when at operating temperature.



## Bleeder

- The functioning of the bleeder (A) must be ensured.  
If soiling has occurred, the bleeder should be cleaned.






## Hydraulic hoses (5)

- Specifically check the condition of the hydraulic hoses.
- Immediately replace any damaged hoses.



Replace hydraulic hoses if the following criteria are found on inspection:



- damage of the outer layer to the inlay (e.g. chafing, cuts, cracks).
- brittleness of the outer layer (cracking of the hose material).
- deformation that does not correspond to the natural shape of the hose or pipe when depressurised or under pressure or when bent (e.g. separated layers, blistering, pinched or buckled points).
- leaks.
- damage or deformation to the hose fittings (affecting the sealing function); replacements are not necessary for minor damage to the surface.
- hose coming away from the fitting.
- corrosion of the fitting with a detrimental effect on function and strength.
- failure to comply with the installation requirements.
- period of use has exceeded 6 years. Here it is the date of manufacture of the hydraulic hose stated on the fitting that counts, plus 6 years. If the fitting states "2013" as the date of manufacture, the period of use ends in February 2019.



See the section on "Marking hydraulic hoses".



Ageing hoses become porous and may burst! Danger of accident!



Always comply with the following instructions when installing and removing hydraulic hoses:

- Always only use original Dynapac hydraulic hoses!
- Always observe high standards of cleanliness!
- Hydraulic hoses must always be fitted to ensure that in all operating statuses,
  - there is no tensile load apart from dead weight.
  - there is no compressive load for short lengths.
  - any external mechanical impact on the hydraulic hoses is avoided.
  - appropriate positioning and fastening of the hoses prevents them from chafing on components or on each other.  
components with sharp edges must be covered when installing hydraulic hoses.
  - bending radii are not smaller than the permitted values.
- When hydraulic hoses are connected to moving parts, the length of the hose must be dimensioned to ensure that the bending radii are not smaller than the permitted smallest values right across the full range of movement and/or that the hydraulic hose is not also exposed to tension.
- Fasten the hydraulic hoses to the provided fastening points. the hoses must not be hindered in their natural movement and change in length.
- Painting the hydraulic hoses is forbidden!

## Marking hydraulic hoses / storage 'period, period of use




A number stamped onto the screwed connection provides information about the date of manufacture (A) (month / year) and the maximum pressure permitted for this hose (B).



Never install hoses on top of one another and always ensure that they are at the correct pressure.

In individual cases, the period of use can be stipulated according to experience and may differ from the following general indications:

- When producing the hose pipe, the hose (purchased by the meter) should not be more than four years old.
- The period of use of a hose pipe should not exceed six years, including any possible storage period.  
The storage period should not exceed two years.



## Auxiliary flow filter (6)



The hydraulic oil change is omitted on use of an auxiliary flow filter!

The quality of the oil must be checked regularly.

The oil level must be topped up if necessary!




### Replace filter element:

- Release the threaded cover connection (A) then open the non-return valve briefly to lower the oil level in the filter, then close the non-return valve again.
- Replace filter element (B) and sealing ring (C):
  - Turn filter element clockwise with the help of carrier straps and, at the same time, raise it slightly.
  - Wait for a moment until the oil has escaped downwards, then remove the filter element.
- Check inlet and outlet in filter housing (D).
- As required, top up hydraulic oil level in filter housing then screw down the cover.
- Bleed the hydraulic system.






Do not remove the cardboard sleeve from the filter element! This is part of the filter!







## F 7.12 Maintenance - drive unit

### 1 Maintenance - drive unit



 <b>WARNING</b>	<b>Danger of being pulled in by rotating or conveying vehicle parts</b>
	<p>Rotating or conveying vehicle parts can cause severe or fatal injuries!</p> <ul style="list-style-type: none"> <li>- Do not enter the danger zone.</li> <li>- Do not reach into rotating or conveying parts.</li> <li>- Only wear close-fitting clothing.</li> <li>- Comply with the warning and information signs on the vehicle.</li> <li>- Stop the engine and remove the ignition key before any maintenance work.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>

 <b>WARNING</b>	<b>Danger from heavy loads</b>
	<p>The raised machine can slide away and cause severe to fatal injuries!</p> <ul style="list-style-type: none"> <li>- The vehicle may only be raised at the marked lifting points.</li> <li>- Heed the operating weight of the vehicle.</li> <li>- Do not enter the danger zone.</li> <li>- Only use approved ramps and adequately dimensioned ramps or pits.</li> <li>- Use only lifting gear that can bear the load.</li> <li>- Do not leave any load or loose parts on the vehicle.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>

 <b>CAUTION</b>	<b>Hot surfaces!</b>
	<p>Surfaces including those behind covering parts, together with combustion fuels from the engine or screed heater can be very hot and cause injuries!</p> <ul style="list-style-type: none"> <li>- Wear your personal safety gear.</li> <li>- Do not touch hot parts of the vehicle.</li> <li>- Only perform maintenance and repair work after the vehicle has cooled down.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>

## 1.1 Maintenance intervals



Item	Interval								Maintenance point	Note
	10	50	100	250	500	1000 / annually	2000 / every 2 years	If necessary		
1	■								- Chain tension - Check	
								■	- Chain tension - Adjust	
								■	- Chains - Relieve	
2				■					- Bottom plates - Check wear	
								■	- Bottom plates - Replace	
3	■								- Rollers - Check for leaks	
				■					- Rollers - Check wear	
								■	- Rollers - Replace	

Maintenance	■
Maintenance during the running-in period	▼

No.	Interval							Maintenance point	Note
	10	50	100	250	500	1000 / annually	2000 / every 2 years		
4		■						- Planetary gear - Check oil level	
							■	- Planetary gear - Top up oil	
			▼		■			- Planetary gear - Change oil	
					■			- Planetary gear - Check oil quality	

Maintenance	■
Maintenance during the running-in period	▼



 <b>WARNING</b>	<b>Danger from pretensioned springs</b>
	<p>Incorrectly performed maintenance and repair work can cause severe or fatal injuries!</p> <ul style="list-style-type: none"> <li>- Always observe the maintenance instructions.</li> <li>- Do not perform any unauthorised maintenance or repair work to pretensioned springs.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>



Any work on the pretensioned spring element of the chain tightener must only be carried out by trained, specialist personnel!



The spring elements must only be removed by a specialist workshop! The following applies to all spring elements in the event of a necessary repair: replace the complete unit only!



Repairing the spring elements involves significant safety measures and should only be carried out by a specialist workshop!



Your Dynapac customer service will be happy to provide support during maintenance, repair and the replacement of wearing parts!

## 1.2 Maintenance points

### Chain tension (1)




If the chains are not tensioned sufficiently, they can slip out of their guide formed by rollers, drive gear and idler wheel, thereby increasing wear levels.



If the chains are tensioned too tightly, this increases wear on the idler wheel and drive unit mounting, and also increases wear on track bolts and bushes.

### Checking / adjusting chain tension - grease tensioner version

- The chain tension is adjusted with grease tensioners. The filling connections (A) are located behind the lateral flaps on the left and right.



- Check the sag of the chain by powerfully pressing and lifting the drive chain in the area (B).
- The sag (C) must be between 10 - 15 mm.



If a different level of slack is detected during the measurement process, proceed as follows:


- Screw head section for flat nipple (tool box) onto the grease gun.
- Refill the chain tensioner with grease at the filler connection (A), then remove the grease gun.
- Check the chain tension once again, as described above.



If the tension is too high: see section "Relieving the chain".



Repeat this procedure on both drive units!



### Relieving the chain:




The grease in the tensioning element is under pressure. Carefully and slowly unscrew the filling valve, but not too far.

- Unscrew the lubricating nipple (A) on the grease tensioner using a tool until the grease is able to emerge from the nipple's lateral hole.




The idler wheel moves back independently or must be reset manually.



## Checking / adjusting chain tension - spring loaded tensioner version

The chain tension is realized by spring loaded tensioners.

The tension adjusters (A) are located left and right on the front beam of the main frame.



- Check the sag of the chain by powerfully pressing and lifting the drive chain in the area (B).
- The sag (C) must be between 10 - 15 mm.




If a different level of slack is detected during the measurement process, adjustment is required:

### Pre-tension of the tension unit.



The correct pre-tension of the tension unit is adjusted when the distance (B) between the two flanges is 186mm.

- Increase or reduce the pre-tension by turning the two bolts (C) and holding the two nuts (D) alternating.



### Adjusting tension:

- Increase the spring tension by turning the adjusting bolt.  
Therefor:
  - dissemble cap (E)
  - untighten counter nut (F)
  - turn adjusting bolt (G) until the two bolts (C) have a clearance of 5 mm between the flanges.




Check the clearance by moving the bolts forward and backward.

- tighten counter nut (F)
- install cap (E).



With that setting the correct slag of the drive chain is realized!



### Relieving the chain:

- untighten counter nut (F)
- unscrew adjusting bolt (G) as far as possible.




The idler wheel moves back independently or must be reset manually.

## Bottom plates (2)



Always use new bolts and nuts when installing new bottom plates!

- After removing the worn bottom plates, the adhesions must be cleaned from the contact surfaces of the chain links and the nut seats.
- Place the bottom plate with the front edge (A) over the chain links' bolt eye (B).
- Lubricate the threads and the contact surfaces beneath the bolt heads with a thin film of oil or grease.
- Insert the bolts (C) into the holes and screw them into the nuts (D) a few turns.
- Tighten the bolts without applying significant torque.
- Tighten the bolts to the required torque 98 +/- 5 Nm.



Check that each bolt has attained the full tightening torque!

### Rollers (3)




Rollers with damaged surfaces or which are leaking should be replaced immediately!

- Relieving the caterpillar chain:
- Raise the track chassis using suitable lifting equipment and remove adhering dirt.



Observe the safety measures when raising and securing loads!

- Remove the defective roller.
- Install the new roller using new assembly parts.
- Tighten the bolts without applying significant torque.
- Tighten the bolts diagonally to the required torque.
- Tighten to the following torques:
  - Small rollers (A): 73 Nm
  - Large rollers (B): 73 Nm



Check that each bolt has attained the full tightening torque!

- Lower the track chassis and tension the caterpillar chain properly.




### Planetary gear (4)

- Turn the drive gear so that the drain plug (B) is located at the bottom.
- For **oil level check** unscrew and remove the inspection bolt (A).



When oil level is correct, the oil comes up to the lower edge of the inspection bore or a small amount of oil escapes through the aperture.



For **filling in** the oil:

- Unscrew the filler screw (A).
- Fill in the specified oil into the filler bore at (A) until the oil level has reached the lower edge of the filler bore.
- Screw the filler screw (A) back in.

### Oil change:




The oil should be changed when at operating temperature.



Ensure that no dirt or foreign bodies are able to enter the gear.


- Turn the drive gear so that the drain plug (B) is located at the bottom.
- Unscrew and remove the drain plug (B) and filler screw (A) and drain off oil.
- Check gaskets on both screws and replace if necessary.
- Screw the drain plug (B) in.
- Fill new oil through the filler opening until the lower edge of the opening is reached.
- Tighten the filler screw (A).











## F 8.12 Maintenance - electrical system

### 1 Maintenance - electrical system



 <b>WARNING</b>	<b>Danger of being pulled in by rotating or conveying vehicle parts</b>
	<p>Rotating or conveying vehicle parts can cause severe or fatal injuries!</p> <ul style="list-style-type: none"> <li>- Do not enter the danger zone.</li> <li>- Do not reach into rotating or conveying parts.</li> <li>- Only wear close-fitting clothing.</li> <li>- Comply with the warning and information signs on the vehicle.</li> <li>- Stop the engine and remove the ignition key before any maintenance work.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>

 <b>CAUTION</b>	<b>Danger due to electric shock</b>
	<p>Injuries can be caused by touching live parts directly or indirectly!</p> <ul style="list-style-type: none"> <li>- Do not remove any protective safeguards.</li> <li>- Never spray water on electric or electronic components.</li> <li>- Maintenance work to the electric system should only be carried out by trained specialist staff.</li> <li>- When equipped with electric screed heater, check the insulation monitoring every day according to the instructions.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>

 <b>CAUTION</b>	<b>Danger from batteries</b>
	<p>Incorrect handling of the batteries poses a danger of injuries!</p> <ul style="list-style-type: none"> <li>- Wear your personal safety gear.</li> <li>- Do not smoke, avoid any open flames.</li> <li>- Ensure the working area is well ventilated after opening the battery compartment.</li> <li>- Avoid short-circuiting the battery terminals.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>

## 1.1 Maintenance intervals

Pos.	Interval							Maintenance point	Note
	10	50	100	250	500	1000 / annually	2000 / every 2 years		
1				■				■ Check batteries	
								■ Apply grease to battery terminals	
2	■							- Alternator Electrical system insulation monitoring Check function	(○)
		■						- Alternator Visual check for pollution or damage - Check the cooling air openings for pollution or clogging, clean if necessary.	(○)
		■						- Check the drive belts for damage and replace them as required.	(○)
	▼		■					- Drive belts - check tension, adjust if necessary.	(○)
						■		- Replace drive belts	(○)
3								■ Electrical fuses	

Maintenance	■
Maintenance during the running-in period	▼

## 1.2 Maintenance points

### Batteries (1)

#### Check batteries



The maintenance-free batteries are in the factory with the correct quantity of acid.  
There is no need to top up water or acid!



Keep the battery surfaces clean and dry, use only a damp or antistatic cloth for cleaning.



Do not open batteries without plugs!



If the starting capacity is insufficient, check and possible recharge the batteries.



Regularly check the charge of the battery and recharge if necessary.




A maintenance-free battery must be recharged slowly with a special battery charger. Do not use conventional chargers as these can damage the battery. Heed the corresponding operating instructions.



The battery terminal clips must be free of oxide and protected with a special terminal grease.



When removing the batteries, always first remove the negative terminal, ensuring that the battery terminals cannot be short circuited.



---

## Recharging the batteries

Both batteries must be recharged individually and must be dismantled from the vehicle for this purpose.



Always keep batteries upright during transport!

Before and after recharging a battery, always check the electrolyte level in every cell; if this needs to be topped up, only use distilled water.



When recharging batteries, every cell must be opened, i.e. plugs and/or covers must be removed.



Only use commercially available automatic battery chargers according to the manufacturer's instructions.




Preferably use the slow recharging procedure and adjust the charge current according to the following rule of thumb:

Battery capacity in Ah divided by 20 results in the safe charge current in A.

## Alternator (2)

### Electrical system insulation monitoring



The function of the protective insulation monitoring measure must be checked every day before starting work.



This check only checks the function of the insulation monitor, not whether an insulation error has occurred on the heating sections or consumers.

- Start the paver finisher's drive engine.
- Switch heating system switch (1) to ON.
- Press test button (2).
- The control light integrated into the test button signals "insulation fault".
- Press reset button (3) for at least 3 sec. to delete the simulated fault.
- The control light goes out.



If the test is conducted successfully, work may be undertaken with the screed and external consumers may be used.

If the "insulation fault" control light displays a fault even before the test button is pressed or if no fault is displayed during the simulation, work must not be undertaken with the screed or with connected, external equipment.



**The screed and equipment must be checked or repaired by a specialist electrician. Only then may work again be undertaken with the screed and equipment.**



**Danger due to electrical voltage**



**Non-adherence to the safety precautions and safety regulations when operating the electric screed heater leads to a risk of electric shock.**

**Danger to life.**

**All maintenance and repair work on the screed's electrical system may be carried out by a specialist electrician only.**



## Insulation faults



If an insulation fault occurs during operation, and the control light displays an insulation fault, the operator may proceed as follows:

- Switch the switches of all external equipment and the heater to OFF and press the reset button for at least 3 seconds to delete the fault.
- If the control light goes not go out, the fault lies in the alternator.



No further work may be carried out.

- If the control light goes out, the switches of the heater and external equipment can be switched back to ON one after another until a message again appears and the system is shut-down.
- The equipment found to be faulty must be removed or must not be engaged, and the reset button must be pressed for at least 3 seconds to delete the fault.



Operation may now be continued - without the faulty equipment, of course.






**The alternator or electrical consumer found to be faulty must be checked or repaired by a specialist electrician. Only then may work again be carried out with the screed and equipment.**






## Cleaning the alternator

-  The alternator must be regularly checked for excessive dirt and must be cleaned if necessary.
  - The air intake (1) must be kept free of dirt.
-  Cleaning with a high-pressure cleaner is not permissible!



## Check belts

Replace belts if there are clear signs of cracking on the ribbed side or any other signs of damage.



## Checking belt tension

The tension of both belts must be inspected with a tension measuring instrument.

New belt		Used belt	
min	max	min	max
679 N	728 N	582 N	631 N
171 Hz	177 Hz	158 Hz	165 Hz




The following tension measuring instruments are available:

- Mechanical tension measuring instrument (A):  
Article number 4753200045
- Electronic tension measuring instrument (B):  
Article number 4812034810




Comply with instructions for checking tension in the manual of the tension measuring instrument!



### Adjusting belt tension

- Unfasten the four mounting screws (A) on the alternator carriage.
- Unfasten lock nuts (B) on the tensioning fixture.
- Using the adjusting screw (C), set the required level of belt tension.
- Tighten lock nuts (B) and mounting screws (A) back down.



### Replacing belt


- Reduce the belt tension on the adjusting device so that the belt can be removed from the pulley.
- Mount the new belt and adjust tension again.



Always replace the belts in sets.

## 2 Electrical fuses


### 2.1 Main fuses (1)



#### Main fuses (A)

F		A
1.1	Main fuse	50
1.2	Main fuse	30
1.4	Preheating ignition system	100

## 2.2 Fuses in main terminal box (operating panel)




### Fuse carrier (B)

F		A
F1	Screed	15
F2	Screed	10
F3	Hopper	10
F4	Emergency stop	5
F5	Vibration	7,5
F6	Retract and extend screed	7,5
F7	Travel drive	7,5
F10	Auger	7,5
F11	Monitoring equipment	10
F12	Conveyor	7,5
F13	Free	5
F14	Levelling	7,5
F15	Screed heater	10
F16	12V socket	10
F17	Free	10
F19	Hazard warning flasher	10
F20	Main computer	20
F21	Horn	10
F22	Free	10
F23	Engine control	30
F24	Monitoring equipment	2

F		A
F25	Fuel pump	10
F26	Ignition	7,5
F27	Main computer	10
F28	Working lights	15
F29	Working lights	15
F30	Engine diagnosis	2
F31	Main computer	3

## Relays



K		
K1	Switched "positive"	C
K4	Switched "positive"	C
K5	Levelling	C
K6	Left screed	C
K7	Right screed	C
K8	Horn	C
K9	Emergency stop	C
K10	Start inhibit	C
K11	Vibration	C
K12	Tamper	C
K13	Conveyor	C
K14	Left auger	C
K15	Right auger	C
K30	Pre-heating	D
K31	Fuel pump	D





---

## F 11.12 Lubricants and operating substances

### 1 Lubricants and operating substances



Use only the lubricants listed below or comparable qualities of well-known brands.



Only use containers which are clean on inside and outside for filling oil or fuel.



Note capacities (see section "Capacities").




Incorrect oil or lubricant levels promote rapid wear and paver finisher failure.



Never mix synthetic oils with mineral oils!



Please heed the equipment-related fuel specification requirements!



## 1.1 Capacities

		Substance	Volume
1	Diesel engine (with oil filter change)	Engine oil	8.0 litres
2	Engine cooling system	Cooling liquid	9.0 litres
3	Fuel tank	Diesel fuel	50.0 litres
4	Hydraulic oil reservoir	Hydraulic oil	90.0 litres
5	Pump distribution gear	Gearbox oil	1.8 litres
6	Planetary gear drive unit	Gearbox oil	approx. 2.0 litres (1.0 l on each side)
7	Auger box	Liquid grease	3.0 kg
	Batteries	Distilled water	



Note specifications on the following pages!

## 2 Operating substance specifications

### 2.1 Notes on diesel fuel



Risk of explosion! Never mix diesel fuel with ethanol, petrol or alcohol!



Diesel fuel contaminated with water or dirt can cause serious damage to the fuel system! Keep fuel and fuel system free of water and impurities!



Observe the instructions for fuel recommendations and the specification in the maintenance instructions of the engine manufacturer!

### 2.2 Drive engine TIER III (○) - fuel specification

Permissible diesel fuels

Specifications				
Diesel fuel as per requirements of the engine manufacturer * Sulphur level max. 2000mg/kg	EN 590	ASTM D975	JIS K 2204 HFRR max. 460µm	

\* Detailed information at:

<http://www.deutz.com>

de	\Service\Betriebsstoffe und Additive\Kraftstoffe
en	\Service\Operating Liquids and Additives\Fuels

### 2.3 Drive engine TIER IV (○) - fuel specification



Low-sulphur diesel fuel is prescribed for correct operation of the exhaust-gas treatment system!

The maximum sulphur level must not exceed 15 ppm!

If low-sulphur diesel fuel is not used, the prescribed exhaust values cannot be met and damage will be caused to the engine and to the exhaust-gas treatment system!


Permissible diesel fuels

Specifications				
EN 590	ASTM D975 S15	JIS K 2204 HFRR max. 460µm		

## 2.4 Engine - lubricating oil

Dynapac	Aral	BP	Esso / Exxon	Fuchs	Mobil	Shell	
Engine Oil 200 (*)							

 (\*) = recommended

 Observe the instructions for lubricant recommendations and the specification in the maintenance instructions of the engine manufacturer!

## 2.5 Cooling system

Dynapac	AGIP	Chevron			Petronas		Finke
Coolant 200 (*)	-Antifreeze Spezial	Extended Life Coolant			Antifreeze G12		Aviaticon Finkofreeze P12+

 (\*) = recommended

## 2.6 Hydraulic system

Dynapac	AGIP	Chevron	Caltex	Fuchs	Mobil	Shell	Finke
Hydraulic 100 (*)		Rando HDZ 46	Rando HDZ 46			-Tellus Oil S2 V46 -Tellus S2 VX46	Aviaticon HV 46

 (\*) = recommended

## 2.7 Pump distribution gear

Dynapac	Aral	BP	Esso / Exxon	Fuchs	Mobil	Shell	
Gear Oil 100 (*)						-Omala S2 GX 220	

 (\*) = filled in at the factory

## 2.8 Drive unit planetary gear

Dynapac	Aral	BP	Esso / Exxon	Fuchs	Mobil	Shell	
Gear Oil 100 (*)						-Omala S2 GX 220	

 (\*) = recommended

## 2.9 Auger box

Dynapac	Aral	BP	Esso / Exxon	Fuchs	Mobil	Shell	
Auger Grease (*)						-Gadus S5 V142W 00	

 (\*) = recommended

## 2.10 Grease

Dynapac	Aral	BP	Esso / Exxon	Fuchs	Mobil	Shell	Chevron
Paver Grease (*)						-Gadus S5 T460 1.5	-High Temp Premium2

 (\*) = recommended

## 2.11 Hydraulic oil

Preferred hydraulic oils:

a) Synthetic hydraulic liquids based on ester, HEES

Manufacturer	ISO viscosity class VG 46
Dynapac	Hydraulic 120 (*)
Shell	Natural HF-E46
Panolin	HLP SYNTH 46
Esso	Univis HEES 46
Total	Total Biohydran SE 46
Aral	Vitam EHF 46
Finke	Aviaticon HY-HE 46



(\*) = recommended




When changing from mineral oil pressure fluids to biodegradable pressure fluids, please contact our factory advisory service!





# F 100 Tests, stopping ...

## 1 Tests, checks, cleaning, stopping



## 1.1 Maintenance intervals

Item	Interval								Maintenance point	Note
	10	50	100	250	500	1000 / annually	2000 / every 2 years	If necessary		
1	■								- General visual inspection	
2	regularly								- Check that the bolts and nuts fit firmly	
3						■		■	- Inspection by an expert	
4								■	- Cleaning	
5								■	- Preserving the paver finisher	

Maintenance	■
Maintenance during the running-in period	▼

## 2 General visual inspection


The daily routine should comprise a visual inspection around the entire paver finisher. The following items must be checked:

- Are components or controls damaged?
- Are there leaks on the engine, the hydraulics, the gearbox, etc.?
- Are all fastening points (conveyor, auger, screed, etc.) in order?
- Are the warnings affixed to the vehicle complete and legible?
- Are the non-slip surfaces at ladders, steps, etc. in correct condition, not worn or soiled?



Immediately take actions to correct any detected malfunction to avoid damages, dangers or environmental hazards!

## 3 Check that the bolts and nuts fit firmly

NOTE	Caution! Possible damage to or destruction of parts!
	<ul style="list-style-type: none"> <li>- Self-locking nuts must always be replaced after removal.</li> <li>- Special torques not mentioned in this manual are stated at the corresponding place in the spare parts catalogue.</li> <li>- Screws locked with screw cement must be cemented in again if found to have come loose.</li> </ul> <p>Always use the stated torque.</p> <ul style="list-style-type: none"> <li>- Stated torques for screwed connections apply to dry (uncoiled) state</li> <li>- Do not reuse screws inserted with the maximum permitted torque; instead, replace with new screws.</li> <li>- Screws in strength class 12.9 should only be used once.</li> <li>- All screwed connections must be clean.</li> <li>- Check all reused components of the screwed connection for any signs of damage.</li> </ul>

Bolts and nuts must be checked regularly to ensure that they fit firmly; retighten them if necessary.



The spare parts catalogue states the special torques at the corresponding parts.



For the necessary standard torques, please refer to the section "Bolts - torques"

#### **4 Inspection by an expert**



Have finisher, screed and optional gas or electric system checked by a trained specialist

- when required (according to the operating conditions and the nature of application),
- however, at least once a year, check that they are all in good operational condition.

## 5 Cleaning

- Clean all parts coming into contact with paving material.
- Spray contaminated parts with the separator fluid spraying system (○).



**Before** cleaning work with the high pressure cleaner, grease all lube points acc. to specification.

- Clean the vehicle with water after laying mineral aggregates, lean-mixed concrete, etc.



Do not spray bearing points, electrical or electronic components with water.

- Remove residual paving material.







**After** cleaning work with the high pressure cleaner, grease all lube points acc. to specification.



Danger of slipping! Ensure that all steps and ladders are free of grease and oil!



 <b>WARNING</b>	<b>Danger of being pulled in by rotating or conveying vehicle parts</b>
	<p>Rotating or conveying vehicle parts can cause severe or fatal injuries!</p> <ul style="list-style-type: none"> <li>- Do not enter the danger zone.</li> <li>- Do not reach into rotating or conveying parts.</li> <li>- Only wear close-fitting clothing.</li> <li>- Comply with the warning and information signs on the vehicle.</li> <li>- Stop the engine and remove the ignition key before any maintenance work.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>

 <b>CAUTION</b>	<b>Hot surfaces!</b>
	<p>Surfaces including those behind covering parts, together with combustion fuels from the engine or screed heater can be very hot and cause injuries!</p> <ul style="list-style-type: none"> <li>- Wear your personal safety gear.</li> <li>- Do not touch hot parts of the vehicle.</li> <li>- Only perform maintenance and repair work after the vehicle has cooled down.</li> <li>- Comply with all further information in these instructions and in the safety manual.</li> </ul>

## 5.1 Cleaning the hopper



Clean the hopper regularly

To clean the hopper, park the vehicle on a smooth surface with the hopper open. Switch off the engine.

## 5.2 Cleaning the conveyor and auger



Clean the conveyor and auger regularly.

If necessary, let the conveyor and auger run at low speed during cleaning.



There must always be an assistant at the operator's platform whenever cleaning work is being carried out to intervene in the event of any potential danger.

## **6 Preserving the paver finisher**

### **6.1 Shutdowns for up to 6 months**

- Park the vehicle in a place where it is protected from great exposure to direct sunlight, wind, humidity and frost.
- Grease all lube points in accordance with specifications. Allow optional central lubricating unit to run if necessary.
- Change oil in diesel engine.
- Seal exhaust silencer to make it airtight.
- Remove batteries, charge them and store them in a well ventilated place at room temperature.



Recharge removed batteries every 2 months.

- Protect all bare metal components, e.g. piston rods on hydraulic cylinders, with a suitable corrosion inhibitor.
- If it is not possible to park the vehicle in an enclosed building or under cover, it must be covered with a suitable size of tarpaulin. In all cases, seal all air intake and exhaust apertures with plastic film and adhesive tape.

### **6.2 Shutdowns lasting from 6 months to 1 year**


- Carry out all the actions listed for "Shutdowns of up to 6 months".
- Once the engine oil has been drained off, fill the diesel engine with a manufacturer-approved grade of preserving oil.

### **6.3 Recommissioning the machine**

- Reverse all the steps described in the "Shutdown" sections.


## **7 Environmental protection, disposal**


### **7.1 Environmental protection**

 Packaging materials, used operating substances, cleaning agents and machine accessories must be correctly recycled.

 Always observe the local regulations!

### **7.2 Disposal**

 Correctly sorted disposal must be carried out after replacing wear and spare parts and after the machine has been withdrawn from service (scrapped).  
The materials must be sorted correctly according to metal, plastic, electronic scrap, various operating substances etc.  
Any oily or greasy parts (hydraulic hoses, lube pipes etc.) must be treated separately.

 Electric devices, accessories and packaging should be recycled in an environment-friendly manner.

 Always observe the local regulations!



## 8 Bolts - torques

### 8.1 Standard metric threads - strength class 8.8 / 10.9 / 12.9

Treatment	dry/lightly oiled						Molykote ®					
	Torque (Nm)	Permitted deviation (+/- Nm)	Torque (Nm)	Permitted deviation (+/- Nm)	Torque (Nm)	Permitted deviation (+/- Nm)	Torque (Nm)	Permitted deviation (+/- Nm)	Torque (Nm)	Permitted deviation (+/- Nm)	Torque (Nm)	Permitted deviation (+/- Nm)
Strength class	8.8	8.8	10.9	10.9	12.9	12.9	8.8	8.8	10.9	10.9	12.9	12.9
M3	1	0,3	1,5	0,4	1,7	0,4	1	0,3	1,4	0,4	1,7	0,4
M4	2,4	0,6	3,5	0,9	4	1	2,3	0,6	3,3	0,8	3,9	1
M5	5	1,2	7	1,7	8	2	4,6	1,1	6,4	1,6	7,7	1,9
M6	8	2,1	12	3	14	3	7,8	1,9	11	2,7	13	3,3
M8	20	5	28	7,1	34	8	19	4,7	26	6,6	31	7,9
M10	41	10	57	14	70	17	37	9	52	13	62	16
M12	73	18	97	24	120	30	63	16	89	22	107	27
M14	115	29	154	39	195	45	100	25	141	35	169	42
M16	185	46	243	61	315	75	156	39	219	55	263	66
M18	238	60	335	84	402	100	215	54	302	76	363	91
M20	335	84	474	119	600	150	304	76	427	107	513	128
M22	462	116	650	162	759	190	410	102	575	144	690	173
M24	600	150	817	204	1020	250	522	131	734	184	881	220
M27	858	214	1206	301	1410	352	760	190	1067	267	1281	320
M30	1200	300	1622	405	1948	487	1049	262	1475	369	1770	443
M33	1581	395	2224	556	2669	667	1400	350	1969	492	2362	590
M36	2000	500	2854	714	3383	846	1819	455	2528	632	3070	767

## 8.2 Fine metric threads - strength class 8.8 / 10.9 / 12.9

Treatment	dry/lightly oiled						Molykote ®					
	Torque (Nm)	Permitted deviation (+/- Nm)	Torque (Nm)	Permitted deviation (+/- Nm)	Torque (Nm)	Permitted deviation (+/- Nm)	Torque (Nm)	Permitted deviation (+/- Nm)	Torque (Nm)	Permitted deviation (+/- Nm)	Torque (Nm)	Permitted deviation (+/- Nm)
Strength class	8.8	8.8	10.9	10.9	12.9	12.9	8.8	8.8	10.9	10.9	12.9	12.9
M3x0,35	1,2	0,3	1,7	0,4	2,1	0,5	1,1	0,3	1,5	0,4	1,8	0,5
M4x0,5	2,8	0,7	3,9	1	4,7	1,2	2,5	0,6	3,5	0,9	4,2	1
M5x0,5	5,7	1,4	8	2	9,6	2,4	5,1	1,3	7,1	1,8	8,5	2,1
M6x0,75	9,2	2,3	12,9	3,2	15,5	3,9	8,3	2,1	11,6	2,9	13,9	3,5
M8x1	21,7	5,4	30,6	7,6	36,7	9,2	19,5	4,9	27,4	6,8	32,8	8,2
M10x1,25	42,1	10,5	59,2	15	71	17,8	37,7	9,4	53	13	63,6	15,9
M12x1,25	75,7	18,9	106,2	26	127	31,9	67,2	16,8	94,5	24	113	28,3
M14x1,5	119	29,7	167	42	200	50,1	106	26	149	37	178	44,6
M16x1,5	183	45,6	257	64	308	77	162	40	227	57	273	68,2
M18x1,5	267	66,8	376	94	451	112,7	236	59	331	83	398	99,4
M20x1,5	373	93,2	524	131	629	157,3	328	82	461	115	553	138,3
M22x1,5	503	126	707	177	848	212,1	442	110	621	155	745	186,3
M24x2	630	158	886	221	1063	265,8	556	139	782	195	938	234,5
M27x2	918	229	1290	323	1548	387,1	807	202	1136	284	1363	340,7
M30x2	1281	320	1802	450	2162	540,6	1124	281	1581	395	1897	474,3
M33x2	1728	432	2430	607	2916	728,9	1514	378	2128	532	2554	638,5
M36x3	2126	532	2990	747	3588	897,1	1876	469	2638	659	3165	791,3



