

Instruction Manual

4812314581EN
Operation and Maintenance

Pneumatic Tire Roller
CP2700

Diesel Engine
Cummins QSB 4.5 – Tier III
Cummins QSF 3.8 - Tier IV

Serial number

10000512KKC009561 -

10000502VMC010959 -



TABLE OF CONTENTS

OPERATION	Page
Operation - Before starting	38
Display and button set	42
Operating the roller.....	43
Ballast box	46
Interlock/Emergency Stop/Parking Brake	50
Long-term storage	53
Jack up the frame, so that the tires do not take any	54
load.....	54
Lifting	55
Towing.....	56
Transport.....	59
Operation instructions - Overview.....	60
Preventive maintenance.....	61
Preventive maintenance - Symbols and lubricants	62
Specifications	65
Maintenance and lubrication points	69
Scheduled maintenance and lubrication.....	70
Maintenance and lubrication procedures	70
Daily (Every 10 hours of operation).....	74
Weekly (Every 50 hours of operation)	80
Monthly (Every 250 hours of operation).....	86
Quarterly (Every 500 hours of operation).....	90
Semiannually (Every 1,000 hours of operation).....	93
Annually (Every 2,000 hours of operation).....	97
Special instructions.....	103
Electrical system	105
Revision.....	108

Introduction

Dynapac CP2700

Dynapac CP2700 is a 27 tonnes rubber wheel roller, with 5,905 ft (2,300 mm) width.

It has five direction front wheels and four back wheels. The hydrostatic drivers, the flexible ballast solution and a wide range of option equipment indicate that the machine has different settings available. CP2700 is mainly used together with other asphalt rollers to seal surfaces. Thanks to its weight, it also serves as a roller for other types of ground.

Warning symbols



WARNING! *Damage to the machine or its parts.*



CAUTION! Risk of death or injuries.

Safety information



The Safety Manual delivered with the machine shall be read by the operator. Always follows the safety instructions and keep the Manual inside the machine.



It is recommended to at least train the operators on daily handling and maintenance of the machine, according to the Instruction Manual. Passengers are not allowed on the machine, and the operator must be on the seat whenever he operates the equipment.



Read throughout the manual before starting the machine and before performing any maintenance.



Request immediately new manuals if the old ones are lost, damaged or become illegible.



Make sure there is a good vent (air exhaust) when the engine is turned on in closed facilities.

General Information

This manual contains instructions to operate and perform the maintenance of the machine.

The machine's maintenance shall be made correctly in order to obtain the maximum performance and the equipment shall also be kept clean, so leakage, loosen bolts and connections can be found as soon as possible.

Perform a daily inspection in the machine before starting, so you can find possible leakage or other failures.

Verify the machine's floor. Leakages are easier detected on the floor than on the equipment itself.



THINK ABOUT THE ENVIRONMENT! Do not dispose oil, fuel or other hazard substances to the environment. Always dispose correctly used filters, draining oil and fuel residues.

This manual contains instructions for periodic maintenance, which is usually performed by the operator.



Other engine instructions can be found at the manufacturer's manual.

CE Marking and Statement of Compliance

(APPLIED TO MACHINES SOLD WITHIN THE EUROPEAN COMMUNITY)

This machine has a CE Marking. It shows that at its delivery, it meets all the applicable health and safety basic directives, according to 2006/42/EC Machinery Directive, besides attending other directives applicable on machinery.

Following the machine there is a "Statement of Compliance" specifying the directive and supplement applicable, as well as the harmonized norms and other regulations relevant to the case.

Safety - General instructions (you must also read the Safety Manual)



1. Read and understand this Manual before starting and operating the machine. The operator must be familiar with the equipment contents before operating it.
2. Observe and follow all the Maintenance Section instructions.
3. Only experienced/trained operators are allowed to operate the machine. **NEVER** allow the presence of passengers and **ALWAYS** remain seated while operating the equipment.
4. Do not operate the equipment if adjustment or repairs are necessary.
5. Use ladders and rails to enter and leave the cab. **NEVER** enter or leave the machine while it is moving.
6. The ROPS (Roll Over Protective Structure) should always be used when the machine is operated on unsafe ground. Always use the seat belt when the ROPS is on.
7. Use the first gear on sharp turns.
8. Avoid driving close to cliffs or sharp side slopes. Operate the machine on first gear and always check the brakes.
9. When driving close to edges or holes, make sure at least 2/3 of the wheels are on the previously compacted materials.
10. Make sure there are no obstacles over your head during the travel. Always look up and down during the travel. Make sure there are no obstacles in the direction of travel - on the ground, in front or behind the roller.
11. Drive particularly carefully on uneven ground.
12. Follow all the safety rules and use the protection equipment proper to the work to be performed.
13. Keep the roller clean. Clean immediately dirt, oil and grease accumulated on the operator platform. Keep all the signs, lanterns, headlights and decals clean, visible and legible.
14. Observe the following safety measures before refueling:
 - Turn off the engine;
 - Do not smoke;
 - Do not allow sparks or flame next to the equipment;
 - To avoid sparks, ground the filling nozzle.
15. Before performing any maintenance operation, chock the roller wheels and apply the emergency/parking brakes.
16. Hearing protection is recommended if the machine's noise level exceeds 85 dB (A). The noise level can vary depending on the work the machine performs.
17. Do not make any changes on the machine, under the risk of affecting the personal safety as well the equipment's. Any change on the machine demands a previous written approval by **DYNAPAC**.
18. Avoid using the machine before the hydraulic oil reaches the normal operating temperature. The braking distance may be longer than normal if the oil is cold. Refer to the operation instructions on "Stop", in the "Operation" section.

19. For your own protection, always wear:
 - Helmet;
 - Working boots with steel toecaps;
 - Ear protectors;
 - Reflecting clothing;
 - Working gloves.
20. If there is a cab in the machine, operate it always with the doors closed and with the seat belt.

Safety - When operating



Avoid people entering at the danger area, that is, at a distance of at least 23 ft (7 m) in all the directions from the machine operating. The operator can allow one person to be at the danger area, but in this case, care must be taken and the machine can only be operated when this person is in a visible place or with clear indication of where he/she is.

Operating on slopes



The machine must never be operated from the outside of the cab. The operator shall be seated when operating.

Slopes

This angle was measured on a flat, hard surface and with the machine in a stationary position.

The steering angle is zero, the tires pressure is normal and all the tanks are full.

Always remember that loosen ground, the steering of the machine, different tire pressures, the operation speed and the gravity center raising may cause the machine to turn, even on slopes smaller than the ones stated here.




Fig.: Operating on downhill.



If you need to leave the cab in emergency situations, take off the hammer at the rear pillar on the right and break the opening windows that are also on the right.



It is recommended that ROPS (Roll Over Protective Structure) is always used when driving on slopes or unsafe ground.



Whenever possible, avoid driving across slopes. On slopes, drive straight up and down.



The speed must always be slow when operating on slopes.



Always operate the machine with the doors closed and with the seat belt.

Transport on steep ground




Fig.: Steep ground
v < max. speed. (9.3 mph or 15 km/h).

During the transport on steep ground (slope >5%), be careful to not exceed the roller's maximum speed.

Take your foot off the throttle pedal and use the engine brake system. Also use the main brake if the speed keeps increasing.

Selecting the low speed will increase the engine brake system efficacy and also the life of the braking system.

Operation and transport on steep ground




Fig.: Steep slope
Low speed (up to 4.7 mph or 7.5 km/h)



(>15%).

Always drive the machine in slow speed when operating or during transport on steep ground.

To drive or stop the machine, the rear wheels shall always be towards the slope, that is, the roller shall go up normally and shall go down in reverse.



Make sure there are no obstacles both in front or behind your work area.

Driving near edges




Fig.: Position of wheel when driving near edges.

When driving close to edges or holes, make sure that at least $\frac{1}{4}$ of the tires is on the compacted ground.

Safety - Option items

Air conditioning




Fig. Air conditioning



The system contains pressurized refrigerant. It is forbidden to release refrigerant to the atmosphere.



The maintenance of the air conditioning system shall be carried out only by trained people and with the proper tools and equipment.



The air conditioning system is pressurized. The incorrect handling can result in serious personal injury. Do not loose or disconnect hoses and connections with the system loaded.



The system must be refilled with approved coolant when necessary. Refer to the safety decal next to the replacement and filling place.

Edge cutter




Fig. Edge cutter
1. Transport position
2. Work position



The operator must make sure that nobody is in the work place when the machine is operating.



The edge cutter has rotating components which may cause crushing.



Immediately after use, the tool shall always be put back on the transport position (1) that is, on the raised position.



If the edge cutter and its components are dismantled, make sure that it is made with the machine in a safe position and that it is on the ground.

Working lights - Xenon




Fig. Xenon working lights



CAUTION! High voltage!

The working lights are Xenon type and have a high voltage auxiliary source of power.

Any maintenance on the lighting system shall be performed by authorized technicians and the main power source shall be off.



CAUTION! Environmentally hazardous waste!

The xenon lamps of the working lights contain mercury (Hg).

A defective lamp is considered a hazardous waste and shall be disposed of properly, according to the applicable local directives.

Contact an **DYNAPAC** dealer!

Technical Specifications

Vibrations – Operator station (ISO 2631)

The vibration levels are measured according to the operational cycle described in the EU directive 2000/14/EC on machines equipped for the EU market with the operator's seat in the transport position.

The measured vibrations on the whole body are below the 0.5 m/s ² action value, as specified in the directive 2002/44/CE (the limit is 1.15 m/s ²).
--

The measured vibrations on the hand/arm are also below the 2.5 m/s ² action value, as specified in the same abovementioned directive (the limit is 5 m/s ²).

Noise level

The sound levels are measured according to the operational cycle described in the EU directive 2000/14/EC on machines equipped for the EU market with the operator's seat in the transport position.

Guaranteed sound power level, L _{WA}	103 dB (A)
Sound pressure level at the operator's ear (platform), L _{pA}	85 ±3 dB (A)
Sound pressure level at the operator's ear (cab), L _{pA}	80 ±3 dB (A)



During normal operations, the values abovementioned may differ, depending on the work specific conditions.

Electrical system



The machines were tested for electromagnetic compatibility (EMC) in accordance with EN 13309:2000: "Construction machinery".

Technical specifications - Dimensions

Dimensions



Dimensions	mm	inches
A – Between axles	4,300	169
B – Total width	2,360	93
H ₁ – Height with attachment	3,344	132
H ₂ – Total height	2,990	118
K – Height from the ground	250	9,8
L – Total length	5,480	216





Dimensions	Millimeter	Inch
R – Outer radius	9045	356
r – Inner radius	5711	225
x – Tire width	300	11,8

Dimensions	Degree
O – Vertical oscillation	4,5
D – Direction angle	33


Safety decals - description and location

Safety decals - description and location



Safety decals - Description and location (cont.)

Always make sure that all the safety decals are completely legible and remove the dirt or request for new ones if they are illegible. Use the part number indicated on each decal.



NOTICE:
Crush zone, wheel.
Keep a safe distance from the crush zone.

NOTICE:
Rotating engine components, be careful!
Keep your hands off the danger zone.

NOTICE:
Hot surface!
Keep your hands off the surface.

NOTICE:
Read carefully the towing chapter before releasing the brakes. Crushing injury danger.

NOTICE:
The operator must read the Safety and Engine Manuals, as well as the Operation and Maintenance instructions.

NOTICE:
High pressure fluid.
Make sure to release the pressure from the accumulators before opening the hydraulic system.










NOTICE:
Gas shall not be use to start the machine.

NOTICE:
Edge cutter (option).







NOTICE:
Toxic gas danger.
Refer to the Instruction Manual.

Safety decals - description and location

Safety decals - Description and location (cont.)

- | | | |
|----|---|----------------------------|
| 10 |  | Emergency exit - Cab |
| 11 |  | Fire extinguisher |
| 12 |  | Hoisting plate |
| 13 |  | Tire pressure |
| 14 |  | Diesel oil |
| 15 |  | Securing point |
| 16 |  | Lifting point |
| 17 |  | Hydraulic oil |
| 18 |  | Bio-hydraulic oil (option) |

Safety decals - Description and location (cont.)

- | | | |
|----|---|----------------------|
| 19 |  | Handbook compartment |
| 20 |  | Master switch |
| 21 |  | Battery voltage |
| 22 |  | Sound power level |
| 23 |  | Water tank |
| 24 |  | Hydraulic oil level |

Identification plates

Machine plate.

The machine plate (1) is on the top step, on the left side of the operator's platform.

It specifies the manufacturer's name, the type of the machine, the serial number, the service weight, the engine power and the manufacturing year (machines delivered outside EU do not present CE marking and in some cases they also do not present the manufacturing year).




Fig.: Frame
 1 – Machine plate
 2 – Engine plate

Product Identification Number			
Designation	Type	Rated Power	Max axle load front / rear
		kW	kg
Gross machinery mass	Operating mass	Max ballast	Year of Mfg
kg	kg	kg	
<div style="display: flex; justify-content: space-between;"> ○ 4811 0001 35 ○ </div>			

NOTE: State the machine plate's serial number when ordering spare parts.

PIN (Product Identification Number) at the frame

The PIN - product identification number (1) is punched on the right side of the right frame. It is the same number of the machine plate (serial number).





Fig. Frame
 1 – PIN

100	00123	V	E	A	123456
A	B	C	D	E	F

Explanation of the 17PIN (Product Identification Number)

- A – Manufacturer's code (100 = Dynapac)
- B – Family/model code (00502 = CP2700)
- C – Check code
- D – Year of manufacturing (E=2014, F=2015...)
- E – Production's unit code (B = Sorocaba, Brazil)
- F – Serial number (from 000001 to 999999)

Engine plate

	Cummins Engine Company Inc. Columbus, Indiana 47203-0005	Engine Cyl./ L	359 5.9	SERIES 403	CPL 2079	Engine Serial No. 45271188
		Timing TDC				Cool Spec.
	Working Valve may Result And Warranty in Work and Fuel Rating May Vary. Always Exceed Published Maximum Values For This Model And Application.					
	Date of Mfg. 19881130		Rated HP 0 at 0 rpm			
	Made in U.S.A. 3006615		Fuel rate at rated HP 0 gph 200000			

The engine plate (1) is on the cylinder head cover (1), and it can be accessible when the hood is open.

The plate is also on the top step of the operator's platform.

It contains information like the serial number and the engine specifications.




Fig. Engine
1. Engine plate

NOTE: State the engine plate's serial number when ordering spare parts.

Instruments/controls

Control panel, side panel and command keyboard.




Fig. Control panel, side panel and command keyboard.

1. Ignition key
2. Forward/reverse lever
3. Command keyboard
4. Direction lights (OPTION)
5. Warning lights
6. High beam lights (OPTION)
7. "+" increase in the tire pressure (OPTION)
8. "-" decrease in the tire pressure (OPTION)
9. High/low speed
10. "MAN" manual sprinkler (OPTION)
11. "AWC" automatic sprinkler (OPTION)
12. "+" increase of the sprinkler interval (timer) - OPTION
13. "-" decrease of the sprinkler interval (timer) - OPTION
14. Working lights (OPTION)
15. Horn
16. Emergency stop button
17. Eco-mode
18. Enable regeneration (Tier iV engine)
19. Disable regeneration (Tier iV engine)
20. Hazard warning lights (OPTION)
21. Rotating beacon (OPTION)
22. Control panel
23. Function buttons (5)
24. Brake test pedal
25. Parking brake
26. Edge cutter (OPTION)
27. Edge cutter sprinkler(OPTION)

Pedals

The roller has two pedals:

1. Throttle pedal
2. Brake pedal




Fig. – Pedals

Steering column multiple switch (option)

Switch functions:

1. Forward/reverse lever
2. Central warning lights
3. Direction lights
















Fig. - Steering column multiple switch (option)










Instrument/controls - Description and function

Instrument/controls - Description and function

No.	DESIGNATION	SYMBOL	FUNCTION
1	Ignition key	  	<p>The electric circuit is off.</p> <p>All instruments and electric controls are on.</p> <p>The starter is activated.</p>
2	Forward/reverse lever	-	To start the machine, the lever shall be in the "neutral" position. Move the lever forward and step on the throttle to drive forwards; move the lever back and step on the throttle to drive backwards.
3	Command keyboard	-	
4	Direction lights		It shows that the direction lights are activated (activation via switch at the steering column).
5	Central warning lights		Appoints general fault. See the control panel (22) for the description of the fault.
6	High beam lights		It shows that the high beam lights are on (via switch at the steering column).
7	"+" increase in the tire pressure		When activated, it increases the tires pressure.
8	"-" decrease in the tire pressure		When activated, it decreases the tires pressure.
9	High/low speed		The roller starts always in the high speed mode. The low speed mode is obtained when activated.
10	Manual sprinkler		Gives continuous sprinkling of water on the wheels.
11	Automatic sprinkler		When activated, sprinkling is automatically turned on/off when the forward/reverse lever is in the "neutral" position.
12	"+" increase of the sprinkler interval (timer)		The sprinkling frequency increases each time the water volume on the wheels is also increased.





Instrument/controls - Description and function

Instrument/controls - Description and function (cont.)

No.	DESIGNATION	SYMBOL	FUNCTION
13	"-" decrease of the sprinkler interval (timer)		The sprinkling frequency decreases each time the water volume on the wheels is also decreased.
14	Working lights		Press to turn on/off all the working lights.
15	Horn switch		Press to sound the horn.
16	Emergency stop button		Press it to turn off the machine and the engine. All the power supply is also turned off.
17	Eco-mode		When activated, maintain speed reducing the engine rotation, thus saving fuel (up to 30% economy)
18	Button to enable the regeneration (Tier IV Engine)		Press to execute the regeneration
19	Button to disable the regeneration (Tier IV Engine)		Press to disable regeneration.
20	Hazard warning lights		Press the switch to activate the hazard warning lights.
21	Rotating beacon		Press the switch to activate the rotating beacon.

Instrument/controls - Description and function

Instrument/controls - Description and function (cont.)

No.	DESIGNATION	SYMBOL	FUNCTION
22	Control panel	-	It shows the engine and transmission functions. Refer to the Section: "Before Starting".
23	Function buttons (5)	-	-
24	Brake test pedal		Press it to test the brakes.
25	Parking brake		<p>When it is pressed, the parking brake is activated.</p> <p>To turn it off, slide the red part backwards (towards you) and change the switch position.</p> <p>NOTE: to start the machine, the parking brake shall be activated.</p>
26	Edge cutter		The edge cutter can be moved up and down when machine is in work position.
27	Edge cutter sprinkler		Press to activate the edge cutter sprinkler.

Control panel – General description



Fig. – Start screen

When the ignition key is in the position "I", the start screen is visible on the display. It remains activated for a few seconds then it switches to the status screen.



Fig. – Status screen

The status screen provides information about the fuel level, the sprinkler tank water level, the working hours and the voltage level. The water and fuel levels are specified in percentage (%).

The screen remains visible until the Diesel engine is turned on or if one of the function buttons below the screen is pressed.



Fig. – Main working screen

If the engine starts before you choose the screen, it will switch to the main screen.

This screen provides an overview and it remains on during the operation:

- The speed is shown in the middle of the screen.
- The high/low speed mode is shown with a symbol in the middle of the screen.
- The engine rpm, the asphalt temperature (option) and the tires pressure (option) are shown in the upper left corner and in the lower left corner, respectively.

Instrument/controls - Description and function

Control panel – General description (cont.)



Fig. – Main working screen with the menu selection buttons

A menu field is shown by pressing one of the selection buttons. It is visible for a short time, then it fades out if any selection is made. A menu field appears again by pressing one of the selection buttons (1).

Example of the menu field:



	Scroll/selection buttons to choose the available functions.
	Alarm log button to show the alarms of the engine and machine.
	Settings/menu selection button, which opens the main menu. Settings can be changed in the main menu.
	Exit/return button, returns 1 step at once. Pressing the button for approximately 2 seconds displays the main menu again.



Fig. – Temperature screen

The temperature screen shows the engine oil (top of the screen) and hydraulic oil temperature (bottom of the screen). The values are shown in Celsius or Fahrenheit, according to the choice of unit system.

Control panel - Alarms



Fig.: Asphalt temperature screen

It is also possible to refer to a menu with the asphalt temperature when the asphalt temperature gauge (option) is installed. Set the upper and lower temperature limits with the function keys.

If the asphalt effective temperature is outside the limits, the value shown in the top of the main screen starts to flash. The temperature value is continuously on when it is in the right limit.



When an engine motor alarm is activated, it is shown in the screen. The alarm is sent from the engine's ECM, which tracks its functions.

The message displays SPN and FMI codes and can be read via the engine supplier error code list. To erase the message, press "OK".











When a machine's alarm is activated, it is shown in the screen with a warning text describing it.

To erase the message, press "OK".

Instrument/controls - Description and function

Control panel – Alarms (cont.)

SYMBOL	DESCRIPTION	FUNCTION
	Warning symbol, hydraulic oil filter.	If the symbol appears with the engine in maximum rpm, it shall be necessary to replace the hydraulic oil.
	Warning symbol, air filter.	If the symbol appears with the engine in maximum rpm, it shall be necessary to clean or replace the air filter.
	Warning symbol, battery charging.	If the symbol appears with the engine running, the alternator is not charging. Stop the engine and find the fault.
	Warning symbol, engine temperature.	If this symbol appears, the engine is too hot. Stop immediately the engine and find the fault. Refer also to the engine manual.
	Warning symbol, hydraulic oil temperature.	This symbol appears when the hydraulic oil is too hot. Do not drive the roller, put the engine on idle, wait until the oil cools down and find the fault.
	Warning symbol, low fuel level.	This symbol appears when the fuel level is 10%.
	Warning symbol, low sprinkler water level.	This symbol appears when the sprinkler water level is 10% in the main tank.
	Warning symbol, low braking capacity.	This symbol appears when the oil level and/or pressure for the brakes are low. If this alarm appears and remains with the machine working, stop it immediately and contact DYNAPAC .

Instrument/controls - Description and function

Fail list

Id	Byte . Bit	Description	Action
1	0.0	Hydraulic Filter	LED
2	0.1	Air Filter	LED
3	0.2	No Charging	LED
4	0.3	Low Fuel	LED
5	0.4	Low Spr. Water	LED
6	0.5	Engine Temp	LED
7	0.6	Hydraulic Temp (Temperatura hidráulica)	LED
8	1.0	Battery tension will be monitored. < 9 V ou > 36V = SAFE MODE < 18V ou > 32V = LIMITED MODE	Safe Mode
9	1.4	Sensor tension error. 5V. <4,875V or >5,125V out of range of work	Safe Mode
10	3.1	Error in the hydraulic pump front valve Error Feedback / Resistance Valve out of range.	Limited Mode
11	3.0	Error in reverse of the valve of hydraulic pump Error Feedback / Resistance Valve out of range.	Limited Mode
12	3.2	Error in the Motor Control Valve Error Feedback / Resistance Valve out of range.	Limited Mode
13	3.3	Hydraulic motor valve BPD. Error Feedback	Limited Mode
14	2.3	Error in the rotation of the pump / diesel engine / Input Frequency >10.000 Hz	Limited Mode
15	2.0	Short circuit on FNR	Safe Mode
16	2.1	Inch sensor error	Limited Mode
17	2.2	Throttle pedal sensor error	Limited Mode
18	2.6	Error in rotation motor H1/ Frequency >8.000 Hz	Limited Mode
19	1.1	Error in direction motor (sensor x joystick)	Limited Mode
20	1.2	Error in J1939	Limited Mode
21	4.0	Coolant Level	LED
22	4.1	Oil Pressure	LED
23	4.2	Water in Fuel	LED

LIMITED mode

Limits the speed to 50%.
This mode is active as long as the fault remains.

SAFE mode

The machine stops and cannot be used before the fault is corrected.

Control panel – Alarms (cont.)



Alarms received are stored/logged and can be seen by selecting Display Alarms .

“ENGINE ALARM”

Stored/logged engine alarms.



“MACHINE ALARM”

Stored/logged machine alarms. They come from other systems on the machine.




“USER SETTINGS”



Users can change lighting settings, choose between Metric or Imperial system and set warning sounds on/off.



Adjustment of light and contrast settings on the display, including brightness of the panel light.



Operator help when starting



When trying to turn on the machine without having set up to three necessary conditions to do so, the missing ones are shown in the display. The missing conditions must be set before turning on the machine.

Conditions that must be set:

- The parking brake shall be activated.
- The forward/reverse lever shall be in the neutral position.
- The Diesel engine rpm shall be in the low speed (low = slow speed) (not all the models, refer to the manual to know if your model fits in this condition).

Operator help when activating



When trying to activate the edge cutter (option) with the machine in high speed, the display will show the slow speed mode for a few seconds.

To activate the previous function, make sure the low speed mode is activated.

Eco-mode

This equipment has a new fuel economy system.

When activated the Eco-mode maintain work speed decreasing the engine rotation (≈ 1700 rpm), so the fuel economy can reach 30% depending on work (slopes, ballast, etc).



Don't use Eco-mode on slopes higher than 15%.



Regeneration system (Emission Control)

After Treatment Screen



Fig. – After Treatment screen

In this screen you will find urea tank level, warning lamps and engine oil temperature.

Make sure that the Urea tank is full during operation.
It's recommended to fill or drain the tank with the system off.



If the Urea tank is completely empty you may have error codes related to the after treatment system in the display due to invalid measurements. To clear the error code the tank must be filled and perform a key cycle, start the engine and run it in high idle for 5 minutes.

Diesel Exhaust Fluid (DEF) Lamps

DEF Lamp



Illuminates when DEF level is low, and flashes when the DEF falls below a very low level. Operator should refill the DEF tank with DEF.

DEF Lamp With Check Engine Lamp




Illuminates when the DEF level is critically low. If the tank is not refilled immediately, power will be reduced. Operator should refill the DEF tank with DEF. Normal engine power will be restored after the DEF tank is refilled.

Flashing DEF Lamp With Check Engine Lamp



Illuminates when the DEF level is near zero. If the tank is not refilled immediately, power will be further reduced. Operator should refill the DEF tank with DEF. Normal engine power will be restored after the DEF tank is refilled.

Flashing DEF Lamp With Stop Engine Lamp



Illuminates when the DEF gauge has read zero for 30 minutes. Power will be limited to idle. Operator should stop the equipment when it is safe to do so, and refill the DEF tank. Normal engine power will be restored after the DEF tank is refilled.



Exhaust System Cleaning Lamps



High Exhaust System Temperature (HEST) Lamp

May illuminate due to higher-than normal exhaust temperature during Exhaust System Cleaning. Operator should ensure that the exhaust pipe outlet is not directed at any flammable or combustible surfaces.



Exhaust System Cleaning Lamp

Illuminates when the exhaust system is unable to complete an automatic Exhaust System Cleaning event. Operator should ensure the Exhaust System Cleaning Switch is not in the "STOP" position and continue working until there is an opportunity, such as at the end of the work day or shift, to complete a stationary Exhaust System Cleaning.



Exhaust System Cleaning Lamp With Check Engine Lamp

If an Exhaust System Cleaning is not performed in a timely manner after the Exhaust System Cleaning Lamp is illuminated, the Check Engine

Lamp will illuminate and engine power will be significantly reduced.

Park

the equipment when safe to do so, and press the Exhaust System Cleaning Start Switch. Once the cleaning is complete, full engine power will be restored.



Exhaust System Cleaning Lamp

Flashes when a stationary Exhaust System Cleaning event is initiated using the Exhaust System Cleaning Start Switch. This lamp will continue

to flash until the stationary cleaning event is complete. Once the lamp turns off, the operator can resume normal work activity.



Exhaust System Cleaning Stop Lamp

Illuminates when the Exhaust System Cleaning Switch is in the "STOP" position, preventing a cleaning event. This switch should be used only when high exhaust temperatures present a hazard. Excessive use of the

Exhaust System Cleaning Switch in the "STOP" position will result in the need for more frequent stationary exhaust cleaning events.

Exhaust System Cleaning Switch



Exhaust System Cleaning Enabled

The switch remains in the standard **mid-position** during normal operations. This means Exhaust System Cleaning is enabled and allows the exhaust system to clear any build-up by initiating automatic cleaning. Exhaust System Cleaning initiated automatically by a preset timer at 20-hour intervals and takes around 15-30 minutes to complete. No operator action is required and the equipment continues to work as normal during the cleaning.

The HEST lamp may illuminate during cleaning to indicate higher than normal exhaust temperatures and safety considerations apply.

Start Exhaust System Cleaning



Pressing the switch into the **top position** starts a manual (parked) Exhaust System Cleaning. This is required on infrequent occasions due to very unusual duty cycle conditions. A manual (parked) Exhaust System Cleaning may be needed when the Exhaust System Cleaning Lamp illuminates. When the Start Switch is pressed, cleaning begins and this is confirmed by the Exhaust System Cleaning Lamp flashing. The HEST lamp may illuminate during the manual (parked) Exhaust System Cleaning to indicate higher than normal exhaust temperatures and safety considerations apply. The switch returns to the standard Mid-Position after pressing the manual (parked) Exhaust System cleaning.

Stop Exhaust System Cleaning Function




Pressing the switch into the **bottom position** prevents Exhaust System Cleaning from occurring. Stopping the Exhaust System Cleaning function is required only for safety reasons to avoid higher than normal exhaust temperatures.









When the switch is pressed the Exhaust System Cleaning STOP Lamp illuminates to indicate Exhaust System Cleaning is disabled. The switch remains engaged in this position until pressed back to the standard mid-position to restore the automatic Exhaust System Cleaning function.

Exhaust System Cleaning should not be left disabled for long periods of time as this results in the need for a manual (parked) Exhaust System Cleaning.

Instruments and Controls - Cab



Instruments and controls - Cab

No.	DESIGNATION	SYMBOL	FUNCTION
1	Automatic Climate Control	-	Air conditioning automatic control (see A/C operation for detail).
2	Front wiper, intermittent	-	Intermittent function for front wiper.
3	Front wiper switch		Press to operate the front windshield wiper.
4	Rear wiper switch		Press to operate the rear windshield wiper.
5	Front and rear windshield washers switch		Press the top to activate the front washers. Press the bottom to activate the rear washers.
6	Asymmetric front wiper switch		Press to operate the front side windshield wiper.
7	Asymmetric rear wiper switch		Press to operate the rear side windshield wiper.
8	Asymmetric side windshield washers switch		Press the top to activate the front side washers. Press the bottom to activate the rear side washers.
9	Fuse box		Contains fuses from the electric system in the cab.
10	Hammer for emergency exit		If it is necessary to leave the cab during an emergency, release the hammer and break the right side windows.
11	Defroster nozzle	-	Turn the defroster nozzle to direct the air flow.

A/C – System operation





Power/Enter

By feeding the panel with 24VDC, the screen will be on, indicating that the product is in standby mode.

Press to turn on the A/C, it will show the software version and then the temperature. To return to standby mode you must press the button for 3s.

Set point Up/Down


Set point is the desired temperature inside the vehicle. To set it

up press  or . The set point temperature will flash on the display; press until reaches desired temperature.





Display


The display shows set point value, bar graph evaporator speed, active function and other information. It also serves to allow the operator to view the coil and return temperature, as well as the parameters. It also serves to alert when there is some system flaws.

Operation Mode


To change the operation mode, press the button  (operation mode), select the desired mode:

The controller has 4 operation modes that are:

- Only ventilation 
- Only cooling 
- Only heating 
- Automatic mode 

Press the button  to confirm or wait a few seconds to cancel.





Ventilation

The controller has two ventilation modes: manual and automatic ventilation.


Manual ventilation

The manual ventilation has three speeds. When some function (cooling, heating or automatic mode) is active, the ventilation function is always on. To change the fan speed, press the key



(Ventilation mode) and after set the desired speed with the



keys or . After press the key  to confirm or wait a few seconds and the speed will be saved.

Operation - Before starting

Daily maintenance



Before starting your work shift and operating the equipment, make sure the daily maintenance was carried out. For further information, refer to the maintenance section in this manual.

Main switch

Check if the master switch is on. The master switch is located in the electric device compartment (1) on the right side of the machine.




Fig. - Engine compartment.
1. Battery switch



After the daily use of the roller, the master switch shall be turned off. It prevents the machine to be turned on accidentally and protects the electronic devices.



If the main battery switch is closed, the engine hood shall be opened during the operation to make it possible to reach in an emergency.

The control and operation unit

The control and operation unit has three adjustment options: transverse travel, rotation and steering column angle.

For transverse travel, raise the inner lever (1). The transverse travel brake will be released.

For rotation, raise the outer lever (2). Make sure the control unit is in the correct position before operating the machine.

For steering column angle, release the locking lever (3). Fix it again in the new position.

To adjust the operator's seat, refer to the next section.



Perform all the control and operation unit adjustments when the machine is stationary.



Before starting your work shift and operating the machine, make sure the seat and the steering column are locked and never release the side travel if you are on a slope.





Fig. - The control and operation unit
1. Locking lever - transverse travel
2. Locking lever - rotation
3. Locking lever - steering column angle

Standard operator's seat - adjustment

Adjust the operator's seat so all the controls are within easy reach and the machine operation is comfortable.



- (1) Length adjustment.
- (2) Weight adjustment.
- (3) Back support adjustment.
- (4) Seat belt.



ALWAYS make sure the seat is locked before starting the operation.




Always use the seat belt (4).

Fig. - Operator's seat

Comfort operator's seat (option) - adjustment

Adjust the operator's seat so all the controls are within easy reach and the machine operation is comfortable.



- (1) Length adjustment.
- (2) Height adjustment.
- (3) Seat-cushion inclination.
- (4) Back support inclination.
- (5) Armrest inclination.
- (6) Lumbar support adjustment.
- (7) Seat belt.

Fig. - Operator's seat (option adjustment)

View

Before starting the engine, make sure that the view around the machine is unobstructed.

All the cab windows shall be clean and the rear view mirrors adjusted for a good rear view.

Operator position

If a ROPS (Roll Over Protective Structure) or a cab is fitted to the roller, always use the seat belt (1) and wear a protective helmet.




Fig. - Operator's seat
 1. Seat belt
 2. Safety railings
 3. Locking knob
 4. Anti-slip protections



Always replace the seat belt for a new one if the previous show signs of wear or has been subjected to a huge impact.



The safety railings (2) around the operator's station are adjustable both in the inner and outer positions. Retract them when driving close to walls or other side obstacles.

Release the locking knob (3) and adjust and lock the railings in the desired position.



Make sure the anti-slip protections (4) of the platform are in good condition and replace them for new ones if they are worn.



If the machine is fitted with a cab, make sure the door is always closed when in motion.

Interlock

The roller is equipped with Interlock.

The Diesel engine turns off after 4 seconds if the operator leaves the seat when the machine is moving forward/backward. If the machine is in neutral position when the operator leaves the seat, a horn is sound until the parking brake is activated.

If the parking brake is activated, the Diesel engine will not stop, but the engine will be automatically turned off if, by any reasons, the transmission is not in the neutral position when the operator is not seated in his place.



Sit down for all operations!

Starting

Screen - Control

Sit down for all operations.

Turn the ignition key (1) to the position I and the initial screen is shown in the Control panel (2).




Fig.- Side panel
 1. Ignition key
 2. Control Panel



Fig.- Status screen
 3. Voltmeter
 4. Fuel level
 5. Water level
 6. Hourmeter

Check if the voltmeter (3) appoints at least 24 volt and if the fuel (4) and water (5) levels show a percentage value.

The hourmeter (6) records and shows the total quantity of the engine working hours.

Starting the engine

Make sure the emergency stop system (2) is off (upper position) and the parking brake is on.

The forward/reverse lever (1) shall be in the neutral position. The Diesel engine cannot be started if the lever is not in this position.

When sitting on the operator's seat, turn the ignition key (3) to the right (the first position I) and then to the start position. Release the switch as soon as the engine starts.




Fig. - Control panel
 1. Forward/reverse lever
 2. Emergency stop button
 3. Ignition key




Do not try to run the start engine for too long (max. 30 seconds). If it does not work, wait 60 seconds to try again.

Let the engine idle for a few minutes or more if the environment temperature is below 50 F (10° C).








When the engine is running indoors, make sure if there is proper ventilation to extract the exhaust gases.

Display and button set



Alarm descriptions

SYMBOL	DESCRIPTION	FUNCTION
	Warning lamp, hydraulic oil filter	If the lamp is lit with the engine in maximum rpm, it shall be necessary to replace the hydraulic oil filter.
	Warning lamp, air filter	If the lamp is lit with the engine in maximum rpm, it shall be necessary to clean or replace the air filter.
	Warning lamp, battery charging	If the lamp is lit with the engine running, the alternator is not charging. Stop the engine and find the fault.
	Warning lamp, engine temperature	If the lamp is lit it means the engine is too hot. Stop IMMEDIATELY the engine and find the fault. Refer to the engine manual.
	Warning lamp, hydraulic oil temperature	If the lamp is lit it means the hydraulic oil is too hot. Do not operate the roller. Cool the oil making the engine run in idle and locate the fault.

Operating the roller



Under no circumstances the machine shall be operated away from the ground. The operator shall be seated inside the machine during the operation.



Make sure the areas at the front and behind the machine are free.




Fig. – Side panel
 1. Manual sprinkler
 2. Automatic sprinkler

1. Select the maximum gear the machine will operate. To activate the operation speed, use the throttle on the right side of the steering column.
2. Make sure the steering is working normally by turning the steering wheel to the left and to the right once with the roller stationary.
3. When compacting asphalts, do not forget to activate the sprinkler system (1) or (2).



Release the parking brake button (5) by sliding the red lock on the button backwards and changing the lever position. Remember that the machine can roll if you are on a slope.




Fig. – Side panel
 3. Low speed
 4. Forward/reverse lever
 5. Parking brake

4. Activate the low speed (3).
5. Move the forward/backward lever (4) carefully to any direction you desire.
6. Increase or decrease the machine speed using the throttle control.



Make sure the parking brake (5) is working correctly by activating it and moving the forward/backward lever (4) to the F or R position. Keep the brake test button pressed. This way, when you throttle the machine, it will not move.

Edge cutter (option)




Fig.– Side panel

1. Edge cutter, up and down
2. Edge cutter, sprinkler

To activate the edge cutter, the machine must be in low speed.

When the side panel button (1) is pressed with the machine in low speed, a hydraulic piston lowers down the edge cutter to the ground.

The tool can also be lifted if the machine is in the transport position.

A bypass valve prevents the hydraulic system being overloaded.

To prevent asphalt sticking to the edge cutter, the operator shall use a separate sprinkler system. It is operated by a switch (2). The water is supplied on the main tank and it is the same used in the standard sprinkler system.

Tire pressure adjustment (option)




Fig.– Side panel

1. Display
2. Increase in the tire pressure
3. Decrease in the tire pressure

The operator can vary the pressure during the operation with the tire air pressure control. It can be variable adjusted with the keys (2) and (3) on the keypad, within the interval from 240 kPa to 830 kPa (35 to 120 PSI) and can be reduced with the key (3). The tire pressure level is shown in the lower left corner, on the Display (1).



When the tire pressure is at the maximum level (830 kPa) or at the minimum level (240 kPa), it will not be possible to increase/decrease the pressure.

Coconut mats (option)

To apply the coconut mats (1) on the wheels, follow the instructions below:

- Hold and lift the handle in the middle of the scraper holder (2).
- Make sure the lock pin (4) releases properly from the locking hook (3) and allow the scraper to rest against the tires in the working position.

To release the coconut mats:

- Hold and lift the handle in the middle of the scraper holder (2).
- Make sure the lock pin (4) fits well in the locking hook (3).




Fig. – Scraper bars adjustment

- 1. Coconut mats**
- 2. Scraper holder**
- 3. Locking hook**
- 4. Lock pin**

Ballast box




Fig.– Ballast box cover

- 1. Top covers
- 2. Side lower covers
- 3. Side upper covers
- 4. Draining plugs

Water and wet sand ballast

Remove the top covers (1) and side upper covers (3) and fill with water and sand through this opening.

Keep the side lower covers (2) closed during the water filling.

Do not remove the draining plugs (4) because the water may leak when the ballast is filled with it.

Fill the ballast box, when necessary, with gravel, sand and steel.

The water shall be added when it is filled with sand, so it can fill all the spaces between the ballast.



When using the roller with mixed ballast, start using the steel objects available, and then add the requisite amount of sand and water.




Distribute the ballast evenly.


Removable steel ballasts

The CP2100/CP2100W roller uses an innovative and patented system of steel ballasts, which can be removed and installed easily and quickly:

1. With the ballast box drained (without water and/or sand), remove four side covers (1) from the ballast box.



2. Unscrew the nuts and counter nuts (2) and four lower bolts (3) of the bedplate in the steel ballasts. Remove the bedplate (4) off the ballasts assembly.



3. Install or remove the ballasts, according to the necessity, using the forks from a standard forklift. The ballasts grooves (5) were projected so the forklift forks fit perfectly and to ease their removal, installation and transport.




Fig. - Removable steel ballasts

1. Side covers
2. Nut and counter nut
3. Bolts
4. Bedplate
5. Ballast grooves

4. After installing or removing the ballasts in the box, mount the bedplate, performing the reversal steps used to remove them.



Distribute the steel ballast evenly in the box.

Ground pressure (driving)

The tire contact surface can be changed by means of tire pressure.

The high pressure on the tires provides a smaller contact surface (1) and the low pressure on the tire provides a larger contact surface (2).

The contact surface with the ground is very important for the compaction result. The total weight divided by the quantity of tires provides the correct pressure for the wheel, according to the following table.




Fig. - Ground contact surface

1. Contact surface with the tire (high pressure)
2. Contact surface with the tire (low pressure)

Ground pressure

	TIRE PRESSURE (kPa)					
	240	350	480	620	720	830
LOAD ON THE WHEEL (kgf)	GROUND PRESSURE (kPa)					
1,125	200	240	270	300	330	340
1,375	220	260	300	330	350	380
1,825	240	280	340	380	400	430
2,250	250	310	360	410	440	480
2,750	260	320	390	440	480	520
3,000	270	330	410	460	490	540

	TIRE PRESSURE (psi)					
	35	50	70	90	105	120
LOAD ON THE WHEEL (kgf)	GROUND PRESSURE (psi)					
2,500	29	35	39	44	47	49
3,000	31	38	44	48	51	55
4,000	35	41	49	55	58	62
5,000	37	45	52	60	64	69
6,000	38	47	57	62	70	75
6,500	39	48	59	66	71	78

Low tire pressure – 240 kPa (34,8 PSI)

The lower the tires pressure, the lower the pressure on the contact surface, due to the larger surface area.



Fig. - Low ground pressure, larger contact area

Normal tire pressure – 480 kPa (69,6 PSI)

Used for degradation session.



Fig. - Normal ground pressure

High tire pressure – 830 kPa (120,4 PSI)

The higher the tires pressure, the higher the pressure on the contact surface, due to the smaller surface area.



Fig. - High ground pressure, smaller contact area

Interlock/Emergency Stop/Parking Brake



The interlock, emergency stop and parking brake shall be checked daily before starting the machine. To check if the emergency stop and interlock are working correctly, it is necessary to turn on and off the machine.



To check if the Interlock works correctly, the operator shall rise from the seat with the roller moving forwards and backwards (perform the test in both ways). The operator must hold the steering wheel firmly and be ready for a sudden stop. The alarm will be activated and after 4 seconds the engine will turn off and the brakes will be activated.



To check if the emergency stop works correctly, the operator shall press the corresponding button with the roller moving forwards and backwards (perform the test in both ways). Next, the operator must hold the steering wheel firmly and be ready for a sudden stop. The engine will be turned off and the brakes will be activated.



To check if the parking brake works correctly, it shall be activated with the roller moving forwards and backwards (perform the test in both ways). The operator shall hold the steering wheel and be ready for a sudden stop when it is activated. The engine does not turn off.

Normal braking

Release the throttle control (1) and press the brake pedal (2).




Fig. – Pedals

- 1. Throttle control
- 2. Brake pedal

Emergency braking

The brake pedal is normally used to brake.



For emergency braking, press the emergency stop button (1), hold the steering wheel and be ready for a sudden stop. The engine stops.

The Diesel engine will be turned off and it must be turned on again, if necessary.

When starting the engine after an emergency stop, the forward/backward lever shall be in the neutral position and the parking brake shall be on.




Fig. – Side panel
1. Emergency stop

Turning off the engine

Allow the engine to cool down in low idle for a few minutes.

Check if the Display (1) shows any indication of faults. Turn off all the lights and other electric functions.

Press the parking brake switch (3).

Turn the ignition key (2) to the left to turn it off.

Fit and fix the cover of the instruments panel over the screen and the upper part of the control box (on rollers without cab).




Fig. – Side panel
1. Display
2. Ignition key
3. Parking brake

Chocking the wheels




Fig. - Choking the wheels
1. Chocks



Never leave the roller and let it with the engine running unless the parking brake is activated.



Make sure the machine is parked in a safe area, without traffic. Chock the wheels when parking on slopes.



In extremely cold weather, some components may freeze. Drain the water tanks and pipings.

Master switch




Fig. – Engine compartment
1. Master switch

At the end of the working shift, turn off the battery master switch (1) and remove the handle.

This will prevent the battery discharging and will also make it difficult to start and drive the machine if unauthorized people try to use it. Close and lock the maintenance covers and doors.

Long-term storage



For long-term storage (more than a month) follow the instructions below:




Fig. - Roller weather protection

These measures are valid for storage for a period of up to 6 months.

Before starting the machine again, the points stated below shall be performed before parking and store the roller.

Wash the machine and touch up the painting finishing to prevent rusting. Use anti-rust agents on the exposed parts and lubricate carefully the machine, besides applying grease to unpainted surfaces.

Engine

Refer to the manufacturer information in the engine instruction manual supplied with the roller.

Battery

Remove the batteries from the roller, clean their outside parts and recharge them once a month.

Air cleaner, exhaust pipe

Close the air tube (refer to the sections "Every 50 Hours of Operation" and "Every 1,000 Hours of Operation") or the respective intake opening with plastic or tape. Also cover the exhaust pipe opening with sealing material to avoid moisture entering in the engine.

Water distribution system

Drain all the water in the water tank and all the hoses. Also drain the filter housing and the water pump and remove all the sprinkler nozzles.

Refer to the Maintenance section to obtain further information about water draining.

Fuel tank

Fill the fuel tank completely to prevent condensation.

Hydraulic oil reservoir

Fill the hydraulic reservoir until the uppermost level mark (refer to the section "Every 10 Hours of Operation").

Tires

Make sure the tires pressure is at least 200 kPa (29 PSI).

Jack up the frame, so that the tires do not take any load.

Steering cylinder, hinges, etc.

Grease the steering cylinder plunger spindle to preserve it.

Also lubricate the hinges on the engine compartment and cab doors.

Hoods, tarpaulin

Lower the instruments hood/covering over the instrument panel.

Cover the entire roller with a tarpaulin. It shall have a gap between it and the ground.

If possible, store the machine indoors and preferably in a place with regular temperature.

When stopping and parking the equipment, always apply the parking brake.

As a precaution measure, chock the roller tires when parking on slopes and turn off the engine.



To prevent accidents, when parking on slopes, stop transversally to the road towards the slope.



Never leave the roller with the engine running. Before leaving it, apply the emergency/parking brake.



Make sure the roller is parked in a safe place and that it is not obstructing the traffic.

Lifting

Lifting the roller

Make sure the front wheels are parallel with the frame before lifting the roller.




Fig. - Roller prepared for lifting.



Make sure the hooks are safely placed in the lifting eyes. The equipment shall only be lifted by the proper lifting eyes.



Always use cables and steel chains according to the safety norms and make sure there are no worn components and that parts are not damaged during the lifting.



The machine's gross weight is specified in the hoisting plate (1). Refer also to the Technical Specifications.



Do not go under or next to the machine when it is being lifted.

Make sure the lifting hooks are safely connected to the machine. Check the machine gross weight and the compatibility of the lifting equipment.

Lifting the roller with a jack




Fig. - Roller lifted with the jack
 1. Hoisting plate
 2. Jack



The machine's gross weight is specified in the hoisting plate (1). Refer also to the Technical Specifications.



Lifting devices such as a jack (2) or equivalents must be dimensioned according to the safety regulations for lifting devices.



Do not go under or next to the machine when it is being lifted. Also check if the lifting device is fixed and secure in its position, and at a steady level and surface.

The roller shall only be lifted with a jack or similar if it is correctly fitted in the lifting eyes. The frame is reinforced in these points to support the tension. Lifting at any other place can result in damage to the machine or personal injury to the operator.

Towing

Short distance towing with the engine running

The roller can be moved up to 984 feet (300 meters), according to the following instructions:

To tow the machine, use the same lifting points.




Fig. - Transmission pump
1. By-pass valves

1. Park the roller on a flat and safe place. If necessary, chock the tires.
2. Open the hood and check if the propulsion pump is accessible.
3. On the pump, there are two by-pass valves (1) (hexagonal bolts) which should be turned three turns anticlockwise to put the whole system in the by-pass mode, which means that the A and B sides of the pump are freely connected to the pressure side. This function allows the machine to be moved without the drive shaft rotating.
4. Start the Diesel engine and run it in idle.
5. Move the forward/backward lever in one of the two positions. If it is in a neutral position, the hydraulic engine brakes are activated.
6. The roller can be towed and even steered now, if the steering system is working.
7. To leave the by-pass mode, turn both valves (1) three times to the right.



The machine must not be moved in a speed higher than 5 km/h and over 984 feet (300 meters). If it happens, there are risks of damage in the transmission system. Make sure the towing valves are reseted (turning them three times to the right) after the towing.

Short distance towing with the engine inoperative



As a safety measure, chock the wheels to prevent the machine to move when the brakes are hydraulically disengaged.

The roller can be moved up to 984 feet (300 meters), according to the following instructions:




Fig. - Transmission pump
1. By-pass valves




Fig. - Brake release valve
2. Valve
3. Pump arm

1. Park the roller on a flat and safe place.
2. Open the hood and check if the propulsion pump is accessible.
3. On the pump, there are two by-pass valves (1) (hexagonal bolts) which should be turned three turns anticlockwise to put the whole system in the by-pass mode, which means that the A and B sides of the pump are freely connected to the pressure side. This function allows the machine to be moved without the drive shaft rotating.
4. The brake release pump is at the right side of the engine compartment.
5. Pump with the arm (3) until the brakes are released.
6. So the brake release pressure is quickly drained, turn on the start engine for a few seconds.
7. If you cannot start it, turn the towing valve four times to the left (remember always to turn it four times later to the right).
8. To disconnect the by-pass mode, loose the hexagon bolts turning them three times to the right.
9. This way the roller can be towed.



The machine must not be moved in a speed higher than 5 km/h and over 984 feet (300 meters). If it happens, there are risks of damage in the transmission system. Make sure the towing valves are reseted (turning them three times to the right) after the towing.

Towing the roller



When towing, the roller shall be braked by the towing vehicle. Always use a towing bar, because the machine cannot brake.



The roller must be towed slowly and must not be moved in a speed higher than 5 km/h and over 984 feet (300 meters).

During the roller towing, its devices shall be connected in both lifting holes.

The pulling forces shall act to the machine's longitudinal axis, as illustrated in the figure. Refer to the table below to know the maximum pulling force allowed for this machine model:




Fig. - Towing direction

MODEL	kN	Lbf
CP2700	412	92,700

Trailer eye (option)

The roller can be equipped with a trailer eye. It shall only be used for towing objects weighing no more than 4,000 kg.




Fig. - Trailer eyes

Transport

Preparing the roller for transport

Apply the parking brake and make sure the machine is in the neutral position, that is, that the tires are pointing forwards.

Chock (1) the tires in an angle of 37° and at a minimum height of 9,9 inches (25 cm). They should be chocked both forwards and backwards.

Chock under the frame (2) to ensure that the chains remain tensioned if the air goes out of the tires. Block up the machine according to the figure.

Secure the roller with chains in all four corners. The attachment points are shown in the safety decals. Put the chains in symmetrical pairs, crossing each other.




Fig. - Positioning

- 1. Chocks**
- 2. Supports**
- 3. Straps**



Make sure the chains, supports and attachments of the transport vehicle are approved and have the proper tension to perform the fitting and locking. Check regularly if the chains are not slack.

Operation instructions - Overview



Follow the safety instructions specified in the Safety Manual.

- Make sure all the MAINTENANCE INSTRUCTIONS were carried out. For further information, refer to the Maintenance section in this manual.
- Turn on the battery switch.
- Move the forward/backward lever to the "P" position.
- Apply the emergency stop. The roller will always start in the **High** speed.
- Keep the ignition key in the "O" position.
- Start the engine and warm it.



Always check the brakes. Before starting the working shift, carry out a test in the system, and remember that if the hydraulic oil is cold, the brake distance will be longer.



When operating the roller, use carefully the forward/backward lever.

- Make sure the tires are well sprinkled, when necessary.



In an emergency, apply the emergency stop, hold well the steering wheel and be ready for a sudden stop.

- When parking: stop the engine, apply the parking brake and chock the roller tires.
- When towing: refer to the towing instructions in this manual.
- When lifting: refer to the lifting instructions in this manual.
- When transporting: refer to the transport instructions in this manual.

Preventive maintenance

Introduction

It is necessary to carry out a complete maintenance so the machine can work satisfactorily and at the lowest possible costs.

The Maintenance section includes the periodic maintenance that shall be carried out on the machine.

The recommended maintenance intervals assume that the machine is being used in a normal environment and working conditions.

Delivery

The machine is tested and adjusted before leaving the plant.

The inspection shall happen in the moment it arrives to the client, following the list in the warranty document.

Any transport damage shall be immediately reported to the carrier company.

Warranty

The warranty is only valid if the inspections were carried out at the time of the delivery, as well as the maintenance inspections according to the warranty.

The warranty is not valid if there are damages due improper assistance, misuse of the machine, use of lubricants and hydraulic oils not specified in the manual or if other adjustments were made without the proper authorization.

Warning symbols



WARNING! Damage to the machine or its parts.



CAUTION! Risk of death or injuries.








Preventive maintenance - Symbols and lubricants

Preventive maintenance - Symbols and lubricants



Always use high quality lubricants and in the amounts required.

Too much grease or lubricant oil can cause overheating and premature wear.










	ENGINE OIL Room temperature: 5 F to 122 F (-15°C to 50°C)	ENGINE TIER III Shell Rimula R4 L 15W-40 or equivalent. ENGINE TIER IV Shell Helix Ultra 5W-40 or equivalent.	
	BRAKE OIL / HYDRAULIC OIL Room temperature: 5 F to 122 F (-15°C to 50°C) Room temperature: above 122 F (50°C)	Shell Tellus V68 or equivalent. Hydraul Shell Tellus V100 or equivalent.	
	BIOLOGICAL HYDRAULIC OIL When leaving the plant, the machine may be filled with biologically degradable oil. When replacing or filling with oil, use the same type of oil used previously.	PANOLIN HLP Synth 46 (www.panolin.com)	
	GREASE	Shell Retinax LX2 or equivalent.	
	FUEL Refer to the engine manual instructions.		
	COOLANT Antifreeze protection effective down to -34.6 F (-37°C). 50/50 mixed (clean water + coolant additive).	GlycoShell/Carcoolant 774C or equivalent.	
	TRANSMISSION OIL	Shell Spirax S2 ALS 85W-140 API GL-5 or equivalent.	








For room temperatures extremely high or low, other lubricants shall be applied.

Refer to the chapter "Special Instructions" or contact **DYNAPAC**.

Preventive maintenance - Symbols and lubricants

	Engine, oil level
	Engine, oil filter
	Hydraulic fluid, level
	Air filter
	Hydraulic fluid, filter
	Transmission, oil level
	Fuel filter
	Battery
	Coolant level

Preventive maintenance - Symbols and lubricants

	Lubricating oil
	Air pressure
	Sprinkler
	Sprinkler water
	Recycling

Specifications

WEIGHTS	
Operational weight with ROPS and series equipment	(10,830 kg) (23,870 lb)
Weight without ballast	(10,440 kg) (23,010 lb)
Weight with ballast, wet sand	(19,330 kg) (42,604 lb)
Weight with maximum ballast	(27,000 kg) (59,510 lb)

The roller can use 16 ballast blocks inside the frame. Each block is 1,102 lb (500 kg) and is used individually. Eight of them are in the front part and eight are in the rear part, so use a proper combination to obtain the maximum of the ballast.

The roller working weight consists of the machine weight and the ballast weight. Thicker layers demand a heavier machine for compacting, and thinner layers do not need a machine that heavy.

FILLING VOLUMES	
Hydraulic oil reservoir	113 L (25.09 gal.)
Hydraulic oil system	35 L (9.24 gal.)
Transmission gear oil	2x8 L (2x2.11 gal)
Diesel engine lubricating oil	14.6 L (3.86 gal.)
Diesel engine coolant	18.5 L (4.88 gal.)
Urea tank	18.9L (5 gal.)
Fuel tank	220 L (58.11 gal.)
Water tank	415 L (109.63 gal.)
Sand ballast box volume (total)	4.25 m ³

ELECTRICAL SYSTEM	
Battery	2 x 12 V / 74 Ah (24V)
Alternator	24 V 45A
Fuses	Refer to "Fuses" in the "Electrical System" section

Specifications (cont.) – Working capacity

COMPACTION DATA	
Load on the tires:	
- Without ballast	(1,200 kg)
- With wet sand ballast	(1,900 kg)
- With the ballast at its max.	(3,000 kg)

Torque

Torque for oiled bolts tightened with a torque wrench.

METRIC COARSE SCREW THREAD, BRIGHT GALVANIZED (fzb)	STRENGTH CLASS					
	8.8, oiled	8.8 dry	10.9, oiled	10.9 dry	12.9, oiled	12.9 dry
M6	8.4 N.m (6.2 lb.ft)	9.4 N.m (6.9 lb.ft)	12 N.m (8.8 lb.ft)	13.4 N.m (9.9 lb.ft)	14.6 N.m (10.7 lb.ft)	16.3 N.m (12.02lb.ft)
M8	21 N.m (15.5 lb.ft)	23 N.m (16.9 lb.ft)	28 N.m (20.6 lb.ft)	32 N.m (23.6 lb.ft)	34 N.m (25.07 lb.ft)	38 N.m (28.02lb.ft)
M10	40 N.m (29.5 lb.ft)	45 N.m (33.1 lb.ft)	56 N.m (41.3 lb.ft)	62 N.m (45.7 lb.ft)	68 N.m (50.1 lb.ft)	76 N.m (56.05 lb.ft)
M12	70 N.m (51.6 lb.ft)	78 N.m (57.5 lb.ft)	98 N.m (72.2 lb.ft)	110 N.m (81.1 lb.ft)	117 N.m (86.3 lb.ft)	131 N.m (96.6 lb.ft)
M14	110 N.m (81.1 lb.ft)	123 N.m (90.7 lb.ft)	156 N.m (115 lb.ft)	174 N.m (128.3 lb.ft)	187 N.m (138 lb.ft)	208 N.m (153.4 lb.ft)
M16	169 N.m (124.6 lb.ft)	190 N.m (140.1 lb.ft)	240 N.m (177 lb.ft)	270 N.m (200 lb.ft)	290 N.m (213.9 lb.ft)	320 N.m (236.01 lb.ft)
M20	330 N.m (243.4 lb.ft)	370 N.m (272.9 lb.ft)	470 N.m (346.6 lb.ft)	520 N.m (383.5 lb.ft)	560 N.m (413.03 lb.ft)	620 N.m (457.28 lb.ft)
M22	446 N.m (329 lb.ft)	497 N.m (366.5 lb.ft)	626 N.m (461.7 lb.ft)	699 N.m (515.5 lb.ft)	752 N.m (554.6 lb.ft)	839 N.m (618.8 lb.ft)
M24	570 N.m (420.4 lb.ft)	640 N.m (472 lb.ft)	800 N.m (590 lb.ft)	900 N.m (663.8 lb.ft)	960 N.m (708.05 lb.ft)	1,080 N.m (796.5 lb.ft)
M30	1,130 N.m (833.5 lb.ft)	1,260 N.m (929.3 lb.ft)	1,580 N.m (1,165.3 lb.ft)	1,770 N.m (1,305.5 lb.ft)	1,900 N.m (1,401.3 lb.ft)	2,100 N.m (1548.8 lb.ft)

Torque (cont.)

METRIC COARSE THREAD, ZINC- TREATED (Dacromet/GEOMET)	STRENGTH CLASS			
	10.9 oiled	10.9 dry	12.9 oiled	12.9 dry
M6	12 N.m (8.8 lb.ft)	15 N.m (11.06 lb.ft)	14.6 N.m (10.7 lb.ft)	18.3 N.m (13.4 lb.ft)
M8	28 N.m (20.6 lb.ft)	36 N.m (26.5 lb.ft)	34 N.m (25.07 lb.ft)	43 N.m (31.7 lb.ft)
M10	56 N.m (41.3 lb.ft)	70 N.m (51.6 lb.ft)	68 N.m (50.1 lb.ft)	86 N.m (63.4 lb.ft)
M12	98 N.m (72.2 lb.ft)	124 N.m (91.4 lb.ft)	117 N.m (86.3 lb.ft)	147 N.m (108.4 lb.ft)
M14	156 N.m (115 lb.ft)	196 N.m (144.5 lb.ft)	187 N.m (138 lb.ft)	234 N.m (172.5 lb.ft)
M16	240 N.m (177 lb.ft)	304 N.m (224.2 lb.ft)	290 N.m (213.9 lb.ft)	360 N.m (265.5 lb.ft)
M20	470 N.m (346.6 lb.ft)	585 N.m (431.4 lb.ft)	560 N.m (413.03 lb.ft)	698 N.m (514.8 lb.ft)
M22	626 N.m (461.7 lb.ft)	786 N.m (579.7 lb.ft)	752 N.m (554.6 lb.ft)	944 N.m (696.2 lb.ft)
M24	800 N.m (590 lb.ft)	1,010 N.m (744.9 lb.ft)	960 N.m (708.05 lb.ft)	1,215 N.m (896.1 lb.ft)
M30	1,580 N.m (1,165.3 lb.ft)	1,990 N.m (1,467, 7 lb.ft)	1,900 N.m (1,401.3 lb.ft)	2,360 N.m (1,740.6 lb.ft)

Wheel bolts

Bolt dimensions	M20 (PN 4700792683)
Strength class	10.9
Torque	Oiled: 494 N.m (364.5 lb.ft)
	Dry: 620 N.m (457.2 lb.ft)

Hydraulic system

OPENING PRESSURE		
Steering system	160 BAR	2,320 PSI
Transmission system	330 BAR	4,786 PSI
Supply system	2 BAR	29 PSI
Brake release	19 BAR	275 PSI

Specifications (cont.)

Air conditioning (option)

The system described in this manual is the ACC (Automatic Climate Control), that is, a system which maintains the set temperature in the cab provided that all the windows and doors are kept closed.

Coolant designation: HFC-R134:A

Coolant weight when full: 1,000 g (2.2 lb).

Engines

ENGINE	
Manufacturer and model	Cummins QSB 4.5 TIER III and QSF 3.8 TIER IV
Power (SAE J1995)	110/130 HP (82/97 kW) @ 2,200 rpm

Lamps (when installed)

LAMPS (POWER - FITTING)	
Drive lights, front	75/70 W - P43t (H4)
Front lights	21 W – BA15s
Side lights	5 W – SV8.5
Brake-position lights	21/5 W – BAY15d
Rear lights	21 W – BA15s
License plate lights	5 W – SV8.5
Working lights	70 W – PK22s (H3) 35 W – Xenon
Cab lights	10 W – SV8.5

Maintenance and lubrication points

Maintenance and lubrication points

Read carefully this manual section before carrying out any maintenance or lubrication on the machine.

Always check the areas around and under the equipment. It is an easy way to detect earlier leakages and possible damages.




Fig. Service and lubrication points.

- | | | |
|----------------------------|-------------------------|--------------------------|
| 1. Engine oil | 9. Coolant | 17. Cab air filter |
| 2. Oil filter | 10. Engine air filter | 18. Cab air conditioning |
| 3. Fuel filter | 11. Fuel supply | 19. Edge cutter |
| 4. Hydraulic oil filter | 12. Scrapers | 20. Lower pivot bearing |
| 5. Hydraulic oil level | 13. Water supply system | 21. Upper pivot bearing |
| 6. Hydraulic oil supply | 14. Sprinkling system | 22. Pivot bearing |
| 7. Hydraulic oil reservoir | 15. Seat bearing | 23. Wheel gear |
| 8. Hydraulic oil cooler | 16. Battery | |

Scheduled maintenance and lubrication

Scheduled maintenance and lubrication

Maintenance and lubrication procedures

The maintenance and lubrication shall be carried out first based on the working hours. When they cannot be considered, use the periods, like daily, weekly, etc.



Always clean around the covers, plugs, grease nipples or hoods before open or apply grease to them.



Respect and follow the engine manufacturer instructions. For further information, refer to the Engine Manual.

DAILY (Every 10 hours of operation)

POSITION IN THE FIGURE	ACTION	NOTES
Before starting the engine		
1	Check the Diesel engine oil level	Refer to the engine manual instructions.
9	Check engine coolant level	Refer to the engine manual instructions
5	Check the hydraulic oil level	
11	Fill the fuel tank	
13	Fill the water tanks	
14	Check the sprinkler system	
14	Clean the sprinkler injector	
12	Adjust the scrapers	
-	Check the brakes oil level	
-	Clean the pre-filter	
-	Check the alternator belt tension	Refer to the engine manual instructions.
-	Check the DEF level	Refer to the engine manual instructions.
-	Drain the fuel filter	Refer to the engine manual instructions.

Scheduled maintenance and lubrication

WEEKLY (after the first 50 hours of operation)

POSITION IN THE FIGURE	ACTION	NOTES
4	Replace the hydraulic oil filters	
20	Lubricate the lower pivot bearing	
21	Lubricate the upper pivot bearing	
23	Replace the wheel gear oil	

WEEKLY (Every 50 hours of operation)

POSITION IN THE FIGURE	ACTION	NOTES
-	Check the engine air intake system	Refer to the engine manual instructions.
-	Check the tires air pressure	
-	Retighten the wheel nuts	
10	Check and clean the engine air filter elements	Replace them, if necessary
-	Drain the fuel pre-filter	Refer to the engine manual instructions.
18	Check the air conditioning	When equipped (option)
-	Clean the air conditioning	
19	Check and lubricate the edge cutter	When equipped (option)
20	Lubricate the lower pivot bearing	
21	Lubricate the upper pivot bearing	

MONTHLY (Every 250 hours of operation)

POSITION IN THE FIGURE	ACTION	NOTES
1, 2	Check the charge-air cooler	Refer to the engine manual instructions.
8	Check and clean the hydraulic and Diesel engine water coolers	If necessary
18	Check the air conditioning	When equipped (option)
16	Check the batteries	
	Lubricate the pilot and link bearings	
20	Lubricate the lower pivot bearing	
21	Lubricate the upper pivot bearing	
	Replace air dryer filter	Machine equipped with AOR

Scheduled maintenance and lubrication

EVERY THREE MONTHS (Every 500 hours of operation)

POSITION IN THE FIGURE	ACTION	NOTES
-	Replace filter and engine oil	Refer to the engine manual instructions.
-	Check the engine Colling fan belt tensioner	Refer to the engine manual instructions.
-	Check the bolted joints	
7	Check the hydraulic oil tank cover	
15	Lubricate the seat bearing	
20	Lubricate the lower pivot bearing	
21	Lubricate the upper pivot bearing	
22	Lubricate the pivot bearing	
	Replace air dryer filter	Machine equipped with AOR

EVERY SIX MONTHS (Every 1,000 hours of operation)

POSITION IN THE FIGURE	ACTION	NOTES
-	Check the Diesel engine Fan Hub, Belt Driven	Refer to the engine manual instructions.
3	Replace the Diesel engine fuel filter	Refer to the engine manual instructions.
-	Replace the Diesel engine pre-filter	Refer to the engine manual instructions.
-	Check the Radiator pressure cap	Refer to the engine manual instructions.
10	Replace the main and the secondary air filters	
	Replace air dryer filter	Machine equipped with AOR
4	Replace the hydraulic oil filters	
17	Replace the cab air filter	
20	Lubricate the lower pivot bearing	
21	Lubricate the upper pivot bearing	
23	Replace the wheel gear oil	
23	Check the wheel gear oil level	

ANNUALLY (Every 2,000 hours of operation)

POSITION IN THE FIGURE	ACTION	NOTES
-	Check the Diesel engine Fan Hub, Belt Driven	Refer to the engine manual instructions.
3	Replace the Diesel engine fuel filter	Refer to the engine manual instructions.
-	Replace the Diesel engine pre-filter	Refer to the engine manual instructions.
-	Check the Radiator pressure cap	Refer to the engine manual instructions.
6	Replace the hydraulic oil	
11	Clean the fuel tank	
13	Clean the water tank	
14	Clean the sprinkler system	
-	Check the pilot bearings	
9	Replace the coolant	Refer to the engine manual instructions.
-	Check the air conditioning	When equipped (option)
20	Lubricate the lower pivot bearing	
21	Lubricate the upper pivot bearing	

Daily (Every 10 hours of operation)



Park the roller on a level surface.



When checking and adjusting the machine, always turn off the engine and make sure the forward/backward lever is in the neutral position.



When the engine is on in enclosed places, make sure there is a good ventilation, to prevent carbon monoxide poisoning.

Check the Diesel engine oil level




Fig. – Engine compartment

- 1. Oil filling plug
- 2. Oil dipstick

The oil dipstick is under the oil filling plug (1), on the left side of the engine.



Be careful with hot engine parts and also with the cooler when removing the oil dipstick. There is risk of burns.

1. Remove the dipstick (2) and check if the oil level is between the upper and lower parts. For further information, refer to the Engine Manual instructions.

Check the engine coolant




Fig. - Expansion tank

- 1. Bolts
- 2. Protective plate
- 3. Expansion tank

The expansion tank is placed in the center, between the operator platform and the engine compartment. To access the expansion tank (3), remove both retaining bolts (1) and also the protective plate (2).

Check if the coolant level is between the MAX and MIN marks in the expansion tank (3). If necessary, remove the tank hood and fill the level.



NEVER open the expansion tank cap if the engine is still hot and always use protective gloves and goggles.

When filling with coolant, always use a mixed solution with 50% of water and 50% of additive. Refer to the lubricant specifications in this manual and in the engine instructions manual.

Check the hydraulic oil level




Fig. - Hydraulic oil reservoir
 1. Oil sight glass
 2. Filling plug

1. Park the roller on a level ground and turn off the engine.
2. Check the hydraulic oil reservoir sight glass (1) located on the right side of the machine.
3. If the oil level is 2 cm below the glass upper line, fill with the recommended hydraulic oil.



Use only hydraulic oil recommended by **DYNAPAC**.

Filling the fuel tank



Never fill the engine when it is working. Do not smoke and avoid spilling fuel.




Fig. - Fuel tank
 1. Tank cap
 2. Filling pipe

The filling nozzle and the tank cap are in the front of the operator platform, in the left side of the machine.

Check the fuel tank daily before starting the operation or fuel the tank when the work is done.

Unscrew the tank cap (1) and check up to the lower edge of the filler pipe.

The tank capacity is of 58 gal (220 liters) of fuel. For further information about the fuel grade, refer to the Engine Manual.



Before filling, stop the machine on a safe place with level surface, turn off the engine and ground the filling pipe, putting it in contact with the frame in a non-insulated place.



When filling, keep the pump nozzle in contact with the filling pipe. Always use fuel recommended by DYNAPAC.



Using adulterated, contaminated, dirty or bad quality fuel damages the injection system and engine components.

The repairs due to the conditions above are NOT covered by the warranty.

Fill the water tanks




Fig. - Filling the water tanks
1. Caps

There are two filling caps above the water tank (1).



Unscrew the tank cap and fill with clean water. Do not replace the filter.

1. Fill the tank; it holds 110 gal. (415 liters).



Only recommended additive: small quantity of environmentally-friendly antifreeze.

Check the sprinkler system

Fill the tank with emulsion fluid, e.g. water mixed with 2% of cutting fluid.

Check if the sprinkler injectors (3) are not blocked, and if necessary, clean them, as well as the filter.



Check periodically if there is excessive wear on the roller tires.



Do not add flammable fluids or those which are hazardous to the environment in the emulsion tank.

Clean the sprinkler injector

Dismantle the blocked nozzle by hand (1).

Use compressed air to clean the nozzle (1) and the strainer (2). It is also possible to use the spare parts and to clean the blocked ones later on.




Fig.- Sprinkler injector
1. Nozzle
2. Strainer
3. Sprinkler injector assembly

NOZZLE	COLOR	Ø (mm)	l/min (2.0 bar)	gal./min (40 PSI)
Standard	Yellow	0.8	0.63	0.20
Option	Blue	1	1	0.31
Option	Red	1.2	1.25	0.39
Option	Brown	1.3	1.63	0.50

After checking and cleaning, turn on the system and inspect if it is working correctly.



Use protective goggles when working with compressed air.

Adjust the scrapers

Make sure the scrapers and tires are in good operation conditions, otherwise, replace them.

If the scraper's wear is uneven, unscrew the adjusting bolt (3) in the back of the scraper attachment.

Pull down the blade (1) until it is leveled with the tire. After the adjustment, tighten the screws again (3).




Fig. - Tire scrapers

- 1. Scraper blade
- 2. Scraper holder
- 3. Bolts

The scrapers shall be adjusted on the tires during the transport.

To do it, lift up the scraper blades (1) and make sure they are fixed at this position by the locking hooks (2).

To lower down the scrapers, raise the scraper blade (1) firmly while pressing the locking hook (2).




Fig. - Tire scrapers

- 1. Scraper blade
- 2. Locking hook

The scrapers can be easily removed for cleaning and inspection.

1. First, fix the scraper in the locking hook (3) at the scraper attachment (4) to prevent the scraper to fall onto the ground.
2. Remove the pin (1) on the hook axle removing the hairpins (2) on both sides of the pin. Grip the hook axle up and pull it straight out.




Fig. - Tire scrapers

- 1. Pin
- 2. Hairpins
- 3. Locking hook
- 4. Attachment

To put the scraper back after the inspection, it shall be initially fit on the locking hook before the up hook is fitted in the right position.

Refit the pin (3) in the right position and make sure it is well secured by the attachment (4).

Check the brakes oil level




Fig. - Brakes oil tank

- 1. Oil tank
- 2. Filling plug

Check daily if the oil level is within the max. and min. marks.

Open the brakes oil tank (1) under the plastic cap, on the right side of the steering column.

Next, fill with hydraulic oil up to the tank's maximum level, if it is under the min. mark.

Clean the coarse filter

The coarse filter is inside the frame' upper compartment, on the right side of the machine.

To clean the coarse filter (1), open the drain cock (2) of the filter and let the dirt run out.

If necessary, close the cock (3) and clean the filter and its housing. Check if the rubber gasket of the filter housing is in intact.

After the cleaning and inspection, put again all the components on their right places and start the system to check if it works correctly.

Another drain cock (5) is under the water tank, on the left side of the front of the frame. It can be used to drain the water tank and the pumping system.

It is also possible to install an extra pump if the standard fails to work.

To drain the complete sprinkler system, refer to "Draining the sprinkler system", in the section "Maintenance - Every 2,000 hours".




Fig. – Pump system, front frame, right side

- 1. Coarse filter
- 2. Drain cock
- 3. Cock
- 4. Water pump
- 5. Extra cock

Check the alternator belt tension

Use the pressure or Burroughs type gauge to check the belt tension.


- The new belt tension shall be 200 lb (890 N).
- The old belt tension shall be 80 – 160 lb (360 – 710 N).

NOTE: The belt is considered used after 10 or more minutes of use.

NOTE: This procedure is not applied in belt automatic tensioners.



If the used belt tension is under the minimum value, tighten it to the maximum allowed value for used belts.



Drain the fuel filter

To drain the fuel filter, follow the instructions below:

1. Unscrew the drain plug (1), in the bottom of the filter.
2. With the hand-operated secondary pump (2), make sure all the sediments were removed. For further information, refer to the Engine Manual instructions.
3. When only clean fuel is coming out of the filter, close the drain plug.




Fig. – Fuel tank

1. Drain plug

2. Hand-operated pump



TAKE CARE OF THE ENVIRONMENT: All the used oil shall be properly stored for subsequent disposal. Do not dispose of oil on the ground, sewage system or other place which can harm the environment.

Weekly (Every 50 hours of operation)



Park the roller on a level surface.



When checking and adjusting the machine, always turn off the engine and make sure the forward/backward lever is in the neutral position.



When the engine is on in enclosed places, make sure there is a good ventilation, to prevent carbon monoxide poisoning.

Replace the Diesel engine oil

The engine oil drain plug is on the rear of the machine, in the right side. Its access can be found when opening the panel in front of the exhaust duct.

Drain the oil when the engine is still hot and put a container with minimum capacity of 3.69 gal (14 liters) under the plug.



Be extremely careful when draining the oil. Use gloves and protective goggles to prevent the hot oil getting in contact with the skin, which can cause burns.




Fig. - Drain plugs

1. Hexagon nut

2. Hose

3. Drain plug

1. Remove the hexagon nut (1), take off the hose (2) and loose the oil drain plug (3).
2. Let all the oil come out to the container and when the operation is done, fix the drain plug (3) back to its place and fit the hose (2) back again.
3. Next, tighten the hexagon nut.



TAKE CARE OF THE ENVIRONMENT: All the used oil shall be properly stored for subsequent disposal. Do not dispose of oil on the ground, sewage system or other place which can harm the environment.

Always fill with new oil. For correct grade oil information, refer to the Lubricant specifications or the Engine Manual Instructions. Fill according to the oil volume necessary to the engine. Check the dipstick to know if the volume is correct and before carrying out the operation, let the engine in idle for a few minutes and turn it off.

Replace the Diesel engine oil filter




Fig. – Engine compartment
1. Oil filter



Never perform any maintenance work under the machine while the engine is still operating. Always park the roller on a flat and safe place and chock the tires.

The oil filter (1) is on the right side of the engine compartment.

Refer to the Engine Instructions Manual to obtain information about the oil filter replacement.

Check and replace the main air filter



Replace the main filter element when the corresponding warning light on the instrument panel comes on and the engine is in the maximum speed.




Fig. – Air filter
1. Clamps
2. Locking hook
3. Main filter
4. Backup filter
5. Filter housing
6. Dust valve

1. Release the clamps (1), take off the cap (2) and the main filter (3). Do not take off the backup filter (4).
2. If necessary, clean the air filter, according to this page instructions.
3. When replacing the main filter (3), put a new one in its place and fit back all the air filter components in the reverse order.
4. Check if the dust valve (6) is in good conditions and replace it, if necessary.
5. When fitting the cap, make sure the dust valve is positioned downwards.

To clean the air filter, follow the instructions below:




Fig.
Inside the
outlet pipe

Outside the
outlet pipe

1. Wipe inside the cap and the filter housing.
2. Wipe also both outlet pipe surfaces, as shown in figure.



Check if the hoses clamps between the filter housing and the intake hose are tighten and if the hoses are intact. Check the entire hose system, all the way to the engine.

Check and replace the secondary air filter



Replace the backup filter when the main air filter is replaced for the third time.

To replace the backup filter for a new one, follow the instructions below:

1. Remove the old backup filter (1) from the holder, install a new one and fit the components back in the reverse order.
2. Clean the main filter, if necessary.




Fig. – Air filter
1. Backup filter

Replace the engine fuel filter

The fuel filter is located in front of the accumulators, on the left side of the engine compartment.

1. Unscrew the bottom of the filter and drain the water. Next, screw the unit back in its place.
2. Fit the fuel filter in the correct place, turn on the engine and check if the filter is well sealed.




Fig. – Engine compartment
1. Filter

Replace the hydraulic oil filters

The hydraulic filters are located on the left side of the engine compartment, behind the battery disconnecter.



TAKE CARE OF THE ENVIRONMENT: All the used oil shall be properly stored for subsequent disposal. Do not dispose of oil on the ground, sewage system or other place which can harm the environment. The filter is disposable and cannot be cleaned.




Fig. - Hydraulic oil tank
 1. Tank cap
 2. Sight glass

1. Open the hydraulic oil tank cap (1).
2. Clean carefully the sealed surface on the filter holder.
3. Apply a thin layer of clean hydraulic oil on the rubber gasket of the new filter.
4. Fit manually the filter, first until the filter gasket manages to reach the holder. Next, tighten it with one more turn.
5. Check the hydraulic oil level on the sight glass (2) and adjust, if necessary. Refer to the section "Every 10 Hours" to obtain further information.
6. Turn on the engine and check if the filter is well sealed.

Check the tires air pressure

To check the pressure, use an air pressure gauge. The pressure in all the tires must be the same.

To know the recommended pressure values, refer to the "Technical Specifications" section.



When replacing the tires, it is important that all of them have the same original diameter and width, otherwise they can slide into the wheel or make their installation impossible.




Fig. - External/internal wheels
 1. Air valve

Lubricate the upper/lower pivot bearing




Fig. - Pivot bearings

1. Upper pivot bearing grease fitting
2. Lower pivot bearing grease fitting

1. Lubricate the grease fitting of the upper pivot bearing (1) and the grease fitting of the lower pivot bearing (2) by operating the grease gun manually with five pump strokes.
2. Use the grease according to the lubricant specifications recommended by **DYNAPAC**.

Replace the wheel gear oil



Be extremely careful when draining the oil. Use gloves and protective goggles to prevent the hot oil getting in contact with the skin, which can cause burns.




Fig. - Wheel gear

1. Drain plug
2. Filling plug

1. Unscrew the drain plug (1).
2. Put a container with 5.28 gal (20 liters) of capacity under the drain plug.
3. Unscrew the drain plug (1) and the filling plug (2) to evacuate the air. Allow all the oil to drain out to the container and refit the plugs.



TAKE CARE OF THE ENVIRONMENT: All the used oil shall be properly stored for subsequent disposal. Do not dispose of oil on the ground, sewage system or other place which can harm the environment.

Check the air conditioning (if equipped)




Fig. – Drying filter

- 1. Sight glass
- 2. Filter holder
- 3. Condenser



Park the roller on a level surface.



When checking and adjusting the machine, always turn off the engine and make sure the forward/backward lever is in the "P" position.

With the machine working and with the aid of the sight glass (1), check if there are no visible bubbles on the drying filter.

The filter is located on the upper rear part, on the cab's roof. If there are visible bubbles, it indicates that the coolant level is too low. Turn off the air conditioning to prevent damages and fill it with coolant.

Clean the air conditioning

If there is a significant loss of cooling capacity, clean the condenser element (3), located on the rear of the cab's roof.

Check and lubricate the edge cutter (if equipped)



Refer to the Operation section to obtain more information about how to work with an edge cutter.

Lubricate both points indicated in the figure.

Recommended grease shall be used to lubricate it.

Lubricate all the pivot points, with 5 grease gun applications each.




Fig. - Edge cutter

- 1. Lubricating point
- 2. Lubricating point

Monthly (Every 250 hours of operation)



Park the roller on a level surface.



When checking and adjusting the machine, always turn off the engine and make sure the forward/backward lever is in the neutral position.



When the engine is on in enclosed places, make sure there is a good ventilation, to prevent carbon monoxide poisoning.

Replace the Diesel engine oil

The engine oil drain plug is on the rear of the machine, in the right side. Its access can be found when opening the panel in front of the exhaustion duct.

Drain the oil when the engine is still hot and put a container with minimum capacity of 3.69 gal (14 liters) under the plug.



Be extremely careful when draining the oil. Use gloves and protective goggles to prevent the hot oil getting in contact with the skin, which can cause burns.




Fig. - Drain plugs
 1. Hexagon nut
 2. Hose
 3. Drain plug

1. Remove the hexagon nut (1), take off the hose (2) and loose the oil drain plug (3).
2. Let all the oil come out to the container and when the operation is done, fix the drain plug (3) back to its place and fit the hose (2) back again.
3. Next, tighten the hexagon nut.



TAKE CARE OF THE ENVIRONMENT: All the used oil shall be properly stored for subsequent disposal. Do not dispose of oil on the ground, sewage system or other place which can harm the environment.

Always fill with new oil. For correct grade oil information, refer to the Lubricant specifications or the Engine Manual Instructions. Fill according to the oil volume necessary to the engine. Check the dipstick to know if the volume is correct and before carrying out the operation, let the engine in idle for a few minutes and turn it off.

Replace the Diesel engine oil filter



Never perform any maintenance work under the machine while the engine is still operating. Always park the roller on a flat and safe place and chock the tires.

The oil filter (1) is on the right side of the engine compartment.

Refer to the Engine Instructions Manual to obtain information about the oil filter replacement.




Fig. – Engine compartment
 1. Oil filter

Check and clean the hydraulic and Diesel engine water coolers.

1. Make sure the air flow through the coolers is unobstructed. If the cores are dirty, wash them with flowing water (with the engine cold) and blow them with compressed air.



When using compressed air, always use protective goggles.



Whenever possible, clean the cores on the opposite direction to the fan air flow. Every time you clean the core, cover the electric and electronic components.




Fig. - Coolers
 1. Recharge air cooler
 2. Water cooler
 3. Hydraulic oil cooler
 4. Cooler grid

Check the air conditioning (if equipped)

Check the coolant hoses and connections and make sure there is no sign of oil. If there is oil, maybe there is a possible leakage as well.




Fig. - Air conditioning
 1. Coolant hoses
 2. Condenser element

Check the batteries



When checking the batteries, never smoke or allow sparks or flame next to them. Usually the batteries produce explosive gases which can cause severe injuries.

The batteries are sealed and maintenance-free.



Never use open flames when checking the electrolyte level. When the alternator is being charged, an explosive gas is formed in the battery.



When removing the battery, first remove the negative pole (-). But when installing it, connect first the positive pole (+). Avoid the contact of both battery posts with metallic tools or the accidental contact between the positive post with the machine's frame, otherwise short circuits can happen.

1. Open the right cap of the equipment, where the batteries are located.
2. Clean the external caps of the batteries.




When working with batteries, protect your face and eyes using the proper equipment for individual protection and always provide the proper ventilation as well.

3. Take off the cell caps and check the electrolyte level, which must be at least 10mm above the plates. If necessary, fill the level with the battery fluid solution. If the operation room temperature is below 32 F (0°C), allow the engine to work for a few minutes after the level is filled, otherwise the solution may freeze.
4. Check if the cell cap breather is not obstructed, and clean it, if necessary.
5. The battery posts must be kept clean and the contacts must have their cables tightened. If they are oxidized, clean them with a solution of water and sodium bicarbonate and apply a layer of petroleum jelly to prevent a new corrosion process.



TAKE CARE OF THE ENVIRONMENT: Return the used battery, according to the CONAMA 257/99 (06/30/1999) resolution. Every client or final user has the obligation to return the used battery to a sales point.

Lubricate the upper/lower pivot bearing



1. Lubricate the grease fitting of the upper pivot bearing (1) and the grease fitting of the lower pivot bearing (2) operating the grease gun manually with five pump strokes.
2. Use the grease according to the lubricant specifications recommended by **DYNAPAC**.

Fig. - Pivot bearings

1. Upper pivot bearing grease fitting
2. Lower pivot bearing grease fitting

Quarterly (Every 500 hours of operation)



Park the roller on a level surface.



When checking and adjusting the machine, always turn off the engine and make sure the forward/backward lever is in the neutral position.



When the engine is on in enclosed places, make sure there is a good ventilation, to prevent carbon monoxide poisoning.

Replace the engine fuel filter

The fuel filter is located in front of the accumulators, on the left side of the engine compartment.

1. Unscrew the bottom of the filter and drain the water. Next, screw the unit back in its place.
2. Fit the fuel filter in the correct place, turn on the engine and check if the filter is well sealed.




Fig. – Engine compartment
1. Filter

Replace the air dryer filter

To replace the filter, empty the compressed air and unscrew the cartridge with suitable tool.

Clean and grease the sealing surfaces and the fixing screw. Manually screw the cartridge until there is resistance, and tighten half turn.




Fig. – Air dryer filter
1. Cartridge

Check the hydraulic oil tank cover

To check the hydraulic oil tank cap:




Fig. - Left side of the frame
1. Tank cap

1. Unscrew the tank cap and check if it's obstructed. The air must flow freely throughout the cap in both ways.
2. If one way is obstructed, wash the filter with a small portion of Diesel oil and use compressed air until the obstruction is eliminated or replace the cap for a new one.



Always use protective goggles when working with compressed air.

Lubricate the seat bearing



Keep in mind that the chain is a vital part of the steering mechanism.

To lubricate the seat bearing:




Fig. - Seat bearing
1. Locking hook
2. Grease fitting
3. Steering column chain
4. Slide rails
5. Sprocket wheel
6. Adjusting bolt
7. Marking

1. Remove the cap (1) to access the grease fitting (2). Lubricate the operator's seat rotation bearing with three strokes of a hand-operated grease gun.
2. Clean and lubricate the chain (3) with grease between the seat and the steering column.
3. Also lubricate the slide rails (4) of the seat with grease.
4. If the chain gap is next to the sprocket wheel (5), loose the bolts (6) and move the steering column forward. Tighten the bolts and check if the chain is with the proper gap.
5. Do not tension the chain too tightly. It should be possible to move the chain about 0.4 inches (10 mm) to the side with a forefinger/thumb at the marking (7) in the seat frame. Fit the chain lock at the bottom.



If it is hard to move the seat, lubricate it more frequently than the instructions specified in this manual.

Lubricate the upper/lower pivot bearing




Fig. - Pivot bearings

1. Upper pivot bearing grease fitting
2. Lower pivot bearing grease fitting

1. Lubricate the grease fitting of the upper pivot bearing (1) and the grease fitting of the lower pivot bearing (2) operating the grease gun manually with five pump strokes.
2. Use the grease according to the lubricant specifications recommended by **DYNAPAC**.

Lubricate the pivot bearing




Fig. - Rear cylinder

1. Grease fittings

1. Lubricate each grease fitting (1) with five hand-operated strokes.
2. Use the grease according to the lubricant specifications recommended by **DYNAPAC**.

Replace the air dryer filter




Fig. - Air dryer filter
1. Cartridge

To replace the filter, empty the compressed air and unscrew the cartridge with suitable tool.
Clean and grease the sealing surfaces and the fixing screw.
Manually screw the cartridge until there is resistance, and tighten half turn.

Semiannually (Every 1,000 hours of operation)



Park the roller on a level surface.



When checking and adjusting the machine, always turn off the engine and make sure the forward/backward lever is in the neutral position.



When the engine is on in enclosed places, make sure there is a good ventilation, to prevent carbon monoxide poisoning.

Replace the main air filter




Fig. – Air filter
1. Main filter

Replace the air filter (1) every 1,000 hours of operation, even if it was not cleaned 5 times. For further information about the filter's replacement, refer to the "Maintenance - Every 50 Hours of Operation" section.



If the filter is not replaced when it is obstructed, the engine will lose power and the exhaust will let the smoke black, besides the risks of damaging the engine.

Replace the secondary air filter




Fig. – Air filter
1. Secondary filter

Replace the secondary air filter for a new one when you clean or replace the main filter for the fifth time. The secondary air filter shall not be cleaned.

To replace it for a new one, follow the instructions below:

1. Remove the old secondary filter (1) from the holder, install a new one and fix the components in the reverse order used to remove them.

Replace the air dryer filter




Fig. – Air dryer filter
1. Cartridge

To replace the filter, empty the compressed air and unscrew the cartridge with suitable tool.

Clean and grease the sealing surfaces and the fixing screw. Manually screw the cartridge until there is resistance, and tighten half turn.

Replace the hydraulic oil filters

The hydraulic filters are located on the left side of the engine compartment, behind the battery switch.



TAKE CARE OF THE ENVIRONMENT: All the used oil shall be properly stored for subsequent disposal. Do not dispose of oil on the ground, sewage system or other place which can harm the environment. The filter is disposable and cannot be cleaned.




Fig. - Hydraulic oil tank

- 1. Tank cap
- 2. Sight glass

1. Open the hydraulic oil tank cap (1).
2. Clean carefully the sealed surface on the filter holder.
3. Apply a thin layer of clean hydraulic oil on the rubber gasket of the new filter.
4. Fit manually the filter, first until the filter gasket manages to reach the holder. Next, tighten it with one more turn.
5. Check the hydraulic oil level on the sight glass (2) and adjust, if necessary. Refer to the section "Every 10 Hours" to obtain further information.
6. Turn on the engine and check if the filter is well sealed.

Replace the cab air filter

There is an air filter (1) on the left side of the cab. To replace it, follow the instructions below:




Fig. - Front of the cab.

- 1. Air filter (1x)
- 2. Bolt (2x)

1. Open the protective cap.
2. Unscrew the bolts (2) and remove the entire holder. Remove the filter element and replace the filter for the new one.
3. If the machine works in places with excessive dust, it may be necessary to replace the filter more frequently.

Lubricate the upper/lower pivot bearing




Fig. - Pivot bearings

1. Upper pivot bearing grease fitting
2. Lower pivot bearing grease fitting

1. Lubricate the grease fitting of the upper pivot bearing (1) and the grease fitting of the lower pivot bearing (2) operating the grease gun manually with five pump strokes.
2. Use the grease according to the lubricant specifications recommended by **DYNAPAC**.

Replace the wheel gear oil



Be extremely careful when draining the oil. Use gloves and protective goggles to prevent the hot oil getting in contact with the skin, which can cause burns.




Fig. - Wheel gear

1. Drain plug
2. Filling plug



TAKE CARE OF THE ENVIRONMENT: All the used oil shall be properly stored for subsequent disposal. Do not dispose of oil on the ground, sewage system or other place which can harm the environment.

1. Unscrew the drain plug (1).
2. Put a container with 5.28 gal (20 liters) of capacity under the drain plug.
3. Unscrew the drain plug (1) and the filling plug (2) to evacuate the air. Allow all the oil to drain out to the container and refit the plugs.

Refill the wheel gear oil




Fig. - Refilling the wheel gear oil

1. Filling plug

2. Level plug

Drive the machine until the filling plug is in the right position. The opening must be a little above the horizontal position in order to make the filling easier.

Unscrew the filling plug (1) and also the level plug (2), so the air can be released. Apply the oil only from the external part of the gears.

Fill with 2.11 gal (8 liters) of new transmission oil. Refer to the manufacturer specifications.

Drive the machine until the level plug (2) is in the horizontal position.

Check if the oil level reaches the bottom of the plug opening.

Clean and fix the plugs again.

Check the wheel gear oil level

Drive the machine until the level plug (2) is in the horizontal position.

Clean the place around the level plug (2) and then unscrew it.

Check if the oil level reaches the bottom of the plug opening.

If the level is low, fill with new transmission oil until it reaches the correct level. Refer to the lubricant specifications.

Clean and fix the plugs again.

Annually (Every 2,000 hours of operation)

Park the roller on a level surface.



When checking and adjusting the machine, always turn off the engine and make sure the forward/backward lever is in the neutral position.



When the engine is on in enclosed places, make sure there is a good ventilation, to prevent carbon monoxide poisoning.

Replace the hydraulic oil

Be extremely careful when draining the oil. Use gloves and protective goggles to prevent the hot oil getting in contact with the skin, which can cause burns.

To replace the hydraulic tank oil, follow the instructions below:




Fig. - Battery cap
1. Drain cock
2. Plug

1. Park the roller on a level surface and turn off the engine.
2. Use a container with the proper capacity to drain the hydraulic circuit tank (13.20 gal or 50 liters).
3. Remove the battery cap in front of the wheel rears, on the left side of the frame. There is a drain cock (1) and a plug (2) on the right side, inside the frame.
4. Remove the hose connected to the drain plug and remove the plug from the hose edge, then, open the cock.
5. Drain totally the oil. Fill the plug again with new oil and close the drain cock.



TAKE CARE OF THE ENVIRONMENT: All the used oil shall be properly stored for subsequent disposal. Do not dispose of oil on the ground, sewage system or other place which can harm the environment.

Clean the fuel tank



NEVER perform maintenance work under the machine when the engine is working. Always park the roller on a flat and safe place and chock the tires.

The fastest and simple way to clean the tank is when it is empty:

1. Open the filling cap (1) of the fuel tank.




Fig. – Fuel tank
1. Filling cap




Fig. – Fuel tank draining
2. Plug

2. Place two proper containers under the drain plug of the fuel tank (2).



The drain plug of the fuel tank is on the right side of the machine, in a proper compartment.

3. Unscrew the drain plug (2) and drain the remaining fuel inside the tank.
4. Refit the drain plug and tighten it.



Using adulterated, contaminated, dirty or bad quality fuel damages the injection system and engine components. The repairs due to the conditions above are NOT covered by the warranty.



TAKE CARE OF THE ENVIRONMENT: All the used waste shall be properly stored for subsequent recycling. Do not dispose of any waste on the ground, sewage system or other place which can harm the environment.



Be extremely careful when handling fuel. There is risk of fire.

Clean the water tank

Wash the water tank adding a small quantity of a suitable detergent for plastic surfaces.

Close the drain cock (1), fill with water and check if there are leakages.




Fig. - Water tank
1. Drain cock



The water tank is made of plastic (polyethylene) and can be recycled.

Clean the sprinkler system



Keep in mind there are risks of freezing components during a cold weather. Empty the tanks, compartments, filters and tubes during such period or mixed fluid with water and antifreeze.

The coarse filter is inside the frame's upper compartment, on the right side of the machine.

The filter housing (1) contains a drain cock (2) on the pumping system, in the water tank. The tank and pumping system parts can be drained through this cock.

The water hoses are connected to the pump with faster joints (3) to make the draining process easier. If necessary, replace the backup pump (if installed).




Fig. - Pump system
1. Filter housing
2. Closing cock
3. Fast joints

Replace the engine coolant



Caution! Risk of severe burns!
Wait until the engine temperature cools down to 122 F (50°C) before removing the coolant tank cap or draining the coolant system.

1. Open the expansion tank cap.



NEVER open the coolant tank cap when the engine is hot.

2. Drain the engine coolant system through the cooler valve drain.
3. Use a proper container to collect the coolant (with 3.69 gal or 14 liters of capacity).



Be careful when draining the product. Use gloves and protective goggles.




Fig. - Drain plugs

1. Hexagon nut
2. Hose
3. Drain plug



TAKE CARE OF THE ENVIRONMENT: All used coolant shall be properly collected and store for subsequent recycling. Do not dispose of the coolant on the ground, sewage system or other place which can harm the environment.

4. Unscrew the hexagon nut (1), remove the hose (2) and unscrew the drain plug (4). Drain all the fluid to the container.
5. After the replacement, tighten the drain plug (4) and fit back the hose and the hexagon nut (1).

Check the air conditioning (if equipped)



Park the roller on a level surface.



When checking and adjusting the machine, always turn off the engine and make sure the forward/backward lever is in the "P" position.

Use compressed air to clean the dust off the condenser element (1). Clean from upwards to downwards.



Do not use compressed air blows with too much power, otherwise the element fins can be damaged.



Always use protective goggles when working with compressed air.




Fig. - Cab
1. Condenser element
2. Drying filter

Check if the condenser element is well secured.

Also check if the system hoses are not in contact with other components.

Check if there are no draining obstructions on the coolant unit. There is a risk of condensation being accumulated inside the unit.

Check the air conditioning draining filter (if equipped)

With the roller operating, use the sight glass (1) to check if there are bubbles on the drying filter.

The filter is located on the upper rear of the cab's roof.

If there are visible bubbles, it means that the coolant level is too low. Turn off the machine to prevent damage and fill with coolant until it reaches the correct level.





Fig. - Drying filter
1. Sight glass
2. Filter holder



Only authorized people/companies can carry out works on the coolant circuit.

Lubricate the upper/lower pivot bearing




1. Lubricate the grease fitting of the upper pivot bearing (1) and the grease fitting of the lower pivot bearing (2) operating the grease gun manually with five pump strokes.
2. Use the grease according to the lubricant specifications recommended by **DYNAPAC**.

Fig. - Pivot bearings

1. *Upper pivot bearing grease fitting*
2. *Lower pivot bearing grease fitting*

Special instructions

Standard oil and fluid recommended	<p>When the roller leaves the plant, its several systems are filled with oil or fluid indicated on the item "Symbols and Lubricants", which are proper for operating in places with temperatures between 5 F and 104 F (-15°C and 40°C).</p> <p>The following recommendations are applied for operations in places with temperatures up to 104 F (40°C).</p>
Highest temperature, from 122F (50°C).	<p>The engine can work under this temperature using standard production oil, but for other components, use the following oils:</p> <p>Hydraulic system - mineral oil, Shell Tellus T100 or equivalent.</p>
Lowest temperature - risk of freezing	<p>To prevent the system freezing, make sure that the system has been drained (sprinkler system, tank(s), hoses) or that antifreezing solutions were applied.</p>
Temperatures	<p>The limit temperatures are valid for series rollers.</p> <p>The rollers with additional equipment, like noise level diminution equipment may need special attention when they are operated in high temperatures.</p>
High pressure washing	<p> It is important to keep in mind that the high pressure water must not be directed towards the fuel tank caps and the hydraulic system.</p> <p>Cover the filling nozzle caps with plastic and lock them with rubber bands. It prevents the water to penetrate into the cap vent hole, which may cause damage on the involved systems and obstructions in the filters.</p> <p>Never direct the high pressure water towards electric and electronic components or on the display (always keep them covered by covers or plastic).</p>
Fire extinguisher	<p>If there is fire on the equipment, use a dry fire extinguisher or ABC class carbon dioxide. It is also possible to use a CO₂ extinguisher (BE class).</p>
Roll Over Protective Structure (ROPS)	<p>NEVER weld or make holes on the ROPS.</p> <p>NEVER repair a ROPS. Always replace it for a new one.</p>

Battery handling	<p>When removing the batteries, always turn off the negative cable first.</p> <p>When mounting them, always turn on the positive cable first.</p> <p>Dispose of the used batteries in an environmentally-friendly way. They do not contain toxic lead.</p> <p>Never use fast charging in the battery. There is a risk of reducing its useful life.</p>
Jump starting (24V)	<p>Do not connect the negative cable to the negative pole in a dead battery. A spark may ignite a gas mixed combustion containing oxygen and hydrogen formed around the battery.</p> <p>Check if the battery used for the jumper starting and the dead battery have the same tension.</p> <p>Turn off the ignition key and all the power consuming equipment. Turn off the roller engine supplying power to the jump starting.</p> <p>The jump starting cables must have 24V.</p>
Auxiliary starting	<p>When using a booster battery besides the ones installed on the roller, always connect the positive post (+) of the booster battery to the positive post (+) of the installed battery, as well as the negative post (-) of the booster battery to the negative post (-) of the installed battery.</p> <p>Turn on the machine engine supplying power and let it work for a little while. Next, try to turn on the other machine. Then disconnect the cables in the reverse order.</p>

Electrical system

The machine's main control box (1) is located on the rear of the operator platform. There is a plastic cap over it and the fuses.

A 24V jack is available in the plastic cap.




Fig. - Main control box

- 1. ECU
- 2. Fuses
- 3. Main relay




Fig. - Battery compartment

- 1. Master switch
- 2. Main fuses panel

The fuses inside the engine compartment are located alongside the battery master switch.


The roller is equipped with a 24V electrical system, supplied by an AC alternator.



Connect the batteries to the correct polarities (negative posts to the mass). NEVER disconnect the cable between the battery and the alternator when the engine is operating.

Fuses


F1 fuse box:



1. Ignition key, main relay (5A)
2. Main ECU, I/O unit, screen (5A)
3. Main ECU, PWR 1 (10A)
4. Main ECU, PWR 2 (10A) - option
5. Main ECU, PWR 3 (20A)
6. Main ECU, PWR 4 (20A)
7. Jack, 24V (10A)
8. Transmission ECU (10A)

Fig. - F1 fuse box

F2 fuse box:



1. Air during the operation (5A)
2. Asphalt, (10A)
3. Backup
4. Backup
5. Backup
6. Backup
7. Driving lights (7.5A)
8. Driving lights, road, (20A)

Fig. - F2 fuse box

Cab fuse box




Fig. - Cab fuse box

1. Indoors lighting (10A)
2. Radio/CD player (10A)
3. Air conditioning (15A)
4. Heating (15A)
5. Windscreen wiper/washers, front/rear (10A)
6. Windscreen wiper/washers, right (10A)
7. Empty
8. Empty

Main fuses panel

The main fuses panel is behind the battery master switch, on the battery compartment.




Fig. - Main fuses panel

1. General key
2. Pre-heating relay (120A)
3. F20 fuse (pre-heating 120A)
4. Starting relay (50A)
5. F13 fuses (engine ECU: 30A), F10 (main: 50A) and F11 (cab: 50A)
6. F5 fuse (cab/Radio/CD player 10A)
7. 24V jack

Revision

DATE	VERSION	MODIFICATION
19/02/2018	0	General
06/11/2019	1	Correction of oils applied on equipment.
13/11/2019	2	Correction of engine motor capacity.
27/11/2019	3	Correction of engine motor informations.



Dynapac (China) Compaction & Paving Equipment Co., Ltd.
No. 38, Quanwang Road, WuQing High Tech Industrial Park,
301700, Tianjin, China
www.dynapac.com