

Instructions Manual

**Operation & Maintenance
4812316020EN**

**Tamping Roller
CT3000**

**Engine
Cummins QSB 6.7 ℓ, Tier III and Tier IV**

**From serial number
10000505xxB005089
10000513xxB005089**



CONTENT

OPERATION	Page
Introduction	1
Safety - General instructions	2
Safety-During operation	3
Safety - General instructions	4
Safety decals – Location and description	5
Technical specifications	7
Identification plates	8
Operator's instruments and controls	10
Instruments and controls – Description and function	13
Emergency procedures	23
Before starting the engine	29
Starting the engine	33
Operation	34
Braking	38
Stopping	40
Parking	41
Lifting	42
Towing	43
Transportation	44
General instructions of operation - Summary	48
Introduction	49
Symbols and Lubricants	50
Specifications	52
Lubrication and maintenance points	55
Lubrication and maintenance procedures	56
Daily (Every 10 hours of operation)	60
Weekly (Every 50 hours of operation)	70
Biweekly (Every 100 hours of operation)	75
Monthly (Every 250 hours of operation)	77
Quarterly (Every 500 hours of operation)	82
Biannually (Every 1,000 hours of operation)	83
Annually (Every 2,000 hours of operation)	91
Long lasting intervals	94
Special instructions	95
Electrical system	100

Introduction

Warning symbols



ATTENTION! *Damage to the machine and its components.*



CAUTION! Your safety might be involved.

Safety manual



The operator should read the safety manual that comes with the machine. Always follow the safety instructions and do not remove the manual from the machine.

Main

This manual has information about the operation and usage of the machine. For instructions and information about lubrication and maintenance, please refer to the respective Maintenance Section.



When releasing the emergency/parking brake check that the warning lamp has turned off after 10 seconds, if not, check the cause of the abnormality before operating the equipment.



NEVER release the emergency brake/parking brake without knowing the conditions of braking.

Safety - General instructions

(Read also the Safety Manual)



1. Read and understand this Manual before starting the engine and operating the machine. The operator should be completely familiarized with the machine before usage.
2. Observe and follow all the instructions of lubrication and maintenance contained in the Maintenance Manual.
3. Do not operate the machine if you are not qualified, by training or experience. NEVER allow passengers and always operate the machine seated.
4. Do not operate the machine if it needs repair or adjustments.
5. When entering or exiting the machine, use the stairs and the handrail. NEVER enter or exit the machine while moving.
6. In the case of the ground stability is irregular or dangerous, use the Roll Over Protective Structure (ROPS). Always use the seat belt with ROPS cabs.
7. In closed turns, maintain the lowest speed possible.
8. Avoid moving near cliffs or locations with high side inclination. Operate the machine in low speed and always check the functionality of the brakes.
9. Beware of obstacles above your head. Always look up and down.
10. Take special attention when operating on rough terrain. Never exceed the speed of 12.4 mph (20 km/h).
11. Obey all the safety rules and use the proper protection equipment according to the work that will be done.
12. Maintain the machine always clean. Clean immediately dirt, grease or oil present on the operator's platform. Keep all the signals, lanterns, headlights and decals clean and clearly readable and visible.
13. Observe the following safety measures when refueling the machine:
 - Turn off the engine;
 - Do not smoke or allow others to smoke;
 - Do not allow sparks or flames near the equipment;
 - Level the nozzle of fueling, as well as the fueling nipple.
14. Before performing any maintenance operation, cleat the tamping cylinders and pull the emergency/parking brake.
15. If the noise level of the machine is superior to 85 dB (A), use proper auricular protectors. The level of noise can fluctuate according to the kind of work the equipment is being subjected to.
16. Do not modify the machine under any pretext, because this action can affect personal safety and equipment safety. Any modification on the machine requires a previous approval by writing from DYNAPAC.
17. Always keep the doors closed when operating machinery equipped with cab.

Safety-During operation

Operation near edges




Fig. Positioning of the tamping rollers while operating near edges or holes.

While operating near to edges or holes, make sure that at least half of the tamping rollers are on a compacted ground.



Remember that the center of gravity of the machine shifts to the external side when operating the steering wheel. As an example: move to the right when the steering wheel is shifted to the left.



It is recommended to use the Roll Over Protective Structure (ROPS) while operating on slopes or irregular ground.



Always avoid when possible to operate transversally on slopes. When on slopes, preferably operate up and down.



Always use the first speed when operating on slopes.



Always operate the machine with doors closed and seat belt fastened.

Safety - General instructions

Air conditioning




Fig. Air conditioning



The system contains coolant under pressure. It is forbidden by law to release the coolant into the atmosphere.



The maintenance services in the air conditioning system should only be performed by trained personnel with proper equipment and tools.



The air conditioning system is under pressure. The incorrect handling may cause severe personal injuries. Do not release or loose hoses or fittings with the system loaded.

Working Lights - Xenon




Fig. Xenon Working Lights



CAUTION! High voltage!

The working lights are Xenon-type, which have a secondary high voltage power source.

Any maintenance procedure in the lighting system must only be performed by qualified personnel and the main power source must be shut off.





CAUTION! Dangerous residue for human being and environment.

The working lights Xenon lamps contain mercury (Hg).

A damaged lamp is considered as a toxic and dangerous residue, thus must be disposed properly and according to the applicable law.

Safety decals – Location and description

Safety decals – Location and description



Safety decals – Location and description



WARNING. Zone subjected to crushing of articulation direction. Keep safe distance from this area.



WARNING. Be careful! Engine rotating components! Keep your hands away from this risk area.




WARNING. Extremely hot surface, danger! Do not touch these surfaces.



WARNING. Before operating the machinery, it is recommended to the operator to read the Safety and Engine Manuals, as well as the instructions of operation and maintenance.



WARNING. Danger for hands and arms, rotating belts. Keep distance from this risk area.




Information plate of the lifting capacity of the equipment.




WARNING. During elevation, block the articulation, read instruction manual.



Fuel.




Fuel (Tier IV engine)



Lifting position.




Fixation position.




Manual compartment.



Main battery switch.




Hydraulic oil level.



Engine coolant.



Hydraulic oil.



Fuel filter.

Technical specifications

Vibrations – Operator station

(ISO 2631)

Vibration levels have been measured according to the operational cycle described in the EU directive 2000/14/EC on machines equipped for the EU market with operator seat in transport position.

Measured whole-body vibrations are below the action value of 0.5 m/s ² as specified in Directive 2002/44/EC. (Limit is 1.15 m/s ²)

Measured hand/arm vibrations also were below the action level of 2.5 m/s ² specified in the same directive. (Limit is 5 m/s ²)

Noise level

Sound levels have been measured according to the operational cycle described in the EU directive 2000/14/EC on machines equipped for the EU market with operator seat in transport position.

Guaranteed sound power level, L_{wA}	103 dB (A)
Sound pressure level at the operator's ear (platform), L_{pA}	85 ±3 dB (A)
Sound pressure level at the driver's ear (cab), L_{pA}	80 ±3 dB (A)

During operation the above values may differ because of the actual operational conditions.

Electrical system

Machines are EMC tested in accordance with EN 13309:2000 'Construction machinery'




Fig. Location of identification plate on the machine.
1 – Identification plate

Identification plates

Machine identification plate

The identification plate (1) is located on the left side of the machine, in the lower chassis below the fuel tank.

This plate indicates the name of the manufacturer and its address, type of machine, serial number and other important information about the product.

When ordering replacement parts, always inform the serial number and the machine model.

		Atlas Copco Construction Technique Brasil Ltda. Rua Georg Schaeffler, 430 – Iporanga Sorocaba SP - Brasil		
Product Identification Number				
Designation	Type	Rated Power	Max axle load front / rear	
		kW	kg	
Gross machinery mass	Operating mass	Max ballast	Year of Mfg	
kg	kg	kg		
4811 0001 36				

NOTE: When ordering replacement parts, always inform the serial number and the machine model.




Fig. Front chassis
2 – PIN

Product Identification Number (PIN) on the chassis


The product identification number - PIN (2) is engraved on the front chassis on the right side right below the fuel tank (1).

Identification plates

100	00505	V	E	B	123456
A	B	C	D	E	F

Explanation about the Product Identification Number (PIN) with 17 characters

A – Manufacturer's code (100 = Dynapac)
B – Family/model code (00505 or 00513 = CT3000)
C – Checking code
D – Year of manufacturing (E = 2014, F=2015...)
E – Unit code (B = Sorocaba, Brasil)
F – Sequential serial number (from 000001 to 999999)



Engine identification plate


The engine identification plate (1) is located in the middle of the engine valve cover. This plate has information such as serial number, model and other information about the engine.

NOTE: When ordering replacement parts, always inform the serial number and machine model.

Fig. Engine
1 – Engine identification plate


Operator's instruments and controls

Multifunction display, side control panel and operator's control keyboard



1. Multifunction display
2. Operator's Control Keyboard
3. Warning lights switch
4. Parking brake switch
5. Starter key switch
6. Beacon warning light switch (Optional)
7. Emergency stop button
8. "Go Home" switch
9. Blade control joystick

Operator's Control Keyboard



- 10. Steering turning light
- 11. Machine warning light – yellow
- 12. Machine warning light – red
- 13. High beam
- 14. Working lights
- 15. Rear working lights
- 16. Front working lights
- 17. Night working lights (Optional)
- 18. Rear working lights (Optional)
- 19. Front working lights (Optional)
- 20. Enable the regeneration (Tier IV Engine)
- 21. Empty
- 22. Engine radiators assembly cleaning
- 23. Disable the regeneration (Tier IV Engine)
- 24. Brake test
- 25. Horn

Speed lever




Fig. – Speed lever

The equipment has four speeds forward and four speeds backwards completely automatic. (*Powershift*).

Position the lever forward or backward, according to the desired direction. On middle position, the transmission will be neutral.

Cab instruments























Fig. – Rear right column.










Instruments and controls – Description and function

No.	Designation	Symbol	Function
1	Multifunction display	-	Shows the transmission and engine functions. Refer to the "Before Starting the Engine" Section.
2	Operator's Control Keyboard	-	Refer to page 10
3	Beacon warning light switch		Press the switch to light on the beacon warning lights.
4	Parking brake switch		<p>When pressed, the parking brake is activated.</p> <p>To release the parking brake, slide the red side backwards (towards the operator) and change the switch's position.</p> <p>NOTE: The parking brake must be activated before turning on the machine.</p>
5	Engine starter key switch		<p>Turn the switch to the left to turn off the electric system.</p> <p>In the middle position the switch turn on all the electric system.</p> <p>Turn the switch to the right to activate the starter motor.</p>
6	Beacon warning light switch (Optional)		Press the switch to activate the beacon warning light, if equipped.
7	Emergency stop button	-	When this button is pressed the machine is stopped and the engine is turned off. All electric system will be also turned off.
8	"Go Home" Switch		In the occurrence of a failure, press the switch in order to send the machine to be repaired.
9	Blade control joystick	-	Perform the blade control functions Refer to the "Blade Operation" Section.

Instruments and controls – Description and function (cont.)

No.	Designation	Symbol	Function
10	Steering turning light		Indicates that the steering turning lights are activated.
11	Machine warning light – yellow		Indicates that there is failure in the machine. Refer to the multifunction display (1) in order to check the failure.
12	Machine warning light – red		Indicates that there is failure in the machine. Refer to the multifunction display (1) in order to check the failure.
13	High beam warning light		Indicates that the high beams are activated (steering column switch).
14	Working lights button		Press to turn ON/OFF all working lights.
15	Rear working lights button		Press to turn ON/OFF all rear working lights.
16	Front working lights button		Press to turn ON/OFF all front working lights.
17	Night working lights button (Optional)		Press to turn ON/OFF all night working lights, if equipped.
18	Rear night working lights button (Optional)		Press to turn ON/OFF all rear night working lights, if equipped.
19	Front night working lights button (Optional)		Press to turn ON/OFF all front night working lights, if equipped.
20	Button to enable the regeneration (Tier IV Engine)		Press to enable the regeneration Refer to the "Operation" section (Tier IV Engine).
21	Empty	-	-
22	Engine radiators assembly cleaning button		Press to turn on the fan in order to clean the radiators assembly. Refer to the "Operation" section.
23	Button to disable the regeneration (Tier IV Engine)		Press to disable the regeneration. Refer to the "Operation" section (Tier IV Engine).
24	Brake test button		Press to test the brake drive mechanism.

Instruments and controls – Description and function (cont.)

No.	Designation	Symbol	Function
25	Horn button		Press to activate the horn.
26	Automatic Climate Control	-	Air conditioning automatic control (see A/C operation for detail).
27	Front wiper, intermittent	-	Intermittent function for front wiper.
28	Front wiper switch		Press to operate the front windshield wiper.
29	Rear wiper switch		Press to operate the rear windshield wiper.
30	Front and rear windshield washers switch		Press the top to activate the front washers. Press the bottom to activate the rear washers.
31	Asymmetric front wiper switch		Press to operate the front side windshield wiper.
32	Asymmetric rear wiper switch		Press to operate the rear side windshield wiper.
33	Asymmetric side windshield washers switch		Press the top to activate the front side washers. Press the bottom to activate the rear side washers.
34	Fuse box		Contains fuses from the electric system in the cab.
35	Hammer for emergency exit		If it is necessary to leave the cab during an emergency, release the hammer and break the right side windows.
36	Defroster nozzle	-	Turn the defroster nozzle to direct the air flow.

A/C – System operation



Power/Enter

By feeding the panel with 24VDC, the screen will be on, indicating that the product is in standby mode.

Press to turn on the A/C, it will show the software version and then the temperature. To return to standby mode you must press the button for 3s.

Set point Up/Down

Set point is the desired temperature inside the vehicle. To set it up press or . The set point temperature will flash on the display; press until reaches desired temperature.

Display

The display shows set point value, bar graph evaporator speed, active function and other information. It also serves to allow the operator to view the coil and return temperature, as well as the parameters. It also serves to alert when there is some system flaws.

Operation Mode


To change the operation mode, press the button (operation mode), select the desired mode:

The controller has 4 operation modes that are:

- Only ventilation
- Only cooling
- Only heating
- Automatic mode

Press the button to confirm or wait a few seconds to cancel.





Ventilation

The controller has two ventilation modes: manual and automatic ventilation.




Manual ventilation

The manual ventilation has three speeds. When some function (cooling, heating or automatic mode) is active, the ventilation function is always on. To change the fan speed, press the key



(Ventilation mode) and after set the desired speed with the



keys  or . After press the key  to confirm or wait a few seconds and the speed will be saved.

Multifunction display – General description



Fig. – Startup screen

When the switch is turned to the "I" position, the startup screen is shown on the screen. The screen stays for a couple of seconds and then goes to the status screen.




Fig. – Status screen

The status screen shows information about the fuel level, fan speed level, operating hours of the machine and voltage. The fuel level and fan speed level are specified in percentage (%).

The screen is shown until the diesel engine starts operating or if one of the function buttons below the screen is pressed.



Fig. – Operation main screen

Is the engine starts running before the selection of the current screen, the screen will change to the main screen.

This screen shows an overview and stays throughout the operation:

- The speed is shown in the middle of the screen.
- The status of the machine gears (N, 1, 2, 3 e 4) is shows with a symbol in the middle of the screen.
- The engine speed and the percentage of the accelerator position are shown on the upper left side and on the lower left side, respectively.

Multifunction display – General description (cont.)



Fig. – Operation main screen with the menu selection buttons

When the selection buttons are pressed a menu field is shown on the screen. The field is shown briefly and then is turned off if no selection is done. A menu field is shown again when one of the selection buttons (1) is pressed.

The current failures of the machine will be shown on the lower side of the screen (2), whereas the active functions will be shown on the vertical side (3).

	Slide/selection buttons to choose amongst the available functions.
	Alarm history button to show engine and machine alarms.
	Definition/menu selection button, which opens the main menu. The definitions can be changed in the main menu.
	Exit/back button, goes 1 step back at a time. If the button is pressed for approximately 2 seconds, the main menu is shown again.




Fig. – Temperature and pressure screen

Press the selection button (1) to show the temperature and pressure screen, which shows the engine oil temperature (on the upper left side), transmission screen (upper right side), hydraulic oil screen (lower left screen) and transmission oil pressure screen (lower right side). The values are specified in Celsius or Fahrenheit degrees and kPa or PSI, according to the measurement system option.

Multifunction display – Alarms DM1 according to SAE J1939



When a transmission or engine alarm is activated, the indication is shown on the screen. The alarm is activated by the engine and transmission controls, which monitor their functions.

The message, which shows SPN and FMI codes, can be understood as a relation of failure codes from the engine and transmission suppliers.

Press the "OK" button on the screen to delete the message.











When a machine alarm is activated, it is shown on the screen along with an alarm text detailing it.

Press the "OK" button on the screen to delete the message.

Fig. – Engine and machine alarm screens


Multifunction display – Alarms DM1 according to SAE J1939 (cont.)

Symbol	Description	Function
	Warning symbol, hydraulic oil filter.	There will be necessary to replace the hydraulic oil filter if the symbols are shown with the engine in full throttle.
	Warning symbol, air filter.	There will be necessary to clean the air filter if the symbols are shown with the engine in full throttle.
	Warning symbol, battery charge.	If the screen shows a symbol while the engine is running, that means that the alternator is not being charged. Stop the engine and find the failure.
	Warning symbol, engine temperature.	This symbol is shown when the engine is too hot. Stop the engine immediately and find the failure. Also refer to the engine manual.
	Warning symbol, hydraulic oil temperature.	This symbol is shown when the hydraulic oil is too hot. Do not move the roller; run the engine in neutral, wait for the oil to be cooled and find the failure.
	Warning symbol, low fuel level.	This symbol is shown when the fuel level is at 10%.
	Warning symbol, radiators assembly fan.	This symbol is shown when there is a need to turn on the radiators assembly fan, in order to avoid them to be clogged due to debris.
	Warning symbol, low braking capacity.	This symbol is shown when the level and/or pressure of oil to the brakes are low. If this alarm is shown and stays turned on, along with the machine or during its operation, stop and turn it off immediately, then contact DYNAPAC .

Multifunction display – User settings



Fig. – User settings screen

Press the setting button () so the users can change the lighting settings, choose between the metric or imperial system and define whether there will be sound alarms.



NOTA: In every screen, pressing the  button returns to the Initial screen.




Fig. – Brightness and contrast screen

Press the + and - buttons to adjust the brightness and contrast values as you wish. Press () to return to the main screen.

Emergency procedures

Failure on the transmission or engine electric system



When the electronic module detects a problem related to the transmission or engine control, the multifunction display will inform the operator through a message with the symbol (2) and the FMI and SPM code (according to DM1 - SAE J1939) of the failure (3), and the machine will be prevented from moving as usual, switching to the emergency movement mode (refer to “Go Home” Switch, on the page 10).



When this failure happens, park the machine on a safe place and contact DYNAPAC.

Press the “OK” button (1) on the screen to delete the message.

To activate the transmission emergency mode, carry out the following procedure:




Fig 1 – Connector XGT

1. Open the right engine door and connect the XGT connector.

Turn off the engine and keep the start engine switch in “O” position.




Fig 2 – Transmission harness



Be certain that the transmission emergency mode switch is on the middle position.




Fig 3 – Cable 312

3. In the fuses and relay compartment, disconnect the cable 312 (X.10 connector) and connect cable 312 (X.10GT connector)





Fig 4 – Connector XA9.R1

4. In the transmission module, disconnect the XA9.R1 connector

NOTE: The procedure above neutralizes the transmissions normal operation and enables the emergency mode.



5. In the cab activate the button in the panel

NOTE: The emergency mode reduces functionalities of the transmission, it only allows that the machine to work on the 1^o gear (forward or backward).

Fig 5 – Forward/Backward button



Fig. – Multifunction display

Machine electronic system failure

In the occurrence of a machine electronic system failure, the multifunction display will inform the operator through a message with a symbol (2) and the failure code (3), thus indicating the problem. There is no emergency procedure for such cases, therefore, turn off the engine immediately and check the cause.



When this failure happens, park the machine on a safe place and contact DYNAPAC.

Press the “OK” button (1) on the screen to delete the message.

Releasing the emergency parking brake

If the engine or the hydraulic system becomes inoperative, the emergency/parking brake can be released so the machine can be towed safely to be repaired.

To release the emergency/parking brake, execute the following procedure:

1. Release all three screws from the caliper cover of the emergency/parking brake (1).



Be careful with spring pressure when performing this procedure.




Fig. – Parking brake caliper

2. Release the nuts from the stud of the return spring of the brake pads.



Only loose the stud enough to release the emergency/parking brake, because the return spring of the brake pads, which is under pressure, can release itself and cause serious personal injuries.




Fig. – Releasing the spring from the caliper

Regeneration system (Emission Control)



Fig. – After Treatment screen

After Treatment Screen

In this screen you will find urea tank level, warning lamps and engine oil temperature.

Make sure that the Urea tank is full during operation. It's recommended to fill or drain the tank with the system off.



If the Urea tank is completely empty you may have error codes related to the after treatment system in the display due to invalid measurements. To clear the error code the tank must be filled and perform a key cycle, start the engine and run it in high idle for 5 minutes.

Diesel Exhaust Fluid (DEF) Lamps

DEF Lamp

Illuminates when DEF level is low, and flashes when the DEF falls below a very low level. Operator should refill the DEF tank with DEF.

DEF Lamp With Check Engine Lamp

Illuminates when the DEF level is critically low. If the tank is not refilled immediately, power will be reduced. Operator should refill the DEF tank with DEF. Normal engine power will be restored after the DEF tank is refilled.

Flashing DEF Lamp With Check Engine Lamp

Illuminates when the DEF level is near zero. If the tank is not refilled immediately, power will be further reduced. Operator should refill the DEF tank with DEF. Normal engine power will be restored after the DEF tank is refilled.

Flashing DEF Lamp With Stop Engine Lamp

Illuminates when the DEF gauge has read zero for 30 minutes. Power will be limited to idle. Operator should stop the equipment when it is safe to do so, and refill the DEF tank. Normal engine power will be restored after the DEF tank is refilled.



On



On



On



On



Flashing



On



On



Flashing

Exhaust System Cleaning Lamps



High Exhaust System Temperature (HEST) Lamp

May illuminate due to higher-than normal exhaust temperature during Exhaust System Cleaning. Operator should ensure that the exhaust pipe outlet is not directed at any flammable or combustible surfaces.



Exhaust System Cleaning Lamp

Illuminates when the exhaust system is unable to complete an automatic Exhaust System Cleaning event. Operator should ensure the Exhaust System Cleaning Switch is not in the "STOP" position and continue working until there is an opportunity, such as at the end of the work day or shift, to complete a stationary Exhaust System Cleaning.



Exhaust System Cleaning Lamp With Check Engine Lamp

If an Exhaust System Cleaning is not performed in a timely manner after the Exhaust System Cleaning Lamp is illuminated, the Check Engine Lamp will illuminate and engine power will be significantly reduced. Park the equipment when safe to do so, and press the Exhaust System Cleaning Start Switch. Once the cleaning is complete, full engine power will be restored.



Exhaust System Cleaning Lamp

Flashes when a stationary Exhaust System Cleaning event is initiated using the Exhaust System Cleaning Start Switch. This lamp will continue to flash until the stationary cleaning event is complete. Once the lamp turns off, the operator can resume normal work activity.



Exhaust System Cleaning Stop Lamp

Illuminates when the Exhaust System Cleaning Switch is in the "STOP" position, preventing a cleaning event. This switch should be used only when high exhaust temperatures present a hazard. Excessive use of the Exhaust System Cleaning Switch in the "STOP" position will result in the need for more frequent stationary exhaust cleaning events.

Exhaust System Cleaning Switch

Exhaust System Cleaning Enabled



The switch remains in the standard **mid-position** during normal operations. This means Exhaust System Cleaning is enabled and allows the exhaust system to clear any build-up by initiating automatic cleaning. Exhaust System Cleaning initiated automatically by a preset timer at 20-hour intervals and takes around 15-30 minutes to complete. No operator action is required and the equipment continues to work as normal during the cleaning.

The HEST lamp may illuminate during cleaning to indicate higher than normal exhaust temperatures and safety considerations apply.

Start Exhaust System Cleaning



Pressing the switch into the **top position** starts a manual (parked) Exhaust System Cleaning. This is required on infrequent occasions due to very unusual duty cycle conditions. A manual (parked) Exhaust System Cleaning may be needed when the Exhaust System Cleaning Lamp illuminates. When the Start Switch is pressed, cleaning begins and this is confirmed by the Exhaust System Cleaning Lamp flashing.

The HEST lamp may illuminate during the manual (parked) Exhaust System Cleaning to indicate higher than normal exhaust temperatures and safety considerations apply. The switch returns to the standard Mid-Position after pressing the manual (parked) Exhaust System cleaning.

Stop Exhaust System Cleaning Function



Pressing the switch into the **bottom position** prevents Exhaust System Cleaning from occurring. Stopping the Exhaust System Cleaning function is required only for safety reasons to avoid higher than normal exhaust temperatures.

When the switch is pressed the Exhaust System Cleaning STOP Lamp illuminates to indicate Exhaust System Cleaning is disabled. The switch remains engaged in this position until pressed back to the standard mid-position to restore the automatic Exhaust System Cleaning function.

Exhaust System Cleaning should not be left disabled for long periods of time as this results in the need for a manual (parked) Exhaust System Cleaning.

Before starting the engine

Daily maintenance



Before starting your shift at work and operating the machine, check that the daily maintenance has been done. Refer to the maintenance section in this manual for other information.

Main switch

Check if the machine main switch is at the "ON" position. The main switch is located at the electrical device compartment (1), on the right side of the machine.



After the daily use of the machine, the main switch must be turned off. This avoids unexpected starting and, mainly, protects the electrical devices.




Fig. – Machine right view

Operator's controls

The operator's control and the machine operation have two adjust options: 180° shifting and steering column inclination.

The 180° shifting is possible by pulling the lever (1) upwards. Make sure that the controls are in their home positions before operating the machine.

The steering column inclination is adjusted by releasing the fixing lever (2). Fasten it again in the new position.

To adjust the operator's seat, please refer to the following section.




Fig. – Operator's controls



Perform all adjustments in the operator's controls with the machine stopped.



Before starting your shift at work and operating the machine, check if the seat and the steering column are locked.




Fig. – Operator's seat

Operator's seat

Adjust the operator's seat in a way that all the controls are easily accessible and the machine operation comfortable.

- (1) Longitudinal: the adjustment is done through the longitudinal lever (1).
- (2) Height adjustment: performed through the 1st adjust button. Turn it clockwise to lift and anti-clockwise to lower it (2).
- (3) Seat inclination adjustment: performed through the 2nd adjust button. Turn it clockwise to lift and anti-clockwise to lower it (3).
- (4) Backrest inclination adjustment: use the adjust button (4) for the real angle of inclination of the backrest.
- (5) Armrest inclination adjustment: the adjustment is performed through the button (5) that can be found under the armrest, turning it to the right or left.
- (6) Lumbar rest adjustment: to adjust it rotate the button (6) clockwise or anti-clockwise.




Fig. – Sub-abdominal seat belt

Sub-abdominal seat belt

If the machine is enabled with cab, the operator should use the seat belt.

To adjust the seat belt, pull the retraction mechanism in a uniform way, taking the necessary cautions so it can adjust comfortably around the waist. The seat belt will jam if pulled sharply, or if the machine is parked on a slope or very stepped bank.



Introduce the buckle until you hear a "click". In any other way the seat belt will not be locked.

To release the seat belt, press the red button. Afterwards, allow the seat belt to be completely retracted.

Before starting the engine

Before starting the machine engine

Be sure that the parking brake (1) is ON, otherwise turn it on.

Turn the engine starter switch (2) to the middle position ("I").




Fig. – Side control panel




Fig. – Multifunction display

After the startup screen appears, check if the voltmeter shows at least 24 Volts of voltage, and if the fuel level shows a percentage value compatible with the operation.

Make sure all warning lights are working properly.



This machine is adjusted at the factory with the main preset functions, i.e., four of them with functions in the local language.



This machine is programmed to shut down the engine if the operator fails to operate it within the maximum time limit of 20 minutes.

Visibility

Before starting the engine, make sure that the visibility around the machine is not impaired.

All cab windows should also be clean and the rear view mirrors adjusted in order to have a good rear visibility.

Before starting the engine

Interlock




Fig. – Cab opened

The machine is equipped with interlock.

The diesel engine will shut down after 4 seconds if the operator leaves the seat during the operation.

If the parking brake is activated, the diesel engine does not stop.

The engine will be shut down automatically if, for any reason, the transmission is not in the neutral position when the operator is not seated in the place.



Always keep seated in all operations!

Alignment of the cab cushions




Fig. – Cushion valve

The alignment of the cab cushions is performed through applying compressed air in the four valves located in the cushions, below the cab.

NOTE: A compressor with a capacity of 50 psi is enough for the job.

The application of compressed air in the valves is only performed when it is noticed the misalignment in the four scales, located besides every cushion, and also in the cab.

1. Park the machine on a completely flat surface, shut off the engine and the main switch.
2. Check if the arrow in the scales is aligned with the number ZERO, in the 4 cushions.

NOTE: The adjustment is at real time, or in others words, when a cushion is inflated or deflated, the other cushions are affected as well.

3. Apply compressed air in the valves or deflate the cushions crossed, according to the scale, starting from the front right side, then going to the rear left side, posteriorly, to rear right side and finally finishing the checking on the front left side.




Fig. – Alignment scale

Starting the engine

Starting the engine

Check if the emergency starting system (1) is not activated (upper position). Check also if the parking brake is activated (2).




Fig. – Side control panel




Fig. – Speed lever

Put the speed lever in the neutral position. The engine will only run with the lever in this position.

While in the operator's seat, turn the starting key switch (3) to the right, to the first position ("I"), and then to the starting position (⏻). Release the switch as soon as the engine starts running.



Do not hold the starter motor for much longer (the maximum allowed is 30 seconds). If the engine does not work, wait approximately one minute before trying again.

Heat the engine for some minutes in idling, or for longer if the room temperature is below 50°F (+10°C).



When operating the engine in enclosed rooms, check if there is proper ventilation to release the exhaust gases.

Operation



Under no circumstances, the machine should be distanced from the ground. The operator must keep seated on the operator's seat during the operation.



Make sure that all areas ahead and behind the machine are free.

1. The selected gear will be the highest one in which the machine will operate. To select the gear, turn the speed lever to the gear desired or put the lever to the "4" position for a fully automatic operation.




Fig. – Speed lever



The machine speed will be controlled via the transmission electronic module within the range chosen according to the accelerator position. The speed obtained will be always within the range chosen by the operator. For example: if the operator selects the 2nd gear, the machine speed will be restricted between the 1st and 2nd gears, at most.

2. Put the Forward/Reverse lever to the desired travel direction.



Never exceeds 12.5 mph (20 km/h) during the tamping and travel operations at the job's site. This operation may cause discomfort, as well as damage in the machine. The machine was designed to have a productivity with speed lower to 12.5 mph (20 km/h).

NOTE: Put, smoothly, the lever in the desired position.



Check if the lock of the "neutral" position is unlocked.



In certain ground conditions, the highest selected speed (normally the fourth gear) will not be reached.

Operation (cont.)

- Press the acceleration pedal (1). The speed will increase according to the pressure on the pedal.



Check that the steering system of the machine is working properly, turning the steering wheel to the left and right with the machine parked.

NOTE: Do not change the travel direction when the machine is traveling.



The transmission electronic module does not allow sudden reversing while traveling, because this action can damage the transmission box.




Fig. – Acceleration pedal

- During the operation, check if all the indicators indicate that, all readings are normal and all warning lamps are off.



The display will show if any function is above its specific limit and an alert will sound. If a warning alert is activated, stop the machine immediately and check for failure.



Fig. – Multifunction display

Leveling blade (Optional)

The leveling blade should only be used to push, spread or level the material. This blade rests upon the sliding pads to avoid excavation of the compacted layer.

NOTE: The blade equipped on the roller is not the dozer kind.




Fig. - Tamping roller with leveling blade





Fig. - Leveling blade control lever

Leveling blade operation (Optional)

The leveling blade control lever – joystick (1) has four stages:



If the lever is released on the stage “Lift” or “Lower” it will always return to the stage “Retain”.

If the lever is released in the “Fluctuate” stage, it will not return to the “Retain” stage.

Tilting blade (Optional)




Fig. - Tamping roller with tilting blade

The tilting blade allows the operator to adjust hydraulically the lifting of the blade and carry out inclination and regulation simultaneously. The versatility of the tilting blade gives the machine the capacity of operating in several usages, as in leveling operations, spreading the material, side unloading and "V" trenching.

NOTE: The blade equipped on the machine is not the dozer kind.





Fig. – Tilting blade control lever

Tilting blade operation

The leveling blade control lever – joystick (1) has eight stages:



LIFT: move the lever backwards

RETAIN: release the lever in any stage

LOWER: move the lever forward

FLUCTUATE: move the lever completely forward

LEFT ANGULATIONS: move the lever laterally to the left.

RIGHT ANGULATIONS: move the lever laterally to the right.

LEFT INCLINATION: press the button and move the lever laterally to the left to incline the blade to the left; release the button to stop the movement.

RIGHT INCLINATION: press the button and move the lever laterally to the right to incline the blade to the right; release the button to stop the movement.

If the lever is released on the stage "Lift" or "Lower" it will always return to the stage "Retain".

If the lever is released in the "Fluctuate" stage, it will not return to the "Retain" stage.

Braking

Service brake

The service brake is activated through the brake pedal (1).

The machine has a hydraulic service brake system, with two independent circuits, one for the front axle and one for the rear axle.




Fig. – Service brake pedal

Parking brake

The parking brake and the emergency transmission disc, has a mechanical activation through a spring that is hydraulically released and operated by button (2) located on the side control panel.

When pressed, the parking brake is activated. To release the parking brake, slide the red button side backwards (towards the operator) and change the switch's position.

NOTE: The parking brake must be activated before turning on the machine.



Make sure that the machine is parked on a safe place and that is not blocking the traffic.




Fig. – Parking brake button




Fig. – Side panel

Emergency brake

The emergency brake has a mechanical activation through a spring and is hydraulically released, being operated by button (3) located on the side control panel.



In case of an emergency the parking brake can be applied as an additional to mobilize the machine. If the machine is traveling forward, as an emergency asset, you can lower the blade to stop the machine.



Use this resource only after exhaust all the others resources.



During emergency brakeage, the operator should hold firmly to the steering wheel until the machine is fully stopped.

Stopping

Stopping the engine

1. Stop the machine positioning the Forward/Backward lever (1) to the neutral position.
2. Release the accelerator pedal (2) and keep the engine working in low idle. Allow the engine to keep working about 3 to 5 minutes.




Fig. – Steering pedals and controls

3. Turn off the engine turning the switch (3) to the “O” position.
4. Push the blade control lever (4) smoothly forward until it lowers all the way to the ground, if it is not locked.



In case of long inactivity periods, the main switch should be turned off.




Fig. – Side panel

Parking

When stopping and parking the machine, always apply the emergency/parking brake.

Place, as a safety measure, blocks on the tamping when parking on slopes. Shut off the engine too.



To avoid accidents, on slopes or hills, park transversally to the direction of the inclination.



Never leave the machine while the engine is operational. Before exiting, apply the emergency/parking brake.



Make sure that the machine is parked on a safe place and that is not blocking the traffic.

Lifting

Joint lock




Fig. – Joint lock



Before turning off the machine, lock the chassis joint.

Extend the bar (1) and lock it with the pin and its lock (2) to the rear segment of the chassis.



Remember to remove the joint lock before using the machine.




Fig. – Lifting points

Lifting



Check that the hooks are securely placed on the rings. Only raise the equipment through the specific rings for this purpose.



Always use steel cables and chains according to the safety regulations.

Equipment weight

	With ROPS cab	With enclosed cab
Operational weight	44,841 lbs (20,340 kg)	45,304 lbs (20,550 kg)
With leveling blade	47,487 lbs (21,540 kg)	47,928 lbs (21,740 kg)
With tilting blade	49,251 lbs (22,340 kg)	49,714 lbs (22,550 kg)

Make sure that the lifting hooks are safely connected to the machine. Verify the weight of the machine and the compatibility of the lifting equipment.

Towing

Short distance towing




Fig. – Towing

To tow the machine, use the same points used on the lifting process.

1. Park the machine on a safe and leveled ground. Shim the cylinders, if necessary.
2. Install the drawbar (avoid the use of cables and chains).



With the engine on: lift the leveling blade or the tilting blade, if equipped (refer to “Operation” chapter) and release the longitudinal transmission (universal joint) of the front and rear axle.



If the machine's breakage system is disabled, avoid towing the machine on slopes when the machine is at high speed. Always use the drawbar.


Transportation

Machine transportation

1. Lift the leveling or tilting blade, if equipped.

NOTE: If necessary, remove the blade to perform the transportation.

2. Shim the tamping cylinders.
3. Tie the machine on the four fixing spots marked with safety decals. Use proper chains or steel cables.
4. Lock the chassis joint.



Before turning off the machine, lock the chassis joint.
Extend the bar (1) and lock it with the pin and its lock (2) to the rear segment of the chassis.



Remember to remove the joint lock before using the machine.

Fig. – Joint lock

Assembly of the tamping cylinder




Fig. – Tamping cylinder

Identify the front and rear cylinders and note that the front ones have a distance between the rim of the tire and the roller extremities of approximately 9.4" (240 mm), while the rear's distance is of approximately 5" (129 mm).



The cylinder's position on the equipment is marked on both cylinders:

- Front: 9.4" (240 mm)
- Rear: 5" (129 mm)




Fig. – Position of the tamping cylinders

Positioning the cylinder on the machine

Make sure that the pads meet the standard of the following figure during the installation of the cylinders:




Fig. – Installation of the tamping cylinders

Installation of the tamping cylinders

Check the minimum distance between the tire and the support easels, so that the cylinders will not touch them, thus preventing the installation to happen.

Installation of the tamping cylinders (cont.)




Fig. – Tamping cylinder

1. Remove the bars and scrapers, if installed.
2. Put the machine on proper easels, with a minimum height of 31.5" (800 mm), supporting it on the axles. Lock the front suspension swing yoke properly.
3. Exhaust the tire to 0.34 bar (5 psi) and clean it to ensure a good tire's assembly on the cylinder.
4. Assemble the tamping cylinders on the tires.



If necessary, lubricate the surface of the tires with water and soap. NEVER use petroleum based lubricant (oil, grease or Vaseline).

5. After the assembly, install the tire locks and apply a torque of 140 lb.ft (190 N.m) on the screws.

NOTE: Apply a chemical lock (Loctite) in all fixating screws of the guide ring.

6. After installing the locks, put the tires in a central position inside the cylinders, sharing equally the gap between the tire and the lock.
7. Inflate all the tires with 3.10 - 4.13 bar (45 - 60 psi), according to the service to be performed, and the soil to be compressed (for more tamped soils, use the lower pressure limit).



When using the machine mainly as a dozer inflate all tires with 6,9 bar (100 psi):

8. Apply dry torque of 545 lb.ft - 740 N.m (oiled 487 lb.ft – 660 N.m) on all the screws of the tires.

Installing the scrapers




Fig. - Installing the scrapers

The scrapers are provided with the scraping bars, however, they are not initially adjusted. Install the scraping bar and apply the torques according to the following figure:

Adjustment of the scraping bars

Check and, if necessary, adjust the positioning of the scraping bars at a 1" (25 mm) gap.

NOTE: Use a bar with a 1" diameter (approx. 25 mm) to assist on adjustment.



For the transportation of the machine for long distances, it is recommended to disassembly all the accessories referred to in this chapter, so they can be assembled and adjusted later.




Fig. – Adjustment of the scraping bars.

General instructions of operation - Summary

General instructions of operation - Summary

- Make sure all the MAINTENANCE INSTRUCTIONS were carried out. For further information, refer to the Maintenance section, in this manual.
- Position the forward/backward lever in the "Neutral" position when the machine is not operating.
- Keep the key starter switch in the position "O".
- Turn on the engine and keep it running until it is warmed up.



Always check the brakes. Before starting the work shift, carry out an operational system test.



When operating the machine , use the forward/backward lever carefully.

- When parking the machine: turn off the engine, apply the parking brake and shim the tamping rollers.
- When towing the machine: refer to the towing instructions in this Manual.
- When lifting the machine: refer to the lifting instructions in this Manual.
- When transporting the machine: refer to the transportation instructions in this Manual.

Maintenance - Symbols and lubricants

Introduction

Warning symbols



ATTENTION! Damage to the machine and its components



CAUTION! Your safety might be involved.

Safety manual



The operator should read the safety manual that comes with the machine. Always follow the safety instructions and do not remove the manual from the machine.

Main

This Manual contains information about the operation and usage of the machine. For instructions and information about lubrication and maintenance, please refer to the respective Operation Section.



The machine requires special care in order to ensure its adequate operation. Keep the machine clean, so leakage, loose bolts and connections, as well as other faults may be easily detected.



Read carefully all the instructions before performing any service.



When operating the engine in enclosed rooms, check if there is proper ventilation to release the exhaust gases.



When performing maintenance services on the machine, always lock the chassis joint and the blade, to prevent serious injury.










TAKE CARE OF THE ENVIRONMENT: Do not discard lubricant or fuel oil in places which may infect the soil or the environment.

Symbols and Lubricants



Always use high quality lubricants on the indicated quantity.

Excessive grease or lubricant oil can cause overheating and fast wear.











	ENGINE OIL Room temperature: 14 °F (-10 °C) to 122 °F (50 °C)	Engine oil according to specifications API CH-4/SJ and ACEA E-5/E-7 with SAE 15W40 viscosity
	HYDRAULIC FLUID Room temperature: 14 °F (-10 °C) to 104 °F (40 °C) Room temperature: over 104 °F (40 °C)	Hydraulic oil ISO VG 68 or equivalent Hydraulic oil ISO VG 100 or equivalent
	TRANSMISSION OIL Room temperature: 32 °F (0 °C) to 140 °F (60 °C) Room temperature: -4 °F (-20 °C) to 140 °F (60 °C)	Transmission oil according to specifications MIL-L-2104 C/D, C-2/C-3 and API CD/SE or CD/SF with viscosity SAE 30. Transmission oil according to specifications MIL-L-2104 C/D, C-2/C-3 and API CD/SE or CD/SF with viscosity SAE 10W.
	DIFFERENTIAL OIL All temperatures	Gear oil lubricant according to specifications API GL-5 or MIL-L 2105D, with SAE 85W140 viscosity
	GREASE	Lithium soap based grease NGLI 2 or equivalent
	FUEL	TIER III: Common Diesel TIER IV: Diesel with low sulfur content
	COOLANT 50% potable water + 50% coolant additive	Coolant additive according to specifications ASTM D4985 or ASTM D6210



For extreme high or low room temperatures, other lubricants will be necessary.

Refer to “Special Instructions” chapter or contact **DYNAPAC**.

Maintenance - Symbols and lubricants

	Engine oil level
	Engine oil filter
	Hydraulic fluid level
	Air filter
	Brake fluid
	Hydraulic fluid filter
	Transmission oil level
	Fuel filter
	Battery
	Coolant level

Specifications

WEIGHT AND DIMENSIONS	
Operational weight with ROPS and blade	49,251 lbs (22,340 kg)
Operational weight with cabin and blade	49,714 lbs (22,550 kg)
Length (with the blade)	23.6 ft (7,220 mm)
Length (without the blade)	20.3 ft (6,184 mm)
Width (with the blade)	11.8 ft (3,598 mm)
Width (without the blade)	10.8 ft (3,300 mm)
Height (with ROPS)	11.4 ft (3,473 mm)
Height (with the cabin)	11.4 ft (3,473 mm)
Height from ground clearance	1.4 ft (430 mm)
Distance between axles	10.6 ft (3,250 mm)
External turning ratio	20.6 ft (6,300 mm)
Steering angle	± 40°
Vertical swing	± 12°

FUELING VOLUME	
Front and rear axle (each)	13.2 gal (50 L)
Hydraulic system reservoir	60.7 gal (230 L)
Tier III engine lubricant oil (with filter)	5 gal (19 L)
Tier III engine lubricant oil (without the filter)	4.7 gal (18 L)
Tier IV engine lubricant oil (with filter)	5 gal (19 L)
Tier IV engine lubricant oil (without the filter)	4.7 gal (18 L)
Urea tank	5 gal (18,9L)
Transmission box oil	11.9 gal (45 L)
Coolant	7.9 gal (30 L)
Fuel tank	105.6 gal (400 L)

ELECTRICAL SYSTEM	
Battery	2 x 12 V / 95 A
Alternator	120 Ah

TIRES AND WHEELS (DOUBLE GEAR PER CYLINDER)	
Wheels	8,00 X 22
Tires	11,00 X 22 14 linings

Specifications (cont.)

COMPACTING DATA	
Cylinder diameter	4.97 ft (1,517 mm)
Cylinder width	3.28 ft (1,000 mm)
Compacting width (double pass)	14.4 ft (4,410 mm)
Pads per cylinder	60
Pads height	0.6 ft (185 mm)
Pads contact area	200 cm ²
Pads distribution model	Chevron

PERFORMANCE DATA	
Maximum theoretical speeds (forward/reverse)	
1st gear	2.30 mph (3.7 km/h)
2nd gear	5.34 mph (8.6 km/h)
3rd gear	9.07 mph (14.6 km/h)
4th gear	14,2 mph (20 km/h)

Torque

Torque for lubricated screws tighten with a torque wrench.

METRIC THREAD	RESISTANCE CATEGORY	
	8.8	10.9
M4	1.8 lb.ft (2.5 N.m)	2.5 lb.ft (3.4 N.m)
M5	3.6 lb.ft (4.9 N.m)	5.2 lb.ft (7.0 N.m)
M6	6.2 lb.ft (8.4 N.m)	8.9 lb.ft (12 N.m)
M8	15.5 lb.ft (21 N.m)	20.7 lb.ft (28 N.m)
M10	29.5 lb.ft (40 N.m)	41.3 lb.ft (56 N.m)
M12	51.6 lb.ft (70 N.m)	72.3 lb.ft (98 N.m)
M16	124.7 lb.ft (169 N.m)	177 lb.ft (240 N.m)
M20	243.4 lb.ft (330 N.m)	346.7 lb.ft (470 N.m)
M24	420.4 lb.ft (570 N.m)	590.1 lb.ft (800 N.m)
M30	833.5 lb.ft (1,130 N.m)	1165.4 lb.ft (1580 N.m)
M36	1445.7 lb.ft (1,960 N.m)	2065.3 lb.ft (2,800 N.m)

Hydraulic system

OPENING PRESSURE		
Transmission	16-21 bar	240 – 310 psi
Converter	1.7 – 4.8 bar	25 – 70 psi
Steering system	170 bar	2320 – 2465 psi
Blade system	140 bar	2000 psi
Brake system	40 bar	580 psi

Specifications (cont.)

Air conditioning (option)

The system described in this manual is the ACC (Automatic Climate Control), that is, a system which maintains the set temperature in the cab provided that all the windows and doors are kept closed.

Coolant designation: HFC-R134:A

Coolant weight when full: 1,000 g (2.2 lb).

Engine

ENGINE	
Make and model	Cummins QSB 6.7ℓ - Tier III / IV
Type	Turbo, Diesel, water coolant and air cooling
Number of cylinders	6 in line, 4 periods
Power (SAE J1995)	194 kW (260 HP) @ 2,200 RPM (Tier III) 194 kW (260 HP) @ 2,200 RPM (Tier IV)
Rotation of idle speed	750 RPM

Blades


BLADES	
Type	Leveling and tilting
Width	11.81 ft (3,600 mm)
Height	2,55 ft (780 mm)

Maintenance - Daily (every 10 hours of operation)

Lubrication and maintenance points

Read this manual carefully before doing any kind of maintenance service or lubrication operation.

Get used to examining the surrounding area around and under the machine. This is an easy way of detecting leaks in their initial stage, as well as anomalies.



- | | | | |
|----------------------------|-------------------------------------|---------------------------------|-------------------------------------|
| 1. Radiator | 8. Batteries | 15. Engine oil filter | 22. Cab |
| 2. Alternator belt | 9. Tires | 16. Front and rear axle | 24. Fuse and relay box |
| 3. Pre-filter | 10. Hydraulic cylinder of the blade | 17. Wheel bolts | 25. Electronic modules |
| 4. Air filter | 11. Fuel tank | 18. Service brake | 26. Transmission box |
| 5. Hydraulic oil reservoir | 12. Scrapers | 19. Transmission box oil filter | 27. Longitudinal transmission shift |
| 6. Hydraulic oil filters | 13. Main fuel filter | 20. Transmission box oil | |
| 7. Chassis joint | 14. Engine lubricant oil | 21. Parking brake | |

Lubrication and maintenance procedures

Maintenance and lubrication procedures should be made based on the number of operation hours, than subsequently based on the periods, as daily, weekly, etc.



Always clean around the caps, grease trays or plugs before opening or applying grease.



Observe and follow the engine manufacturer instructions. For further information, refer to the Engine Manual.

DAILY (Every 10 hours of operation)

ITEM ON PAG. 52	PROCEDURE	PAGE
Before starting the engine		
18 - 21	Check the brakes	58
12	Check the scrapers adjustment	59
9	Check the tire pressure	60
17	Check the tightening of the wheel bolts	60
5	Check the hydraulic oil reservoir oil level	61
22	Check the alignment of the cab cushions	61
1	Check the engine's coolant level	62
14	Check the engine's lubricant oil level	62
2	Check the tension on the alternator's belt	63
3	Check the pre-filter's water divider	63
20	Check the transmission box oil level	64
-	Check the Multi-function display and the operator's control keyboard	64
At the end of the work shift		
11	Refuel the fuel tank	65
22	Check the cabin's cushion height	65
28	Check the exhaust gases post-treatment connecting line (Tier IV Engine)	66
4	Clean the dust ejector valve (Tier IV Engine)	66

Maintenance – Maintenance and lubrication procedures

WEEKLY (Every 50 hours of operation)

ITEM ON PAG. 52	PROCEDURE	PAGE
9	Check the tire pressure	67
17	Check the tightening of the wheel bolts	67
8	Check batteries	68
7	Lubricate the chassis joint	69
-	Lubricate the steering system joints	69
27	Lubricate the longitudinal transmission shaft (axle shaft)	70
-	Check the condition of the hydraulic hoses and connections	70
4	Clean the main and the air filter safety element	70
6	Replace the hydraulic oil filters (ONLY ON THE FIRST 50 HOURS)	71



After the first 50 hours of operation, replace the engine oil, the hydraulic system filter elements, the fuel filters, the engine lubricant oil;



Do NOT replace the hydraulic oil now.



In more severe temperature environments and dust, reduce the frequency of cleaning the radiator.

BIWEEKLY (Every 100 hours of operation)

ITEM ON PAG. 52	PROCEDURE	PAGE
16	Replace the front and rear axle oil (ONLY ON THE FIRST 100 HOURS)	72
19	Replace the oil filters of the transmission box (ONLY ON THE FIRST 100 HOURS)	72
7	Verify the torque in the screws of Chassis joint	72



Only the initial replacement. The other ones should be done every 1,000 hours.

Maintenance – Maintenance and lubrication procedures

MONTHLY (Every 250 hours of operation)

ITEM ON PAG. 52	PROCEDURE	PAGE
-	Check the conditions and tightening of the bolts and cushion of the cabin or operation platform	74
20	Check the transmission box oil level	74
16	Check the front and rear axle oil level	75
21	Check the parking brake disc and pads	75
1	Check and clean the radiator	76
14 - 15	Replace the lubricant oil and the engine oil filter	76
3 - 13	Replace the fuel filters	78

TRIMESTRIALLY (Every 500 hours of operation)

ITEM ON PAG. 52	PROCEDURE	PAGE
4	Replace the air filter main element	79
19	Replace the transmission box oil filters	79

BY-ANNUALLY (Every 1,000 hours of operation)

ITEM ON PAG. 52	PROCEDURE	PAGE
-	Check the condition of the hydraulic hoses and connections	80
6	Replace the hydraulic oil filters	81
5	Drain the condensed water from the hydraulic oil reservoir	82
18	Check the wear of the service brake friction discs	82
20	Replace the transmission box oil	83
4	Replace the air filter safety element	85
-	Check the clearance of the engine valves	85
11	Drain the sediment water from the fuel tank	86
2	Check the alternator's belt tensions (Tier IV Engine)	86
16	Replace the front and rear axle oil	87

Maintenance – Maintenance and lubrication procedures

ANNUALLY (Every 2,000 hours of operation)

ITEM ON PAG. 52	PROCEDURE	PAGE
5 - 6	Clean the reservoir, replace the hydraulic oil and the brake and fan drive circuit filters.	88
1	Replace the engine coolant.	89
11	Clean and refuel the fuel tank	90
-	Check the vibration shock absorber of the engine crankshaft	90

Maintenance – Daily (Every 10 hours of operation)

Daily (Every 10 hours of operation)





Fig. – Side control panel



1. The interlock, emergency stop and parking brake must be checked daily before operating. A function check of the interlock and emergency stop requires a restart.
2. The interlock function is checked by the operator standing up from the seat when the machine is moving very slowly forwards/backwards. (Check in both directions) .Hold the steering wheel firmly and brace yourself for a sudden stop. A buzzer goes and after 4 seconds the engine switches off and the brakes are activated.
3. Check the function of the emergency stop by pressing the emergency stop button when the machine is moving slowly forwards/backwards . (Check in both directions) . Hold the steering wheel firmly and brace yourself for a sudden stop . The engine switches off and the brakes are activated .
4. Check the function of the parking brake, start the machine engine. For further information, please refer to the chapters “Before drive the engine” and “Engine start”, in the Operation section, activate de parking brake and the test button 24 holding it activated. Press the work brake, put the first gear and accelerate the machine slowly forwards/backwards. The machine must remain stopped.



Maintenance – Daily (Every 10 hours of operation)

Check the brakes

Check the brakeage system in the following manner:

1. Run the machine engine. For further information, please refer to the chapters "Before drive the engine" and "Engine start", in the Operation section.
2. Release the parking brake (1). The warning lamp should turn off; otherwise check the cause of the problem.



Only release the parking brake if none of the warning lamps is on.

3. Move slowly the machine forward and backward, increasing and controlling the engine acceleration.
4. Press the service brake pedal. The machine should stop immediately, either forward or backward.
5. When finishing all testing, stop and turn off the machine. For further information, please refer to the chapters "Stopping" and "Parking", in the Operation section.

Maintenance – Daily (Every 10 hours of operation)

Check the scrapers adjustment

Assure that the scrapers are in good operational condition, otherwise, replace them.

If adjustment is needed, follow in the following manner:

1. Release the fixing bolts (1) from the scrapers bar, not completely.
2. Adjust the scraper so that its distance relevant to the cylinders stays among 1" (approx. 25 mm).

NOTE: Use a bar with a 1" diameter (approx. 25 mm) to assist on adjustment.

3. Tighten the fixing bolts again (1) with the following torque values:

- M20: 383 lb.ft (520 N.m) (dry) / 346 lb.ft (470 N.m) (greased)
- M16: 199 lb.ft (270 N.m) (dry) / 177 lb.ft (240 N.m) (greased)




Fig. – Adjustment of the scraping bars.

Maintenance – Daily (Every 10 hours of operation)

Check the tire pressure

Tire pressure should be checked when the tires are cold.

- Normal pressure: 3.1 bar (45 psi)
- Maximum pressure: 4.1 bar (60 psi) – When used for compactation
- Maximum pressure: 6.9 bar (100 psi) – When used as dozer




Fig. – Wheel, tire and compacting cylinder



When replacing the tires, it is important to know that they have the same diameter and original width, otherwise they can slide into the cylinder or unable its installation.




Fig. – Wheel, tire and compacting cylinder

Check the tightening of the wheel bolts


The wheel bolts should be tightened crossed, alternately and opposite to each other.

- Bolts dry torque: 545 lb.ft (740 N.m)

Maintenance – Daily (Every 10 hours of operation)

Check the hydraulic oil reservoir oil level


1. Park the machine in a leveled ground and shut off the engine.
2. Check the hydraulic oil reservoir (1) located on the left side of the machine, behind the operator's post.
3. If the oil level is 2 cm below the upper line of the display, fill with the recommended hydraulic oil.



Use only hydraulic oil recommended by **DYNAPAC**.

Fig. – Hydraulic oil reservoir

Check the alignment of the cab cushions



1. Park the machine on a completely flat surface, shut off the engine and the main switch.
2. Check if the arrow in the scales is aligned with the number ZERO, in the four cushions.

NOTE: The adjustment is at real time, or in others words, when a cushion is inflated or deflated, the other cushions are affected as well.

3. Apply compressed air in the valves or deflate the cushions crossed, according to the scale, starting from the front right side, then going to the rear left side, posteriorly, to rear right side and finally finishing the checking on the front left side.

Fig. – Alignment scale

NOTE: A compressor with a capacity of 50 psi is enough for the job.

Maintenance – Daily (Every 10 hours of operation)

Check the engine's coolant level




Fig. – Coolant reservoir

The level of the engine coolant can be visualized through the reservoir translucent walls (1) which are located in the engine compartment, near the radiators. The level should be between the marks "MIN" and "MAX" when the engine is cold.



During this operation, the coolant of the system is under pressure and very hot. NEVER open the cap of the expansion reservoir when the engine is warm.

The coolant should only be refilled when the engine is cold. If necessary, add coolant when the engine is still warm, wait 10 minutes. Initially turn the cap only once: it does allow the depressurization of the system. Wait a moment and then remove the cap completely.

Check the engine's lubricant oil level




Fig. – Engine's lubricant oil level

To check the oil level, shut down the engine and wait a few minutes, until all the oil returns to the crankcase.

1. Pull off the dipstick (2) and clean it with a clean cloth without threads.
2. Put the dipstick back all the way to the end and pull it out again.



Fig. – Dipstick

3. The oil level should be between the marks "FULL" and "ADD" of the dipstick. If it's not on the mark ADD or below, fill it with engine oil, according to **DYNAPAC** specifications.

4. Fill enough oil so that the level is near "FULL", through the filling cap (3).



Never fill the engine oil over the "FULL" mark.

Maintenance – Daily (Every 10 hours of operation)

Check the tension on the alternator's belt

Checking the belt tension should be done with a belt tension meter of tension type or Burroughs type.

- A new belt should have a tension of 200 lb (890 N).
- A used belt should have a tension of 80-160 lb (360-710 N).

NOTE: The belt is considered used after ten minutes of usage or more.

OBSERVATION: This procedure is not applied on automatic belt tensioners.



If the tension of a used belt is under the minimum value, adjust it again to the maximum value for used belts.




Fig. – Alternator's tension belt

Check the pre-filter's water divider

Check and drain the remaining water in the pre-filter divider.

1. Clean the filter body with a cloth, including the drainage plug.
2. At the lower part of the filter, loosen manually the water drainage plug (1).
3. Allow the water that is stored in the divider to run and as soon as the diesel oil starts running, close the plug.



TAKE CARE OF THE ENVIRONMENT: Don't allow the fuel to drain on the ground. Place a container under the filter before draining the water.





Fig. – Pre-filter and DIVder

Maintenance – Daily (Every 10 hours of operation)

Check the transmission box oil level




1. Turn the steering wheel completely to the right, to allow better access to the level display.



Keep personnel away from the chassis joint while executing this operation: risk of accidents.

2. Check the oil level, with the engine working in low idle and the transmission warmed up at 176 °F (80 °C), and through the display located on the left side of the machine.
3. Oil should be at the designated level of the display. If it's below this mark, fill with the recommended oil.

Fig. – Transmission box oil level



Check the Multi-function display and the operator's control keyboard

1. Turn the key starter switch (1) to the position "I". The screen of the multi-function display and the keys light up, including when there are failure indications.
2. In case of any control not turning on, replace it.

Fig. – Side panel

Maintenance – Daily (Every 10 hours of operation)

Refuel the fuel tank




Fig. – Fuel tank

Refuel daily with high quality diesel oil up to the beginning of the filler pipe, at the end of a working shift.



While filling the fuel, park the machine on a safe and leveled ground, turn the engine off and level the filler nozzle, putting it in contact with the chassis in a non isolated location, before filling the reservoir with fuel.



During this process, keep the tip of the pump in contact with the filler nozzle. Always fill with fuel recommended by DYNAPAC.



The usage of mixed, contaminated, dirty or low quality fuel damages the injection and engine components.

The repairs resulting from these conditions are NOT covered by the warranty.

Check the cabin's cushion height

The cab's height is verified through scales in 4 points of the cabin and all of them must be in the same position, around position ZERO ± 1

If the height must be adjusted, refer to "Cabin's cushion adjustment", in the Operation section, page 25

Maintenance – Daily (Every 10 hours of operation)

Check the exhaust gases post-treatment connecting line (Tier IV Engine)

Check leakages, cracking and loose connections in an exhaust line.

Check all the line connections, from the turbocharger up to the exhaust line. Be careful with the connecting lines of the Diesel Particulate Filter (DPF), and tight the clamps, if necessary.



For further information, refer to the Operation and Engine Maintenance Manual.

Check if there is damage and dirt in the exhaust gases post-treatment connecting line system. Clean it, if necessary.




Fig. – DPF

Clean the dust ejector valve (Tier IV Engine)

Clean the dust ejector valve from the air filter daily, after the working shift, pressing the valve and releasing the dust when it is open.

When there is no dust remaining in the valve, release it.



For further information, refer to the Operation and Engine Maintenance Manual.




Fig. – Dust ejector valve

Weekly (Every 50 hours of operation)

Check the tire pressure

Tire pressure should be checked when the tires are cold.

- Normal pressure: 3.1 bar (45 psi)
- Maximum pressure: 4.1 bar (60 psi) – When used for compactation
- Maximum pressure: 6.9 bar (100 psi) – When used as dozer




Fig. – Wheel, tire and compacting cylinder



When replacing the tires, it's important to know that they have the same diameter and original width, otherwise they can slide into the cylinder or unable its installation.




Fig. – Wheel, tire and compacting cylinder

Check the tightening of the wheel bolts

The wheel bolts should be tightening crossed, alternately and opposite to each other.

- Bolts dry torque: 545 lb.ft (740 N.m)

Maintenance - Weekly (Every 50 hours of operation)

Check batteries



Never smoke or allow sparks and flames to be exposed near the batteries while examining them. The batteries usually produce explosive gases, which can cause severe injuries.




Fig. – Batteries

1. Open the front cap of the equipment, where the batteries are located.
2. Clean the outer caps of the batteries.



While working with batteries protect you face and eyes, using the proper safety equipment and always arrange for proper fan.

3. Remove the cell caps and check the electrolyte level; it should be at least 0.4" (10 mm) above the plates. If necessary, complete the level with battery solution. If the environment operating temperature is below 32 °F (0 °C), the engine should run for a few minutes after completing the level, otherwise the solution may freeze.
4. Check if the cell cap breathers don't have restrictions; if necessary, clean them.
5. The battery terminals should be kept clean and the contact cables should be always tight. In case they are rusted, clean them with a water and sodium bicarbonate solution and apply a layer of Vaseline to prevent a new corrosion process.



When removing the battery, initially disconnect the negative (-) terminal. Nevertheless, when installing the battery, connect first the positive (+) terminal. Avoid that both terminals of the battery have any contact with the metallic tools or the unintentional contact between the positive terminal and the machine chassis, may cause a short circuit.



Before performing repairs with electric welding on the machine, disconnect the negative (-) terminal of the battery, and all the alternator's cables.



TAKE CARE OF THE ENVIRONMENT: return the used battery at the time of replacement, according to the local environmental legislation. Every consumer or user has the obligation to return the used battery to a specific dealer. Don't dispose of them in regular trash.

Maintenance - Weekly (Every 50 hours of operation)

Lubricate the chassis joint




Fig. – Chassis joint

1. Turn the steering wheel completely to the left to have better access to the grease fittings on the right side of the machine.



Keep personnel away from the chassis joint while executing this operation: risk of injuries.

2. Clean all the grease fitting nozzles before performing the lubrication.
3. Lubricate each grease fitting with approximately 5 manual cycles of the grease recommended by **DYNAPAC**. Certify that the grease has penetrated the bearings and that a small excess came out of them and from the grease fittings.



Use only grease recommended by **DYNAPAC**.

4. If the grease hasn't penetrated, it will be necessary to relief the bearing with a hydraulic jack, and to repeat the steps above.

Lubricate the steering system joints




Fig. – Steering joints

1. Clean all the grease fitting nozzles before performing the lubrication.
2. Lubricate each grease fitting (front and rear, on each side) with approximately 2 manual cycles of the grease recommended by **DYNAPAC**. Use only a hand grease fitting.



Use only grease recommended by **DYNAPAC**.

3. Certify that the grease has penetrated the bearings and that a small excess came out of them and from the grease fittings. It is recommended to keep a little bit of grease in the grease fitting, because it helps preventing the deposit of dirt on it.

Maintenance - Weekly (Every 50 hours of operation)

Lubricate the longitudinal transmission shaft (axle shaft)




Fig. – Longitudinal transmission shaft

1. Lubricate each grease fitting with the manual cycles of the grease recommended by **DYNAPAC**.



Use only grease recommended by **DYNAPAC**.

2. Certify that the grease has penetrated the spider and universal joints, and that a small excess came out of them and from the grease fitting nozzle. It is recommended to keep a little bit of grease in the grease fitting, because it helps preventing the deposit of dirt on it.

Check the condition of the hydraulic hoses and connections

Verify if the hydraulic system hoses and connections are loose, cracked or damaged, and if so, replace them.

Also check the seal rings and clamps. If they are damaged, replace them.





Fig. – Hydraulic connections

Maintenance - Weekly (Every 50 hours of operation)

Replace the hydraulic oil filters (ONLY ON THE FIRST 50 HOURS)



1. Open the reservoir cap to relief any kind of pressure inside it.
2. Verify if the filter breath of the cap is not clogged and clean it, if necessary.
3. Clean the area around the base of the filter.
4. Remove the filter elements with a belt wrench and discard it.
5. Clean inside the base of the filter and the housing of the seal ring.
6. Fill the new filter elements with new oil recommended by **DYNAPAC** and lubricate the seal ring with the same oil.



Use only hydraulic oil recommended by **DYNAPAC**.

7. Install the element, screwing it manually until it reaches the base of the filter, then adjust it with another ½ turn. Don't adjust it excessively, because the seal ring may be damaged and it may cause leaks.
8. Run the machine engine and check the oil level at the display and fill it if necessary (refer to the procedure "Verify the brakeage circuit hydraulic oil reservoir" in this section).
9. Inspect visually the filter and the reservoir for leakages.



The filters are below the reservoir and can be accessed by the right side of the engine compartment.

Maintenance - Biweekly (Every 100 hours of operation)

Biweekly (Every 100 hours of operation)

Replace the front and rear axle oil (ONLY ON THE FIRST 100 HOURS)



This oil replacement should be done only with 100 hours of operation. The other ones should be done every 1,500 hours.



Never perform maintenance under the machine when the engine is running. Always park the machine on a leveled ground and shim the cylinders.




Fig. – Differential axle

1. Make sure that the machine is on a leveled ground and the parking brake is applied.
2. Clean the area around the drainage plug (1) and remove the refueling plug (2).
3. Release and remove the drainage plug and drain the oil in a proper container.
4. Install the drainage plug and tighten it with a 69 lb.ft (93 N.m) torque.
5. Refill with the recommended oil until the edge of the refueling plug.

Replace the transmission box oil filters (ONLY ON THE FIRST 100 HOURS)




Fig. – Transmission box oil filters

1. Clean the area around the base of the filters.
2. Remove the filter elements individually with a belt wrench and discard them.
3. Clean inside the base of the filters and the housing of the seal rings.
4. Complete the new filters elements with new oil recommended by **DYNAPAC** and lubricate the seal ring with the same oil.



Use only hydraulic oil recommended by **DYNAPAC**.

5. Install the elements individually, screwing them manually until they reach the base of the filter, then adjust it with another ½ turn. Don't adjust it excessively, because the seal ring may be damaged and it may cause leaks.

Maintenance - Biweekly (Every 100 hours of operation)

6. Run the engine at low idle and with the transmission warmed up at 176 F (80 °C), check the oil level on the display and refill if necessary (refer to the procedure "Check the transmission box oil level", in this section).
7. Inspect visually the transmission box for leakages.

Verify the torque in the screws of Chassis joint




Fig. – Top Screw




Fig. – Lower Screw

1. Make sure that the machine is on a leveled ground and the parking brake is applied.
2. With a torque wrench verify if the top screw is with 200 Nm. If necessary make the torque in screw.
3. With a torque wrench verify if the lower screw is with 556 Nm. If necessary make the torque in screw.

Maintenance - Monthly (Every 250 hours of operation)

Monthly (Every 250 hours of operation)

Check the conditions and tightening of the bolts and cushion of the cabin or operation platform




Fig. – Cushion of the cabin

1. Carry out a visual inspection of the cushions, brackets and dampers of the cabin or the operation platform. If necessary, replace them.
2. Tighten the fixing bolts again, if necessary.
3. Tighten all bolts and nuts of the cabin's accessories again (rear view mirrors, caps, A/C, etc).



If the machine operates under severe conditions, replace the cushions if their rubber or spacer is damaged.

Check the transmission box oil level




Fig. – Transmission box oil level

4. Turn the steering wheel completely to the right, to allow better access to the level display.



Keep personnel away from the chassis joint while executing this operation: risk of accidents.

5. Check the oil level, with the engine working in low idle and the transmission warmed up at 176 °F (80 °C), and through the display located on the left side of the machine.
6. Oil should be at the designated level of the display. If it's below this mark, fill with the recommended oil.

Maintenance – Monthly (Every 250 hours of operation)

Check the front and rear axle oil level



Never perform maintenance under the machine when the engine is running. Always park the machine on a leveled ground and shim the cylinders.




Fig. – Differential axle

1. Make sure that the machine is on a leveled ground and the parking brake is applied.
2. Clean the area around the refueling plug (2).
3. Loose and remove the refueling plug and check the oil level. The correct level can be found when the oil flows out from the plug hole.
4. Fill it with the recommended oil, if necessary, through the refueling plug until it reaches the correct level.
5. Install the drainage plug and tighten it with a 69 lb.ft (93 N.m) torque.

Check the parking brake disc and pads




Fig. – Parking brake disc

1. Check the parking brake pads for wear. Replace the pads if their thickness is less than 6 mm.
2. Check if the thickness of the disc (3) has any cracks or splits and if the friction surface is damaged or excessively scratched. Replace the disc if the thickness is less than 10 mm and if any of the above mentioned defects exist.

Maintenance - Monthly (Every 250 hours of operation)

Check and clean the radiator




Fig. – Radiators

1. Make sure that the air flow is freely passing through the radiators, without any obstructions. In case the hives are dirty, wash them with running water (with the engine off) and clean them with pressurized air.



Every time you are using the pressurized air, you must wear safety goggles.



Whenever possible, clean the hives in the opposite direction of the fan air flow. Always cover the electric and electronic components during the washing of the hives.




In more severe temperature environments and dust, reduce the frequency of cleanings.



Whenever possible, clean the hives in the opposite direction of the fan air flow. Always cover the electric and electronic components during the washing of the hives.

Replace the lubricant oil and the engine oil filter



Never perform maintenance under the machine when the engine is running. Always park the machine on a leveled ground and shim the cylinders.

1. Make sure that the roller is on a leveled ground and the parking brake is applied, then open both the engine side covers.
2. Open the cap of the oil filler nozzle (1).
3. Clean the area around the refueling plug.
4. Remove the drainage plug (2) located behind the rear axle, at the right side of the machine, then drain the crankcase oil in a proper container.



Used oil is harmful to the health. Avoid contact with the skin for long periods of time and wash your hands thoroughly with water and soap after handling.



TAKE CARE OF THE ENVIRONMENT: All used oil shall be collected and stored properly for recycling. Don't discard oil on the soil, sewerage system or any other location that can harm the environment.




Fig. – Engine's lubricant oil drainage plug and cap

Maintenance – Monthly (Every 250 hours of operation)

Replace the lubricant oil and the engine oil filter (cont.)




Fig. – Engine oil filter

1. Clean the area around the engine base of the oil filter.
2. Remove the filter element (3) with a belt wrench and discard it.
3. Clean inside the base of the filter and the housing of the seal ring.
4. After draining all the crankcase oil, install the drainage plug and tighten it.
5. Fill the new filter element with new oil recommended by **DYNAPAC** and lubricate the seal rings with the same oil.



Use only engine oil recommended by **DYNAPAC**.

Install the element, screwing it manually until it reaches the base of the filter, then adjust it with another $\frac{1}{2}$ turn. Do not adjust it excessively, because the seal ring may be damaged and it may cause leaks.




Fig. – Engine oil dipstick and filler nozzle

6. Fill the engine again with the new engine oil recommended by **DYNAPAC**, with the proper amount, through the filler nozzle (1).
7. Wait a few minutes until the oil is entirely inside the crankcase.
8. Pull the dipstick (2) out ; clean it with a clean cloth, without threads.
9. Put the dipstick back all the way to the end and pull it out again.
10. The oil level should be between the marks “FULL” and “ADD” of the dipstick. If the level is not on the mark ADD or below it, fill it with new engine oil, according to **DYNAPAC** specifications.
11. Fill enough oil so that the level is near the mark “FULL”, through the filler nozzle (1).



Fig. – Dipstick




Never fill the engine oil over the “FULL” mark.

12. Close the oil filler nozzle and the engine compartment caps.

Maintenance - Monthly (Every 250 hours of operation)

Replace the fuel filters



1. Clean the area around the bases of the fuel pre-filter and main filter.
2. Remove the pre-filter (1) and main filter (2) elements with a belt wrench and discard them properly.

NOTE : The pre-filter has a black stripe indicating when it should be replaced. The replacement should be done when the fuel level reaches the black strip.

3. Clean inside the bases of the filters and the housing of the ring seals.
4. Fill the new filter elements with fuel recommended by **DYNAPAC** and lubricate the seal rings with the same fuel.



Use only filters recommended by **DYNAPAC**.

5. Install the elements tighten them manually until they reach the base of the filter, then adjust it with another $\frac{1}{2}$ turn. Do not adjust it excessively, because the seal ring may be damaged and it may cause leaks.




Fig. – Fuel pre-filter and main filter

Maintenance – Monthly (Every 250 hours of operation)




Fig. – Air filter

Quarterly (Every 500 hours of operation)

Replace the air filter main element

1. Release the clamps and remove the cap (1).
2. Remove the main element from the air filter casing, pulling it out.
3. Clean inside the filter casing and the inlet pipe with a cloth without threads.



NEVER use twine to clean inside the air filter and its components.

4. Install the new main element on the air filter casing, pressing it against the casing base;
5. Mount the cap again and press the clamps (1).

Replace the transmission box oil filters




Fig. – Transmission box oil filters

1. Clean the area around the base of the filters.
2. Remove the filters element individually with a belt wrench and discard them.
3. Clean inside the base of the filters and the housing of the seal rings.
4. Complete the new filters elements with new oil recommended by **DYNAPAC** and lubricate the seal ring with the same oil.



Use only hydraulic oil recommended by **DYNAPAC**.

5. Install the elements individually, screwing them manually until they reach the base of the filter, then adjust it with another $\frac{1}{2}$ turn. Do not adjust it excessively, because the seal ring may be damaged and it may cause leaks.
6. Run the engine at low idle and with the transmission warmed up at 176 F (80 °C), check the oil level on the display and refill if necessary (refer to the procedure "Check the transmission box oil level", in this section).
7. Inspect visually the transmission box for leakages.

Maintenance - Bi-annually (Every 1,000 hours of operation)

Bi annually (Every 1,000 hours of operation)

Check the condition of the hydraulic hoses and connections

Verify if the hydraulic system hoses and connections are loose, cracked or damaged, and if so, replace them.

Also check the seal rings and clamps. If they are damaged, replace them.




Fig. – Hydraulic connections

Maintenance – By-annually (Every 1,000 hours of operation)

Replace the hydraulic oil filters




Fig. – Hydraulic reservoir cap

1. Open the reservoir cap (1) to relief any kind of pressure inside it.
2. Verify if the filter breath of the cap is not clogged and clean it, if necessary.




Fig. – Hydraulic filters

3. Clean the area around the bases of the filter.
4. Remove the filter elements with a belt wrench and discard them properly.
5. Clean inside the base of the filter and the housing of the seal ring.
6. Fill the new filter elements with new oil recommended by **DYNAPAC** and lubricate the seal ring with the same oil.



Use only hydraulic oil recommended by **DYNAPAC**.

7. Install the elements (2), tightening them manually until they reach the bases of the filter, then adjust it with another $\frac{1}{2}$ turn. Do not adjust it excessively, because the seal ring may be damaged and it may cause leaks.
8. Run the machine engine and check the oil level at the display and fill it if necessary (refer to the procedure "Verify the brakeage circuit hydraulic oil reservoir" in this section).
9. Inspect visually the filter and the reservoir for leakages.



The filters are below the reservoir and can be accessed by the right side of the engine compartment.

Maintenance - By-annually (Every 1,000 hours of operation)

Drain the condensed water from the hydraulic oil reservoir




Fig. – Hydraulic oil drainage plug

1. Place a proper container under the drainage plug of the reservoir.
2. Open the drainage plug and only allow the water to drain from the reservoir.
3. Close the drainage plug.
4. Check the reservoir level display. If the oil level is 2 cm below the upper line of the display, fill with the recommended hydraulic oil.



Use only hydraulic oil recommended by **DYNAPAC**.

Check the wear of the service brake friction discs



Never perform maintenance under the machine when the engine is running. Always park the machine on a leveled ground and shim the cylinders.




Fig. – Inspection of wear of the brake lining

1. Make sure that the machine is on a leveled ground and the parking brake is applied.
2. Clean the area around the inspection plug of the service brake friction discs.
3. Release and remove the inspection plug of the service brake friction discs (1) and check the thickness of the friction discs:

Friction Disc pol (mm)	Stationary Disc pol (mm)	Wear of the Disc Wear %
0.209 (5,31)	0.180 (4.56)	0
0.194 (4.93)	0.168 (4.26)	50
0.180 (4.56)	0.156 (3.96)	100

4. If the discs have 100% of wear, contact **DYNAPAC** immediately.
5. Install the inspection plug of the service brake friction discs and tighten it with 69 lb.ft (93 N.m) torque.

Maintenance – By-annually (Every 1,000 hours of operation)




Fig. – Transmission box oil level

Replace the transmission box oil

1. Turn the steering wheel completely to the right, to allow better access to the level display.

NOTE: Make sure that the machine is on a leveled ground and the parking brake is applied.



Keep personnel away from the chassis joint while executing this operation: risk of accidents.

2. Clean the area around the drainage plug and remove the refueling plug.
3. Release and remove the drainage plug and drain the oil in a proper container.



Used oil is harmful to the health. Avoid contact with the skin for long periods of time and wash your hands thoroughly with water and soap after handling.

NOTE: Drain the transmission box oil with a temperature between 176 °F (80 °C) - 194 °F (90 °C).



TAKE CARE OF THE ENVIRONMENT: All used oil shall be collected and stored properly for recycling. Do not discard oil on the soil, sewerage system or any other location that can harm the environment.

4. Clean the area around the base of the filters.
5. Remove the filters element individually with a belt wrench and discard them.
6. Clean inside the base of the filters and the housing of the seal rings.
7. Fill the new filters elements with new oil recommended by **DYNAPAC** and lubricate the seal ring with the same oil.



Use only filters recommended by **DYNAPAC**.

8. Install the elements individually, screwing them manually until they reach the base of the filter, then adjust it with another ½ turn. Do not adjust it excessively, because the seal ring may be damaged and it may cause leaks.
9. Install the drainage plug and tighten it with a 69 lb.ft (20 N.m) torque.
10. Refill with the recommended oil until the lower mark on the display.

Maintenance – By-annually (Every 1,000 hours of operation)

Replace the transmission box oil (cont.)



Use only oil recommended by **DYNAPAC**.




Fig. – Transmission box oil level

11. Run the engine and keep it at low idle until it fills the lines and feeds the torque converter (approximately 8 minutes).
12. Check the level with the engine at low idle, and add recommended oil until the lower mark of the display.
13. When the oil temperature is between 356 °F (180 °C) - 392 °F (200 °C), perform the final verification of the level.
14. The oil should be at the maximum level, as indicated on the display. If it is below this mark, fill with the recommended oil.

Maintenance – By-annually (Every 1,000 hours of operation)

Replace the air filter safety element




Fig. – Air filter

The air filter is located on the right side of the engine compartment.

1. Release the clamps and remove the cap.
2. Remove the main element from the air filter casing, pulling it out.
3. Remove the safety element, pulling it out, than discard it.
4. Clean inside the filter casing and the inlet pipe with a cloth without threads.



NEVER use twine to clean inside the air filter and its components.

5. Inspect the condition and torque of the hoses and connections between the filter and the engine. Repair, if necessary.
6. Install the new safety element on the air filter casing, pressing it against the casing's base;



Replace the safety element every time you detect any trace of dirt. The element cannot be cleaned or reused.

7. Install the main element on the air filter casing, pressing it against the casing base ; Clean it, if necessary.
8. Clean the air collector installed on the cap of the air filter, and inside the cap as well.
9. Mount the cap on the casing of the filter and close the clamps.

Check the clearance of the engine valves



The machine engine has modern constructive characteristics that avoid the constant adjustment of the valve clearance.

The valve train was designed so that the valve clearance does not need adjusting in regular service, during at least 5,000 hours (approximately 149,130 mi [240,000 km]).

For further information, contact DYNAPAC.

Maintenance – By-annually (Every 1,000 hours of operation)




Fig. – Fuel tank drainage plug

Drain the sediment water from the fuel tank



NEVER perform maintenance under the machine when the engine is running. Always park the machine on a leveled ground and shim the cylinders.

1. Place a proper container under the drainage plug of the fuel tank (1).
2. Release the plug (1) and allow the sediment water to drain until the clean fuel starts to drain.
3. Reinstall the drain plug and tighten it.
4. Repeat the operations above on the opposite side plug.

NOTE: The sediment water draining process on the fuel tank should also be made when the equipment is not being used for a long period of time.

Check the alternator belt tensions (Tier IV Engine)

Checking the belt tension should be done with a belt tension meter of tension type or Burroughs type.

- A new belt should have a tension of 200 lb (890 N).
- A used belt should have a tension of 80-160 lb (360-710 N).

NOTE: The belt is considered used after ten minutes of usage or more.

OBSERVATION: This procedure is not applied on automatic belt tensioners.




Fig. – Alternator's tension belt



If the tension of a used belt is under the minimum value, adjust it again to the maximum value for used belts..

Maintenance – By-annually (Every 1,000 hours of operation)

Replace the front and rear axle oil (initial)



This oil replacement should be done only with 100 hours of operation. The other ones should be done every 1,000 hours.



Never perform maintenance under the machine when the engine is running. Always park the machine on a leveled ground and shim the cylinders.




Fig. – Differential axle

1. Make sure that the machine is on a leveled ground and the parking brake is applied.
2. Clean the area around the drainage plug (1) and remove the refueling plug (2).
3. Release and remove the drainage plug and drain the oil in a proper container.
4. Install the drainage plug and tighten it with a 69 lb.ft (93 N.m) torque.
5. Refill with the recommended oil until the edge of the refueling plug.

Maintenance - Annually (Every 2,000 hours of operation)

Annually (Every 2,000 hours of operation)

Clean the reservoir and replace the hydraulic oil and filters

1. Park the machine in a leveled ground and shut off the engine.
2. Provide a container capable of draining the hydraulic circuit reservoir.
3. Remove the inspection cap, located on the upper part of the reservoir, releasing its fixing bolts.

NOTE: Remove eventual residues of the flange seal joint on the inspection orifice.

4. Open the drainage plug and drain all the reservoir content.



TAKE CARE OF THE ENVIRONMENT: All used oil shall be collected and stored properly for recycling. Do not discard oil on the soil, sewerage system or any other location that can harm the environment.

5. Perform an internal cleaning of the reservoir using hot water under pressure, with a proper detergent. Clean the reservoir until the dirt is totally eliminated, then dry it with pressurized air.
6. Close the drainage plug and reinstall the inspection cap, tightening the fixing bolts.

NOTE: Replace the seal joint cap.

7. Fill the reservoir with recommended hydraulic oil until the correct level (refer to "Check the oil reservoir level").



Use only hydraulic oil recommended by **DYNAPAC**.

8. Replace the hydraulic oil filter elements (refer to the item "Replace hydraulic oil filters").
9. Start the engine and operate the main functions of the hydraulic circuit, such as brakes and the fan drive circuit.
10. Check the oil level and fill it, if necessary.

Maintenance – Annually (Every 2,000 hours of operation)

Replace the engine coolant.



Caution! Risk of severe burns!
Wait until the engine's temperature is below 122 °F (50 °C) before removing the cap of the coolant reservoir or draining the cooling system.

1. Open the expansion reservoir cap.



NEVER open the coolant reservoir cap while the engine is hot.

2. Drain the engine cooling system through the radiator drain valve.

NOTE: Use a proper container to collect the coolant.



TAKE CARE OF THE ENVIRONMENT: All used coolant shall be collected and stored properly for recycling. Do not discard coolant on the soil, sewerage system or any other location that can harm the environment.

3. Fill the system through the expansion reservoir, with the proper mixture of coolant, according to the item "Symbols and Lubricants".
4. The level of the engine coolant can be visualized through the reservoir translucent walls, which are located in the engine compartment, near the radiators. The level should be between the marks "MIN" and "MAX" when the engine is cold.



During this operation, the coolant of the system is under pressure and very hot. NEVER open the cap of the expansion reservoir when the engine is warm.

5. The coolant should only be refilled when the engine is cold. If necessary, add coolant when the engine is still warm, wait 10 minutes. Initially turn the cap only once: it does allow the depressurization of the system. Wait a moment and then remove the cap completely.

Maintenance - Annually (Every 2,000 hours of operation)

Clean and refuel the fuel tank



NEVER perform maintenance under the machine when the engine is running. Always park the machine on a leveled ground and shim the cylinders.




Fig. – Fuel tank

1. Open the fuel tank cap.
2. Place two proper containers under the drainage plugs of the fuel tank.

NOTE: A small amount of new fuel shall remain in the reservoir.

3. Release the drainage plugs and the fuel remaining in the reservoir.
4. Reinstall the drainage plugs and tighten them.
5. Refuel the fuel tank. For further information, refer to the item "Refuel the fuel tank".



The usage of mixed, contaminated, dirty or low quality fuel damages the injection and engine components. The repairs resulting from these conditions are NOT covered by the warranty.

Check the vibration shock absorber of the engine crankshaft




Fig. – Vibration shock absorber of the engine crankshaft

1. Inspect the rubber element of the shock absorber and check if it is worn. If there are missing pieces of rubber or if the rubber element is more than 0.125" (3.18 mm) under the metal surface, replace the component.
2. Check if there is an excessive clearance on the outer ring of the vibration shock absorber or if it is damaged, tampered or cracked. Replace the vibration shock absorber, if necessary.

NOTE: If it is necessary to replace the vibration shock absorber, contact **DYNAPAC**.

Maintenance – Annually (Every 2,000 hours of operation)

Long lasting intervals




Fig. – Tamping roller protected against wear and tear.




The following instructions should be noticed if there is the intention of keeping the machine parked over a month without any usage.

These parameters are applied to long lasting intervals up to six months.

Diesel Engine	*	<ul style="list-style-type: none"> For further information on long lasting engine intervals, refer to CUMMINS Engine Manual.
Battery	*	<ul style="list-style-type: none"> Remove the battery from the machine, clean it externally, check the electrolyte level, and if necessary, charge it monthly.
Air filter	*	<ul style="list-style-type: none"> Cover the air filter inlet with a plastic cover and seal it with adhesive tape.
Exhaust pipe	*	<ul style="list-style-type: none"> The nozzle of the exhaustion pipe should be covered using the same procedure mentioned above (air filter).
Fuel tank		<ul style="list-style-type: none"> Refuel completely the tank in order to avoid water condensation and corrosion.
Hydraulic oil reservoir		<ul style="list-style-type: none"> Drain the accumulated water on the bottom of the reservoir.
Caps, plastic canvas, Hydraulic cylinder, joints, etc	*	<ul style="list-style-type: none"> Apply grease on the steering joint, on both cylinder edges. Cover the cylinder steering rod with grease to avoid oxidation. Apply grease on the forward/reverse joint control.
Tires	*	<ul style="list-style-type: none"> Check if the tires have at least 3.1 bar (45 PSI) pressure.
Cover	*	<ul style="list-style-type: none"> Lower the cover of the instrument panel, cover the entire machine with a plastic canvas, without allowing it to touch the floor. If possible, store the machine in a shelter place, like a warehouse with stable temperature.

The instructions above marked with * should be performed one more time before operating the roller again.

Special instructions

Recommended standard fluids and oil	<p>When the machine leaves the factory, it is fueled with the recommended fluids and oils indicated in the item “Symbols and lubricants”, which are the proper ones for operating in environments with temperatures between 14 °F (-10 °C) - + 104 °F (40 °C).</p> <p>The following recommendations are only applied for operations under temperatures up to + 122 °F (50 °C).</p>
Maximum room temperature: + 122 °F (50 °C)	<p>The engine can operate up to this temperature using the standard operating oil, but for other components, use fluids with SAE 20W specification.</p>
High pressure washing	<p> It is important to verify if the water jet under pressure is not hitting the fuel tank and hydraulic system caps.</p> <p>Cover the filler nozzle caps with plastic and secure it with rubber bands. This procedure prevents the water to penetrate in the cap breath hole, which may cause issues in the involved systems and possible clogging in the filters.</p> <p>NEVER drive the water jet under pressure into electrical or electronic components, or into the instrument panel (always keep them covered with caps or plastic wrappers).</p>
Fire extinguishers	<p>In case of fire on the equipment, use the carbon powder or carbon dioxide class ABC fire extinguisher.</p>
Roll Over Protective Structure (ROPS)	<p>NEVER perform welding or make holes on the ROPS structure.</p> <p>NEVER repair a ROPS structure; replace it for a new one.</p>
Auxiliary starter	<p>While using an auxiliary battery in parallel with the ones installed on the roller, always connect the positive (+) terminal of the auxiliary battery to the positive (+) terminal of the installed battery, and the negative (-) terminal of the auxiliary battery to the negative (-) terminal installed on the roller.</p>
Welding on the structure	<p>To perform any welding work on the machine, proceed as follows:</p> <ul style="list-style-type: none"> - Turn off the main switch; - Remove the connectors from all the electronic modules or remove the grounded cables from the machine (3 on chassis and 2 on the cab). <p>For further information, refer to the chapter "Welding on the structure".</p>

Welding on the Structure

In order to prevent damage on the electronic modules, it is necessary to perform the welding correctly. Whenever possible, remove the component to be welded from the machine or engine, and only after that carry out the operation/maintenance. If it is necessary to perform the welding next to one of the engine or machine electronic modules, remove it for a while, to prevent possible damage due the heat or electric discharge.

To perform welding on machine or engine components, proceed as follows:

1. Turn off the engine. Put the engine key starter switch in the position "O".
2. Put the main switch in the position "OFF".



NEVER use electronic components (ECM or ECM sensors) or electronic components linkage points to the ground to turn on the welding machine to the ground.




Fig. – Tamping roller


3. Remove the connectors from the machine electronic modules (engine and transmission ECM, Multifunction display etc) or remove the grounded cables from the machine (3 on chassis and 2 on the cab). Refer to the chapter "Electric System" in order to find the location of these points.
4. Attach the ground connecting cable of the welding machine to the structural component to be welded. Put the fastening element as near as possible to the welding. Make sure that the ground connecting cable reaches the structural component without passing through any bearing. Follow the procedure above to reduce the damage occurrence on the components below:
 - Transmission bearings;
 - Hydraulic components;
 - Electric components;
 - Other components.
5. Protect the cables so there is no dirt on them due residues remaining from the welding process. Protect the cables so there is no dirt on them due residues remaining from the welding process.
6. Adopt standardized techniques to perform welding on the machine.



Any damaged inflicted on the electronic components of the machine which result from the failure in complying with the procedures above, will invalidate the product warranty.

Hydraulic System Pressure Values

The machine has 8 pressure measurement points, and maintenance and verification can be performed through them:



POINT 1 – Steering system pressure measurement point It is located on the front chassis, at the left side, next to the joint.

- Measurement pressure: Maximum of 170 bar (2,466 psi)




Fig. – Measurement point 1

Maintenance – Special instructions





Fig. – Measurement points 2,3,4 and 5

POINT 2 – Fan drive pressure measurement point. It is located on the rear chassis, at the right side, on the engine's cap (1st point from the rear to the front part).

- Measurement pressure: 100 bar (1,450 psi) with the fan working at 2,200 RPM. (to realize measurement press the Engine radiators assembly cleaning button )




Fig. – Fan pump solenoid

POINT 3 – Fan drive pressure measurement point. It is located on the rear chassis, at the right side, on the engine's cap (2nd point from the rear to the front part).

- Measurement pressure: 280 bar (4,061 psi) with the fan working at 2,200 RPM (to perform the measurement disconnect the fan pump solenoid)

POINTS 4 & 5 – Radiator pressure measurement point. It is located on the rear chassis (input and output), at the right side, on the engine's cap (3rd and 4th points from the rear to the front part).

- Measurement maximum pressure: 4 bar (60 psi) with the fan working at 2,200 RP





Fig. – Measurement point 6

POINT 6 – Blade pressure measurement point. It is located on the front chassis, at the right side, next to the joint.

- Measurement pressure: Maximum of 140 bar (2,030 psi)


Maintenance – Special instructions



POINT 7 – Rear brake measurement point. It is located on the rear chassis, at the right side, next to the joint and transmission.

- Measurement pressure: Maximum of 40 bar (580 psi).

Fig. – Measurement point 7



POINT 8 – Front brake measurement point. It is located on the front chassis, at the right side, next to the joint.

- Measurement pressure: Maximum of 40 bar (580 psi).

Fig. – Measurement point 8

Electrical system

The fuse and relay box is located on the left side of the machine, right under the operation post.

The machine is equipped with a 12 V electrical system, supplied by a 95 A alternator powered by two batteries.



Connect the batteries on their correct polarity (negative terminals to the mass). The cable between the batteries and the alternator shall never be disconnected while the engine is running.




Before performing repairs with electric welding on the machine, disconnect the negative (-) terminal of the battery, and all the alternator cables.

Fuses

Fuse box F1:

It is located on the engine compartment, at the left side.



1. Key starter switch, main relay (5A)
2. Main ECM, I/O unit, screen (5A)
3. Main ECM PWR 1 (10A)
4. Main ECM PWR 2, optional (10A)
5. Main ECM PWR 3 (20A)
6. Main ECM PWR 4 (20A)
7. Electric jack, 24 V (10A)
8. Transmission ECM (10A)

Fig. – Fuse box F1

Cabin fuse box

It is located on the cabin roof, above the switch panel.




Fig. - Cabin's fuse box

1. Inner Illumination (10A)
2. CD/Radio (10A)
3. Air Conditioning (15A)
4. Heating system (10A)
5. Front windshield washer and wiper (10A)
6. Rear windshield washer and wiper (10A)
7. Free
8. Free

Main fuse panel

The main fuse panel is located behind the battery main switch, on the batteries compartment.





Fig. – Main fuse panel


1. Main switch
2. Pre-heating relay (120A)
3. Fuse F20 (pre-heating 125A)
4. Starting relay (50A)
5. Fuses F13 (Engine 30A ECM), F10 (main 50A) and F11 (cabin 50A)
6. Fuse F5 (cabin/CD/radio 10A)
7. Electric jack, 24 V

Electronic modules



The electronic modules are located on the engine compartment, at the left side of the machine, and can be accessed by opening the cap with a belt wrench.

Fig. – Electronic modules compartment



The engine electronic module (1) is located on its right side, next to the diagnostic connector - DLC (2).

Fig. – Electronic modules compartment



Rua Georg Schaeffler, 430, Sorocaba/SP, Brasil
Tel.: +55 (15) 3412-7500 Fax.: +55 (15) 3412-7522
www.atlascopco.com.br