

OPERATION & MAINTENANCE Paver F1000T

Type 717



Keep this manual for future reference

Order number for this manual: D717.41.00.38

1DEC2011





VALUE QUALITY THE ORIGINAL

Your Authorized Dynapac Dealer:

Table of contents

V	Preface	1
1 1.1	General safety instructions Acts, directives, accident prevention regulations	3 3
1.2	Warning instructions	3
1.3	Prohibitive signs	6
1.4	Protective gear	7
1.5	Environmental protection	8
16	Fire prevention	8
1.7	Further instructions	9
Α	Correct use and application	1
В	Vehicle description	1
4	Application	4
1		1
2	Description of assemblies and functions	2
2.1	Vehicle	3
_	Construction	3
3	Danger Zones	6
4	Technical data, standard configuration	7
4.1	Dimensions (all dimensions in inches)	7
4.2	Allowed angle of rise and slope	8
4.3	Permissible approach angle	8
4.4	Turning circle	8
4.5	Weights, F1000W	9
4.6	Performance data	9
4.7	Traction drive/chassis 1	0
4.8	Engine	0
4.9	Hvdraulic systemOperator stations	0
4 10	Flectrical system	0
4 11	Operator stations	1
1 12	Material compartment (honner)	i
1 12	Convoyor	1
4.10	Conveyor	1
4.14	Augeri	1
4.15	Permissible temperature ranges	1
5	Location of instruction labels and identification plates	2
6		1
6.1	Continuous sound pressure level on the F1000W Wheeled Paver, Cummins	_
	QSB-6.70 Tier III Engine	7
6.2	Operating conditions during measurement 1	7
6.3	Measuring point configuration1	8
C1.1	Transport	1
1	Safety regulations for transportation	1
2	Transportation on low-bed trailers	3
2.1	Preparations	3
2.2	Driving onto the low-bed trailer	6
23	Secure the paver finisher to the low-bed trailer	6
2.4	After transportation	7

3	Transportation8	3
3.1	Preparations8	3
3.2	Driving mode11	I
4	Loading by crane	3
5	Towing15	5
6	Safely parking the vehicle	3
D1.1	Operation1	
1	Safety regulations	1
2	Controls	2
2.1	Operating panel	2
3	Auxiliary functions	5
4	Left / right remote controls and handsets 27	7
·	Left / right remote control 22	2
	Left / right handset	7
ח כים	Onoration 1	1
D2.0		
1	Operation of the graphical terminal 1	I
1.1	Navigation using Soft Keys 2)
	Brightness/Contrast	
	Adjustment	3
	Main Menu - Start Menu	3
	Main Menu - Basic Setup 4	ļ
	Main Menu - Basic Setup	
	-Time / Date	5
	Main Menu - Basic Setup	
	-Language	5
	Main Menu - Basic Setup	
	-Units	3
	Main Menu - Diagnostics	7
	Main Menu - Diagnostics	
	-System Info	2
	Main Menu - Diagnostics	'
	-Fault Log	ł
	Main Menu - Diagnostics	΄
	-Fault Log	
	Active and Previous Faults	ג
	Main Manu - Diagnostics	'
	Fault Pop Lip Alarma 10	۱
	-rault rop-op Alams	J
	Main Menu - Diagnosiics	•
	-Device List	1
	Main Menu - Diagnostics	`
		-
	Start Display	5
	Uispiay 01	ł
	Display menu	ł
	Display 02	ł
	Display menu	ł
	Active Faults Display15	5
	Fault Sources and Codes15	5
	Warnings Display17	7

US_wheel_10ftIVZ.fm 2-6 - 02-0103

1.2 1.3	Engine Error messages FMI-codes	18 23
D3.0	Operation	1
1	Operating elements on the paver Operator's platform Seat console Operating panel Driver's seat Batteries Battery main switch Transport safeguards for the hopper Mechanical screed transport safeguard (to the left and the right beneath	1 1 1 2 2 3 4
	the driver's seat) Paving thickness indicator Release Agent System On/Off switch of working lights (1) On/Off switch hazard flasher (2): Warning Beacon Conveyor limit sensors Ultrasonic auger limit sensors (left and right) Sockets 24V	4 5 6 7 7 7 8 8 8
D4.0	Operation	1
1	Preparation of operation Required equipment and tools Before starting work (in the morning or when starting paving)	1 1 2
1.1	Checklist for the machine operator Starting the paver Before starting the paver "Normal" starting Jump starting After starting	2 5 5 7 7
1.2	Transport Operation Lifting and securing the screed Driving and stopping the paver	11 11 11 11
1.3	Preparations for paving Releasing agent Screed heater Direction marks Loading/distributing material	12 12 12 12 12 12 14
14	Starting for paving	16
1.5	Check during paving Paver function Quality of the laver	17 17 17 17
1.6	Interrupting/terminating operation During breaks (i.e. the material supply truck is late) During extended interruptions (i.e. lunch break)	19 19 19

	When work is finished	21
2	Malfunctions	22
2.1	Problems during paving	22
2.2	Malfunctions on the paver or screed	24
E1.0	Set-up and modification	1
1	Special notes on safety	. 1
2	Auger	. 2
2.1	Height adjustment	. 2
2.2	Auger crossbeam - hydraulic height adjustment	. 2
2.3	Auger extension	. 3
2.4	Mounting extension parts	. 4
2.5	Mounting support tube extensions	. 5
2.6	Installing tunnel plates	. 6
2.7	Installing additional braces	. 7
3	Screed	. 8
4	Electrical connections	. 8
4.1	Remotes from screed to paver	. 8
4.2	Right hand conveyor sensor control	. 8
4.3	Right hand auger sensor control	. 8
4.4	Left hand conveyor sensor control	. 9
4.5	Left hand auger sensor control	. 9
4.6	Auger Chart	10
F1.0	Maintenance	1
1	Notes regarding safety	. 1
1 F2.1	Notes regarding safety Maintenance Overview	. 1 1
1 F2.1 1	Notes regarding safety Maintenance Overview Maintenance overview	. 1 1 . 1
1 F2.1 1 F3.0	Notes regarding safety Maintenance Overview Maintenance overview Maintenance - Conveyor	.1 1 .1
1 F2.1 1 F3.0	Notes regarding safety Maintenance Overview Maintenance overview Maintenance - Conveyor Maintenance - Conveyor	.1 1 .1 1
1 F2.1 1 F3.0 1 1.1	Notes regarding safety Maintenance Overview Maintenance overview Maintenance - Conveyor Maintenance - Conveyor Maintenance intervals	.1 1 .1 .1
1 F2.1 1 F3.0 1 1.1 1.2	Notes regarding safety Maintenance Overview Maintenance overview Maintenance - Conveyor Maintenance - Conveyor Maintenance intervals Points of maintenance	.1 1.1 1.2 .3
1 F2.1 1 F3.0 1 1.1 1.2	Notes regarding safety Maintenance Overview Maintenance overview Maintenance - Conveyor Maintenance - Conveyor Maintenance intervals Points of maintenance Chain tension of the conveyor (1)	.1 1.1 .1 .2 .3 .3
1 F2.1 1 F3.0 1 1.1 1.2	Notes regarding safety Maintenance Overview Maintenance overview Maintenance - Conveyor Maintenance - Conveyor Maintenance intervals Points of maintenance Chain tension of the conveyor (1) Conveyor tensioning sprocket bearings (2)	.1 1.1 .1 .2 .3 .3
1 F2.1 1 F3.0 1 1.1 1.2	Notes regarding safety Maintenance Overview Maintenance overview Maintenance - Conveyor Maintenance - Conveyor Maintenance - Conveyor Maintenance intervals Points of maintenance Chain tension of the conveyor (1) Conveyor tensioning sprocket bearings (2) Conveyor bearing (3)	.1 1.1 .1 .2 .3 .5
1 F2.1 1 F3.0 1 1.1 1.2	Notes regarding safety Maintenance Overview Maintenance overview Maintenance - Conveyor Maintenance - Conveyor Maintenance - Conveyor Maintenance intervals Points of maintenance Conveyor tensioning sprocket bearings (2) Conveyor drive - (5) drive chains	1 1 1 1 1 1 1 1 1 1
1 F2.1 1 F3.0 1 1.1 1.2	Notes regarding safety Maintenance Overview Maintenance overview Maintenance - Conveyor Maintenance - Conveyor Maintenance intervals Points of maintenance Chain tension of the conveyor (1) Conveyor tensioning sprocket bearings (2) Conveyor drive - (5) drive chains Conveyor drive - (6) planetary drive (left/right)	1 1 1 1 1 1 1 1 1 1
1 F2.1 1 F3.0 1 1.1 1.2	Notes regarding safety Maintenance Overview Maintenance overview Maintenance - Conveyor Maintenance - Conveyor Maintenance - Conveyor Maintenance intervals Points of maintenance Chain tension of the conveyor (1) Conveyor tensioning sprocket bearings (2) Conveyor bearing (3) Conveyor drive - (5) drive chains Conveyor drive - (6) planetary drive (left/right) Conveyor chain guards / conveyor plates (7)	.1 1.1 .1 .2 .3 .5 .6 .7 .8
1 F2.1 1 F3.0 1 1.1 1.2 F4.0	Notes regarding safety Maintenance Overview Maintenance overview Maintenance - Conveyor Maintenance - Conveyor Maintenance - Conveyor Maintenance intervals Points of maintenance Chain tension of the conveyor (1) Conveyor tensioning sprocket bearings (2) Conveyor drive - (5) drive chains Conveyor drive - (6) planetary drive (left/right) Conveyor chain guards / conveyor plates (7)	.1 .1 .12.3 .55.6 .7 .8 1
1 F2.1 1 F3.0 1 1.1 1.2 F4.0	Notes regarding safety Maintenance Overview Maintenance overview Maintenance - Conveyor Maintenance - Conveyor Maintenance - Conveyor Maintenance intervals Points of maintenance Chain tension of the conveyor (1) Conveyor tensioning sprocket bearings (2) Conveyor bearing (3) Conveyor drive - (5) drive chains Conveyor drive - (6) planetary drive (left/right) Conveyor chain guards / conveyor plates (7) Maintenance - Auger Maintenance - Auger sub-unit 1	.1 1.1 .12.33.55.67.8 1.1
1 F2.1 1 F3.0 1 1.1 1.2 F4.0 1 1.1	Notes regarding safety Maintenance Overview Maintenance overview Maintenance - Conveyor Maintenance - Conveyor Maintenance - Conveyor Maintenance intervals Points of maintenance Chain tension of the conveyor (1) Conveyor tensioning sprocket bearings (2) Conveyor bearing (3) Conveyor drive - (5) drive chains Conveyor drive - (6) planetary drive (left/right) Conveyor chain guards / conveyor plates (7) Maintenance - Auger Maintenance - Auger sub-unit I Maintenance intervals	.1 1 .1 .1 .1 .1 .1 .1 .1 .1 .1 .1
1 F2.1 1 F3.0 1 1.1 1.2 F4.0 1 1.1 1.2	Notes regarding safety Maintenance Overview Maintenance overview Maintenance - Conveyor Maintenance - Conveyor Maintenance - Conveyor Maintenance intervals Points of maintenance Chain tension of the conveyor (1) Conveyor tensioning sprocket bearings (2) Conveyor bearing (3) Conveyor drive - (5) drive chains Conveyor drive - (6) planetary drive (left/right) Conveyor chain guards / conveyor plates (7) Maintenance - Auger Maintenance - Auger sub-unit I Maintenance intervals Points of maintenance	.1 1.1 .1 .1 .1 .1 .1 .1 .1 .1 .1 .1 .1
1 F2.1 1 F3.0 1 1.1 1.2 F4.0 1 1.1 1.2	Notes regarding safety Maintenance Overview Maintenance overview Maintenance - Conveyor Maintenance - Conveyor Maintenance intervals Points of maintenance Chain tension of the conveyor (1) Conveyor tensioning sprocket bearings (2) Conveyor bearing (3) Conveyor drive - (5) drive chains Conveyor drive - (6) planetary drive (left/right) Conveyor chain guards / conveyor plates (7) Maintenance - Auger Maintenance - Auger sub-unit I Maintenance - nucleur sub-unit I Maintenance - Auger sub-unit I Maintenance - Auger sub-unit I Maintenance - Auger sub-unit I Maintenance intervals Points of maintenance	.1 1 .1 .1 .1 .1 .1 .1 .1 .1 .1 .1
1 F2.1 1 F3.0 1 1.1 1.2 F4.0 1 1.1 1.2	Notes regarding safety Maintenance Overview Maintenance overview Maintenance - Conveyor Maintenance - Conveyor Maintenance intervals Points of maintenance Chain tension of the conveyor (1) Conveyor tensioning sprocket bearings (2) Conveyor bearing (3) Conveyor drive - (5) drive chains Conveyor drive - (6) planetary drive (left/right) Conveyor chain guards / conveyor plates (7) Maintenance - Auger Maintenance - Auger sub-unit I Maintenance intervals Points of maintenance Auger - outer bearing (1) Auger middle bearing (2)	.1 1 .1 .1 .1 .1 .1 .1 .1 .1 .1 .1
1 F2.1 1 F3.0 1 1.1 1.2 F4.0 1 1.1 1.2	Notes regarding safety Maintenance Overview Maintenance overview Maintenance - Conveyor Maintenance - Conveyor Maintenance intervals Points of maintenance Chain tension of the conveyor (1) Conveyor tensioning sprocket bearings (2) Conveyor bearing (3) Conveyor drive - (5) drive chains Conveyor drive - (6) planetary drive (left/right) Conveyor chain guards / conveyor plates (7) Maintenance - Auger Maintenance - Auger sub-unit I Maintenance intervals Points of maintenance Auger - outer bearing (1) Auger middle bearing (2) Auger - drive gear neck bearing (3)	.1 1 .1 .1 .1 .1 .1 .1 .1 .1 .1 .1

	Auger bevel gear (on the RH and LH sides) (4) Auger blade (5)	. 5 . 6
F5.0	Maintenance - Engine	.1
1 1.1 1.2	Maintenance - engine sub-unit Maintenance intervals Points of maintenance Engine fuel tank (1) Engine lube-oil system (2) Engine fuel system (3) Engine air cleaner (4) Engine Coolant system (5) Engine drive belt (6)	. 1 . 2 . 4 . 5 . 7 . 9 11 13
F6.0	Maintenance - Hydraulic System	.1
1 1.1 1.2 1.3	Maintenance - hydraulic system Maintenance intervals Hydraulic System Points of maintenance Hydraulic oil tank (1) Suction/return flow hydraulic filter (2) Venting the filter: High pressure filter (3) Pump distribution gear (4) Hydraulic hoses (5)	. 1 . 2 . 3 . 4 . 4 . 6 . 7 . 8 . 9 11
F7.1	Maintenance - Travel Drive, Steering	.1
1 1.1 1.2	Maintenance - travel drive, steering Maintenance intervals Points of maintenance Wheel mounting nuts (1) Rear wheels Front wheels (with front wheel drive) Planetary gear (2) Air pressure (driving wheels) (3) Places of lubrication (4)	. 1 . 2 . 3 . 3 . 3 . 4 6 7
F8.1	Maintenance - Electronic System	. 1
1 1.1 1.2	Maintenance - Electronic system Maintenance intervals Points of maintenance Batteries (1) Electric fuses / relays (3) Fuses in terminal box (B) Relays in terminal box (C)	. 1 . 2 . 3 . 3 . 4 . 5 . 7
F9.0	Maintenance - Lubricating Points	.1
1	Maintenance - Lubricating points	1

1.1 1.2	Maintenance intervals Points of maintenance Bearing points (1)	2
F10.0	Checks, Decommissioning	1
1	Tests, check-up, cleaning, stopping	1
1.1	Maintenance intervals	2
2	General observation	3
3	Check performed by a specialist	3
4	Cleaning	4
5	Preservation for storage of paver	5
5.1	Downtime up to 6 months	5
5.2	Downtime between 6 months and 1 year.	5
5.3	Re-commissioning:	5
F11.0	Lubricants and Operating Substances	1
1	Lubricants and operating substances	1
1.1	Capacities	2

V Preface

Safe operation of the machine requires specific knowledge that is in these operating instructions. The information is provided in a concise, clearly structured form. The individual chapters are arranged in alphabetical order and every chapter starts with page 1. The individual pages are identified by the chapter letter and the page number. Example: Page B 2 is the second page of chapter B.

These operating instructions cover various machine options. Make sure that during operation and maintenance work the description appropriate to the machine option is used.

Safety instructions and important notes are identified by the following:

A DANGER

Danger is used ot indicate the presence of a hazard which <u>will</u> cause <u>severe</u> personal injury, death, or substantial property damage if the warning is ignored.

A WARNING

Warning is used to indicate the presence of a hazard which can cause severe personal injury, death, or extensive property damage if the warning is ignored.

A CAUTION

Caution is used to indicate the presence of a hazard which will or can cause minor personel injury or property damage if the warning is ignored.

NOTICE

Notifies people of installation, operation or maintenance information which is important but not hazard-related. Hazard warnings should never be included under the Notice indicator.

NOTE:

Note is used for supplementary information not directly effecting safety or damage to the equipment. Note can also refer to special information on the efficient use of the equipment.

In the interest of continued development, the manufacturer reserves the right to make changes to the machine (which will not, however, change the essential features of the type of machine described) without updating the present operating instructions at the same time.

Dynapac USA, Inc.

2100 N. First Street Garland, Texas 75040 Telephone: (972) 496-7400 Fax: (972) 496-7310 www.dynapac.com

1 General safety instructions

1.1 Acts, directives, accident prevention regulations

NOTICE

The locally applicable acts, directives and accident prevention regulations shall be observed, even if the attention is not specifically directed to these.

The operator himself shall be responsible for the observation and performance of the related regulations and actions!

NOTICE

The following alerts, prohibitions and instructions refer to the risks to which people, machinery and environment are exposed.

NOTICE

Ignoring these instructions, bans and commands may lead to fatal injuries!

NOTICE

Furthermore, the Dynapac publication "Directives for the correct and specified application of pavers" shall also be observed.

1.2 Warning instructions

A paving machine has many components and implements that are controlled by a hydraulic system, either directly or indirectly. Before working on or inspecting any part of a paving machine, it is important that the individual knows how the components move and are controlled by the hydraulic system components including the respective control circuits.

Before working on or inspecting any component, it must be physically constrained from any movement that chould cause injury to the worker. The worker must be alert to not placing any part of his/her body where movement of a component could cause injury, unless that component is physically constrained from movement, if the hydraulic system fails, is disconnected, or is asignaled to cause movement.

It must also be recognized that there are occasions where component and or vehicle movement may react to the release of potential energy. Where applicable it must be confirmed that all measures are employed to ensure that any and all sources of potential energy are released and/ or physically restrained.

It is also the responsibility of those involved to insure that all local, state and federal safety regulations are followed, prior to, and during any work or inspection.

Rotating parts or transport parts can cause severe injury or death! Perform each operation only with equipment switched off!

Not observing the warning instructions may lead to injuries or death!



A WARNING

Warning: rotating parts!

Attention: electric voltage!

All maintenance and repair work on the screed's electrical system must always be carried out by an electrician!

Attention: suspended load!

Never stand under suspended loads!

A WARNING

Warning: risk of crushing!

Operation of certain parts or functions and moving the machine can produce a risk of crushing.

Always make sure that no one is in the areas exposed to risk!

▲ CAUTION

Caution: risk of hand injury!

▲ CAUTION

Caution: hot surfaces or hot liquids!





















Warning, risk of falling off!

Falling can cause severe injury or death!



Caution: hazardous batteries!

Combustible gas can cause severe burns, blindness or death!

Keep sparks and open flame away from batteries.



Caution: materials harmful to health and irritating substances!







Caution: flammable materials!



Caution: gas bottles!





1.3 Prohibitive signs

It is prohibited to open / step on / reach into / perform / adjust during operation or when the paver engine is running!

Do not start the engine/drive! Maintenance and repair can be carried out only with the Diesel engine turned off!

Do not spray with water!

Do not extinguish with water!

Unskilled maintenance is prohibited! Maintenance can be performed by skilled professionals only!











NOTICE

Contact the Dynapac service for maintenance assistance!

Danger of fire: do not use open flame and no smoking!

Do not turn on!



1.4 Protective gear

NOTICE

The applicable local regulations may define the use of different protective gear! Observe these specifications!

Protect your eyes with goggles!

Wear appropriate head protection!

Protect your hearing with appropriate ear mufflers!

Protect your feet with safety footwear!

Always wear tight, conforming working coveralls! Wear visibility vest for good visibility!

In case of polluted air, wear respiratory mask!



NOTICE

The locally applicable acts, directives and waste disposal regulations shall be observed, even if the attention is not specifically directed to these.

During cleaning, maintenance and repair operations, pollutants such as:

- lubricants (oils, grease)
- hydraulic oil
- gas oil
- coolant
- detergents

may not enter the soil or the sewer system!

These materials shall be collected, stored, transported in the correct containers until professional disposal!



Material harmful for the environment!



NOTICE

The applicable local regulations may specify that appropriate fire extinguishers be mounted! Observe these specifications!

Fire fighting device (optional equipment)



NOTICE

Observe the manufacturer's and other instructions!

(i.e. the maintenance instructions from the engine manufacturer)

Indicates a bottled gas heated design!

indicates an electrically heated design!





A Correct use and application

NOTICE

The "Guidelines for the Correct Use and Application of Paver" compiled by Dynapac are included in the scope of delivery for the present machine. The guidelines are part of the present operating instructions and must always be followed. Federal, state and local regulations are fully applicable.

The road construction machine described in these operating instructions is a paver that is suited for laying mixed materials, roll-down concrete or lean-mixed concrete, track-laying ballast and unbound mineral aggregates for paving foundations.

This machine shall be used, operated and maintained for the purpose of the intended work as included in the operation manual. Any other use is regarded as improper use and can cause injury to persons or damage to the paver or other equipment or property.

Any use going beyond the range of applications described above is regarded as improper use and is expressly forbidden! Especially in those cases where the paver is to be operated on inclines or where it is to be used for special purposes (i.e. construction of dumps, dams), it is absolutely necessary to contact the manufacturer.

Duties of the user: A "user" within the meaning of the present operating instructions is defined as any natural or legal person who either uses the paver himself, or on whose behalf it is used. In special cases (i.e. leasing or renting), the user is considered the person who, in accordance with existing contractual agreements between the owner and the user of the paver, is charged with the observation of the operating duties.

The user must ensure that the paver is only used in the stipulated manner and that all danger to life and limb of the operator, or third parties, is avoided. In addition to this, it must be ensured that the relevant accident prevention regulations and other safety-related provisions as well as the operating, servicing and maintenance guidelines are observed. The user must also ensure that all persons operating the equipment have read and understood the present operating instructions.

Mounting attachments: The paver must only be operated in conjunction with screeds that have been approved by the manufacturer. Mounting or installation of any attachments that will interfere with or supplement the functions of the paver is permitted only after written approval by the manufacturer has been obtained. If necessary, the approval of local authorities has to be obtained.

Any approval obtained from local authorities does not, however, make the approval by the manufacturer unnecessary.

B Vehicle description

1 Application

The DYNAPAC F1000T is a rubber track paver that is used for laying bituminous mixed material, roll-down or lean-mixed concrete, track-laying ballast and unbound mineral aggregates for paving foundations.



2 Description of assemblies and functions



Item	Standard or Optional	Designation
1	Standard	Material hopper
2	Standard	Conveyor
3	Standard	Truck push rollers
4	Optional	Truck hitch
5	Standard	Mounting tube for alignment indicator
6	Standard	Rubber track
7	Standard	Track drive wheel
8	Standard	Levelling cylinder (for paving thickness)
9	Standard	Levelling arm guide
10	Standard	Guide roller (Side arm tow point)
11	Standard	Idler
12	Standard	Screed side arm
13	Standard	Auger
14	Standard	Screed
15	Standard	Power pack enclosure
16	Standard	Engine exhaust & fume extraction
17	Standard	Operator's platform
18	Standard	Operator's panels
19	Optional	Warning beacon
20	Optional	Washer/sprayer

B_F1000T_US.fm 2-18

2.1 Vehicle

Construction

The Dynapac F1000T is a rubber track propelled paver built with a welded steel frame on which the power pack, augers, conveyors, hopper and operator positons are mounted.

The track suspension compensates for uneven areas on the ground. The suspension of the attached screed helps to attain high paving precision. The machine is designed to move material via hydraulically driven conveyor chains and spread it with augers to allow the screed to spread the materials evenly. The adjustable hydrostatic drive system allows the speed of the paver to keep pace with other equipment in all work conditions.

The operation of the paver is largely facilitated by the easy to use operator controls. The operator can control the functions of the paver from either the left control panel or the right control panel.

Available options include:

Grade Control -Control System -Averaging Ski -Non-Contacting Averaging Ski -Contacting Grade Control **Truck Hitch** Washdown System and Hose Reel Auger Extensions Frame Extensions Steering Guide (Truck Hitch) Secondary Drive Controller Umbrella Auxiliary Power Panel (220/110V) **Bubble Lights** Road Lights (Tail Lights) Warning Beacon Magnetic Base Lights Up Time Kit Screed -Berm -Screed Corded Controls -Screed Extensions Further equipment and upgrade options on request **Engine:** The paver is powered by a 6-cylinder, water cooled diesel engine with direct injection and a turbo charger. Electric starting and belt driven alternator battery charging is standard. The engine power / rpm is controlled by the engine speed control on either of the consoles. The engine is shut down either by removing the key "ON/OFF" switch or the emergency stop switch. For further details, see the technical data in the engine's instruction manual.

Track: The two rubber tracks are driven indepently of each other. They are each direct drive requiring less maintenance and service than chain driven machines. Each track is adjusted automatically using hydraulic pressure. The rubber track allows the machine to attain a high transportation speed with excellent maneuverability and traction.

Hydraulic system: The diesel engine has the Pump Drive gear box attached to it. This drives the hydraulic pumps for all of the main and auxilary paver functions. The hydraulic system also drives the generator needed to heat materials to prevent the material from sticking to the screed plate. All power on the paver comes from hydraulics.

Track drive: The closed-loop track drive system includes two speed track drive motors that are connected to the drive pumps by means of high pressure hydraulic hoses. The hydraulic motors are mounted to the track drive wheels and mobilize the tracks. Track movement is controlled by directional control joysticks on the consoles.

Steering system/operator's platform: The independent hydrostatic travel drives allow the paver to be turned on the spot. The electronic synchronization, controlled from the operating panel, ensures that the paver runs straight ahead. The operating panels can be secured in variable positions on both left and right console panels, by a locking mechanism. Steering is accomplished merely by driving one track at a different speed than the other. If turning left, the track on the right hand side will move faster than the track on the left. If turning right, the track on the left hand side will move faster than the track on the right.

Push roller crossbar: The push rollers for material trucks are connected to a crossbar that pivots at its center. This crossbar allows for differences in distances to the rear wheels on a variety of material trucks. This permits the paver to deviate less from its course and makes paving curves easier.

Material compartment (hopper): The hopper inlet is equipped with a conveyor system that empties the hopper and transfers the material to the auger. The hopper can hold approximately 30,000 lbs. (13608 kg) and are raised hydraulically to empty onto the conveyor chains. To facilitate the emptying and to improve material transfer, each of the lateral covers of the hopper are hydraulically moved.

Conveyors (Material transfer): The paver is equipped with two conveyors driven separately with pressure from a single pump. The system consists of a single, pressure compensated, load sense style, variable displacement, open loop pump driving two fixed volume hydraulic motors. This pump supplies hydraulic power for both conveyors of the machine and provides power for the cylinders on the machine.

These conveyors transer the material from the hopper to the augers. By using sensors to monitor the filling height during the paving proceedure, the transfer amount or speed regulation is completely automatic.

Augers: The augers are driven and controlled independently from the conveyors. The auger hydraulics consist of two high pressure, variable displacement, closed loop pumps driving two fixed volume motors. The left-hand and the right-hand half of the auger can be controlled separately.

The auger direction can be changed to direct material towards the center of the screed or towards the outside of the screed. There is always a sufficient supply of material even if an excessive amount of material is required at one side. The auger speed is controlled by sensors that monitor the material flow leaving the auger area.

Height adjustment and extension of augers: Height adjustment and extension of augers ensure an optimum variety of a wide range of paving thicknesses and widths. Auger height is regulated at the operating panel and moved by means of hydraulic cylinders.

Auger segments of different lengths can be attached to easily adapt to the different paving widths.

Levelling/slope control system: The slope control system allows the paving thickness to be regulated at the left-hand or the right-hand side with a defined difference to the opposite side.

To determine the actual value, the two screed leveling arms are linked with a slope beam.

The slope control system always operates in conjunction with the screed height adjustment of the opposite side.

By adjusting the height of the screed leveling cylinders, the paving thickness of the material or the laying height of the screed can be controlled.

Activation occurs electro-hydraulically on both sides and can be controlled manually by means of toggle switches or automatically by means of an electronic grade control system.

Screed lifting arms: The screed lifting arms are used to lift the screed during transport. Lifting occurs electro-hydraulically on both sides by activating the hydraulic cylinders on the screed lifting arms which is controlled by means of toggle switches on the operating panel.

Truck hitch (option): The truck hitch holds the transport vehicle, containing the paving material, in contact with the paver. The truck hitch mounts are located on the front of the hopper.

3 Danger zones

In the working areas around the machine (marked in red), there may be a risk of drawing in or crushing during normal operation caused by rotating and conveying elements, or by components in motion.



B_F1000T_US.fm 6-18

4 Technical data, standard configuration

4.1 Dimensions



NOTICE

For screed technical data, refer to the screed operating instructions.



NOTICE

Before operating your machine in an inclined position (gradient, slope, lateral inclination) which is above the specified limit value, please consult the customer service department for your machine!

4.3 Permissible approach angle



Paver without screed	approx. 38,000 lbs. (17237 kg)
Paver with screed: - Carlson EZ IV 1019 (7000 lbs.)	approx. 45000 lbs. (20412 kg)
With filled hopper, include an Additional maximum of:	approx. 44000 lbs. (19958 kg) approx. 30000 lbs. (13608 kg)

4.5 Performance data

Screed used	Basic width	Minimum paving width	Continuously hydraulically adjustable up to	Maximum working widths (with extension parts)	
Carlson EZ IV 1019	10	10	19	26	ft
	3.05	3.05	5.79	7.92	m
Carlson EZ III 10	10	10	17	24	ft
	3.05	3.05	5.18	7.3	m

Maximum transport speed (travel)	10 16.9	mph km/hr
Operating speed (Paving, 1800 rpm)	0 - 110 0 - 33.5	fpm m/min
Maximum paving speed	240 73.2	fpm m/min
Paving thickness	12 30.5	in cm
Theoretical paving performance	2500	t/h

4.6 Engine

Make/type	Cummins QSB-6.7 Tier III
Version	6-cylinder diesel engine (water-cooled)
Performance	230 hp @ 1800rpm 220 hp @ 2000rpm
Fuel tank capacity	2 tanks, 49 Gal (185 lt) each.

4.7 Hydraulic system

Hydraulic pressure supply source	Hydraulic pumps via distribution gear (directly flanged to the engine)
Pressure distribution	 Hydraulic circuits for: Propel system Auger drive system Works system (conveyor, hydraulic cylinders) Generator system Vibration system Front wheel system (including the FWA, or Front Wheel Assist, and the steering
Hydraulic oil tank capacity	50 Gal (189 lt)
Hydraulic oil filling volume	80 Gal (303 lt)

4.8 Material compartment (hopper)

Volume	approx. 207ft ³ (5.86m ³)
Minimum inlet height, center	38.5 in (978mm)

4.9 Electrical system

On-board voltage	24 VDC
Batteries	2 x 12 V, 32F 1050, RC 195
Alternator	24V, 70A
Generator	110/220, 36kw, 60Hz

4.10 Operator stations

	Control consoles	Dual swing out operation stations
--	------------------	-----------------------------------

4.11 Conveyors

Conveyor type	Dual independent slat conveyor
Conveyor control	Proportional speed control, both side driven independently

4.12 Auger

Auger control	Dual independent proportional augers

4.13 Permissible temperature ranges

Maximum Ambient Operating	+120°F (+48.9°C)
Temperature	

NOTICE

For the capacities for the various lubricants and operating substances, see chapter F.

5 Location of instruction labels and identification plates



Item	Decal	Description			
1		Warning! Crush area! Keep a safe distance when machine is running or moving. Do not work in this area when the machine turns or ma- chine parts move! Crushing can cause severe injury or death!			
2	A WARNING Image: Constraint of the second	Warning! Do not work on this machine unless you have read and fully under- stand the warnings and instructions in the Operation/Maintenance and Safe- ty Manual! Failure to follow the in- structions or heed the warnings could result in injury or death. Contact your Dynapac dealer for replacement of manuals. Proper care is your personal responsibility!			
3		Warning! Keep a safe distance from rotating fans! Do not work around or on the fan when fan is in operation! Rotating fan blades can cause severe injury or death!			
4	DIESEL	Filler neck for diesel fuel! (Located on both sides of machine)			
5	B	Tie-down points on machine! (Located on both sides and front and back of the machine)			
6	g	Lifting point on machine! (Located on both sides and front and back of the machine)			

Item	Decal	Description			
7	È	Main battery switch location! NOTE: Follow instructions for using battery main switch!			
8	OFF	ON/OFF positions for battery main switch. ON - battery connected OFF - battery disconnected			
9		Warning! Hot parts or components can cause burns! Keep a safe dis- tance! Hot surfaces can cause burns or per- sonal injury. Do not come into contact with hot parts or components. Wear protective clothing or protective equip- ment!			
10		Wear ear protection when using the machine! Hearing damage could result from high noise level when ear protection is not used!			
12	WARNING	Warning! Do not drive the machine while standing! Severe injury or death from an unseat- ed position could occur! Always use seat and seatbelt when driving machine in transport gear!			
13		Location of technical manuals on the machine!			

5.1 Identification label for the paver (6)

• DY	Dynapac USA, Inc. Garland, Texas, USA			
Туре	Operating mass R	beter	Power	Year of Mfg
F1888T	19898 Mg	164	F HW	2918
Max axle load front	Max axie load rear	Sec. 1	Max be	llast
Kg		KD.		kg
Product Identification N	under #7170820	34		
•	Contraction of the local division of the loc			-

Item	Designation
1	Paver type
2	Operating Mass
3	Rated performance in kW
4	Year of Manufacture
5	Product identification number (PIN)

NOTICE

The stamped vehicle identification number on the paver must match the product identification number (8).

6 EN standards

6.1 Continuous sound pressure level on the F1000T Track Paver, Cummins QSB-6.70 Tier III Engine.

NOTICE

The operator always must use ear protection. The noise level at the operator's ear varies depending on the materials used for paving and may even rise above 85 dB(A). If no ear protection devices are used, hearing can be impaired.

The noise emission level of the paver was measured under free-field conditions according to the EN 500-6 draft dated March 1997, and ISO 4872.

Sound pressure level at the operator's p at the height of the head):		OSITION LH Console	RH Console
	L _{AF} =	93.5 dB(A)	92.6 dB(A)

Sound capacity level:

 $L_{WA} = 122.34 \text{ dB}(A)$

Sound pressure level at the machine

Measuring point	2	4	6	8	10	12
Sound pressure level L_{AFeq} (dB(A))	92.4	93.1	94.6	88.6	81.0	79.9

6.2 Operating conditions during measurement

The diesel engine was running at maximum speed. The screed was in working position, lowered to a rubber mat. Tamper and vibration unit were operated at min. 50%, while the augers were operated at a minimum of 40% and the conveyors were operated at a minimum of 10% of their maximum speed.
6.3 Measuring point configuration

Hemispherical measuring surface with a radius of 52.5 ft. (16 m). The machine was at the center. The measuring points had been assigned the following coordinates:

	Measuri	ng points	2, 4, 6, 8	Measu	ring points	s 10, 12
Co-ordinates	Х	Y	Z	Х	Y	Z
	±11.2	±11.2	1.5	- 4.32 +4.32	+10.4 -10.4	11.36 11.36



C 1.0 Transport

1 Safety regulations for transportation

A WARNING

Accidents can happen when the paver and the screed are not properly prepared for transportation or when transportation is carried out improperly!

A WARNING

Reduce both the paver and the screed to their basic widths. Remove all protruding parts (such as the automatic levelling system, auger limit switches, aprons, etc.). When transporting under a special permit, secure these parts!

A WARNING

Close the hopper lids and engage the hopper transport safeguards. Lift the screed and engage the screed transport safeguards. Convert the protective roof (if equipped) and engage the latch.

A WARNING

Check that the clamping device for the auger crossbeam is fastened and that the telescopic tube cannot slide out (see chapter E, section 2.5).

A WARNING

Pack all parts that are not permanently fixed to the paver and the screed into the appropriate boxes and into the hopper.

Close all coverings and check that they are securely seated.

A DANGER

When loading using ramps, there is a risk that the machine will slip, tilt or overturn. Drive carefully! Keep people away from the danger area!

Additional stipulations for transportation on public roads:

A WARNING

Depending on local regulations, tracked propelled paver must not be driven as selfpropelling vehicles on public roads.

Note the different state and local regulations.



The operator must be in the possession of a valid permit for vehicles of this type.



The operating panel must be moved to the side of the oncoming traffic and secured in this position.

The driving lights must be properly adjusted.

A WARNING

Only attachments and extension parts may be transported in the hopper, no material!

A WARNING

If necessary, the operator must be assisted by a second person when driving on public roads – especially at road crossings and junctions.

2 Transportation on low-bed trailers

A WARNING

Reduce the paver and the screed to their basic widths; also remove any attached side plates.

The maximum approach angle is indicated in the section entitled "Technical Data"!

A WARNING

Check the fill level of the operating fluids so that these do not escape when driving on an incline.

A WARNING

Attachment and loading equipment must meet the federal, state and local safety regulations!

A WARNING

The weight of the paver must be taken into consideration when selecting the attachment and loading equipment!

2.1 Preparations

- Prepare the paver for transportation (see chapter D).
- Remove all overlaying or loose parts from the paver and screed (see also Operating instructions for the screed). Store these parts in a safe place.
- Move the paver to the uppermost position if necessary.



Step	Operation	
1	- Select the master console.	
2	- Close the hopper lids.	
3	- Engage both hopper transport safeguards.	
4	- Lift the screed.	
5	- Retract the screed to the basic width of the paver.	
6	- Engage both screed transport safeguards.	
7	- Lift the auger.	
8	- Turn the range shift selector to zero.	
9	- Turn the travel speed preselecting regulator to zero.	
10	- Move the drive lever forward.	
11	- Extend levelling cylinders completely.	
12	- Set the drive lever to the center position.	

2.2 Driving onto the low-bed trailer

A DANGER

Make sure that there are no persons in the danger area during loading.



- Use the work gear and low engine speeds to drive onto the low-bed trailer.
- Lower the screed onto wooden blocks on the low-bed trailer.
- Turn the switch off.
- Attach and secure the protective hood to protect the operating panel.

2.3 Secure the paver to the low-bed trailer:

- Use only proper and permitted load fastening devices.
- Use the four tie-down points provided (1, 2). These points have a tie-down limit of 10,000 lbs. (3545.9 kg) each.
- Wait until the exhaust extension pipe has cooled down; then swing and secure it.

2.4 After transportation

- Remove the chains, hooks and all other transport tie-down tools.
- Swing the exhaust extension pipe up and secure it.
- Lift the screed to the transport position.
- Start the engine and drive from the trailer at a low speed.
- Park the paver in a secure spot, lower the screed and switch the engine off.
- Remove the key and cover the operating panel with the protective hood, then secure it.

3 Transportation

A WARNING

Reduce the paver and the screed to their basic widths; also remove any attached side plates.

3.1 Preparations

- Prepare the paver for transportation (see chapter D).
- Remove all overlaying or loose parts from the paver and screed (see also Operating instructions for the screed). Store these parts in a safe place.



Step	Operation	
1	- Select the master console.	
2	- Close the hopper lids.	
3	- Engage both hopper transport safeguards.	
4	- Lift the screed.	
5	- Retract the screed to the basic width of the paver.	
6	- Engage both screed transport safeguards.	
7	- Lift the auger.	
8	- Turn the range shift selector to zero.	
9	- Turn the travel speed preselecting regulator to zero.	
10	- Move the drive lever forward.	
11	- Extend levelling cylinders completely.	
12	- Set the drive lever to the center position.	



Step	Operation	
1	- Turn the selector to position 3.	
2	- Turn the pre-selecting regulator to its maxi- mum point.	
3	- Use the drive lever to regulate the speed.	

A DANGER

Press the emergency stop button when an emergency situation arises!

A WARNING

Use only lifting gear that can bear the load. (See chapter B for weights and dimensions).

Attachment and loading equipment must meet the conditions of the applicable accident prevention regulations!

The vehicle's center of gravity is dependent on the mounted screed.



NOTICE

Four lifting eyes (1, 2) are provided for loading the vehicle with a crane.

NOTICE

Depending on the type of screed used, the paver's center of gravity, with the screed mounted, is located in the area of the drive unit's rear reversing roller.

- Secure vehicle wherever it is parked.
- Engage the transport safeguards.

- Remove any attachments and extension parts from the paver and the screed until the basic width has been attained.
- Remove all protruding or loose parts of screed and machine.
- Attach lifting gear to the four attachment points (1, 2).

A WARNING

The max. permissible attachment point load is Attachment point (1): 20,000 lbs. (9071.9 kg) each for a total of 40,000 lbs. (18144 kg) Attachment point (2): 20,000 lbs. (9071.9 kg) each for a total of 40,000 lbs. (18144 kg)

Make sure that the paver is secured in a horizontal position during transport!

5 Towing

▲ CAUTION

Follow all regulations and apply all safety measures applicable for towing heavy construction machines.

A WARNING

The towing vehicle must be capable of securing the paver, even on slopes.

Use only approved tow bars!

If necessary, remove any attachments and accessories from the paver and the screed until the basic width has been attained.

A hand pump is located in the engine compartment (left) that must be activated to be able to tow the machine.

Pressure for releasing the track drive system brakes is built up with the hand pump.

A WARNING

Do not release the track drive system brakes until the machine is sufficiently secured against accidental rolling or is already properly connected to the towing vehicle.

- Attach the towing device to the tiedown points located in the bumper under the hopper.
- Push down and turn the Pump Pressure Lock and Release Handle (2) to the DOWN position.
- Pump the Handle (3) of the hand pump up and down until sufficient pressure has been built up for the track drive system brakes to release.



NOTICE

Now carefully and slowly tow the paver out of the construction area. The maximum towing speed is 2 mph (3.2 kph).

A WARNING

Always tow the machine the shortest distance to the means of transport or the next parking opportunity.

After towing, return the Pump Pressure Lock and Release Handle (2) to the UP position. This will release pressure in the Hand Pump and will allow the braking system to engage.

The track drive system brakes are now reactivated and the machine is secured against rolling.

When the paver is parked at a location accessible to the public, it must be secured in such a way that unauthorized persons or playing children cannot damage the vehicle.



D 1.0 Operation

1 Safety regulations

A WARNING

Starting the engine, the traction drive, the conveyor, the auger, the screed or the lifting devices can cause severe injury or death.

Make sure, before starting any of these devices, that no-one is working on, in or beneath the paver or within its danger area!

- Do not start the engine or actuate any controls when this is expressly forbidden! Unless otherwise specified, the controls may only be actuated when the engine is running!

A DANGER

Never crawl into the auger tunnel or step into the hopper or onto the conveyor. Danger to life and limb!

- Always make sure during operation that no-one is endangered by the machine!
- Ensure that all protective covers and hoods are fitted and secured accordingly!
- When damage is detected, eliminate it immediately! Operation must not be continued when the machine is defective!
- Do not let any persons ride on the paver or the screed!
- Remove obstacles from the road and the work area!
- Always try to choose a driver position which is opposite to the flow of traffic! Lock the operating panel and the driver's seat.
- Maintain sufficient safety clearance from overhanging objects, other machines and points of danger!
- Be careful when traveling on rough terrain to keep the paver from slipping, tipping or turning over.

▲ CAUTION

Always maintain control of the machine; never try to use it beyond its capabilities!

2 Controls

2.1 Operating panel



D_1.0_01_US.fm 2-42

ltem	Designation	Brief description
1	Steering wheel	 Steering is regulated by the speed of the two drive units. NOTE: Use the turn signals when turning! For precise adjustment, see "Straight-ahead travel trimming".
2	Operating panel latch	 Secures the adjustable operating panel into position. Pull the locking knob and swivel the operating panel to the desired position. Allow the latch to engage in one of the possible positions again. Allow the latch to engage in one of the possible positions again. When not secured, the operating panel can move. Danger of accidents!
3	EIC Engine Information Center	- Display for engine information, diagnostic information and configuration.
4	Console lights	Illuminates the instrument panels when the parking light is switched on.



ltem	Designation	Brief description
10	Ignition lock	Key positions: - 1: Ignition OFF - 2: Ignition ON - 3: Starting position NOTE: The key can only be removed in position 1.
11	Horn	Press in the case of emergencies and to indicate when the machine starts to move! NOTE: The horn can also be used to communicate acoustically with the truck driver for material loading!
12	Travel drive pre-selec- tor	Setting the maximum speed that can be performed when the drive lever is at its stop. NOTE: The speed level is preset with the "Travel drive/engine pre-selector switch".
13	Straight-ahead travel trimming	 This potentiometer has the following functions: Steering the paver through a large curved radius: Turn the potentiometer in the corresponding direction until the required steering angle is achieved. Straight-ahead travel trimming in speed level 3 : Set the steering wheel to position "0"; then adjust the potentiometer until the paver is traveling straight ahead. NOTE: Automatic straight-ahead travel trimming takes place in preset speed levels 1 and 2.
14	Truck hitch	Opening and closing the truck hitch device at the front of the paver. Toggle switch function: - Toggle the switch left: Open truck hitch. - Toggle the switch right: Close truck hitch. MOANGER Do move or tow the paver until all persons and equipment are out of the Danger Zone!
15	Open/close hopper	 To open/close both halves of the hopper. Toggle switch function: Toggle the switch forward (away from the operator): Close hoppers. Toggle the switch back (toward the operator): Open hoppers. Do not open or close the hopper until all equipment and persons are out of the Danger Zone!



D 1.0 6

ltem	Designation	Brief description
20	Drive lever (traction)	For switching on the paver functions and for regulating the road speed – for- ward or reverse. Zero position: starting is possible; engine at idling speed; no track drive; pro- tected against inadvertent start. To move the lever, lift the ring (20a) to release it. Depending on the position of the drive lever, the following functions can be activated: - 1st position: Engine runs at preselected speed (see "Travel drive/engine preselector switch"). - 2nd position: Conveyor and auger on. - 3rd position: Travel drive (propel) on; increase speed by turning the speed control until it stops. NOTICE The maximum speed is set with the travel drive/engine preselector switch and with the travel drive preselector. NOTICE The floating position function is only active when the drive lever is moved from its central position! If the drive lever is moved to the central position, the paver automat- ically switches to screed stop(lock).
21	Preselector switch travel drive/engine fast/slow	 To preselect the desired speed level. Switch setting 0: Preselected vehicle speed "0" Switch setting 1: Vehicle speed – for paving with low operating speed. Switch setting 2: Vehicle speed – for paving with higher operating speed. Switch setting 3: Transport speed – for transportation.



ltem	Designation	Brief description
22	Push button parking brake	Use the push button to activate the parking brake. The parking brake must be activated anytime the vehicle is stationary. - Parking brake activated – push button illuminated - Parking brake de-activated – push button not illuminated
23	not used	
24	not used	
25	Working lights ON / OFF	Switches the working lights on and off. Toggle switch function: - Toggle the switch to setting 0: Working lights OFF. - Toggle the switch to setting 1: Working lights ON.
26	Turn signal indicator ("flasher")	The turn signal indicates the direction the paver is turning. Detent switch function: - Left switch position: Left-hand flasher. - Right switch position: Right-hand flasher.



D 1.0 10

ltem	Designation	Brief description
27	Vibration ON / OFF	Switches screed vibration on and off. Toggle function: - Toggle the switch to setting 0: Vibration OFF. - Toggle the switch to setting 1: Vibration ON. NOTE: Speed control (see "Operating instructions for the screed")
28 (○)	Tamper ON / OFF	Switches the screed tamper function on and off. Toggle switch function: - Toggle the switch to setting 0: Tamper OFF. - Toggle the switch to setting 1: Tamper ON. NOTE: Speed control (see "Operating instructions for the screed")
29 30	Selector switch left / right operating panel (19) + active panel LED (20)	To select the primary activated operating panel. Toggle switch function: NOTICE To avoid operator errors, only one operating panel –left or right- can be activated at any one time. - Toggle the switch left: Left operating panel active. - Toggle the switch right: Right operating panel active. - Toggle the switch right: Right operating panel active. MOTICE The active panel LED indicates whether the relevant operating pan- el is activated or deactivated by switch (19). - LED "ON": Operating panel active. - LED "OFF": Operating panel inactive.



ltem	Designation	Brief description
40	Emergency Stop button	 In case of an emergency (danger to persons, possible collision, etc.), press the Emergency Stop button! Pressing the Emergency Stop button switches the engine, the drives and the steering system off.
		WARNING Paving, lifting the screed or other functions are no longer possible! Do not reset the Emergency Stop Button until the danger is no long- er present!
		- To restart the engine, the button must be pulled out again.
41	Left conveyor OFF / max. output	 Overrides the conveyor function in automatic mode. Toggle switch function: Toggle the switch forward (away from the operator): Conveyor OFF. Toggle the switch back (toward the operator): Conveyor is at 100% feed capacity.
42	Right conveyor OFF / max. output	 Overrides the conveyor function in automatic mode. Toggle switch function: Toggle the switch forward (away from the operator): Conveyor OFF. Toggle the switch back (toward the operator): Conveyor is at 100% feed capacity.
43	Left auger OFF / max. output	 Overrides the auger function in automatic mode. Toggle switch function: Toggle the switch forward (away from the operator): Auger OFF. Toggle the switch back (toward the operator): Auger is at 100% feed capacity.
44	Right auger OFF / max. output	Overrides the auger function in automatic mode. Toggle switch function: - Toggle the switch forward (away from the operator): Auger OFF. - Toggle the switch back (toward the operator): Auger is at 100% feed capacity.



ltem	Designation	Brief description
45	Conveyor + auger ON + activation LED / OFF	 Toggles the conveyor and auger (automatic or manual mode) on and off. Toggle switch function: Toggle the switch forward (away from the operator): Auger + conveyor are ready for operation (LED ON). Toggle the switch back (toward the operator): Auger + conveyor OFF. NOTICE If the vehicle must be restarted, this function is automatically switched OFF.
46	Operating mode conveyor + auger AUTO + activation LED / MANUAL + activation LED	Toggles between AUTOMATIC and MANUAL operating modes for the con- veyor + auger. Toggle switch function: - Toggle the switch forward (away from the operator): Operating mode "AUTO" (LED ON). NOTICE The auger + conveyor are switched on by moving the drive (propel) lever from the center position and are controlled by the relevant ma- terial limit switches. - Toggle the switch back (toward the operator): Operating mode "MANUAL" (LED ON). NOTICE The auger + conveyor are permanently switched on (without mate- rial control thru the relevant limit switches). NOTICE If the vehicle must be restarted, this function is automatically switched OFF.



ltem	Designation	Brief description
47	Raise / lower left auger	 Hydraulically adjusts the height of the left auger. Toggle switch function: Toggle the switch forward (away from the operator): Raise auger. Toggle the switch back (toward the operator): Lower auger. NOTICE
		Toggle both switches (raise / lower left + right auger) at the same time to keep the auger crossbeam level!
		ADANGER Do not raise or lower the auger until all equipment and persons are clear of the machine
48		 Hydraulically adjusts the height of the right auger. Toggle switch function: Toggle the switch forward (away from the operator): Raise auger. Toggle the switch back (toward the operator): Lower auger.
	Raise / lower right auger	NOTICE Toggle both switches (raise / lower left + right auger) at the same time to keep the auger crossbeam level!
		ADANGER Do not raise or lower the auger until all equipment and persons are clear of the machine


ltem	Designation	Brief description
50	Extend / retract left screed extension	 Hydraulically retracts and extends the left extendable part of the screed. Toggle switch function: Toggle the switch left: Extend screed extension. Toggle the switch right: Retract screed extension. DANGER Do not extend or retract the screed until all equipment and persons are away from the machine
51	Extend / retract right screed extension	 Hydraulically retracted and extended the right extendable part of the screed. Toggle switch function: Toggle the switch left: Retract screed extension. Toggle the switch right: Extend screed extension. ADANGER Do not extend or retract the screed until all equipment and persons are away from the machine
52	Raise / lower screed	 Hydraulically raises and lowers the screed. Push button function: Toggle the switch up: Raise screed. Toggle the switch down: Lower screed. ADANGER Do not raise or lower the screed until all equipment and persons are away from the machine



ltem	Designation	Brief description
53	Screed floating position + activation LED / screed stop + activation LED	 Switches between floating screed functions and screed stop. Toggle switch function: Toggle the switch forward (away from the operator): Screed stop. "Screed stop" is used to lock the screed hydraulics to prevent the screed from sinking into the paved material when the paver is stationary (intermediate stop).
		WARNING "Screed stop" is not sufficient as a safeguard during transport or maintenance work! Insert the mechanical screed transport safe- guard!
		 Toggle the switch back (toward the operator): Lower the screed and switch to "floating position". During paving, the screed must always be in its floating position. This also applies to intermediate stops and truck changes.
		NOTICE As soon as the floating position function has been activated and the screed is lowered, the screed lifting cylinder pressure is reduced.
		NOTICE The raise / lower screed function can be carried out while the screed is switched to the floating position. Following adjustment, the screed is automatically switched back to the floating position.
		NOTICE
		The floating position function is only active when the drive lever is moved from its central position! If the drive lever is moved to the central position, the paver automat- ically switches to screed stop(or locked position). The activation LED for screed stop is then activated.



Item	Designation	Brief description
54	Left leveling cylinder	 Manually extends and retracts the leveling cylinder when the vehicle is being operated without the automatic leveling system. Toggle switch function: Toggle the switch forward (away from the screed): Retract or raise the leveling cylinder to raise the screed. Toggle the switch back (toward the screed): Extend or lower the leveling cylinder to lower the screed. Manually extends and retracts the leveling cylinder until all equipment and persons are clear of the machine!
55	Right leveling cylinder	 Manually extends and retracts the leveling cylinder when the vehicle is being operated without the automatic leveling system. Toggle switch function: Toggle the switch forward (away from the screed): Retract or raise the leveling cylinder to raise the screed. Toggle the switch back (toward the screed): Extend or the lower leveling cylinder to lower the screed. MANGER Do not raise or lower the leveling cylinder until all equipment and persons are clear of the machine!



Item	Designation	Brief description
60	Headlights ON / OFF	Controls the working lights. Toggle the switch up: Turns on the lights. Toggle the switch down: Turns off the lights. NOTICE To prevent the battery from being drained, switch the headlights "ON" only when the diesel engine is running!
61	Release Agent fluid spray system ON/OFF	Activates the Release Agent fluid spraying system. - Toggle the switch up: Turns on the sprayer. - Toggle the switch down: Turns off the sprayer. NOTICE To prevent the battery from being drained, switch the sprayer "ON" only when the diesel engine is running!
62	Hazard warning flasher	Push button to turn the Hazard Warning Flasher "ON". Hazard Warning Flasher must be turned "ON" on roads and in the construction site area. NOTE: The Hazard Warning Flasher button is also for activating the rotary beacon when attached.



ltem	Designation	Brief description
A	LEFT remote control	- Controls certain functions on the left-hand side of the vehicle and various overall functions.
В	RIGHT remote control	- Controls certain functions on the right-hand side of the vehicle and vari- ous overall functions.
С	LEFT handset	- Removable handset for controlling certain functions on the left-hand side of the vehicle.
D	RIGHT handset	- Removable handset for controlling certain functions on the right-hand side of the vehicle.



D_1.0_01_US.fm 27-42

Item	Designation	Brief description
	Emergency stop button	 In case of an emergency (danger to persons, possible collision, etc.), press the Emergency Stop button! Pressing the Emergency Stop button switches the engine, the drives and the steering system off.
70		
		Paving, lifting the screed or other functions are no longer possible! Do not reset the Emergency Stop Button until the danger is no longer present!
		- To restart the engine, the button must be pulled out again.
71	Left auger OFF / max. output	Overrides the conveyor function in automatic mode. Toggle switch function: - Toggle the switch right: Auger OFF. - Toggle the switch left: Auger 100% feed capacity.
72	Right auger OFF / max. output	Overrides the auger function in automatic mode. Toggle switch function: - Toggle the switch left: Auger OFF. - Toggle the switch right: Auger 100% feed capacity.
73	Left conveyor OFF / max. output	 Overrides the conveyor function in automatic mode. Toggle switch function: Toggle the switch forward (away from the operator): Conveyor OFF. Toggle the switch back (toward the operator): Conveyor 100% feed capacity.
74	Right conveyor OFF / max. output	 Overrides the conveyor function in automatic mode. Toggle switch function: Toggle the switch forward (away from the operator): Conveyor OFF. Toggle the switch back (toward the operator): Conveyor 100% feed capacity.
75	Left auger reversing switch	The conveying direction of the left half of the auger can be reversed in order to slightly reverse a material supply which may be too high. NOTICE The switch can be activated as often as needed to allow the conveyor to run further in the reverse direction.

		The conveying direction of the right half of the auger can be reversed in order to slightly reverse a material supply which may be too high.
76	Right auger reversing switch	NOTICE
		The switch can be activated as often as needed to allow the conveyor to run further in the reverse direction.



Item	Designation	Brief description
77	Horn	Sound the horn to warn of danger! NOTE: The horn can also be used to communicate with the vehicle driver!
78	Left leveling cylinder	 Manually extends and retracts the leveling cylinder when the vehicle is being operated without the automatic leveling system. Toggle switch function: Toggle the switch forward (away from the screed): Retract or raise the leveling cylinder to raise the screed. Toggle the switch back (toward the screed): Extend or lower the the leveling cylinder to lower the screed. Manually extends and retracts the leveling cylinder to raise the screed. Toggle the switch back (toward the screed): Extend or lower the the leveling cylinder to lower the screed.
79	Right leveling cylinder	 Manually extends and retracts the leveling cylinder when the vehicle is being operated without the automatic leveling system. Toggle switch function: Toggle the switch forward (away from the screed): Retract or raise the leveling cylinder to raise the screed. Toggle the switch back (toward the screed): Extend or lower the leveling cylinder to lower the screed. Manually extends and retracts the leveling cylinder to raise the screed. Toggle the switch back (toward the screed): Extend or lower the leveling cylinder to lower the screed. Before operating the toggle switch, ensure that equipment and persons are clear of the machine!
80	Extend / retract left screed extension	 Hydraulically retracts and extends the left extendable part of the screed. Toggle switch function: Toggle the switch left: Extend screed extension. Toggle the switch right: Retract screed extension. MARNING Before operating the toggle switch, ensure that equipment and persons are clear of the machine!
81	Extend / retract right screed extension	 To hydraulically retract and extend the right extendable part of the screed. Toggle switch function: Toggle the switch left: Retract screed extension. Toggle the switch right: Extend screed extension. MARNING Before operating the toggle switch, ensure that equipment and persons are clear of the machine!



Item	Designation	Brief description
82	Raise / lower extendable screed part	 Hydraulically raises and lowers the extendable screed part. Toggle switch function: Toggle the switch forward (away from the operator): Raise extendable part. Toggle the switch back (toward the operator): Lower extendable part. MARNING Before operating the toggle switch, ensure that equipment and persons are clear of the machine!
83	Raise / lower extension scope	 Hydraulically raises and lowers the extension slope. Toggle switch function: Toggle the switch forward (away from the operator): Raise extension slope. Toggle the switch back (toward the operator): Lower extension slope. MARNING Before operating the toggle switch, ensure that equipment and persons are clear of the machine!
84	Berm lock / unlock	 Locks and unlocks the Berm. Toggle switch function: Toggle the switch forward (away from the operator): Unlocks the Berm. Toggle the switch back (toward the operator): Locks the berm. MARNING Before operating the toggle switch, ensure that equipment and persons are clear of the machine!
85	Berm raise / lower	 Hydraulically raises or lowers the Berm. Toggle switch function: Toggle the switch forward (away from the operator): Raises Berm. Toggle the switch back (toward the operator): Lowers Berm. MARNING Before operating the toggle switch, ensure that equipment and persons are clear of the machine!

86	Screed heater system ON / OFF + activation LED	 Jointly switches all of the screed heater system's heating sections on and off. Toggle switch function: Toggle the switch forward (away from the operator): Screed heater system ON and indicator (LED) light ON. Toggle the switch back (toward the operator): Screed heater system OFF.
87	Crowning Adjustment	 The screed is equipped with adjustable crowning; adjusting this enables the required crowning to be set. Toggle switch function: Toggle the switch forward (away from the operator): Increases Crowning. Toggle the switch back (toward the operator): Decreases Crowning.



D_1.0_01_US.fm 35-42

Item	Designation	Brief description
100	Left leveling cylinder	 Manually extends and retracts the leveling cylinder when the vehicle is being operated without the automatic leveling system. Toggle switch function: Toggle the switch forward (away from the operator): Raises the left screed side arm. Toggle the switch back (toward the operator): Lowers the screed side arm. Before operating the toggle switch, ensure that equipment and persons are clear of the machine!
101	Right leveling cylinder	 Manually extends and retracts the leveling cylinder when the vehicle is being operated without the automatic leveling system. Toggle switch function: Toggle the switch forward (away from the operator): Raises the right screed side arm. Toggle the switch back (toward the operator): Lowers the screed side arm. Before operating the toggle switch, ensure that equipment and persons are clear of the machine!
102	Left auger OFF / max. output	Overrides the auger function in automatic mode. Toggle switch function: - Toggle the switch right: Auger OFF. - Toggle the switch left: Auger 100% feed capacity.
103	Right auger OFF / max. output	Overrides the auger function in automatic mode. Toggle switch function: - Toggle the switch left: Auger OFF. - Toggle the switch right: Auger 100% feed capacity.
104	Extend / retract left screed	 Hydraulically retracts and extends the left extendable part of the screed. Toggle switch left: Extend screed. Toggle switch right: Retract screed. WARNING Before operating the toggle switch, ensure that equipment and persons are clear of the machine!

105	Extend / retract	 Hydraulically retracts and extends the right extendable part of the screed. Push button function: Toggle switch left: Retract screed. Toggle switch right: Extend screed.
		A WARNING Before operating the toggle switch, ensure that equipment and per- sons are clear of the machine!



Item	Designation	Brief description
106	Handset connection cable	- Connects to the left remote control.
107	Handset connection cable	- Connects to the right remote control.

D_1.0_01_US.fm 41-42

D 2.0 Operation

1 Operation of the graphical terminal



Item	Designation	Brief description
1	Display	 Display for engine information, diagnostic information and configuration.
2	Softkeys	 Terminal is controlled by navigation through a set of four soft keys. The keys are context dependent. Soft key selection options are displayed above each key and are dependent on the current navigation location within the engine monitor software program.



Item	Designation	Brief description
1	Brightness/Contrast	- Press to access brightness and contrast settings.
2	Navigate Up	- Press up to move up through menu items.
3	Navigate Down	- Press up to move down through menu items.
4	Main Menu	- Press to go to Main Menu screen.
5	Exit/back one screen	- Press to go back one screen.
6	Select	- Press to make selection.
7	Next	- Press to navigate to next digit or screen element.

NOTICE

As a general rule, the far right soft key is the selector button and the far left soft key is the step back one screen key. To engage full screen use, the on-screen selections are not displayed when not in use. Press any soft key to display current selection options. The selection options will be displayed for three seconds.

Brightness/Contrast Adjustment

- Adjust brightness and contrast levels by pressing the far left soft key. This will display the brightness and contrast soft key bar.



NOTICE

The bar will disappear after 3 seconds of inactivity.

Main Menu - Start Menu

The Main Menu screen is the starting point for configuring the terminal.



Basic Setup	-	Use to set time/date, language and units.
Diagnostics	-	Use to set system info, info fault log and J1939 lists.
Screen Setup	-	(PIN protected)
System Setup	-	(PIN protected)

Main Menu - Basic Setup

Use the Basic setup screen to set time, language and display units for the terminal.



Time/Date	-	Use Time/Date set date and display style for time and date information.
Language	-	Use Language to set the system language.
Units	-	Use Units to set speed, distance, pressure, volume, temperature and fuel rates and economy settings.

Main Menu - Basic Setup -Time / Date

Use Time/Date screen to set Time, Date, calendar style and time style. Use up, down select and next soft keys to navigate.



Main Menu - Basic Setup -Language

Use Language screen to select program language. Languages available, English, French, German, Italian, Swedish and Spanish. The default language setting is English.

Main Menu - Basic Setup -Units

Use the up, down, select and next soft keys to define unit measurements.



Speed	-	km/h, mph
Distance	-	km, mi
Pressure	-	kPa, bar, lbs/ sq in
Volume	-	l, gal, imp gal
Temperature	-	°C, °F
Fuel Economy	-	1/100km, mpg, mpig
Fuel Rate	-	l/h, g/h, ig/h

Main Menu - Diagnostics

Use the Diagnostics screen to display current system information, view and monitor fault logs and display all J1939 devices connected to the graphical terminal.



Main Menu - Diagnostics -System Info

The system info screen displays the hardware system serial number, current software version, current system version and node number. Only information is displayed in the System Info window. No changes can be made.



Main Menu - Diagnostics -Fault Log

Fault information is saved and stored to the fault log. Select either Active or Previous Faults to monitor fault activity. Select specific faults to list more information.





Main Menu - Diagnostics -Fault Pop-Up Alarms

When a fault is detected on the CAN network, a flashing red warning alarm will be activated and a fault information pop-up window will be displayed listing current fault information. Warning lights will flash when a popup alarm occurs and will stay flashing until acknowledged.

Warning lights will remain lit until the fault is no longer on the CAN network.

Fault pop-up softkey actions:



	- Select to clear pop up and return directly to previous screens
V	- Scroll between screens and within screens.
	- Scroll between screens and within screens.
~	 Confirm any selections or acknowledge any fault/ warning and to go back to normal screen.

NOTICE

Fault Pop-Up Alarms

- Faults no longer active will also be displayed in the Previous Faults log.
- Faults that have been acknowledged and are no longer active will be shown in the Currently Active Faults log in italics.
- Pop-up fault alarms can be disabled by setting the Fault Pop-Up to off in the CAN section of the System.

Main Menu - Diagnostics -Device List

The Device list page will list all J1939 devices and addresses that are currently being monitored on the network.



Main Menu - Diagnostics -Quick Data

The Quick Data function allows selected signals to be monitored in a scrollable single view display. To select signals for display, press the far right soft key.

Quick Data softkey



Scroll through signal list using the up and down arrow soft keys and select/de-select signals for Quick View monitoring by pressing the far right (check mark) soft key. Signals selected for display will show an asterisks to the left of the signal name.


Start Display

Appears at system start.



Display 01

Display menu

- Vehicle Speed (1) in fpm.
- Engine RPM (2) in rpm with bar chart.
- Diesel tank filling (3) in % with bar chart.
- Engine Coolant Temperature(4) in °F.



Display 02

Display menu

- Actual Engine Torque(1) in %.
- Engine RPM (2) in rpm with bar chart.
- Actual Engine Torque(1) in% with bar chart.
- Engine Coolant Temperature(4) in °F - with bar chart.

Active Faults Display

Appears when a fault occurs.

- To see a list with active faults, first use button 2 or 3 from the current screen and go to Active Fault Screen, then press button 4 to get into the Active Fault Screen.
- After entering the Active Fault Screen, Scroll thru the faults by using buttons 2 or 3.
- To leave the Active Fault Screen, press button 1



Fault Sources and Codes

Nr.	Source
1	Sensor Power
2	Battery
3	Left Joystick
4	Right Joystick
5	Left Steer Wheel/ Position Sensor
6	Right Steer Wheel/ Position Sensor
7	Left Trim Steer POT
8	Right Trim Steer POT
9	Left Max Speed POT
10	Right Max Speed POT
11	Left Pump
12	Right Pump
13	Generator Pump
14	Left PPU
15	Right PPU
16	Generator PPU

Nr.	Cause of Issue
10	Open circuit
11	Input at 0V
12	Short circuit
13	Input at 5V
20	Too low
21	Too high
30	No response
40	Invalid calibration
41	Invalid configuration

Warnings Display

Appears due to faulty machine operation.

- Line (1): Actual displayed Warning of (x) active Warnings. Code number is displayed
 - Scroll between the active warnings by using buttons 2 or 3.
- Leave Warning display by using button 1



Warning Codes

Situation	Code	Display Message
Propel Selector in Position 4, while joy- stick is stroked backward	1	Counter Rotate: stroke joystick forward
Propel Selector in Position 4, while joystick is in neutral for long (e.g. more than 10 seconds)	2	Counter Rotate: stroke joystick forward
Change Propel selector switch while machine in moving	3	Change propel selector when machine is stopped
Change Propel selector switch while joystick is not neutral	4	Change propel selector when joystick is in neutral
Joystick not in neutral when machine is powered up	5	Return Joystick to neutral
Brake is applied, try to stroke joystick	6	Release the brake before driving
Change console selector switch while ma- chine in moving	7	Change active console when machine is stopped
Change console selector switch while joy- stick is not in neutral	8	Change active console when joystick is in neutral
Propel Selector in Position 4, Joystick is moved forward with no steering command for more than 5 seconds	9	
Slope detection beyond the allowable limit	11	Beyond allowable slope. Bring the gear down.
If the Generator frequency goes beyond the allowable limits	12	Generator is not within al- lowable limit

Self- curing ¹		•		•	•	•	•	•		•	•	•	•	•	•	•	•	•	•	•	•			•		•	•	•	•	•	•	•
FMI	2, 3, 4, 11	0, 8, 12, 14	2, 3, 4, 11	2,8	8, 11	3, 4, 11	2, 11	3, 4, 11	11, 12	0, 2, 3, 4	1, 11	0, 11	1, 11	2, 3, 4	2, 11	2, 3, 4, 11	0, 11	0, 11	2, 3, 4, 11	2, 3, 4	0, 11	1, 11	3, 4, 11	0, 1, 11	11, 12	0, 1, 11	2, 11	3, 4, 11	0, 11	2, 3, 4	0, 11	11, 12
Blink code	1-2-6	5-2-1	2-2-6	2-2-2	2-2-2	2-1-6	2-1-6	2-2-8	2-2-8	2-2-4	2-3-1	2-3-1	2-3-1	2-2-3	2-2-3	1-2-8	2-3-3	1-3-6	2-9-2	2-2-5	2-3-2	2-3-5	1-4-7	1-4-7	5-1-4	3-1-8	3-1-8	2-2-7	2-3-7	1-4-4	1-4-4	2-1-2
9	8 HdThrt	VSSCD1	2 APP1	4PPPwm	5 APPPwmPer	I FIPSCD	FIPSCDSysReac	7 FIFCD	FIFCD_WtLvI	S OPSCD	OPSCD1	8 OPSCDSysReacHi) OPSCDSysReacLo	BPSCD	8 BPSCDSysReac) IATSCD	IATSCDSysReac	AirFltSysReac	S APSCD	5 CTSCD	S CTSCDSysReac	<pre>CLSCDSysReac</pre>	B RailCD	RailCDOfsTst	5 T15CD	2 BattCD	8 BattCDSysReac	5 FTSCD	FTSCDSysReac	OTSCD	3 OTSCDSysReac	5 EngMBackUp
· Error code	138	232	12	4	15	6	9	87	8	196	197	198	199	32	33	149	150	÷	16	55	56	37	209	210	226	22	23	133	134	201	203	75
Defined for	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Description (Error location)	Cable break or short circuit, signal implausible compared to signal of idle sensor	Speed above target range, signal missing or implausible	Cable break or short circuit, signal implausible compared to signal of idle sensor (analog pedal)	Cable break or short circuit, bad PWM signal range or frequency (digital pedal)	Bad PWM pulse-width repetition rate (digital pedal)	Cable break or short circuit	Below target range with system reaction	Cable break or short circuit	Above target range	Cable break or short circuit	Pressure value implausible low	Above target range	Below target range	Cable break or short circuit	Outside target range with system reaction	Cable break or short circuit	Above target range with system reaction	Pressure loss above target range with system reaction	Ambient pressure sensor defective	Cable break or short circuit	Outside target range with system reaction	Outside target range with system reaction	Cable break or short circuit	Deviation of signal during start or after-run above target range	Ignition ON not detected	Voltage below target range	Above target range with system reaction	Fuel temp. sensor: cable break or short circuit	Above target range with system reaction	Cable break or short circuit	Below target range with system reaction	Engine running with cam-shaft speed signal only
	1			1		1	I																									
Component / Location	Hand throttle	/ehicle speed signal	Accelerator pedal	Accelerator pedal	Accelerator pedal	-uel low pressure sensor	-uel low pressure	-uel filter water level sensor	Nater level in fuel filter	Dil pressure sensor	Dil pressure sensor	Dil pressure	Dil pressure	Charge air pressure sensor	Charge air pressure	Charge air temperature sensor	Charge air temperature	Air filter condition	ECU internal error	Coolant temperature sensor	Coolant temperature	Coolant level	Rail pressure sensor	Rail pressure sensor	Terminal 15	3attery	Sattery voltage	uel temperature sensor	-uel temperature	Dil temperature sensor	Oil temperature	Engine speed sensor

1.2 Engine Error messages

2
4
o
-
Ξ
÷
S
<u>ر</u>
'
ò
o.
2
۵

			Defined for	L	ŝ	1.00		2.1
	Component / Location	Description (Error rocation)		SERDIA	2	code		curing ¹
190	Engine speed sensor	Speed signal from cam-shaft bad or missing	•	76	EngMCaS1	2-1-2	8, 11, 12	•
190	Engine speed sensor	Speed signal from crank-shaft bad or missing	•	17	EngMCrS1	2-1-2	8, 11, 12	•
190	Engine speed sensor	Speed signals of crank-shaft and cam-shaft are phase-shifted	•	78	EngMOfsCaSCrS	2-1-3	2, 11	
190	Overspeed	Engine overspeed with system reaction	•	62	EngPrtSysReacFOC	2-1-4	0, 11	
190	Overrun conditions	Overrun conditions with system reaction	•	80	EngPrtSysReacORC	2-1-4	11, 14	•
520	CAN message	Missing (message "TSC1-TR")	•	126	FrmMngTOTSC1TR	1-1-9	11, 12	
563	Main relay	Short circuit to ground or emergency shut-off (relay 3)	•	187	MRIyCDMnRIy2	2-6-1	7, 11, 12	
624	Diagnostic lamp	Cable break or short circuit, disabled by ECU	•	225	SysLamp	5-1-3	2, 3, 4, 5	
630	ECU internal error	EEPROM memory access	•	142	HWEMonEEPROM	2-8-1	11, 12	
639	CAN bus off-state	Cable break or short circuit, off-state (CAN bus A)	•	192	NetMngCANAOff	2-7-1	11, 14	•
651	Single injector	Short circuit (injector 1)	•	159	InjVIvCy11A	1-5-4	3, 4, 11, 13	•
651	Single injector	Cable break (injector 1)	•	160	InjVIvCyI1B	1-5-4	5, 13	•
652	Single injector	Short circuit (injector 2)	•	161	InjVIvCyl2A	1-5-5	3, 4, 11, 13	•
652	Single injector	Cable break (injector 2)	•	162	InjVIvCyl2B	1-5-5	5, 13	•
653	Single injector	Short circuit (injector 3)	•	163	InjVIvCyI3A	1-5-6	3, 4, 11, 13	•
653	Single injector	Cable break (injector 3)	•	164	InjVIvCyI3B	1-5-6	5, 13	•
654	Single injector	Short circuit (injector 4)	•	165	InjVIvCyl4A	1-6-1	3, 4, 11, 13	•
654	Single injector	Cable break (injector 4)	•	166	InjVIvCyl4B	1-6-1	5, 13	•
655	Single injector	Short circuit (injector 5)	•	167	InjVIvCyI5A	1-6-2	3, 4, 11, 13	•
655	Single injector	Cable break (injector 5)	•	168	InjVIvCyI5B	1-6-2	5, 13	•
656	Single injector	Short circuit (injector 6)	•	169	InjVIvCyl6A	1-6-3	3, 4, 11, 13	•
656	Single injector	Cable break (injector 6)	•	170	InjVIvCyl6B	1-6-3	5, 13	•
657	Single injector	Short circuit (injector 7)	•	171	InjVIvCyI7A	1-6-4	3, 4, 11, 13	•
657	Single injector	Cable break (injector 7)	•	172	InjVIvCyI7B	1-6-4	5, 13	•
658	Single injector	Short circuit (injector 8)	•	173	InjVIvCyI8A	1-6-5	3, 4, 11, 13	•
658	Single injector	Cable break (injector 8)	•	174	InjVIvCyI8B	1-6-5	5, 13	•
676	Air heater relay	Cable break or wrong connection	•	19	ArHtCD_NoLd	2-6-3	4, 11	
676	Air heater relay	Inoperable during shut-off	•	20	ArHtCD_RIyErr	2-6-3	2, 5, 11	
677	Start relay	Start relay (high side): short circuit	•	223	StrtCDHS	5-1-2	3, 4, 11	
677	Start relay	Start relay (low side): cable break or short circuit, disabled by ECU	•	224	StrtcDLS	5-1-2	3, 4, 5, 11	
701	Reserve output	Short circuit to Ubatt (output 1)	•	57	Dummy1CD_Max	•	11	
701	Reserve output	Short circuit to ground (output 1)	•	58	Dummy1CD_Min	•	11	
701	Reserve output	Cable break or ECU internal error (output 1)	•	59	Dummy1CD_SigNpl	•	11	
702	Reserve output	Short circuit to Ubatt (output 2)	•	99	Dummy2CD_Max	ŀ	11	

Self- curing ¹						•	•						•	•			•	•	•											•	•			
EMI	11	1	2, 3, 4, 5	11	2, 3, 4, 5	3, 4, 5, 11	3, 4, 5, 11	11, 12	2, 3, 4, 5	2, 3, 4, 5	3, 4, 5, 11	3, 4, 5, 11	3, 4, 11	3, 4, 11	2, 3, 4, 5	2, 11	11, 14	11, 14	2, 11	11, 12	11, 12	11, 12	11, 12	11, 12	11, 12	11, 12	0, 11	11, 12	11, 12	3, 4, 11, 12	2, 11	3, 11	4, 11	7, 11, 12
Blink code	•	•	1-4-2	1-2-3	1-3-5	2-6-3	2-6-3	1-1-8	5-5-5	2-3-8	5-2-8	2-1-9	2-8-2	2-8-2	3-2-8	3-4-1	2-7-1	2-7-1	1-4-5	2-4-1	2-4-1	2-4-1	2-4-1	2-4-1	2-4-1	2-4-1	2-4-1	2-4-1	2-4-1	3-1-4	3-1-4	1-3-7	1-3-8	2-6-1
Error ID seroid	61 Dummy2CD_Min	62 Dummy2CD_SigNpl	81 ESLpCD	54 CTLpCD	195 OPLpCD	17 ArHt1	18 ArHt2	125 FrmMngTOTSC1TE	74 EngCDTrqCalcOut	83 FanCD	52 CRERCD	82 EXFICD	219 SSpMon1	221 SSpMon2	53 CSLpCD	48 CoEngShOffDemlgr	193 NetMngCANBOff	194 NetMngCANCOff	200 OSWCD	46 CmbChbMisfireMul	38 CmbChbMisfire1	39 CmbChbMisfire2	40 CmbChbMisfire3	41 CmbChbMisfire4	42 CmbChbMisfire5	43 CmbChbMisfire6	47 CmbChbSysReac	44 CmbChbMisfire7	45 CmbChbMisfire8	139 HOTSCD	140 HOTSCDSysReac	182 MnRly1_SCB	183 MnRly1_SCG	186 MRIyCD
efined foi	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•
Description (Error location)	Short circuit to ground (output 2)	Cable break or ECU internal error (output 2)	Cable break or ECU internal error	Cable break or short circuit	Missing (message "TSC1-TE")	Engine Power output: cable break or short circuit	Fan actuator: cable break or short circuit	Internal engine brake: cable break or short circuit	Engine brake flap actuator: cable break or short circuit	Wrong voltage of internal 5V reference source 1	Wrong voltage of internal 5V reference source 2	Cable break or short circuit	Shut-off request ignored by operator	Cable break or short circuit, off-state (CAN bus B)	Cable break or short circuit, off-state (CAN bus C)	Switch hangs	Misfire detected	Misfire detected (cylinder 1)	Misfire detected (cylinder 2)	Misfire detected (cylinder 3)	Misfire detected (cylinder 4)	Misfire detected (cylinder 5)	Misfire detected (cylinder 6)	Misfire detected with system reaction	Misfire detected (cylinder 7)	Misfire detected (cylinder 8)	Cable break or short circuit (sensor 2)	Outside target range with system reaction (temperature 2)	Short circuit to Ubatt (relay 1)	Short circuit to ground (relay 1)	Short circuit to ground or emergency shut-off (relay 2)			
			d	ig lamp								tor																		sor	perature			

7
5
Ē
Ś
-
0
ς.
D

SPN Con Loca	nponent / ation	Description (Error location)	Defined for DCR DMV	Error code SERDIA	Q	Blink code	EMI	Self- curing ¹
2634 Main	r relay	Short circuit to ground or emergency shut-off (relay 3)	•	188	MRIyCDMnRIy3	2-6-1	7, 11, 12	
2791 EGR	R actuator (external)	Short circuit to Ubatt	•	69	EGRCD_Max	4-1-4	3, 11	
2791 EGR	R actuator (external)	Short circuit to ground	•	70	EGRCD_Min	4-1-4	4, 11	
2791 EGR	R actuator (external)	Cable break or ECU internal error	•	71	EGRCD_SigNpl	4-1-5	2, 5, 11	
2791 EGR	R actuator (external)	Cable break or short circuit	•	72	EGRCDINEGR	4-1-6	2, 3, 4, 5	
523212 CAN	message	Missing (message "EngPrt" = engine protection)	•	106	FrmMngTOEngPrt	3-3-3	11, 12	•
523216 CAN	message	Missing (message "PrHtEnCmd" = preheat and engine command)	•	110	FrmMngTOPrHtEnCmd	3-3-7	11, 12	•
523218 CAN	message	Missing (message "RXCCVS" = cruise control)	•	112	FrmMngTORxCCVS	1-1-1	11, 12	•
523222 CAN	message	Missing (message "TCO1" = speedo signal)	•	118	FrmMngTOTC01	1-1-6	11, 12	•
523238 CAN	message	Missing (message "SwtOut" = switch outputs)	•	117	FrmMngTOSwtOut	1-1-5	11, 12	•
523239 CAN	message	Missing or value above target range (message "DecV1" = pseudo pedal)	•	94	FrmMngDecV1	5-2-6	2, 12	•
523240 CAN	message	Missing (message "FunModCtl" = function mode control)	•	95	FrmMngFunModCtl	5-2-7	11, 12	•
523350 Multi	iple injectors	Short circuit (cylinder bank 1)	•	153	InjVIvBnk1A	1-5-1	3, 4, 11, 13	•
523351 Multi	iple injectors	Cable break (cylinder bank 1)	•	154	InjVIvBnk1B	1-5-1	5, 13	•
523352 Multi	iple injectors	Short circuit (cylinder bank 2)	•	155	InjVIvBnk2A	1-5-2	3, 4, 11, 13	•
523353 Multi	iple injectors	Cable break (cylinder bank 2)	•	156	InjVIvBnk2B	1-5-2	5, 13	•
523354 ECU	l internal error	Injector power stage A	•	157	InjVIvChipA	1-5-3	2, 3, 12, 14	
523355 ECU	l internal error	Injector power stage B	•	158	Inj/IvChipB	1-5-3	12	
523370 Rail	pressure	Compression test active: rail-pressure monitoring is going to be disabled	•	175	Inj/VVErrDet	5-5-5	11, 14	
523420 ECU	l internal error	Watchdog counter exceeds maximum	•	184	Montr	1-3-9	11, 14	
523450 Multi	i state switch	Cable break or short circuit, input voltage outside target range (switch 1)	•	189	MSSCD1	1-4-3	2, 3, 4, 11	•
523451 Multi	i state switch	Cable break or short circuit, input voltage outside target range (switch 2)	•	190	MSSCD2	1-4-3	2, 3, 4, 11	•
523452 Multi	i state switch	Cable break or short circuit, input voltage outside target range (switch 3)	•	191	MSSCD3	1-4-3	2, 3, 4, 11	•
523470 Rail	pressure limiting valve	Opening failure	•	208	PRVMon	1-4-6	2, 11, 12, 14	
523470 Rail	pressure limiting valve	Opening failure with system reaction	•	236	PRVMonSysReac	1-4-6	11, 12	
523490 ECU	l internal error	Redundant shut-off conditions detected	•	218	SOPTst	1-4-9	3, 4, 11, 12	
523500 CAN	l message	Time-out of at least one sended message	•	131	FrmMngTxTO	2-7-1	11, 12	•
523550 Term	ninal 50	Engine start switch hangs	•	227	T50CD	5-1-5	11, 12	
523550 ECU	l internal error	Time processing unit (TPU) defective	•	228	TPUMon	5-5-5	2, 11	
523561 Begi	in of injection period	Outside target range or missing (cylinder 1)	•	24	BIPCyl1	5-3-1	2	•
523562 Begi	in of injection period	Outside target range or missing (cylinder 2)	•	25	BIPCyl2	5-3-2	2	•
523563 Begi	in of injection period	Outside target range or missing (cylinder 3)	•	26	BIPCyI3	5-3-3	2	•
523564 Begi	in of injection period	Outside target range or missing (cylinder 4)	•	27	BIPCyl4	5-3-4	2	•
523565 Begi	in of injection period	Outside target range or missing (cylinder 5)	•	28	BIPCyl5	5-3-5	2	•

Self- curing ¹	•	•	•		•	•	•													•	•	•	•	•	•						•	•
M	5	2	2	11, 12	3, 4, 11	2, 11	11, 12	11, 12	11, 12	11, 12	11, 12	11, 12	11, 12	11, 12	11, 14	11, 14	11, 14	3, 11	4, 11	0, 11	0, 11	0, 11	1, 11	0, 11	2, 11	3, 4, 11	5, 11, 12	11, 12	11, 12	11, 12	2, 3, 4, 11	2, 11
Blink code	5-3-6	5-3-7	5-3-8	5-5-5	2-8-2	2-3-8	1-1-2	1-1-8	1-1-9	1-1-8	1-1-9	1-1-8	1-1-8	1-1-9	5-5-5	5-5-5	5-5-5	5-5-5	5-5-5	1-3-4	1-3-4	1-3-4	1-3-4	1-3-4	1-3-4	1-3-5	1-3-5	1-3-5	1-3-5	5-5-5	1-3-3	1-3-3
Error ID code SERDIA	29 BIPCyl6	30 BIPCyI7	31 BIPCyI8	235 WdCom	222 SSpMon3	86 FanCDSysReac	113 FrmMngTORxEngTemp	120 FrmMngTOTSC1AE	121 FrmMngTOTSC1AR	122 FrmMngTOTSC1DE	123 FrmMngTOTSC1DR	124 FrmMngTOTSC1PE	127 FrmMngTOTSC1VE	128 FrmMngTOTSC1VR	143 HWEMonRcyLocked	144 HWEMonRcySuppres-	145 HWEMonRcyVisible	146 HWEMonUMaxSupply	147 HWEMonUMinSupply	211 RailMeUn0	212 RailMeUn1	213 RailMeUn2	214 RailMeUn3	215 RailMeUn4	216 RailMeUn7	176 MeUnCD_ADC	177 MeUnCDNoLoad	178 MeUnCDSCBat	179 MeUnCDSCGnd	141 HWEMonCom	136 GOTSCD	137 GOTSCDSysReac
fined for R DMV	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•	•											•	•	•
Description (Error location)	Outside target range or missing (cylinder 6)	Outside target range or missing (cylinder 7)	Outside target range or missing (cylinder 8)	Serial communication interface defective	Wrong voltage of internal 5V reference source 3	Above target range with system reaction	Missing (message "RxEngTemp" = engine temperature)	Missing (message "TSC1-AE")	Missing (message "TSC1-AR")	Missing (message "TSC1-DE")	Missing (message "TSC1-DR")	Missing (message "TSC1-PE")	Missing (message "TSC1-VE")	Missing (message "TSC1-VR")	A recovery occurred which is stored as protected	A recovery occurred which is not stored	A recovery occurred which is visible in the error memory	Overvoltage	Undervoltage	Positive deviation (speed dependent) outside target range	Positive deviation (flow dependent) outside target range (⇔ leakage!)	Negative deviation (flow dependent) outside target range	Negative deviation (speed dependent) outside target range	Pressure above target range	Implausible (leakage, injector needle blocked in open position)	Flow rate outside target range	Not connected or output disabled	Short circuit to Ubatt	Short circuit to ground	Communication with chip CJ 940 disturbed	Cable break or short circuit (sensor 1)	Outside target range with system reaction (temperature 1)
Component / _ocation	Segin of injection period	Segin of injection period	Segin of injection period	ECU internal error	ECU internal error	an speed	CAN message	CAN message	CAN message	CAN message	CAN message	CAN message	CAN message	CAN message	ECU internal hardware monitoring	ECU internal hardware monitoring	ECU internal hardware monitoring	ECU internal hardware monitoring	ECU internal hardware monitoring	Rail pressure	Rail pressure	Rail pressure	Rail pressure	Rail pressure	Rail pressure	Metering unit valve	Metering unit valve	Metering unit valve	Metering unit valve	ECU internal error	Customer-specific sensor	Customer-specific temperature
							-	-	-	-	-	-	-	-					1												-	-

23-24
US.fm
0_01_
D_12

F٨	/II-c	cod	le	S	S	S	S
1					ment	ment	ment
-	ed	ange		entifiable	e or compor	e or compor	e or compor
	update rate	rate of char		de not iden	de not iden jent device	de not iden jent device bration	de not iden jent device bration itructions
Abnormal fr	Abnormal u	Abnormal ra		Failure moo	Failure moo Bad intellige	Failure moo Bad intellig Out of Calit	Failure mod Bad intellig Out of Calit Special Inst
8	6	10 A		1	11 F	12 EB F	11 12 12 12 12 12 12 12 12 12 12 12 12 1
-	<u> </u>						
	t						
range	range						
perational	erational		orrect	orrect ed high	orrect ed high ed low	orrect ed high ed low circuit	orrect ed high ed low circuit ded circui
iormal ope	iormal ope		int, or inco	int, or inco or shorter	int, or inco or shorted or shorted	int, or inco or shorted or shorted or open c	int, or inco or shorted or shorted or open c
it above n	It below n		intermitter	intermitter /e normal	intermittel e normal w normal	e normal w normal w normal	intermittel e normal w normal w normal fe normal
12	12	:	atic,	abov	ratic, abov	e abov e belov t belov	e abov e belov it belov t abov
ata valid t	ata valid t	-	ata eri	ata er oltage	ata er oltage oltage	ata el oltage urren	ata e oltage urren
0 Data valid {	1 Data valid b	O Data and	India ell	 voltage 	 Voltage Voltage 	 4 Voltage 4 Voltage 5 Curren 	 A Uata e 3 Voltage 4 Voltage 5 Curren 6 Curren

1.3

D 3.0 Operation

1 Operating elements on the paver

Operator's platform



Seat console

The seat console can pivot beyond the outer edge of the vehicle, providing the driver with a better view of the paving area in this position.

- Step on the lock release (1).
- Swing the seat console to the desired position.
- Engage the lock into one of the fixed positions (2).



After locking the seat console, check it to ensure it will not move into another position!

Operating panel

The operating panel can be pivoted so that the seat console is beyond the outer edge of the vehicle.

- Pull the locking knob (3).
- Swing the operating panel to the desired position.
- Engage the lock in one of the fixed positions (4).

After locking the panel, check it to ensure it will not move to another position!

Driver's seat

To avoid injury, the individual seat settings should be checked and adjusted before starting the vehicle.

After the adjustments are set, check the seat to ensure it does not move out of adjustment.

- Seaforwardandbackadjustmen(1)The seat can be moved forward or it can be moved back. to adjust the seat, raise the lever on the lower left side of the seat to release the lock. Once the seat is in the desired position, release the lever and the seat will lock into place
- Seatbackrestadjustment(2):Theback rest can be adjusted to lean forward or lean back. To adjust the back rest, turn the knob



on the lower front part of the seat. Turn the knob clockwise to lean the back rest forward; turn the knob counter-clockwise to lean the back rest back.

- Armrest positions (3): The armrest can be lowered to support the arm or it can be raised to be stowed out of the way.

Batteries

The batteries are located under the right hand side (from operator platform) maintenance door.

There are two 12 V batteries to produce the 24 V needed for the electrical system. For servicing, see chapter F.





Follow the instructions when jump starting the paver. (see section D 4).

Battery main switch

The main switch interrupting the circuit between the battery and the main fuse is located under the center maintenance door.





See chapter F for fuse locations and fuse order.

- To switch the ignition off, turn the key (1) to the left and pull it out.





Do not lose the key. Without it the paver can no longer be moved!

Transport safeguards for the hopper

Before parking or transporting the paver, the hopper halves must be pivoted upwards and the transport safeguards for the hopper must be inserted.

- Insert the safeguards on both sides of the machine (1) into the pinning hole.
- Without transport safeguards inserted, the hopper halves will slowly open; danger during transportation!



Do not enter the hopper while the engine is running! Danger of being caught by the conveyor!

Mechanical screed transport safeguard (to the left and the right beneath the driver's seat)

Used to protect the lifted screed from inadvertent lowering. The screed transport safeguard must be inserted before transportation and when work is finished.

- Lift the screed.
- Activate the levers (1).
- Check that the safeguards (to the left and to the right) engage under the crossbeams.



A WARNING

Transportation with an unsecured screed bears the danger of accidents!

A DANGER

Insert screed lock only at crown adjustment "zero"! Lock the screed only for transportation. Use the lock for transportation only! Do not enter or work under screed if it is only secured with the screed locked for transportation!

Paving thickness indicator

The Paving Thickness Indicator scales are located on the left and right sides of the vehicle.

- The Paving Thickness Indicator (1) shows the setting on the Scale (2).
- In normal paving situations, the same paving thickness should be set on both sides of the vehicle!





Before transporting the vehicle, ensure the Paving Thickness Indicator and the Scale swing in against the machine. Do not transport the machine unless the indicator and the scale are in against the machine.



Avoid different settings on the scales as this will produce un-even pavement.

Release Agent System

Used to spray the parts coming into contact with asphalt with a separator emulsion.

NOTE:

Check local regulations concerning use of cleaners and use of solvents!

- Pull hose (1) out of the guide until there is an audible click. The hose will lock in this position.

NOTE:

The hose will retract automatically into the guide by pulling out until it clicks again, then it will reel in again.

- On/off switch (2) for the emulsion pump.
- Press hand-valve (3) to spray, release to stop spraying.
- The spraying system is fed by the tank (4). (Only fill the tank when the machine is not moving.)



Switch on the spraying system only when the diesel engine is running; otherwise, the battery will be drained. Switch off after use.

A DANGER

Don't spray into open flame or onto hot surface! Danger of explosion!

On/Off switch of working lights (1)

Toggle switch (1) to switch on all installed working lights.

On/Off switch hazard flasher (2):

Activate switch (2) to switch on installed flasher.

Warning Beacon

NOTE:

The function of the warning beacon must be checked daily before starting work.

- Place the warning beacon onto the plug-in contact and secure with a wing bolt (1).
- Slide the warning beacon with tube (2) to the desired height and secure with the both clamping screws (3).
- Turn the switch on to activate the warning beacon.

NOTE:

The rotary warning beacon is easy to remove and should be stored securely when the work is done.



Conveyor limit sensors

The ultrasonic conveyor limit sensors control the material flow at the respective conveyor half. The conveyors should stop when the material has roughly reached the area below the auger tube.

NOTE:

This requires that the auger height has been adjusted correctly (see chapter E).



Ultrasonic auger limit sensors (left and right)

The limit sensors control the material flow at the respective auger half.

The ultrasonic sensor is mounted to the side plate. Loose clamping lever for adjustment and modify angle / height of the sensor.

The cables must be connected to the remote control units located at the sides of the screed.



NOTE:

Adjust the limit sensor positions while the material is distributed.

Sockets 24V

Connect the working lights (24 V) or other devices here.

- Power is present when the main switch is switched on.

NOTE:

As an option, one socket can be used to provide power for accessories.



D 4.0 +Operation

1 Preparation of operation

Required equipment and tools

To avoid delays on site, check before starting work whether or not the following equipment and tools are present:

- Wheel loader for transporting heavy extendable parts
- Diesel fuel
- Engine oil and hydraulic oil, lubricants
- Separating agents (emulsion) and manual injector
- Shovel and broom
- Scraper (shovel or scoop) for cleaning the auger and the hopper intake area
- Necessary parts for extending the auger
- Necessary parts for extending the screed
- Percentage spirit level and levelling rail, 4 yards (4 m) long
- Levelling wire
- Protective clothing, signal vest, gloves, hearing protection

Before starting work

(in the morning or when starting paving)

- Follow the safety instructions.
- Check personal protective equipment.
- Take an inspection walk around the paver and check for leaks and damages.
- Install parts removed for transportation or for the night.
- Perform the check according to the "Checklist for the machine operator" given below.

Checklist for the machine operator

Check!	How?
Emergency stop button - on the operating panel - on both remote control units	Push in the button. The diesel engine and all running drives must stop immediately. Button must be pulled out to start machine again
Steering	The paver must follow every movement of the steering wheel. Check straight running.
Horn - on the operating panel - on both remote control units	Briefly press the horn button. The horn must sound.
Lights	Switch on (with the paver started), walk around the paver and inspect it, then switch off again.

Check!	How?
Auger covers	For larger working widths, the walkway plates must be extended and the auger tunnels must be covered.
Screed covers and walkways	For larger working widths, the walkway plates must be extended. Hinged walkway plates must be swung down. Check that the side shields, the side plates and the covers are securely seated.
Screed transport safeguard	When the screed is lifted, the operator must be able to engage both screed transport safeguards.
Hopper transport safeguard	When the hopper is closed, the operator must be able to engage both hopper transport safeguards.
Miscellaneous: - Engine hood - Lateral flaps	Check that the hoods and flaps are closed and secured.
Accessories: - First-aid kit	The accessories must be in the pro- vided holders.



D_4.0_01_US.fm 4-26

Before starting the paver

Before starting the diesel engine and beginning operation, the following steps must be performed:

- Daily maintenance of the paver (see chapter F)

Check the operating hours counter to determine whether or not additional maintenance work (such as monthly or yearly maintenance) must be performed.

- Check the safety devices and protective devices.

"Normal" starting

- Set the drive lever (20) to the center position and the speed preselector (12) and the selector (21) for traction drive / engine to minimum.
- Insert the ignition key (10) in position "0". The lights should be switched off during starting to reduce the current drain on the battery.

NOTICE

Starting is not possible if the drive lever is not in the central position or if the emergency stop button (40) is depressed,

- Turn the ignition key (10) into position 3 to start the engine. Once engine has started, release the key and it will spring-return to the "On" position. Do not let the starter run continuously for more than 20 seconds; wait 1 minute before turning the starter again.



D_4.0_01_US.fm 6-26

Jump starting

The engine can be started with the help of an external power source if the batteries are low and the starter no longer turns.

Suitable power sources are:

- Other vehicles with a 24 V system
- Additional 24 V battery
- Start device that is suitable for jump starting (24 V/90 A).

NOTICE

Standard 12V chargers or quick chargers cannot be used for jump starting.

To jump start the engine:

- Set the drive lever (20) to the center position. Set the speed preselector (12) and the selector (21) for traction drive / engine to minimum.
- Insert ignition switch (10) to position "0" to turn on the ignition.
- Connect the power source with the appropriate cables.

▲ CAUTION

Check for proper polarity! Always connect the negative cable last and remove it first!

- Turn the ignition key (10) completely to the right to start the engine. Once the engine starts, release the key and it will spring-return to the "ON" position. Do not let the starter run for more than 20 seconds; wait 1 minute after every attempt before turning the starter again!



D_4.0_01_US.fm 8-26

After starting

To increase the engine speed:

- Set selector (21) for traction drive / engine to position 2.

NOTICE

Let the paver warm up for about 5 minutes if the engine is cold.

NOTICE

Read and follow Chapter D2 of this manual for possible warnings on the graphical terminal!



1.2 Transport Operation

Lifting and securing the screed

- Raise the screed using switch (52).
- Center the levelling cylinders using the switches (54)/(55).

NOTICE

The remote control must be connected and this function must be set to "Manual".

- Raise the auger crossbeam using switches (47)/(48).

NOTICE

Engage both screed transport safeguards to secure the screed in the raised position.

Driving and stopping the paver

- Set the selector (21) for traction drive / engine to position 3.
- Set the preselector (12) for traction drive to approx. 50%.
- To start driving, carefully tilt the drive lever (20) forward or backward according to the drive direction desired.

In case of an emergency, press the emergency stop button (40)!

- To stop the vehicle, move the drive lever (20) into its center position.

Switching off and securing the paver

- Lower the screed using switch (52).
- Turn off the engine by turning the ignition key (10) to the "0" position. Pull the key out of the switch.

The battery may become drained if the paver stands still for long periods of time even though the ignition is not switched on.

Releasing agent

Spray the parts coming into contact with asphalt (hopper, screed, auger, push roller) with a separator emulsion.





Do not use diesel fuel as it dissolves the bitumen.

Screed heater

Switch the screed heater "On" for about 15–30 minutes (depending on the ambient temperature) before paving begins. Warming up prevents the material from sticking to the screed plates.

Direction marks

To ensure straight paving, a direction mark must be present or established (road edge, chalk lines or similar).

- Slide the operating panel to the desired side and secure it.
- Pull the alignment indicator out of the bumper (see arrow) and adjust it accordingly.





D_4.0_01_US.fm 13-26

Loading/distributing material

- Open the hopper with switch (15). Have the truck back short of the paver and pull the paver against the truck tires. Guide the truck driver when dumping the material mix.
- Set the switch (45) of the auger and conveyor to the "ON" position.
- Set the switch (46) of the auger and conveyor to "AUTO" position.
- Set the appropriate auger switch on the remote control and conveyor switch (if applicable) to "auto" position.
- Set the selector (21) for traction drive / engine to position 2 and push the drive lever (20) forward (away from operator).

Conveyor and auger will begin to work.

NOTICE

The limit sensors for the conveyors and augers must switch off the function when the material has reached the height limit in the area beneath the auger crossbeam (conveyor sensors) or at the auger ends (auger sensors).

Check that the material is being conveyed properly.

- If the material is not being conveyed properly, switch conveyor and auger to "MAN-UAL" by using switch (46) until a sufficient amount of material lies in front of the screed.
- Switch conveyor and auger to "AUTO" using switch (46).



D_4.0_01_US.fm 15-26

1.4 Starting for paving

Set the switches, levers and controls listed below to the specified positions when the screed has reached its operating temperature and a sufficient amount of material lies in front of the screed:

Item	Switch	Position
21	Selector	position 2
12	Preselector	approx. 50%
53	Screed position	to floating position.
27	Vibration	ON
24	Tamper (option)	ON
45	Auger+conveyor	ON
46	Auger+conveyor	AUTO

- Push the drive lever (20) to its most forward position and start driving. Screed floating position is activated now.

- Observe the distribution of the material and adjust the limit sensors if necessary.
- Set the compacting elements (vibration and/or tamper) according to the required compaction ratio.
- Let the paving supervisor check the layer thickness after 15-20 feet (5-6 meters) and correct if necessary.

Carry out the check in the area of the drive chains or wheels as the screed tends to level an uneven ground. The reference points for the layer thickness are the drive chains or wheels.

The basic screed setting must be corrected when the actual layer thickness deviates significantly from the values needed for the job requirement (see the operating instructions for the screed).
1.5 Check during paving

The following points must be constantly observed during paving:

Paver function

- Screed heater
- Tamper and vibration
- Engine oil and hydraulic oil temperature
- The screed parts must be retracted and extended in time when obstacles are in the way.
- Uniform material transport and distribution or supply to the screed; may require corrections to settings of the material switches for conveyor and auger.

NOTE:

See the section D4 "Malfunctions" when paver functions fail.

Quality of the layer

- Mat thickness
- Slope
- Evenness in the driving direction and at right angles to it (check with a level)
- Surface structure/texture behind the screed.

NOTE:

See section D 4 "Malfunctions, Problems during Paving" if the paving quality is poor.



D_4.0_01_US.fm 18-26

1.6 Interrupting/terminating operation

During breaks (i.e. the material supply truck is late)

- Determine the approximate duration.
- When the material's temperature drops below the minimum paving temperature, run the paver empty and create an edge like the end of a layer.
- Set the drive lever (20) to the center position.

NOTICE

Screed will be switched into "STOP" function automatically.

During extended interruptions (i.e. lunch break)

- Turn drive lever (20) to center position. Move the preselector (12) and selector (21) to minimum position.

NOTICE

Screed will be switched into "STOP" function automatically.

- Switch off conveyor+auger (45), vibration (27), tamper (if equipped)(24), lights (25) and exhaust system (28).
- Switch ignition (10) off.
 - Switch screed heater (system) off.

NOTICE

The screed must be heated up to the correct paving temperature before paving can be resumed.



D_4.0_01_US.fm 20-26

When work is finished

- Run the paver empty, then bring it to a stop.
- Turn drive lever (20) to the center position. Move the preselector (12) and selector (21) to minimum position.
- Switch off conveyor+auger (45), vibration (27), tamper (if equipped)(24), lights (25) and exhaust system (28).
- Lift the screed by using switch (52).
- Retract the screed parts to the basic screed width with switches (50) and (51).
- Use switch (47) and (48) to lift the auger .
- Where applicable, completely extend the levelling cylinders by using switches (54) and (55).
- Insert the mechanical screed transport safeguard (74) on both screed lifting cylinders.
- While operating the tampers at a low speed, let any material residue drop out.



Switch the ignition (10) off.

- Switch screed heater (system) off.
- Remove the levelling units and stow them away in their boxes and close the boxes.
- Remove all parts that extend beyond the paver width. Secure them if the paver is to be transported over public roads on a low-bed trailer.

▲ CAUTION

Do not turn the main switch off until 15 seconds after the ignition has been turned off! The engine electronics requires this length of time to back up data.

- Read and check the operating hour meter to determine whether maintenance work must be performed (see chapter F).
- Cover and lock the operating panel.
- Remove material residue from the screed and the paver and spray all parts with release agent fluid.



2 Malfunctions

2.1 Problems during paving

Problem	Cause:
Wavy surface ("short waves")	 change in the material temperature, segregation wrong material composition incorrect operation of the roller incorrectly prepared foundation long idle standing times between loads grade control reference line is not suitable grade control toggles between up and down (inertia setting is too high) bottom plates of the screed are loose bottom plates of the screed are warped or not uniformly worn screed does not work in the floating position too much play in the mechanical screed link/suspension paver speed is too high augers are overloaded changing material pressure against the screed
Wavy surface ("long waves")	 change in the material temperature segregation roller has stopped on the hot material roller has turned or roller speed has been changed too quickly incorrect roller operation incorrect foundation preparation truck brake is applied too tight long idle standing times between loads grade control reference line is not suitable incorrect installation of the grade control limit sensors are not correctly set screed is empty screed has not been switched to the floating position too much play in the mechanical screed link auger is set too deep auger is overloaded changing material pressure against the screed
Cracks in the layer (over the entire width)	 material temperature is too low change in the material temperature moisture on the foundation segregation wrong material composition wrong layer height for the maximum grain size cold screed bottom plates of the screed are worn or warped paver speed is too high

Problem	Cause:
Cracks in the layer (center strip)	 temperature of the material cold screed bottom plates are worn or warped wrong crowning
Cracks in the layer (outer strip)	 temperature of the material screed extendable parts are incorrectly installed limit switch is not correctly set cold screed bottom plates are worn or warped paver speed is too high
Layer composition is not uniform	 temperature of the material change in the material temperature moisture on the foundation segregation wrong material composition incorrectly prepared foundation wrong layer height for the maximum stone size long idle standing times between loads vibration is too slow screed extendable parts are incorrectly installed cold screed bottom plates are worn or warped screed does not work in the floating position paver speed is too high auger is overloaded changing material pressure against the screed
Marks in the surface	 truck hits against the paver too much while aligning to the paver too much play in the mechanical screed link/suspension truck parking brake is applied vibration is too high while standing in one spot
Screed does not react to corrective measures as expected	 temperature of the material change in the material temperature wrong layer height for maximum grain size incorrect installation of the grade control vibration is too slow screed does not work in the floating position too much play in the mechanical screed link paver speed is too high

2.2 Malfunctions on the paver or screed

Malfunction	Cause:	Remedy			
At the diesel engine	Diverse	See operating instructions for the engine			
Diesel engine does	Batteries drained	See "External starting" (start assistance)			
not start	Other	see "Towing"			
	Tamper is obstructed by cold bitumen	Properly heat the screed			
	Hydraulic oil level in the tank is too low	Fill with oil			
Tamper or vibration	Pressure limiting valve is defective	Replace the valve; if necessary, repair and adjust the valve			
	Leak in the suction line of	Seal or replace the connections			
	the pump	Tighten or replace the hose clamps			
	Oil filter is dirty or plugged (clogged)	Replace the filter			
	Hydraulic oil level in the tank is too low.	Fill with oil			
	Power supply is interrupted	Check fuses and cables; replace if necessary			
	Sensor is defective	Replace the sensor			
Conveyor or augers	One of the pressure limit- ing valves is defective	Repair or replace the valves			
	Pump shaft broken	Replace the pump			
	Limit sensor does not regu- late correctly	Check the sensor; replace the sensor if necessary			
	Pump is defective	Replace the pump. Check the system for contaminants			
	Oil filter is dirty or plugged	Replace the filter			
	Engine speed is too low	Increase the speed			
	Hydraulic oil level is too low	Fill with oil			
	Leak in the suction line	Tighten the connections			
Hopper cannot be	Flow rate regulator defective	Replace			
swung open	Leaking seals in the hydraulic cylinder	Replace			
	Control valve is defective	Replace			
	Power supply interrupted	Check fuse and cables; replace if necessary			

Malfunction	Cause:	Remedy
Hoppore Jowers	Control valve is defective	Replace
inadvertently	Leaking seals in the hydraulic cylinder	Replace
	Oil pressure too low	Increase the oil pressure
	Leaking seal	Replace
Screed cannot be lifted	Screed relieving or charging is switched on	Switch must be in the center position
	Power supply is interrupted	Check fuse and cables; replace if necessary
	Check to see if the switch on the remote control is set to "auto"	Set the switch to "manual"
	Power supply is interrupted	Check fuse and cables; replace if necessary
Lifting Arms cannot be lifted or lowered	Switch on the operating panel defective	Replace
	Excess pressure valve defective	Replace
	Flow rate regulator defec- tive	Replace
	Seals defective	Replace
	Control valves defective	Replace
Lifting Arms lower inadvertently	Pilot-controlled non-return valves defective	Replace
	Seals defective	Replace

Malfunction	Cause:	Remedy		
	Traction drive fuse defective	Replace (Fuse holder is on the operating panel)		
	Power supply is interrupted	Check potentiometer, cables, connectors; replace if necessary		
-	Traction drive monitoring defective	Replace		
work	Electro-hydraulic servo unit of the pump is defective	Replace the servo unit		
		Check and adjust if necessary		
	Insufficient supply pressure	Check the suction filter; replace the supply pump and the filter if necessary		
	Drive shaft at hydraulic pumps or engine is broken	Replace pump or engine		
	Fuel level too low	Check the fuel level; refill fuel if necessary		
Irregular engine speed, engine stop function does not	Fuse for "engine speed control" defective	Replace (fuse strip on the operating panel)		
WORK	Defective power supply cables (cables broken or short-circuits)	Check potentiometer, cables, connectors; replace if necessary		

E 01 Set-up and modification

1 Special notes on safety

A DANGER

Inadvertently starting the engine, the traction drive, the conveyor, the auger, the screed or the lifting units can be dangerous. Unless specified otherwise, work may only be performed when the engine is not running!

- To protect the paver against inadvertent starting:
- Set the drive lever to the center position and set the preselector to zero; if applicable, pull out the ignition key and the battery main switch.
- Secure lifted machine parts (e.g. screed or hopper) against lowering by means of mechanical supports.
- Replace parts or have them replaced as required.

When connecting or disconnecting hydraulic hoses and when working on the hydraulic system, hot hydraulic fluid can escape at a high pressure.

Switch the engine off and de-pressurize the hydraulic system! Protect your eyes!

- Mount all protective and safety devices before re-commissioning the paver.
- The walking platform must always reach over the entire width of the screed. The hinged walkway (optional for all variable screeds) may only be swung up under the following circumstances:
- When paving next to a wall or a similar obstacle.
- During transportation on a low-bed trailer.

2 Auger

2.1 Height adjustment

Depending on the mix of materials, when working with layer thicknesses of up to 10 in. (25.4 cm), the height of the distribution auger (1) – measured from its bottom edge – should be around 5 cm (2 inches) above the material layer thickness (depending on its mix of materials).

Example: Layer height 3 in. (7.6 cm) Adjustment: 5 in. (12.7 cm) from the ground

An incorrect height adjustment can result in the following problems:



- Auger too high:

Too much material in front of the screed; material overflow. When operating with larger widths, segregation and traction problems may occur.

- Auger too low:

Not enough material that can be pre-compacted by the auger. Irregularities resulting from this cannot be completely compensated for by the screed (wavy surface). In addition, an increased wear on the auger segments occurs.

2.2 Auger crossbeam - hydraulic height adjustment

- Measure the set height of the auger crossbeam (left and right).

NOTE:

Equally press both switches/buttons (47)/(48) so that the auger beam stays level.

- Check whether the height on the left and on the right are identical.



E_1.0_01_US.fm. 2-10

2.3 Auger extension

Depending on the type of screed, the most diversified working widths can be reached.

NOTICE

Auger and screed extension must match. See the operating instructions for the appropriate screed, chapter "Set-up and modification", especially:

- Screed extension chart,
- Auger extension chart.

To attain the desired working width, the respective screed extensions, side plates, augers, tunnel plates or cut-off shoes must be mounted.

For widths of more than 11.5 ft. (3.5 m.), the auger should be fitted with extension parts on both sides to improve material distribution and to reduce the wear.

A DANGER

The diesel engine must be switched off whenever work is performed on the auger as there is a danger of being pulled into rotating parts. This could cause severe injury or death!

2.4 Mounting extension parts

- Loosen the clamping screws (6) on the support tube. Then turn in the center expanding screw (5) to expand the clamping joint.

- Pull the telescopic tube out of the support tube (7).
- Mount the required extension parts.

NOTE:

Observe the guide groove of the spline! Make sure that the shaft end is clean!

 Install auger so pick end of auger is "IN TIME" with the discharge of the main auger. This is called "IN TIME" or "NORMAL" set up and is used to prevent segregation (or separation) of material. The auger pickup can be mounted 180 degrees away from the discharge. This called "OUT OF TIME"



and is used with large or rounded stone to prevent segregation. If already mounted and segregation occurs in the mat at extension to main connection, move the auger pickup 180 degrees from the current position.

- Slide in the telescopic tube. When doing so, make sure that the drive of the auger gear is slid all the way over the shaft end of the auger extension part and that the threads of the augers match.
- Remove the expansion screw (5). Then tighten the clamping screws (6). Finally tighten the expansion screw by hand.

▲ CAUTION

Before the clamping screws (6) can be tightened again, the expansion screw (5) must be sufficiently turned back!

Otherwise, the telescopic tube cannot be safely clamped and the splined shaft ends break.

A DANGER

When clamped insufficiently, the telescopic tube can slide out of the support tube and can cause severe injury or death as well as damage to the machine!

2.5 Mounting support tube extensions

If the working width exceeds 23 ft. (7.01 m.), an auger crossbeam extension must be mounted.

The support tube extension of the auger crossbeam consists of two halves (8) and is attached to the existing support tube by using a total of 5 screws. After the two halves have been screwed to the support tube, they also must be linked to each other by means of screwed connections.

Clamping of the telescopic tube occurs by tightening the screwed connections (9) linking the support tube extension.



If the working width exceeds 14 ft. (6.26 m.) the hydraulic hoses (10) for the auger motors must be replaced with longer ones.

These long hoses are included in the scope of delivery for this working width.

A DANGER

When connecting or disconnecting hydraulic hoses, hydraulic fluid can spray out at a high pressure and can cut or enter the skin.

Switch the paver off and de-pressurize the hydraulic circuit! Protect your eyes!

When installing the hoses, make sure that the area around the connections is clean. Any contaminants that enter the hydraulic system can cause damage to the hydraulic system.

2.6 Installing tunnel plates

To ensure an optimum material flow – especially in the case of large paving widths – so-called tunnel plates (11) must be installed.

They are located directly in front of the auger distributor and – in conjunction with the auger – are an ideal system for conveying the material.

When operating with widths of more than 14.4 ft (4.4 m), two or more combined tunnel plates (13) must be used.

In this case, additional stabilizing supports (12) must be attached to the telescopic tube.

The tunnel plates must be directly screwed to the receptacles provided for this purpose (14); they are located on the auger frame sides and can be adjusted in height.

Refer to the auger extension chart to determine which parts of the conveyor system are required for the desired paving width.





2.7 Installing additional braces

When operating with width of more than 25 ft. (7.62 m.) the augers must be provided with an additional support.

To do so, attach two braces on both the left-hand and the right-hand side, between the tunnel plate support and the bracket provided on the paver.

The braces are included in the scope of delivery for this working width.

3 Screed

The operating instructions for the screed explains what is required for mounting, setting up and extending the screed.

4 Electrical connections

Ensure the following connections have been made once the screed has been mounted and set up:

4.1 Remotes from screed to paver

The screed plugs into the back of the paver socket (15). The paver and the screed communicate through this connection.



4.2 Right hand conveyor sensor control

The Conveyor Sensor plugs into the remote control unit on the right hand side at socket (16a). The remote then sends the signal from the sensor to the paver thru the cable shown.

4.3 Right hand auger sensor control

The Auger Sensor plugs into the remote control unit on the right hand side at socket (17a). The remote then sends the signal from the sensor to the paver thru the cable shown.



4.4 Left hand conveyor sensor control

The Conveyor Sensor plugs into the remote control unit on the left hand side at socket (16a). The remote then sends the signal from the sensor to the paver through the cable shown.



4.5 Left hand auger sensor control

The Auger Sensor plugs into the remote control unit on the left hand side at socket (17a). The remote then sends the signal from the sensor to the paver through the cable shown.

A	uger	ext.	part	s pe	r sid	e		
	Auge	er	Gu pla	ide ate	su			
1	2	3	1	2	ensio	ed	ء	
11.4 in. (290 mm)	17.0 in. (434 mm)	34.1 in. (866 mm)	11.75 in. (298 mm)	19.75 in. (502 mm)	Support for tunnel ext	Hyd. hose - as requir	Auger extension vridt (per side)	Basic Width: 10 ft. (3.05 m)
1			1			3	11.4 in. (289.6 mm)	Guide plate
	1			1		3	17.0 in. (431.8 mm)	<u>↑</u> ↑ ↑ ↑ ↑ ↑ ↑ 12.8 ft. (3.9 m)
2			1	1		3	22.8 in. (579.1 mm)	13.8 ft. (4.2m)
1	1		1	1		3	28.4 in. (721.4 mm)	14.7 ft. (4.5m)
		1		2	1	3	34.1 in. (866.1 mm)	Support for guide plate
1		1	1	2	1	3	45.5 in. (1155.7 mm)	17.6 ft. (5.4m)

F 1.0 Maintenance

1 Notes regarding safety

A WARNING

Maintenance work: Maintenance work may only be carried out when the engine is not running.

Secure the paver and the attachments against inadvertent starting before beginning any maintenance work:

- Set the drive lever to the center position and the speed preselector to zero.
- Remove the ignition key and the battery main switch.

A WARNING

Lifting and jacking up: Secure lifted machine parts (i.e. screed or hopper) against lowering by means of mechanical supports.

▲ CAUTION

Spare parts: Use only approved parts and install them according to the specifications! If in doubt, contact the manufacturer!

▲ CAUTION

Re-commissioning: Mount all protective devices before re-commissioning the paver.

A WARNING

Cleaning: Cleaning must not be carried out while the engine is running.

Do not use any flammable substances (such as gasoline or diesel fuel).

Avoid directly cleaning electrical parts and insulation material with a steam jet; cover them up beforehand.

A WARNING

Working in closed environments: Always run the engine in a well ventilated area.

NOTICE

In addition to these Maintenance Instructions, the Maintenance Instructions of the engine manufacturer must always be observed. All other maintenance work and intervals noted in these instructions are also binding.

F 2.0 Maintenance overview



		Μ	aint fo	tena ollov	anco wing	e re g se	qui ervio	red ce h	afte Ioui	er th 's	ie
Assembly	Chapter	10	50	100	250	500	1000 / annually	2000 / every 2 years	5000	20000	If necessary
			1	1	1	1	-	-	1		
Conveyor	F3.0										
Auger	F4.0										
Engine	F5.0										
Hydraulics	F6.0										
Track	F7.0										
Electronics	F8.0										
Lubrication points	F9.0										
Checking/decommis- sioning	F10.0										

Maintenance required	
I	

F 3.0 Maintenance - Conveyor





Interval					rva	I				
No.	10	50	100	250	500	1000 / year	2000 / 2 years	as required	Points of maintenance	Remark
									- Checking the tension of the conveyor chain	
									 Adjusting the tension of the conveyor chain 	
1									- Conveyor chain - Check chain	
									- Conveyor chain - Replace chain	
									- Clean Conveyor chain supports	
2									 Conveyor tensioning sprocket - Lubricate grease zert 	
3									- Conveyor bearing - Lubricate grease zert	
4									 Conveyor drive bearings - Lubricate grease zert 	
F									 Conveyor drive / drive chains Check chain tension 	
Э									- Conveyor drive / drive chains Set chain tension	
									 Conveyor drive - planetary gear oil level check 	
6									- Conveyor drive - planetary gear fill with oil	
			▼						 Conveyor drive - planetary gear Oil change (▼ indicates initial break-in period) 	
-									- Check conveyor chain guards, conveyor plates	
/									- Replace conveyor chain guards, conveyor plates	
Mai	nten	ance	e							1
Mai	nten	ance	e du	ring	brea	ak-in	per	iod	▼	

F_3.0_01_US.fm 2-8

Chain tension of the conveyor (1)

Checking the track tension:

For daily inspection look straight through under the bumper. The chain must not hang below the bottom edge of the bumper.

Should readjustment be necessary, measure the slack unloaded from the bottom edge of the floor plate to the bottom edge of the chain (see the figure). Also conveyor chain supports should be inspected daily and can be seen by looking straight through under the bumper. Clean the support every 1000 hours of operation and before adjusting the tension.

▲ CAUTION

The chains should not be too tight or too slack. If the chain is too tight, material between the chain and the sprocket wheel can lead to stoppage or breakage.

If the chain is too slack, it may get stuck in the protruding objects and be damaged.

11 in. 11 in.

NOTICE

With the paver resting on a level surface the sag of both portions should be a minimum of 11 inches!

Checking the chain tension:

Chain tension can be adjusted with 4 tension-screws (A) The tension-screws are located at the front of the cross-beam.

- Loosen the bolts (B) and remove the locking clamp (C).
- Set the necessary chain tension by turning the tension-screws (A).
- Remount the locking clamp (C) with the bolt (B).







NOTICE

When the conveyor chains (A) have stretched so far that they can no longer be adjusted, they must be replaced.

A WARNING

Chain links must not be removed to shorten the chain! Shortening the chains would lead to the destruction of the drive sprockets! Adjust the tensioning instead!



If components have to be replaced as a result of wear, the following components should always be replaced in sets:

- Conveyor chain
- Conveyor chain guards
- Conveyor plates
- Conveyor chain tensioning sprockets
- Conveyor gear drive sprockets

NOTICE

Contact your Dynapac customer service representative for support during maintenance, repair and the replacement of worn parts! The tensioning sprocket bearings for the conveyors are lubricated at the grease zerts (A) located behind the crossbeam.



The center bearings are lubricated at the outer lubricating grease zerts.

Pump 5 strokes of grease with a grease gun.!



Conveyor bearing (3)

The conveyor bearings are lubricated with grease zerts (B) located behind the crossbeam, r.h. side.

Pump 5 strokes of grease with a grease gun.!

Conveyor drive bearing (4)

The conveyor drive bearings are lubricated with grease zerts (C) located behind the crossbeam, r.h. and l.h. side.

Pump 5 strokes of grease with a grease gun.





Conveyor drive - (5) drive chains

Checking for chain **tension**:

- In normal conditions, the chain has to have approximately .4 to .6 inch (10 - 15 mm) of play.

To set the chain **tension**:

- Loosen the locking bolts (A) and the lock-nut (B).
- Set the necessary chain tension with the tension-screw (C).
- Tighten the locking bolts (A) and locknut (B) again.





Conveyor drive - (6) planetary drive (left/right)

- To **check the oil level**, unscrew the inspection plug (A).

NOTE:

For proper oil level, the oil must be at the lower edge of the inspection port or a little oil flows from the hole.

To **add** oil:

- Check oil at oil level site glass (A).
- Fill with oil of the correct specification through port (B) until the oil level reaches the middle of the oil level site glass (A). Use only recommended oil.

Oil change:

NOTE:

Change the oil when the engine is at operating temperature.

- Remove the the filling plug (B) and the drain plug (C).
- Drain the oil.
- Return plug (C).
- Fill oil through the filling port until the oil level reaches the middle of the oil level site glass (A).
- Replace the plug at the filling port (B).





Make sure that no pollution or foreign matter gets into the drive.

Conveyor chain guards / conveyor plates (7)

NOTE:



When the lower edges of the conveyor chain guards (A) are worn or reveal holes, they must be replaced.

The conveyor chain is not protected when the conveyor chain guards are worn!

- Remove conveyor chain guard bolts.
- Remove the conveyor chain guards from the material tunnel.
- Install new conveyor chain guards with new bolts.

NOTE:

The conveyor plates (B) must be replaced when the wear limit of .2 inch (5 mm) in the rear area beneath the chain has been reached.



If components have to be replaced as a result of wear, the following components should always be replaced in sets:

- Conveyor chain
- Conveyor chain guards
- Conveyor plates
- Conveyor chain tensioning sprockets
- Conveyor gear drive sprockets

NOTICE

Contact your Dynapac customer service representative for support during maintenance, repair and the replacement of worn parts!

F 4.0 Maintenance - Auger



	Interval									
No.	10	50	100	250	500	1000 / year	2000 / 2 years	as required	Points of maintenance	Remark
1									- Auger - outer bearing Lubrication	
2									- Auger central bearing Lubrication	
3		▼							 Auger drive neck bearing Lubrication 	
		▼							 Auger bevel gear oil level check 	
4									- Auger bevel gear topping up the oil	
									- Auger bevel gear oil change	
5									 Auger wear plates (auger seg- ments)- Check wear 	
5									 Auger wear plates (auger seg- ments)- Replace auger blade 	

Maintenance	
Maintenance during run-in period	▼

Auger - outer bearing (1)

The grease zerts (A) are located on each side on the top of outer bearing. These zerts must be lubricated each time work is finished.



NOTICE

The outer bearings of the auger must be lubricated when hot, so that the eventual bitumen residue is expelled.

Pump 5 strokes of grease with a grease gun!



Auger middle bearing (2)

The central bearing (A) is lubricated on the LH-side of the auger. To do so, slide the bevel gear out.



NOTICE

The central bearing must be lubricated when hot, so that the eventual bitumen residue is expelled.

Pump 5 strokes of grease with a grease gun!



Auger - drive gear neck bearing (3)

Remove the hexagonal plug (A) in the neck of the drive. Replace the plug under it with an extended grease zert 10x1. Use a grease gun to pump about 10 strokes of grease.

Next, unscrew the grease zert and screw back in both plugs. The neck of the drive is sealed downwards and is lubricated with grease only.




Auger bevel gear (on the RH and LH sides) (4)

- To **check the oil level** unscrew the inspection / filling plug (A).

NOTE:

The oil level is full when the oil is at the lower edge of the inspection port or a little oil flows from the hole.

To **add** oil:

- Remove the inspection / filling plug (A).
- Add the proper oil through port (A) until the oil level reaches the lower edge of the inspection hole (A). Use only approved oil.
- Replace the inspection / filling plug (A).

To **change** the oil:

NOTE:

Change the oil when the engine is at operating temperature.

- Remove the inspection / filling plug (A) and the drain plug (B).
- Drain the oil.
- Return the oil drain plug (B) and tighten.
- Fill oil, using an approved fluid, through the filling port (A) until the oil level reaches the lower edge of the inspection hole (A).
- Replace the inspection / filling plug (A).



Keep the work area clean. Clean any spills!





NOTICE

If the surface of the auger blade (A) becomes sharp-edged, the diameter of the auger is reduced and the blades (B) have to be replaced.



- Remove the bolts (C), washers (D), nuts (E) and auger blade (B).

Sharp-edged parts can cause personal injury!

Auger blades must be installed with out any play and the contact surfaces must be dirt-free!

- Install the new auger blade (B); replace the bolts (C), washers (D) and nuts (E) if necessary.

F 5.0 Maintenance - Engine





In addition to these Maintenance Instructions, the Maintenance Instructions of the engine manufacturer must always also be observed. All other maintenance work and intervals noted in these instructions are also binding.

1.1 Maintenance intervals

	Interval									
No.	10	50	100	250	500	1000 / year	2000 / 2 years	as required	Points of maintenance	Remark
									- Fuel tank Check the filling level	
1									- Fuel tank Refill with fuel	
									- Fuel tank Clean the tank	
									- Engine oil system Check oil level	
2									- Engine oil system Fill with oil	
2									- Engine lube-oil system Change the oil	
									- Engine lube-oil system Oil filter change	
									 Engine fuel system Fuel filter (drain the water separator) 	
3									- Engine fuel system Replace the fuel pre-filter	
									- Engine fuel system Replace the fuel filter	
									- Engine fuel system Bleeding the fuel system	

Maintenance	
Maintenance during run-in period	▼

	Interval									
No.	10	50	100	250	500	1000 / year	2000 / 2 years	as required	Points of maintenance	Remark
									- Engine air filter Check the air filter	
4									 Engine air filter Empty the dust collecting bin 	
									 Engine air filter Clean / Replace the filter car- tridge 	
									 Engine cooling system Inspection the radiator fins 	
									- Engine cooling system Clean the radiator fins	
									 Engine cooling system Check the level of the coolant. 	
5									 Engine cooling system Fill with coolant 	
									 Engine cooling system Changing the coolant 	
									 Engine cooling system Check coolant level (additive concentration) 	
									 Engine drive belt Checking of drive belt 	
6									 Engine drive belt Tightening the drive belt 	
									- Engine drive belt Replace drive belt	

Maintenance	
Maintenance during run-in period	▼

Engine fuel tank (1)

NOTE:

There is one fuel tank on each side of the machine!

- Check the **fuel level** on the operating panel (check display).



NOTICE

Fill the fuel tank before each work shift to prevent the fuel system of running dry. If the tank is ran dry, the system will have to be bled causing work delay.

To add fuel:

- Unscrew cap (A) (under the tank covers, r.h. and l.h. paver side).
- Fill with fuel through the filler neck until the tank is full.
- Replace the cap (A).
- Repeat the process for the other tank.

Cleaning the fuel tanks:

- Unscrew the plug (B) at the bottom of the tank and drain about 1 qt. (1 L) of fuel into an environmentally safe collection pan.
- After draining, add a new seal ring to the plug and screw the plug back in place.

Repeat the process for the second fuel tank.



F_5.0_01_US.fm 4-14

Engine lube-oil system (2)

Check oil level

Check that the oil level is between the maximum and minimum lines on the dipstick (A).

NOTE:

Check the oil level with the paver parked on a flat surface!



A WARNING

Some state and federal agencies in the United States of America have determined that used engine oil can be carcinogenic and can cause reproductive toxicity. Avoid inhaling vapors, ingestion and common prolonged contact with used engine oil. Do not allow used oil to drain into the ground. Always used proper proceedures to dispose of the oil.

A WARNING

To avoid personal injury, avoid direct contact of hot oil with your skin.

If there is too much oil in the engine, the gaskets and seals may become damaged, while too little oil can lead to the oil overheating and damage to the engine.

To **add** oil:

- Remove the cap (B).
- Add oil until the correct level is achieved.
- Return and tighten the cap (B).
- Check the oil level once again using the dipstick.



Oil change:

Do not drain the oil when the engine is cold. As the oil cools, suspended waste particals settle on the bottom of the oil pan. The waste particles are not removed with the draining cold oil. Drain the crankcase with the engine stopped. Draining the crankcase with the oil warm will allow the waste particles that are suspended in the oil to be drained properly.

Avoid contact with hot oil or components. Do not allow used oil to drain into the ground.

There is a drain hose stored behind the left hand side flap.

- Place the end of the hose into a pan to catch the oil.
- Remove the oil drain port plug (C) and let the oil drain.
- Return the plug.
- Remove the oil cap (B) and add only approved oil until the oil level reaches the full mark on the dipstick (A).

Changing the oil filter:

When changing the oil, mount the new filter after the used oil has been drained.

- Remove the filter (D) and clean where the new filter will go.
- Apply a thin coat of oil to the seal of the new filter and fill the filter with oil, then mount the filter and tighten by hand.



▲ CAUTION

Fill the oil filter(s) with clean lubricating oil before installation onto the engine. Lack of engine lubrication while the filter(s) are pumped full of oil is harmful to the engine.

Engine fuel system (3)

The fuel filter system consists of two filters:

- Pre-filter (A) with water separator (located in the engine compartment).
- Main filters (B)

Pre-filter - drain the water

Empty the condensation prior to every engine start or when the engine electronics indicate a fault.

- Drain the water at the drain valve (C), collect it, then close the drain valve again.



A WARNING

Fuel leaked or spilled onto hot surfaces or electrical components can cause a fire. To help prevent possible injury, turn the start switch off when chaning fuel filter or water separtor elements. Clean up any spilled fuel immediately.

Α

Change the pre-filter:

- Drain the separated water at the tap (C), collect it, then close the tap again.
- Remove the water detection indicator connection (D).
- Loosen the filter cartridge (E) using an oil filter wrench or oil filter strap and remove it.
- Clean the sealing surface where the new filter will mount.
- Apply a thin coat of oil to the gasket of the collection sump, mount it under the filter cartridge and tighten by hand.
- Apply a thin coat of oil to the gasket of the filter cartridges, mount them under the holder and tighten by hand.
- Replace the water detector indicator connection (D).
- Unscrew hand wheel of the pump (F). Pump the hand wheel until the filter has filled with fuel.

The system is filled with fuel when resistance at the hand wheel is noticeable during pumping!

- Screw in pump's hand wheel (F).

Main filter replacement:

- Loosen the filter (A) and clean the surface where the new filter will mount.
- Apply a thin coat of oil to the gasket of the new filter.
- Tighten the filter by hand.

NOTE:

After mounting the filter, check it for proper tightness.





Do not fill the fuel filters with fuel before installing them. Then fuel would not be filtered and could be contaminated. Comtaminated fuel will cause accelerated wear to the fuel system parts.

Engine air cleaner (4)

The function of the engine air cleaner is to filter the air taken into the engine through the engine's air intake. The engine air cleaner is the dry type with two element elements: а primary that is cleanable and replacable, and a safety replaced element that should only be and not cleaned. The assembly also include a dust vacuator valve and an air cleaner indicator.



Emptying the dust vacuator valve

- Discharge the dust by pressing together the upper part of the valve (B).

NOTICE

Clean the vacuator valve periodically.

Cleaning / replacing the air filter cartridge

NOTE:

Air intake filter pollution depends on the dust content in the air and the mesh size of the filter selected.

The maintenance of the filter becomes necessary if:

- The visual restriction indicator (C) is red when the engine is stopped. This indicates that a restriction has occured. This usually means the filters are dirty. A RED indicator requires opening th eair cleaner and cleaning or replacing the elements.
- When the engine electronic unit indicates service required.



NOTICE

Never leave the air cleaner open longer than necessary!

To remove the filter cartridges:

- Open the air filter lid.
- Remove the filter cartridge (D) and the safety cartridge (E)

NOTE:

Clean the filter cartridge (D) and replace at least once per year.

- Blow out with dry pressure air (max. 30 psi / 2.07 bar) from inside blowing out. In case of an urgency, tap the cartridge to remove dust.
- Check the filter's paper of the filter cartridge (by exposing to light) and inspect the seals. Replace them as required.

NOTICE

Replace the safety cartridge (E) after 3 filter maintenance intervals, but no longer than once per year (never clean it!).

After completing the maintenance:

- Press the reset button (F) for the maintenance indicator (if equipped). The maintenance indicator is ready for operation.

Engine Coolant system (5)

Fully formulated antifreeze must be mixed with quality water at a 50/50 ratio. A 50/50 mixture of water and ethylene glycol or propylene glycol antifreeze to fill the cooling system. The 50/50 mix gives protection to the cooling system at a range of --34_F(--36_C) freezing point 228_F (110_C) boiling and а point, which is adequate for locations in North America. The actual lowest freezing point of ethylene glycol antifreeze is 68 Using higher concentrations percent. of



antifreeze will raise the freezing point of the solution and increase the possibility of a silica gel problem.

A WARNING

Do not remove the radiator cap from a hot engine. Wait until the temperature is below 120° F (50° C) before removing the pressure cap. Failure to do so can result in personal injury from heated coolant spray or steam. Remove the filler cap slowly to relieve coolant system pressure.

Checking / filling coolant level

The coolant level is checked when the engine is cold. Check the coolant level daily (10 hours or as needed). Use a Refractometer to ensure the antifreeze and anti-corrosive liquid is sufficient (-25° F / -31.6° C).

 Add sufficient amount of coolant through the fill cap (A) on the coolant tank. Check the coolant level at the site-glass (B) inside the fuel fill door. Do not mix coolants. Only use Dynapac approved coolants.



Do not add cold coolant to a hot engine. Engine castings can be damaged. Allow the engine to cool to 120° F (50° C) before adding coolant.

Changing the coolant

To change the coolant:

- Remove the radiator cap.

- Open the drain valve at the bottom of the radiator and drain the cooler into an environmentally approved drain pan with a capacity of about 5 gallons (19 liters).
- Inspect the hoses to and from the radiator and replace them if they look worn or cracked.
- Once drained, dispose of the coolant fluid in an appropriate manner.

A DANGER

Coolant is toxic. Keep away from children and pets. Dispose of in accordance with federal, state and local environmental regulations

- Close the drain valve.
- Fill the radiator with a 50/50 mix of water and ethylene glycol or propylene glycol antifreeze.
- Install the radiator cap.
- Start the engine and allow it to run a few minutes.
- While the engine is running, check the radiator and hoses for leaks.
- When the engine coolant temperature reaches about 180°F (80°C), turn the engine off and check the coolant level again.

Checking and cleaning of the radiator fins

- If necessary, remove leaves, asphaltic oils and residue, dust or sand from the radiator.

Check drive belt/replacement

Under normal operating conditions, the engine drive belt(s) should be inspected daily. Belt damage can be caused by incorrect size or length, pulley misalignment, incorrect installation, severe operating environment and oil or grease on the belt(s).

Adjust the belt tension in order to minimize belt slippage. Belt slippage will decrease the life of a belt. If the belt is too loose, the belt will vibrate. This vibration is enough to cause unnecessary wear on the belt(s) and on the pulleys. If the belt(s) are too tight, unnecessary stress-



es are placed upon the pulley bearings and upon the belts. These stresses will shorten the life of the belt(s) and the pulley bearings.

To maximize the engine performance, visually inspect the belts for tension, wear, breaks, cracks or other damage. Replace the belts that are cracked or frayed. Adjust belts that have a glazed or shiny surface which indicates belt slippage. Correctly installed and tensioned belst will show even pulley and belt wear.

Refer to the Engine Manual for proper proceedure for removing and installing the belts.

F 6.0 Maintenance - Hydraulic System



	Interval									
No.	10	50	100	250	500	1000	2000 / 1 years	as required	Points of maintenance	Remark
									 Hydraulic oil tank Check the oil level 	
1									 Hydraulic oil tank Fill with oil 	
									 Hydraulic oil tank Oil change and cleaning 	
									 Hydraulic oil tank Check the maintenance indicator 	
2									 Hydraulic oil tank Intake / return 	
			▼						- Change the hydraulic filter	
0									- High pressure filter Check the maintenance indicator	
3			▼						- High pressure filter Replace the filter cartridge	
									 Pump distribution gear Check the oil level 	
4									 Pump distribution gear Fill with oil 	
									 Pump distribution gear Oil change 	
_									- Hydraulic hoses Inspect hoses	
5									- Hydraulic hoses Replace the hoses	

Maintenance	
Maintenance during break-in period	▼

1.2 Hydraulic System

A paving machine has many components and implements that are controlled by a hydraulic system, either directly or indirectly. Before working on or inspecting any part of a paving machine, it is important that the individual knows how the components move and are controlled by the hydraulic system components including the respective control circuits.

Before working on or inspecting any component, it must be physically constrained from any movement that could cause injury to the worker. The worker must be alert to not placing any part of his/her body where movement of a component could cause injury, unless that component is physically contrained from movement, if the hydraulic system fails, is disconnected, or is asignaled to cause movement.

It must also be recognized that there are occasions where component and or vehicle movement may react to the release of potential energy. Where applicable it must be confirmed that all measures are employed to ensure that any and all sources of potential energy are released and/ or physically restrained.

All tramming, hopper and conveyor functions and augers are hydraulically powered. The hydraulic system consists of a 50 gallon (189.21 liter) hydraulic reservoir with a 10 micron filtration system. The propel pumps, conveyor and auger pump, generator pump and screed functions are driven by the pump drive gear box which is mounted directly to the engine. The hydraulic system includes various motors, cylinders, valves, filters and hose piping. A hydraulic oil cooler assures optimum oil temperatures to maximize system efficiency and component life.

Hydraulic oil tank (1)

- **Oil level** check at sight level gauge (A) on the side of the tank.

NOTE:

View the sight level gauge by the opening fuel tank flap on the L.H. side of the machine.



NOTICE

With the cylinders fully retracted, the oil level should be at the upper mark.



To **add** oil:

- Remove cap (B).
- Add oil through the fill port until the level shows full at the sight level gauge (A).
- Return cap (B).

NOTE:

Regularly clean dust and contaminants from the vent port on the oil tank. Clean the surfaces of the oil cooler.



Use only the recommended hydraulic oils - see section "Recommended hydraulic oils".

To **change** the oil:

- To drain the hydraulic oil unscrew the drain plug (C) at the bottom of the tank.
- Collect the oil in an appropriate container using a funnel.
- After draining, add a new seal ring and then screw the plug back into place.



A WARNING

Hot oil or components can burn. Oil must be at normal operation temperature when draining. Avoid contact with hot oil or components.

A WARNING

Gearbox must be filled with fresh, clean oil.

A WARNING

Always change the hydraulic oil filter(s) when changing the hydraulic oil.

Suction/return flow hydraulic filter (2)

Change the **filter** at the intervals specified or when the **maintenance indicator** (A) is at the red mark or when changing hydraulic oil. The hydraulic oil must be at least 175° F (80° C).



A WARNING

When changing the hydraulic oil also change the filter.

- Remove the lid fastening screws (B) and remove the lid.
- Disassemble the withdrawn unit into the following parts:
 - lid (C)
 - separating plate (D)
 - filter (E)
 - dirt collection cage (F)
- Clean the filter case, the lid, the separating plate and the dirt collection cage.
- Check and replace the O-rings (G) when required.
- Wet the seal surfaces and the O-ring with clean fuel.



Venting the filter:

- Fill the open filter case with hydraulic oil to just below the upper rim.
- Should the oil level drop, fill with oil.

NOTICE

The oil level slowly lowering by about 1/4 in./min. (1 cm/min) is normal!

- When the oil level remains steady, mount the assembled unit with the new filter cartridge, carefully into the housing and tighten the locking screws of the lid (B).
- Open the vent screw (H).
- Mount a transparent hose (I) on the vent screw and lead it into an appropriate container.
- Start the engine and run it at idle speed.
- Shut-off the bleeding screw (H) as soon as the oil discharged through the hose is clean and free of air bubbles.

A WARNING

The process from mounting the filter lid until starting the engine should take place within 3 minutes or the oil level will drop too much in the filter case.

Check the seal after changing the filter.

High pressure filter (3)

Replace the filter cartridge when the maintenance indicator on top of the filter cartridge head turns "red".

- Unscrew filter housing (B).
- Remove the filter cartridge
- Clean the filter housing.
- Insert the new filter cartidge.
- Replace the seal (o'ring) on the filter housing.
- Screw the filter housing on by hand, then tighten it using the appropriate tool.
- Test the filter for tightness and leaks.



Always replace the seal (o'ring) whenever the filter cartridge is replaced.

NOTICE

After the filter cartridge has been replaced, the indicator on top of the filter cartridge head will return to "green".

Pump distribution gear (4)

- **Check the Oil level** at the sight glass (A) (at the side of the distribution box).

NOTE:

The oil level must be up to the center of the sight glass.

To **add** oil:

- Unscrew the plug (B).
- Add oil until the sight glass (A) shows the correct fluid level.
- Return and tighten the plug (B).





Keep the work area clean!

Hot oil or components can burn. Oil must be at normal operation temperature when draining. Avoid contact with hot oil or components.



Gearbox must be filled with fresh, clean oil.

Oil change:

Change the oil when the engine is at operating temperature.

- Remove the cap for the oil drain port (C) and screw on the hose provided as an accessory.
- Place the end of the hose in an appropriate container and catch the oil.
- Open the shut-off valve and let the oil drain completely.
- Shut off the valve, remove the hose and return the cover cap.
- Add only approved oil to the distribution box (B) until the oil level is at the center of the sight glass (A).





Hot oil or components can burn. Oil must be at normal operation temperature when draining. Avoid contact with hot oil or components.

Hydraulic hoses (5)

Frayed or damaged hoses can break instantly causing hot hydraulic fluid to spray causing severe burns. Always replace worn or damage hoses immediately.



A WARNING

Hot oil or components can burn. Oil must be at normal operation temperature when draining. Avoid contact with hot oil or components.

- Check the condition of the hydraulic hoses carefully.
- Immediately replace any damaged hoses.



A DANGER

Old hoses may become porous and burst! Hot oil spraying from a burst hose can cause severe burns!

NOTICE

Each hose has the maximum pressure allowed for that hose printed on it.

Do not use hoses that have been in storage for a long time. Check for the proper pressure rating printed on the hose.

F 7.0 Maintenance - Track





		Interval								
No.	10	50	100	250	500	1000	2000 / 1 years	as required	Points of maintenance	Remark
4									 Idlers, guide rollers, drive wheels Check the torque at the bolts 	
									 Idlers, guide rollers, drive wheels Ensure proper torque for bolts 	
									 Guide rollers - check straight run- ning 	
0									- Guide rollers - straight running, setting	
2	▼								 Guide rollers - ensure the adjust- ing bolts are tight 	
									 Guide rollers - tighten the adjust- ing bolts 	
									 Planetary gear Check the oil level 	
3									- Planetary gear - fill with oil	
									- Planetary gear oil change	
4									- Gear- guide rollers front - Grease them	

Maintenance	
Maintenance during run-in period	▼

NOTICE

In order to avoid a disclaimer of responsibility by the manufacturer or dealer and to extend the life of the rubber parts, the directives below should be strictly adhered to.

Check and maintain the track and undercarriage as specified. Although the rubber itself needs little daily maintenance, the metal parts of the undercarriage are very sophisticated, therefore they require frequent checking. Ensure that they have no visible damage and that the drive wheels, idlers and guide rollers are properly secured to the vehicle. The drive wheels, idlers and rollers should not show evidence of unusual wear and tear (on the tread, on the driven surface and at the driving gears).

▲ CAUTION

New drive wheels, idlers and guide rollers tend to become sticky. This is a normal consequence of the vulcanizing procedure. Generally, these parts work better if the sticky layer is removed. Therefore, we recommend coating each new drive wheel, idler and roller with chalk or similar non-corrosive material in order to make them work more smoothly. To do this, simply put a thin layer of this material on the driven surface of the drive wheel, idler or roller and turn on the drive for a very short period. This serves to remove the sticky layer and provides optimal "biting" for the gear and the drive wheel, idler and rollers. Pre-treatment of these parts is necessary only when they are new.

A WARNING

The wheels, idlers or guide rollers should not come into contact with grease, oil, benzene, gasoline or other corrosive chemicals. These attack the rubber and in case of contact they should be immediately removed. When greasing the machine and/or the gear, strictly avoid grease or oil on the drive wheels, idlers and guide rollers. Frequently check for hydraulic oil leaks. Hydraulic oil making contact with the rubber should be avoided. Do not wash or treat the machine with gasoline or other fuels; use only appropriate cleaning materials instead (i.e. soft soap and water). Discuss use of other separating agents with your machine dealer.

NOTICE

If necessary, exchange the left and right side drive wheels with each other. In certain applications, wheel abrasion may differ. By exchanging the right and left wheels with each other, their lifetime can be prolonged.

In this chapter you shall find all information regarding lubrication materials required for maintenance of the undercarriage.

2.1 Long-term effect of parked machines

If the machine is not used for a long period, observe the following directives.

A WARNING

Avoid exposing the machine to direct sunlight.

Over a period of time, the direct UV radiation may cause the drive wheels, idlers or guide rollers to become porous. They become rigid and tiny ruptures may appear. For these reasons, the machine should be stored under a roof or in a protected area when it is possible. If the machine must be stored outdoors, please cover the tracks, drive wheels, idlers and guide rollers with non-transparent canvas.

A WARNING

Avoid excessive humidity. Longer contact with water may attack the drive wheels, idlers or guide rollers. Do not store the machine in standing water. The machine must be stored under a roof or in a protected area whenever it is possible. If the machine must be stored outdoors, please cover the tracks, drive wheels, idlers and guide rollers with watertight canvas.

NOTICE

Separate directives apply to long/term storage for the drive wheels, idlers and guide rollers! Consult with the Dynapac, USA customer center for these directives.

Idlers, guide rollers, drive (1)

Check / tighten the mounting bolts

Mounting bolts for all idlers, guide rollers and drives should be checked and tightened if necessary!





The mounting bolts should be tightened to the following torque values:

-	Guide rollers (A)	-	(12 rollers):
			105 ft. lbs / 142.4 Nm

- Idlers (B) (2 idlers): 314 ft. lbs / 425.7 Nm
- In addition to this, all mounting bolts on the drive wheel (C) should be checked and re-torqued if necessary!
- Drive Wheels (2 drive wheels):

375 ft. lbs / 508.4 Nm

Guide rollers - straight running, secure the adjustment bolts (2)

The adjustment bolts are located in the front part of the drives and at the regulator links of the guide rollers.

If the wheels and rollers run outwards or inwards or are not centered on the two guide rollers, side-ward tilt of the guide rollers should be adjusted.

Check whether the adjusting bolts and counter nuts are properly tightened and retighten them if necessary.

Guide rollers runs excessively inwards:

- Loosen the counter-nuts of both adjusting bolts (A) and (B).
- Loosen the inner adjusting bolt (A).
- Retighten the outer adjusting bolt (B).





Never turn the adjusting bolts more than a half turn!

If the guide rollers run excessively outwards, you should adjust the guide rollers in the opposite direction!

- Move the machine forward and check to see if the rollers are running straight. Repeat the adjustment if necessary.

When checking the adjustments, drive the machine until the drive wheels make two complete turns!

The adjustment is correct if the teeth of the rollers run in the middle between the idlers and the front/rear guide rollers!

- Tighten the counter-nuts on the adjusting bolts (A) and (B) on a regular basis!
- Move the machine forward and backward to check if the rollers are running straight!

The rollers running straight is very important and directly affects their life cycle!

NOTICE

Care must be taken to ensure fluids are contained during performance of inspection, maintenance, testing, adjusting and repair of the paver. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids. Dispose of fluids according to local regulations and mandates.

To check the oil level in the Planetary Gearbox:

- Position the planetary gearbox so that the oil drain (B) is vertical at its lowest point (about the 6 o'clock position). The oil filler plug (A) should then be on the Left or Right outside fo the planetary middle.
- Clean the area around the check plug (C) and fill plugs and the drain plug.
- Place an oil collection container underneath the planetary gearbox.
- Remove the oil level check plug (C). The oil level should be at the oil level check port.
- If the level is low, add oil through the fill plug (A).
- If the oil looks contaminated, drain the oil completely.
- Insert the drain plug (B) and tighten.

A WARNING

Gearbox must be filled with fresh, clean oil.

- Fill with oil until the level has reached the oil level check port (C). Insert check and fill plugs and then tighten

Hot oil or components can burn. Oil must be at normal operation temperature when draining. Avoid contact with hot oil or components.





Idler rollers, front (4)

Tracks that are not adjusted properly can cause rapid wear at the idler bearings and can put extra stress on the undercarriage while wasting horsepower and causing higher fule consumption.

Checkthedriveidlerbearing(A) for wear and ensure they are filled with grease.

To re-grease the idler bearings::

- Remove protective cap (B).
- Clean any used grease from the bearing assembly (A) and replace the old grease with the proper amount of new grease by packing the grease into the bearing.
- Return protective cap (B).





Ensure no contaminants or foreign materials enter into the bearing.
3 Gear- lubrication materials (5)

3.1 Lubricants and fuels

NOTE:

Use only the lubricants listed or the equivalent quality lubricants. Use only clean containers for adding oil or fuel.

Take into account the filling volumes (see the section "Filling volumes").

Low quality oil or lubricant causes faster wear and the failure of the machine.

A WARNING

Mixing of synthetic and natural oils is explicitly prohibited!

	BP	Esso	Total Fina (Total)	Mobil	Renault	Shell	Wisura
Grease	BP universal grease L2	ESSO Universal grease	Total Multis EP 2	Mobilux 2 Mobiplex 47	Universal grease	SHELL Alvania Grease EP (LF) 2	Retinax A
Gear oil Machine drive						SHELL Transaxle 75W-90	
Transmission oil Idlers							

3.2 Filling volumes

	Fuel	Volume
Planetary gear	Transmission oil 220	to the max. filling level
Lubrication points	Grease	

F 8.0 Maintenance - Electronic system



				Int	terv	val					
ltem	10	50	100	250	500	1000 / annually	5000	20000	If necessary	Maintenance point	Note
1										Check the charge level of the batteries, replace if necessary	
										Apply grease to battery terminals	
3										Electric fuses	

Maintenance	
Maintenance during the running-in period	▼

Batteries (1)

Maintenance of batteries

NOTE:

The batteries equipped with the paver "Maintenance Free" batteries. When are batteries can no longer hold charge, а they must be replaced.



NOTICE

The battery terminal clips must be free of corrosion (oxide) and protected with grease.



When removing the batteries, always remove the negative terminal first, ensuring that the battery terminals do not short circuit.



Always where protective glasses when working with battires.

A WARNING

Never disconnect any charging unit circuit or battery circuit cable from the battery when charging unit is operating. A spark can cause explosions.

Electric fuses / relays (3)

Main fuses (A)



Fuse No.	Description	Rating (A)
F1	Main Battery Fuse	100
F2	Alternator Fuse	100
F3	Key Switch Line Fuse	50
F4	Air Heater Fuse	125
F7	ECM Power Supply Fuse	30



Fuse No.	Description	Rating (A)
F5	Propel Controller	10
F6	Emergency stop	5
F8	ECM Key Switch Signal	5
F9	Key Switch Power	10
F10	Multi functional Display	5
F11	Horn Power Supply	3
F12	Hour Meter & Track Low pressure Alarm	10
F13	Propel Input Devices	10
F14	Console Select switch & parking brake	5
F15	Auger / Conveyor status LED's on Console	5
F16	Auger / Conveyor Controller & Sensor	15
F17	Auger & Hopper Raise/Lower	10
F18	Levelling Controls	10
F19	Screed Extend/Retract, Float / Lock	10
F20	Vibration Solenoid	3
F22	Work Lights	10
F23	Dash Board Lamp	3
F24	DC 24 V outlet front	10
F25	DC 24 V outlet front	10
F26	DC 24 V outlet rear	10
F27	DC 24 V outlet rear	10
F28	Warning / Turning Lights	10
F29	Warning / Turning Lights	10
F30	Road lights	10

Fuse No.	Description	Rating (A)
F31	Wash Down & Truck Hitch	3
F32	Screed Power Supply	15
F33	Screed Power Supply	15
F34	FWA Switch & Steering Position Sensors	3



Relay No.	Description
R1	Starter
R2	Anti Start Circuit
R3	Emergency Stop Circuit
R4	Intake Air Heater
R5	Auger / Conveyor ON / OFF
R6	Auger / Conveyor Auto / Manual
R7	Auger / Conveyor Auto Mode
R8	Left Conveyor OFF
R9	Right Conveyor OFF
R10	Starter Lock Out
R11	Screed Float / Lock
R12	Console Select Indication
R13	Left Auger OFF
R14	Right Auger OFF
R15	Key Switch Power
R16	Flasher - Warning / Turning Signal
R17	Flasher - Warning / Turning Signal

F 9.0 Maintenance - Lubricating Points





NOTE:

The information on the lubrication points for the various assemblies is assigned to the specific maintenance descriptions (I.E. grease points for the auger are in the auger section and grease points for the undercarriage are in the section on undercarriages)!

			I	nte	rva	I				
ltem	10	50	100	250	500	1000 / annually	2000 / every 2 years	If necessary	Maintenance point	Note
1									- Bearing points	

Maintenance	
Maintenance during the break-in period	▼

Bearing points (1)

One grease zert (A) is located at each hydraulic cylinder bearing point (top and bottom).



F10.0 Checks, Decommissioning





	Interval									
No.	10	50	100	250	500	1000 / year	2000 / 2 years	as required	Points of maintenance	Remark
1									- General observation	
2									- Checked by a specialist	
3									- Cleaning	
4									- Preservation for storage of paver	

Maintenance	
Maintenance during run-in period	▼

2 General observation

The daily check includes a walk around the machine while checking the following items:

- Are any of the parts or controls damaged?
- Are there leaks at the engine, the hydraulics, the gear box, etc.?
- Are all the locking points secure (conveyor, auger, screed)?

▲ CAUTION

Repair the damages and clean any spills immediately to avoid risks of accidents and environmental pollution!

3 Check performed by a specialist

The paver, the screed and the electrical equipment MUST be checked regularly by a specialist:

- as required (according to the circumstances of application and operating conditions),
- however, at lease once a year, so that the machine retains its reliable operating condition.

4 Cleaning

- Clean all parts that come into contact with the material to be laid.
 - Spray these parts with the release agent spray equipment.

▲ CAUTION

Before cleaning with high pressure jet, lubricate all the bearings with grease as specified.

- Clean the machine with water after laying mineral mixes, lean concrete etc. Remove all residue of the materials laid.

A WARNING

Do not spray water on the bearings, electric or electronic parts.



- Remove the residue of the material laid.

After cleaning with the high pressure jet, lubricate all of the bearings with grease as specified.



Slippery walkways and steps can result in severe or deadly slipping and falling! Ensure the cleanliness of the walkways and steps and that they are free of grease and oil.



5 Preservation for storage of paver

5.1 Downtime up to 6 months

- Stop the machine in a place protected from intensive sunshine, wind, moisture and frost.
- Lubricate all the lubrication points with grease as specified.
- Change the oil in the Diesel engine
- Seal the muffler of the exhaust pipe.
- Remove the batteries, charge and store them at room temperature in well ventilated premises.

NOTICE

Recharge the stored batteries every 2nd month.

- Protect all metal surfaces, (i.e. hydraulic cylinder piston rods) against corrosion using an appropriate agent.
- If the machine cannot be parked in a garage, barn or a shed, it must be covered with an appropriate canvas. In each case all the air inlets and outlets must be tightly sealed using plastic film and adhesive tape.

5.2 Downtime between 6 months and 1 year.

- Perform all operations described for "Downtime up to 6 months".
- After draining the engine oil, fill the engine with preservative oil permitted by the manufacturer of the engine. Contact the Dynapac, USA (a part of Atlas Copco) customer center for further detail.

5.3 Re-commissioning:

- Reverse the steps in the section "Downtime".

F11.0 Lubricants and Operating Substances

1 Lubricants and operating substances

Use only the lubricants listed below or their equivalents.

Only use clean containers for filling oil or fuel.

Follow to the correct filling volumes (see the section "Capacities").

Incorrect oil or lubricant levels increase the wear and cause the paver to fail.

Never mix synthetic oils with mineral oils!

	BP	Exxon	Total Fina (Total)	Mobil	Shell	Shell
Grease				XHP 462 Moly		
Engine oil				Delvac MX	Rimula 15W - 40	
Hydraulic oils				DTE 10 Excel - 46	Tellus T46	
Synthetic gearbox oil				Delvac Synthetic Gear Oil 80W - 140	Spirax 80 W - 140	
Dist. water						
Diesel fuel						
Cooling liquid	Cooli	ing liquid: 50% ethy	lene glycol or pror	bylene glycol based antifreez	e and 50% water mix (to -2	25°F)

1.1 Capacities

	Substance	Volume	
Fuel tanks	Diesel fuel	49 gal (185.43 L) each	
Hydraulic oil tank	Hydraulic oil (Multigrade Oil ISO 46-68)	50 gal (189.21 L)	
Pump distribution gear	80W-140 full synthetic oil	1.4 gal (5.3 L)	
Planetary gear - track	80W-140 full synthetic oil	0.8 gal (3.0 L) each	
Conveyor - gear box	80W-140 full synthetic oil	1.58 qt. (1.5 L) each	
Auger - center gear box	80W-140 full synthetic oil	2.64 qt. (2.5 L) each	
Auger - angle gear box	80W-140 full synthetic oil	0.63 qt. (0.6 L) each	
Diesel engine oil (with filter)	Engine oil 15W-40 (API CI-4)	18.5 qts (17.5 L)	
Diesel - cooling system	Engine coolant 50:50 Mix	6.5 gal (24.6 L)	
Batteries	Distilled water		



TRAINING/ EDUCATION

We offer our Customers various training programs on DYNAPAC equipment in our specialised training center in our factory. We hold training sessions also for special arrangements in addition to courses and programs held on





SERVICE

In case of operational failures and questions related to parts, please, contact one of our authorised service representations. Our skilled specialists will arrange for fast and professional repair.

OPERATING ADVICE

Anytime when our dealers cannot help you, please, feel free to contact us directly. Our team of "Technical Advisors" is at your disposal.





