

# Instructions Manual

**ICP275-EN1.pdf**  
**Operating & Maintenance**

**Rubber wheel roller**  
**CP275**

**Diesel engine**  
**Cummins 4BTAA3.9**

**Serial number**  
**10000508x0C002027-**



Created & Printed by China



## Table of Contents

Introduction .....	1
The machine .....	1
Intended use .....	1
Warning symbols.....	1
Safety information .....	1
General .....	2
Safety - General instructions.....	5
Safety - when operating .....	7
Slopes .....	7
Driving near edges .....	8
Safety (Optional) .....	9
Air conditioning (Optional).....	9
Special instructions .....	10
Standard lubricants and other recommended oils and fluids .....	10
Higher ambient temperatures, above +40°C (104°F).....	10
Lower ambient temperature - Freeze risk .....	10
Temperatures.....	10
High pressure cleaning .....	10
Fire fighting .....	10
Roll Over Protective Structure (ROPS), ROPS approved cab .....	11
Battery handling .....	11
Jump starting (24V).....	12
Technical specifications .....	13
Technical specifications .....	13
Noise level.....	13
Technical specifications - Dimensions .....	15
Dimensions .....	15
Weights and volumes.....	16

---

Air condition system.....	16
Mixed ballast - max .....	16
Working capacity.....	17
General .....	17
Tightening torque .....	18
ROPS - bolts .....	19
Hydraulic system.....	19
Machine description.....	21
Identification .....	21
Product identification number on the frame .....	21
Machine plate.....	21
Explanation of 17PIN serial number.....	22
Engine plates .....	22
Location - decals .....	23
Safety decals.....	24
Locations - Control panel and controls.....	27
Machine descriptions.....	28
Function description of instruments and controls in the cab .....	29
Using the cab controls.....	30
Defroster.....	30
Heat.....	30
AC.....	30
Electrical system.....	31
Fuse .....	32
Cab fuse.....	32
Operation.....	33
Before starting.....	33
Master switch - Switching on.....	33
Driver seat - Adjustment.....	33
Control panel and lights, check.....	34
Forward and backward lever, check.....	34
Parking brake - Check.....	35



View .....	35
Operator position.....	36
Interlock.....	36
Operating the roller.....	37
Speed selecting.....	37
Operating on a slope.....	38
Checking the treads on the tires .....	39
Variable tire pressure (air-on-the-run) (Option).....	39
Ballast box.....	40
Driving (Ground Pressure) .....	41
Ground pressure .....	41
Low tire pressure - 380 kPa (55 psi). ....	42
Normal tire pressure - 510 kPa (70 psi) .....	43
High tire pressure - 780 kPa (110 psi). ....	43
Interlock/Emergency stop/Parking brake - Check .....	44
Normal braking.....	44
Emergency braking.....	45
Switching off.....	45
Chocking the wheels .....	45
Master switch .....	46
Long-term parking.....	47
Engine .....	47
Battery.....	47
Air cleaner, exhaust pipe.....	47
Watering system .....	47
Fuel tank .....	47
Hydraulic reservoir .....	47
Tires .....	48
Steering cylinder, hinges, etc. ....	48
Hoods, tarpaulin.....	48

Miscellaneous .....	49
Lifting .....	49
Lifting the roller.....	49
Lifting the roller with jack:.....	49
Roller prepared for transport .....	50
Towing the roller.....	52
Operating instructions - Summary .....	53
Preventive maintenance .....	55
Acceptance and delivery inspection.....	55
Warranty.....	55
Maintenance - Lubricants and symbols .....	57
Maintenance symbols .....	58
Maintenance - Maintenance schedule .....	59
Service and maintenance points .....	59
General .....	60
Every 10 hours of operation (Daily).....	60
After the FIRST 50 hours of operation .....	60
Every 50 hours of operation (Weekly) .....	61
Every 250 hours of operation (Monthly) .....	61
Every 500 hours of operation (Every three months) .....	62
Every 1000 hours of operation (Every six months) .....	62
Every 2000 hours of operation (Yearly) .....	63
Maintenance - 10h .....	65
Diesel engine - Check oil level .....	65
Coolant level - Check .....	66
Brake fluid level - Check .....	66
Fuel tank - Refueling.....	67
Hydraulic reservoir - Check fluid level.....	67
Water tank, Std - Filling.....	68

Cleaning the coarse filter .....	68
Sprinkler system	
Cleaning of sprinkler nozzle .....	69
Sprinkler system - Check .....	69
Sprinkler system - Freeze risk.....	70
Draining the system. ....	70
Freeze protection .....	70
Check the emergency stop system pressure.....	70
Wheel scrapers	
Control.....	71
Removing the scrapers .....	71
Maintenance - 50h .....	73
Air cleaner	
Checking - Change the main air filter .....	73
Air cleaner	
- Cleaning.....	74
Backup filter - Change.....	74
Fuel filter - Draining.....	75
Air conditioning (Optional)	
- Inspection.....	76
Air conditioning (Optional)	
- Cleaning.....	76
Tires - Tire pressure.....	77
Upper/Lower Pivot bearing - Lubrication.....	78
Driving axle - Oil change .....	78
Maintenance - 250h .....	79
Hydraulic fluid cooler	
Checking - Cleaning.....	79
Air conditioning (Optional)	
- Inspection .....	80
Battery	
- Check condition .....	80
Upper/Lower Pivot bearing - Lubrication.....	81
Change propulsion pump filter.....	81
Check the compressor belt .....	81
Drive chain maintenance .....	82
Maintenance - 500h .....	83

Diesel engine	
Oil change .....	83
Engine	
Replacing oil filter .....	84
The engine fuel filter - replacement/cleaning .....	85
Hydraulic reservoir cap - Check .....	86
Pivot bearing - Lubrication .....	87
Upper/Lower Pivot bearing - Lubrication .....	87
Maintenance - 1000h .....	89
Air filter - Changing .....	89
Backup filter - Change .....	89
Hydraulic filter	
Change .....	90
Cab	
Fresh air filter - Replacing .....	91
Upper/Lower Pivot bearing - Lubrication .....	91
Wheel gear - Oil change .....	92
Driving gear - Replenishing the oil .....	92
Driving gear - Checking the oil level .....	93
Change propulsion pump filter .....	93
Adjust the emergency stop .....	93
Maintenance - 2000h .....	95
Hydraulic reservoir	
Fluid change .....	95
Fuel tank	
- Cleaning .....	96
Watering system	
- Draining .....	96
Water tank - Cleaning .....	97
Air conditioning (Optional)	
- Overhaul .....	97
Air conditioning (Optional)	
Drying filter - Inspection .....	98
Engine	
Replacing the coolant .....	98
Upper/Lower Pivot bearing - Lubrication .....	99
Change propulsion pump filter .....	99
Drive chain - Adjustment .....	100
Hydraulic oil change .....	100



## Introduction

### The machine

Dynapac CP275 is a heavy rubber wheel roller in the 27 tonnes class, with a working width of 2370 mm.

It has five guide wheels at the front, and four drive wheels at the back. The hydrostatic drives, flexible ballast solution, and a wide range of optional equipment mean that the machine is available in many different configurations.

### Intended use

CP275 is mainly used together with other asphalt rollers for surface sealing. Thanks to its weight, it is also suitable for soil compaction.

### Warning symbols



**WARNING ! Marks a danger or a hazardous procedure that can result in life threatening or serious injury if the warning is ignored.**



**CAUTION ! Marks a danger or hazardous procedure that can result in damage to the machine or property if the warning is ignored.**

### Safety information



***It is recommended to at least train operators in handling and daily maintenance of the machine in accordance with the instruction manual. Passengers are not allowed on the machine, and you must sit in the seat when operating the machine.***



***The safety manual supplied with the machine must be read by all roller operators. Always follow the safety instructions. Do not remove the manual from the machine.***



***We recommend that the operator reads the safety instructions in this manual carefully. Always follow the safety instructions. Ensure that this manual is always easily accessible.***



***Read the entire manual before starting the machine and before carrying out any maintenance.***



***Replace immediately the instruction manuals if lost, damaged or unreadable.***



***Ensure good ventilation (extraction of air by fan) where the engine is run indoors.***



***Prevent persons from entering or remaining in the danger area, i.e. a distance of at least 7 m (23 ft) in all directions from operating machines. The operator may allow a person to remain in the danger area, but should then observe caution and operate the machine only when the person is visible or has given clear indications of where he or she is.***

### General

This manual contains instructions for machine operation and maintenance.

The machine must be correctly maintained for maximal performance.

The machine should be kept clean so that any leakages, loose bolts and loose connections are discovered at as early a point in time as possible.

Inspect the machine every day, before starting. Inspect the entire machine so that any leakages or other faults are detected.

Check the ground under the machine. Leakages are more easily detected on the ground than on the machine itself.



**THINK ENVIRONMENT !** Do not release oil, fuel and other environmentally hazardous substances into the environment. Always send used filters, drain oil and fuel remnants to environmentally correct disposal.

This manual contains instructions for periodic maintenance normally carried out by the operator.



Additional instructions for the engine can be found in the manufacturer's engine manual.





### Safety - General instructions

(Also read the safety manual)



1. The operator must be familiar with the contents of the OPERATION section before starting the roller.
2. Ensure that all instructions in the MAINTENANCE section are followed.
3. Only trained and/or experienced operators are to operate the roller. Passengers are not permitted on the roller. Remain seated at all times when operating the roller.
4. Never use the roller if it is in need of adjustment or repair.
5. Only mount and dismount the roller when it is stationary. Use the intended grips and rails. Always use the three-point grip (both feet and one hand, or one foot and both hands) when mounting or dismounting the machine. Never jump down from the machine.
6. The ROPS (Roll Over Protective Structure) should always be used when the machine is operated on unsafe ground.
7. Drive slowly in sharp bends.
8. Avoid driving across slopes. Drive straight up or straight down the slope.
9. Make sure that there are no obstacles in the direction of travel, on the ground, in front of or behind the roller, or overhead.
10. Drive particularly carefully on uneven ground.
11. Use the safety equipment provided. The seat belt must be worn on machines fitted with ROPS.
12. Keep the roller clean. Clean any dirt or grease that accumulates on the operator platform immediately. Keep all signs and decals clean and legible.
13. Safety measures before refueling:
  - Shut off the engine
  - Do not smoke
  - No naked flame in the vicinity of the machine
  - Ground the filling device nozzle to the tank to avoid sparks
14. Before repairs or service:
  - Chock the wheels.
  - Lock the hitch system when necessary.
15. Hearing protection is recommended if the noise level exceeds 85 dB(A). The noise level can vary depending on the equipment on the machine and the surface the machine is being used on.

16. Do not make any changes or modifications to the roller that could affect safety. Changes are only to be made after written approval has been given by Dynapac.
17. Avoid using the roller before the hydraulic fluid has reached its normal working temperature. Braking distances can be longer than normal when the fluid is cold. Refer to the operating instruction in the STOP section.
18. For your own protection always wear:
  - helmet
  - working boots with steel toecaps
  - ear protectors
  - reflecting clothing/high visibility jacket
  - working gloves

### Safety - when operating



**Prevent persons from entering or remaining in the danger area, i.e. a distance of at least 7 m (23 ft) in all directions from operating machines. The operator may allow a person to remain in the danger area, but should then observe caution and operate the machine only when the person is visible or has given clear indications of where he or she is.**

### Slopes

This angle has been measured on a hard, flat surface with the machine stationary.

The steering angle is zero, the tires have normal air pressure and all the tanks are full.

Always take into consideration that loose ground, the steering of the machine, different tire pressures, the operating speed and that an increase in the center of gravity can all cause the machine to topple even on slopes with lesser gradients than those specified here.




Fig. Operating on slopes

Max. 15°  
or 27%



**To exit the cab in an emergency, release the hammer on the rear right post and break the right opening side-windows.**



**It is recommended that ROPS (Roll Over Protective Structure) or a ROPS approved cab, is always used when driving on slopes or unsafe ground.**




**Always use the lowest gear when operating on slopes.**



**Where possible, avoid driving across slopes. Drive instead straight up and down sloping ground.**

### Driving near edges


When driving close to edges or holes, make sure that at least 1/4 of the outer tires are on the previously compacted material.



**Fig. Position of wheels when driving near an edge**

## **Safety (Optional)**

### **Air conditioning (Optional)**



**Fig. Air conditioning**



***The system contains pressurized refrigerant. It is forbidden to release refrigerants into the atmosphere.***



***Work on the refrigerant circuit is only to be carried out by authorized companies.***



***The cooling system is pressurized. Incorrect handling can result in serious personal injury. Do not disconnect or undo the hose couplings.***



**The system must be re-filled with an approved refrigerant by authorized personnel when necessary. See decal on or in the vicinity of the installation.**

## **Special instructions**

### **Standard lubricants and other recommended oils and fluids**

Before leaving the factory, the systems and components are filled with the oils and fluids specified in the lubricant specification. These are suitable for ambient temperatures in the range -15°C to +40°C (5°F - 104°F).

### **Higher ambient temperatures, above +40°C (104°F)**

For operation of the machine at higher ambient temperatures, however maximum +50°C (122°F), the following recommendations apply:

The diesel engine can be run at this temperature using normal oil. However, the following fluids must be used for other components:

Hydraulic system - mineral oil Shell Tellus T100 or similar.

### **Lower ambient temperature - Freeze risk**

Make sure that the watering system is empty/drained of water (sprinkler, hoses, tank/s) or that anti-freeze has been added, to prevent the system freezing.

### **Temperatures**

The temperature limits apply to standard versions of rollers.

Rollers equipped with additional equipment, such as noise suppression, may need to be more carefully monitored in the higher temperature ranges.

### **High pressure cleaning**

Do not spray water directly onto electrical components or the instrument panels.

Place a plastic bag over the fuel filler cap and secure with a rubber band. This is to avoid high pressure water entering the vent hole in the filler cap. This could cause malfunctions, such as the blocking of filters.

### **Fire fighting**

If the machine catches fire, use an ABE-class powder fire extinguisher.

A BE-class carbon dioxide fire extinguisher can also be used.

### Roll Over Protective Structure (ROPS), ROPS approved cab



*If the machine is fitted with a Roll Over Protective Structure (ROPS, or ROPS approved cab) never carry out any welding or drilling in the structure or cab.*



*Never attempt to repair a damaged ROPS structure or cab. These must be replaced with new ROPS structure or cabs.*

### Battery handling



*When removing batteries, always disconnect the negative cable first.*



*When fitting batteries, always connect the positive cable first.*



Dispose of old batteries in an environmentally friendly way. Batteries contain toxic lead.



Do not use a quick-charger for charging the battery. This may shorten battery life.




### Jump starting (24V)



**Do not connect the negative cable to the negative terminal on the dead battery. A spark can ignite the oxy-hydrogen gas formed around the battery.**



**Check that the battery used for jump starting has the same voltage as the dead battery.**



**Fig. Jump starting**

Turn the ignition and all power consuming equipment off. Switch off the engine on the machine which is providing jump start power.

#### **Jump leads must have 24V.**

First connect the plus terminal (1) on the auxiliary battery to the plus terminal (2) on the flat battery, then connect the minus terminal (3) to a suitable earth point (4) on the machine.

Start the engine on the power providing machine. Let it run for a while. Now try to start the other machine. Disconnect the cables in the reverse order.

## Technical specifications

**Vibration levels have been measured according to the operational cycle described in the EU directive 2000/14/EC on machines equipped for the EU market with operator seat in transport position.**


Measured whole-body vibrations are below the action value of  $0.5 \text{ m/s}^2$  as specified in Directive 2002/44/EC. (Limit is  $1.15 \text{ m/s}^2$ )

Measured hand/arm vibrations also were below the action level of  $2.5 \text{ m/s}^2$  specified in the same directive.



## Technical specifications - Dimensions

### Dimensions



Dimensions	mm	in
A	4250	167
B	2370	93
H <sub>1</sub>	3408	134
H <sub>2</sub>	3000	118
K	270	10.6
L	5360	211

**Weights and volumes****Weights**

Weight without ballast	14000 kg	30,890 lbs
Weight with max ballast	27000 kg	59,575 lbs

**Fluid volumes**

Hydraulic reservoir	80 liters	84.6 qts
Lubrication oil, diesel engine	9,1 liters	9.6 qts
Coolant, diesel engine	18,5 liters	19.5 qts
Fuel tank	300 liters	79.3 gal
Rear axle	20 liters	21.1 qts
Water tank	650 liters	171.7 gal

**Air condition system**

Coolant designation: HFC-R134:A

Coolant weight when full: 1350 gram (2.98 lbs)

<b>Mixed ballast - max</b>	13 tonnes	14,2 tonnes
----------------------------	-----------	-------------

The machine can use 12 steel blocks of 6 types of steel blocks as ballast in the lower of the frame. Red type blocks are mounted on the front; black type blocks are mounted on the rear.

Use a suitable combination to achieve max ballast.

The roller's service weight consists of the weight of the roller plus the weight of the ballast.

Thicker layers require a heavier roller for compaction, while thinner layers do not need such a heavy roller.

**Working capacity****Compaction data**

Tire pressure:

- Without ballast	1530 kg	3,576 lbs
- With max ballast	3000 kg	6.615 lbs

**General****Engine**

Manufacturer/Model	Cummins 4BTAA 3.9-C125	
Power (SAE J1995)	93 kW	125 hp
Engine speed	2200 rpm	

**Electrical system**

Battery	24V (2x12V 74Ah)
Alternator	24V 60A
Fuses	See the Electrical system section - fuses

**Bulbs (if mounted)**

	<b>Watt</b>	<b>Socket</b>
Drive lights, front	75/70	P43t (H4)
Direction lights, front	21	BA15s Si
Brake-Position lights	21	BA15s
Direction lights, rear	21	BA
Working lights	70	PK22s (H3)
Cab lights	5	C5W

**Tightening torque**

Tightening torque in Nm (lbf.ft) for oiled or dry bolts tightened with a torque wrench.

**Metric coarse screw thread, bright galvanized (fzb):**

**STRENGTH CLASS:**

<b>M - thread</b>	<b>8.8, Oiled</b>	<b>8.8, Dry</b>	<b>10.9, Oiled</b>	<b>10.9, Dry</b>	<b>12.9, Oiled</b>	<b>12.9, Dry</b>
<b>M6</b>	8,4	9,4	12	13,4	14,6	16,3
<b>M8</b>	21	23	28	32	34	38
<b>M10</b>	40	45	56	62	68	76
<b>M12</b>	70	78	98	110	117	131
<b>M14</b>	110	123	156	174	187	208
<b>M16</b>	169	190	240	270	290	320
<b>M20</b>	330	370	470	520	560	620
<b>M22</b>	446	497	626	699	752	839
<b>M24</b>	570	640	800	900	960	1080
<b>M30</b>	1130	1260	1580	1770	1900	2100

**Metric coarse thread, zinc-treated  
(Dacromet/GEOMET):**

**STRENGTH CLASS:**

<b>M - thread</b>	<b>10.9, Oiled</b>	<b>10.9, Dry</b>	<b>12.9, Oiled</b>	<b>12.9, Dry</b>
<b>M6</b>	12,0	15,0	14,6	18,3
<b>M8</b>	28	36	34	43
<b>M10</b>	56	70	68	86
<b>M12</b>	98	124	117	147
<b>M14</b>	156	196	187	234
<b>M16</b>	240	304	290	360
<b>M20</b>	470	585	560	698
<b>M22</b>	626	786	752	944
<b>M24</b>	800	1010	960	1215
<b>M30</b>	1580	1990	1900	2360

### ROPS - bolts

Bolt dimensions :	M22 (PN 4812266655)
Strength class :	10.9
Tightening torque :	786 Nm

### Hydraulic system

Opening pressure	MPa
Drive system	42,0
Supply system	2,5
Control systems	16,0
Fan drive	12,5
Brake release	2,5






## Machine description

### Identification

#### Product identification number on the frame

The machine's PIN (product identification number) is punched on the right edge of the frame (1). This number is the same number as the machine plate's PIN (serial number).




**Fig. Front frame**  
1. PIN

### Machine plate

The machine plate (1) is fixed on the top step, on the left side of the operator platform.

The plate specifies the manufacturer's name and address, the type of machine, the PIN number (serial number), service weight, engine power and year of manufacture. (On machines supplied outside the EU, there are no CE markings and in some cases no year of manufacture.)



**Fig. Operator platform**  
1. Machine plate  
2. Engine plate

<b>DYNAPAC</b>			
<b>Dynapac (China) Compaction &amp; Paving Equipment Co.,Ltd.</b> 38, Quanwang Road, Wuqing High Tech Ind. Park, Tianjin, China 301700.			
•Product Identification Number			
•	Type	Rated Power	Max axle load front / rear
		kW	kg
Gross machinery mass	Operating mass	Max ballast	Year of Mfg
kg	kg	kg	
4811 0001 40			

**Please state the machine's PIN when ordering spares.**

100	00123	V	0	A	123456
A	B	C	D	E	F

### Explanation of 17PIN serial number

A= Manufacturer

B= Family/Model


C= Check letter

D= No coding

E= Production unit

F= Serial number

D, E, F would be useful when ordering spare parts or check the machine information.



**Fig. Engine**


### Engine plates

The engine's type plate is located on the left side of engine under the ejector and is accessible when the hood is opened.

The type plate is also placed under the machine plate on the top step to the operator platform.

The plate specifies the type of engine, its serial number and the engine specification. Please specify the engine serial number when ordering spares. Refer also to the engine manual.






1.	Warning, crush zone	4700903422		
2.	Warning, rotating engine components	4700903423		
3.	Warning, burning hot surface	4700903424	14.	Battery voltage 4700393959
4.	Warning, instruction manual	4700903459	15.	Water tank 4700991657
6.	Hoisting plate	4700904870	16.	Warning, high pressure fluid 4700397286
7.	Tire pressure	4700374765	17.	Warning, starting gas 4700791642
8.	Diesel fuel	4700991658	18.	Emergency exit (cab only) 4700903590
9.	Fixing point	4700357587		
10.	Hydraulic fluid	4700272372		
11.	Handbook compartment	4700903425	19.	Coolant 4700388449
12.	Battery disconnect	4700904835	20.	Warning, toxic gas 4700904185
13.	Fixing point	4700382751		

### Safety decals


Always make sure that all safety decals are completely legible, and remove dirt or order new decals if they have become illegible. Use the part number specified on each decal.



**4700903422**

**Warning - Crush zone, wheel.**


**Maintain a safe distance from the crush zone.**



**4700903423**

**Warning - Rotating engine components.**


**Keep your hands at a safe distance from the danger zone.**



**4700903424**

**Warning - Hot surfaces in the engine compartment.**

**Keep your hands at a safe distance from the danger zone.**



**4700904895**

**Warning - Brake disengagement**

**Study the towing chapter before disengaging the brakes.**

**Danger of being crushed.**



**4700903459**

**Warning - Instruction manual**


**The operator must read the safety, operation and maintenance instructions before operating the machine.**



**4700791642**

**Warning - Starting gas**

**Starting gas is not to be used.**



**4700904165**  
**Warning - Toxic gas**

**Read the instruction manual.**



**4700397286**  
**Warning - High pressure fluid**

**Make sure to drain the pressure in the accumulators before opening the hydraulic system.**


**Diesel fuel**




**Lifting point**




**Hoisting plate**



**Handbook compartment**




**Master switch**




**Hydraulic fluid**



**Tire pressure**



**Securing point**




**Battery voltage**



**Emergency exit (cab only)**



## Locations - Control panel and controls



- |  |                                    |  |
|--|------------------------------------|--|
| 1 Driving lights switch                  | 2 Working lights switch            | 3 Rotation beacon switch                           |
| 4 Parking brake                          | 5 Control indicator (left)         | 6 Horn   |
| 7 Steering indicator (left)              | 8 Start switch                     | 9 Manual/Automatic water sprinkler                 |
| 10 Water/Oil sprinkle selector           | 11 Oil/Water sprinkle time control | 12 Manual/Automatic oil sprinkler                  |
| 13 Direction indicator (right)           | 14 Hazard warning lights           | 15 Control indicator (right)                       |
| 16 Tire barometre (optional)             | 17 Oil pressure (low) alarm lamp   | 18 Oil filter blockage alarm indicator             |
| 19 Engine water thermometer              | 20 Parking indicator               | 21 Centralized air filling pressure control button |
| 22 Speed meter                           | 23 Left/Right control panel button | 24 Speedometer                                     |
| 25 Neutral position indicator            | 26 Air filter blockage alarm lamp  | 27 Fuel guage                                      |
| 28 Charging indicator                    | 29 Water level guage (water tank)  | 30 Emergency stop switch                           |
| 31 Speed selector                        | 32 Forward/Reverse lever           | 33 Throttle control handle                         |
| 34 Direction control switch (left/right) | 35 Brake padel                     | 36 Fuel filter alarm lamp                          |
| 37 Brake pressure guage                  |                                    |  |



## Location & control, cab




Fig. Cab roof, front















Fig. Rear right cab post

### Function description of instruments and controls in the cab

No	Designation	Symbol	Function
1	Heater control		Turn to the right to increase heating. Turn to the left to reduce heating.
2	Ventilation fan, switch		In the left position, the fan is off. Turning the knob to the right increases the volume of air entering the cab.
3	Air conditioning, switch		Starts and stops the air conditioning.
4	Cab air recirculation, switch	 	Pressing the top opens the air damper so that fresh air comes into the cab. Pressing the bottom closes the damper so that the air recirculates inside the cab.
5	Front wiper, switch		Press to operate the front screen wiper.
6	Front and rear window screen washers, switch		Press the upper edge to activate the front screen washers. Press the lower edge to activate the rear screen washers.
7	Rear wiper, switch		Press to operate the rear screen wiper.
8	Fuse box		Contains fuses for the electrical system in the cab.
14	Defroster nozzle		Turn the nozzle to direct the flow of air.
15	Hammer for emergency exit		To escape from the cab in an emergency, release the hammer and break the opening windows on the right-hand side.


### Using the cab controls.

#### Defroster

To quickly remove ice or mist, make sure that only the front and rear air nozzles are open.

Turn the heater and fan dial (1 and 2) to max.

Adjust the nozzle so that it blows on the window to be de-iced, or to remove mist.



#### Heat

If the cab is cold, open the lower nozzle on the front columns and the middle nozzles just over the controls for the heater and fan.

Turn to max heat and max fan speed.

When the required temperature has been reached, open the other nozzles and if necessary turn down the heat and fan speed.

#### AC

**NOTE:** When using AC all the windows must be closed for the system to work efficiently.

To quickly reduce the temperature in the cab, adjust the following settings on the control panel.


Turn on AC (3) and set the fresh air (4) in the lower position to switch off the fresh air valve.

Set the heater control (1) to minimum and turn up the fan speed (2). Keep only the front middle nozzles in the ceiling open.

When the temperature has dropped to a comfortable level, adjust the required temperature on the heater control (1) and reduce the fan speed (2).

Now open the remaining nozzles in the roof to achieve a comfortable temperature in the cab.

Reset the fresh air button (4) to the upper position for fresh air.



1

2

### Electrical system

The machine's main switchbox (1) is located on the rear of the operator platform. There is a plastic cover over the switchbox and fuses.

On the plastic cover there is a 24V socket.



3

**Fig. Main switchbox**  
1. Control unit (ECU)  
2. Main switch  
3. Fuse




**Fig. Main switch**

The roller is equipped with 24 V electrical system and an AC alternator.




**Connect the correct polarities (ground) to the battery. The cable between the battery and the alternator must not be disconnected when the engine is running.**



**Fig. Fuse panel**

## Fuse

The figure shows the position of the fuses. The table in below gives fuse amperage and function.



### FUSE BOX1

- FU2: Power supply ECU
- FU3: Power supply ECU
- FU4: Power supply ECU
- FU5: Power supply ECU
- FU6: Power supply ECU
- FU7: Pump neutral position

### FUSE BOX2

- FU8: Sprinkler shift
- FU9: Oil/water sprinkler shift
- FU10: Seat switch/High speed switch
- FU11: Warning lighting
- FU12: Backup alarm
- FU13: Water pump

### FUSE BOX3


- FU14: Oil pump
- FU15: Instrument
- FU16: Emergency stop

### FUSE BOX5

- FU17: Driving lighting
- FU18: Cab lighting
- FU19: Working lighting
- FU20: Turn lighting
- FU24: Heat

### FUSE BOX6

- FU21: Horn
- FU22: Stop lighting
- FU23: Radio FM/AM




**Fig. Cab roof fuse box**

## Cab fuse

The figure shows the position of the fuses. The table in below gives fuse amperage and function. All fuses are flat pin fuses.

### Fuse box F7

1.	Interior lighting	10A	4.	Heater fan	15A
2.	CD/Radio	10A	5.	Windscreen wiper/washers, front/rear	10A



**Fig1. Engine compartment**  
1. Battery disconnect

## Operation

### Before starting

#### Master switch - Switching on

Remember to carry out daily maintenance. Refer to the maintenance instructions.

The battery disconnecter is located in the engine compartment, on the right side of engine parts. Open the engine hood, turn the key (1) to the On position. The roller is now supplied with power.



***If the main battery/master switch is covered, the engine hood must be unlocked during operation, to be able to reach the switch in an emergency.***

### Driver seat - Adjustment



**Fig2. Driver seat**  
1. Locking lever - length adjustment  
2. Backrest angle

Adjust the operator's seat so that the position is comfortable and so that the controls are within easy reach.

The seat can be adjusted as follows.


- Length adjustment (1)
- Back support angle (2)



***Always make sure that the seat is secure before beginning operation.***

## Before starting

### 1. Control panel and lights - Check




Turn the ignition key (2) to "ON" position, neutral position indicator (5), parking indicator (4) and control indicator (1) or (3) on operator side are all activated.

Make sure the parking brake button (7) is on "pressed" condition.

Make sure the emergency stop button is on "unpressed" condition.

Make sure the fuel gauge, water level gauge have readings, oil pressure alarm is "on".

### 2. Forward and backward lever - Check



To start the machine the forward/backward lever must be in neutral position, in the middle.



Before starting, make sure the throttle is in idle state.  
(the state showed in figure is on the left operation side)



## 2. Parking brake - Check



1

2



3

### Parking brake - Check

Check tire pressure for all tires ensure the pressure accuracy.  
Check the "tire pressure gauge" (2) (option) on the control panel, move the manual pressure control valve (1) in the middle, move it upward to increase pressure, downward to decrease pressure.  
Or check each tire's pressure by using tire pressure gauge.



Test the brake valve function, ensure the normalcy of this function is essential for normal operating the machine.

Test through pressing the brake pedal (3), the brake pressure indicator will be activated.

### View

Before starting, make sure that the view ahead, to the rear, and to the sides is unobstructed.

All cab windows should be clean and the rear view mirrors should be correctly adjusted.



**Fig. View**






Fig. Driver seat

### Operator position

If a ROPS (Roll Over Protective Structure) or a cab is fitted to the roller, always wear the seat belt provided and wear a protective helmet.



***Replace the seat belt if it shows signs of wear or has been subjected to high levels of force.***



***If the machine is fitted with a cab, make sure that the door is closed when in motion.***

### Interlock

The roller is equipped with Interlock.

The diesel engine switches off after 7 seconds if the operator rises from the seat when going forwards/backwards.


If the Forward/Reverse lever is in neutral, when the operator stands up a buzzer will be activated until parking switch is activated.

The engine does not stop if the parking brake is activated.

The engine will switch off immediately if for any reason the Forward/Reverse lever is moved out of neutral when the operator is not sitting down in the seat.



***Sit down for all operations!***



## Operating the roller



**Under no circumstances is the machine to be operated from the ground. The operator must be seated inside the machine during all operation.**

Check that the steering is working correctly by turning the steering wheel once to the right and once to the left while the roller is stationary.

When compacting asphalt, remember to turn on the sprinkler system.



**Make sure that the area in front of and behind the roller is clear.**

In below there are some speed recommendation according to different working conditions:

First gear speed (tortoise):

Used for variety different material session

Used for climbing working condition

Second gear speed (rabbit):

Used for transportation



1

1. Speed selector

## Speed selecting

CAUTION



While roller is stationary, change the direction, or change gears.

CAUTION



When the tire temperature is low, from time to time to check tire surface to ensure whether asphalt mixture stuck to the tire, sprinkle water or oil on the tire could effectively prevent this problem.

## Operating on a slope



***Under no circumstances is the machine to be operated from the ground. The operator must be seated inside the machine during all operation.***

When transporting on steep ground (downward slope > 5%) make sure not to exceed the maximum speed for the roller.

Selecting low speed increases the efficiency of the engine brake and prolongs the brake life.

Low speed should **always** be selected when working and transporting on steep slopes (>15%).

The driving and braking rear wheels should also **always** be pointing down the slope, i.e. the roller is driven forwards up the slope and reversed down the slope.



***Make sure that the area in front of and behind the roller is clear.***

## Checking the treads on the tires



Inspect the tire treads from time to time to ensure no asphalt has stuck to the tires. This can occur before the tires are sufficiently warm. Mixing 2-4% cutting fluid to the tire sprinkler water can prevent this problem.



**Fig. Control panel**

- 1. Tire pressure (+)**
- 2. Tire pressure (-)**


## Variable tire pressure (air-on-the-run) (Option)

The operator can vary the pressure while work is in progress with the air pressure control on the roller. The pressure can be variably adjusted with the keys (1) and (2) on the keypad within the interval 380 kPa to 780 kPa (55 to 110 psi). The tire pressure is increased with the (1) key, and reduced with the (2) key. The pressure level of the tire is shown on the pressure gage on the top left corner of the instrument board.



The tire pressure should not be lower than 380 kPa, otherwise it would impair the service life of the tire.

## Ballast box



**Fig. Ballast box cover**

- 1. Top left cover**
- 2. Rear left cover**
- 3. Top right cover**
- 4. Rear right cover**

Increase ballast from both side of the frame




Remove the top left cover (1), rear left cover (2), top right cover (3), and the rear right cover (4).

The machine can use 12 steel blocks of 6 types of steel blocks as ballast in the lower of the frame. Red type blocks are mounted on the front; black type blocks are mounted on the rear.

Use a suitable combination to achieve max ballast.

The roller's service weight consists of the weight of the roller plus the weight of the ballast.



**Fig. Ground contact surface**  
**1. Contact surface at high tire pressure**  
**2. Contact surface at low tire pressure**

## Driving (Ground Pressure)

### Ground pressure

The contact surface of the tire can be changed by means of tire pressure.

High tire pressure gives a smaller contact surface (1).

Low tire pressure gives a larger contact surface (2).

The total service weight divided by the number of tires give the pressure per wheel. See Table.

The ground contact surface of the tire is relevant for the compaction result.

Tire load/Kg	Tire inflation pressure/KPa			
	380	510	640	780
	Average contact pressure/KPa			
1550	325.4	427.1	472.8	542.1
2020	359.4	428.7	443.3	544.2
2500	376.9	427.5	473.8	508.8
3000	388.2	435.2	468.7	490.3

Tire load/lbs	Tire inflation pressure/psi			
	55	70	90	110
	Average contact pressure/psi			
3420	22.5	29.5	32.6	37.4
4450	25	29.6	30.6	37.5
5515	26	29.5	32.7	35
6620	27	30	32.3	33.8

### Low tire pressure - 380 kPa (55 psi).

The lower the tire pressure, the lower the pressure on the contact surface due to larger contact surface.

Is used on lots of loose material.



**Fig. Low ground pressure, larger area**

**Normal tire pressure - 510 kPa (70 psi)**

Used for degradation session.



*Fig. Normal ground pressure*

**High tire pressure - 780 kPa (110 psi).**

The higher the tire pressure, the greater the pressure on the contact surface due to smaller contact surface.

Used for thick layers and finishing sessions.



*Fig. High ground pressure, smaller area*



## Interlock/Emergency stop/Parking brake - Check



***The interlock, emergency stop and parking brake must be checked daily before operating. A function check of the interlock and emergency stop requires a restart.***



***The interlock function is checked by the operator standing up from the seat when the roller is moving very slowly forwards/backwards. (Check in both directions). Hold the steering wheel firmly and brace yourself for a sudden stop. A buzzer goes on and after 7 seconds the engine switches off and the brakes are activated.***



***Check the function of the emergency stop by pressing the emergency stop button when the roller is moving slowly forwards/backwards. (Check in both directions). Hold the steering wheel firmly and brace yourself for a sudden stop. The engine switches off and the brakes are activated.***



***Check the function of the parking brake by activating the parking brake when the roller is moving very slowly forwards/backwards. (Check in both directions). Hold the steering wheel and brace yourself for a sudden stop when the brakes are activated. The engine does not switch off.***



**Fig. Forward/Reverse lever**

## Normal braking

Set the Forward/Reverse lever to "N" position.



**Fig. Emergency braking**

### Emergency braking

The brake pedal is normally used to emergency brake.



***When Forward/Reverse lever back to Neutral position, apply the brake pedal for emergency brake; When Forward/Reverse lever does not back to Neutral position, then apply the brake pedal would lead Diesel engine stop. If the Diesel engine stops, it must be restarted.***

### Switching off

Allow the engine to low idle for a few minutes to cool down.

Switch off all lights and other electrical functions.

Push in the parking brake switch.

Turn the ignition switch to the left to the shut off position.

Fit the instrument cover on the display and top of the control box (on rollers without cab), and lock it.


### Chocking the wheels



***Never leave the roller when the engine is running, unless the parking brake is activated.***



***Make sure that the roller is parked in a safe area, free from traffic. Chock the wheels if the roller is parked on sloping ground.***



**Fig. Chocking the wheels**  
**1. Chocks**



**Keep in mind that there is a risk of freezing during the winter. Drain the water tanks and water lines.**



**Fig. 10 Engine compartment**  
**1. Battery disconnect**

### Master switch


Before leaving the roller for the day, switch the master switch (1) to the disconnected position and remove the handle.

This will prevent battery discharging and will also make it difficult for unauthorized persons to start and operate the machine. Lock the service doors/covers.

### Long-term parking



The following instructions should be followed when long term parking (more than one month).



**Fig. Roller weather protection**

These measures apply when parking for a period of up to 6 months.

Before re-commissioning the roller, the points marked with an asterisk \* must be returned to the pre-storage state.

Wash the machine and touch up the paint finish to avoid rusting.

Treat exposed parts with anti-rust agent, lubricate the machine thoroughly and apply grease to unpainted surfaces.

#### Engine

\* Refer to the manufacturer's instructions in the engine manual that is supplied with the roller.

#### Battery

\* Remove the battery/batteries from the machine, clean the outside and trickle charge once a month.

#### Air cleaner, exhaust pipe

\* Cover the air cleaner (see under the heading 'Every 50 hours of operation' or 'Every 1000 hours of operation') or its opening with plastic or tape. Also cover the exhaust pipe opening. This is to avoid moisture entering the engine.

#### Watering system

\* Empty the water tank and all hoses of water. Empty the filter housing and the water pump. Undo all sprinkler nozzles.

See maintenance sections for "Watering system - draining".

#### Fuel tank

Fill the fuel tank completely full to prevent condensation.

#### Hydraulic reservoir

Fill the hydraulic reservoir to the uppermost level mark (see under the heading 'Every 10 hours of operation.')

### **Tires**

Make sure that tire pressures are at least 380 kPa (55 psi).

### **Steering cylinder, hinges, etc.**

Grease the steering cylinder piston with conservation grease.

Grease the hinges on the doors to the engine compartment and the cab.

### **Hoods, tarpaulin**

\* Lower the instrument cover over the instrument panel.

\* Cover the entire roller with a tarpaulin. A gap must be left between the tarpaulin and the ground.

\* If possible, store the roller indoors and ideally in a building where the temperature is constant.


## Miscellaneous

### Lifting

#### Lifting the roller

Ensure that the front wheels are parallel with the frame before the roller is lifted.

Place the lifting chains in the lifting eyes and make sure that no parts are damaged by the chains when lifting.



**Fig. Roller prepared for lifting**  
1. Hoisting plate



**The machine's gross weight is specified on the hoisting plate (1). Refer also to the Technical specifications.**




Lifting equipment such as chains, steel wires, straps and lifting hooks must be dimensioned in accordance with the relevant safety regulations for the lifting equipment.



**Stand well clear of the hoisted machine! Make sure that the lifting hooks are properly secured.**

Weight: refer to the hoisting plate on the roller



**Fig. Roller lifted with jack**  
1. Lifting plate  
2. Jack

#### Lifting the roller with jack:



**The machine's gross weight is specified on the hoisting plate (1). Refer also to the Technical specifications.**




The lifting device such as a jack (2), or equivalent, must be dimensioned according to the safety regulations for lifting devices.



**Do not go under a lifted load! Make sure that the lifting device is secure in its position, and on a level and stable surface.**

The machine **must only be lifted** with a jack, or the like, positioned as per the markings. The frame is reinforced at these points to withstand the tension. Lifting at any other place can result in damage to the machine or personal injury.



**Fig. Positioning**  
1. Chocks  
2. Blocks  
3. Straps

### Roller prepared for transport

Activate the parking brake.

Make sure that the machine is in a neutral position, i.e. that the front tires are pointing forwards.


Chock the tiers (1) and secure the chocks to the transport vehicle. The chock should have an angle of 37° and minimum height of 25 cm (9.9 inches). The tiers should be chocked both forwards and backwards.

Block under the frame (2) to ensure tensioned chains if the air goes out of the tires. Block up the machine as shown in figure

Secure the roller with chains in all four corners. The attachment points are shown on the decals. Place the chains in symmetrical pairs crossing each other.




Make sure that the chains, blocks and attachments in the transport vehicle are approved and have the requisite breaking strain. Check at regular intervals that the chains are not slack.



When engine or pump damage could not be repaired, roller need to be towed by towing vehicle park to safe place waiting for repairing.

Firstly, rotate the ball valve (1) handle 90 degrees, switch the oil-way, then rotate the hand pump handle (2) to hydraulic oil output (the handle rotation direction is the same as hydraulic pipeline connections); enter the cab, open the cover you could see the propulsion multi-function valve(3), turn the bypass nut on up & down multi-function valve(3) counterclockwise to startup the multi-function bypass valve; Fluctuate handpump's handle (4) until feels heave; after finishing all those actions, machine could be towed.



The machine must not be moved at a speed higher than 5 km/h, and no more than 300 meters. Otherwise there is a risk of damaging the drives. Make sure to reset the towing valves to brake status after towing.

1. Ball valve
2. Hand pump handle
3. Multi-function valve
4. Hand pump handle




### Towing the roller



***When towing/recovering, the roller must be braked by the towing vehicle. A towing bar must be used as the roller has no brakes.***



The roller must be towed slowly, max. 5 km/h (3 mph) and only towed a short distance, max. 300 m (1,000 ft).



**Fig. Towing**

When towing/retrieving a machine, the towing device must be connected to both lifting holes in the diagram.

Pulling forces should act parallel to the machine's longitudinal axis, as illustrated. See table below for maximum permitted pulling force for machine model.

Model	kN	lbf
CP275	412	92,700



Reverse the towing preparations made to the hydraulic pump and/or the motor.

### Operating instructions - Summary



1. **Follow the SAFETY INSTRUCTIONS specified in the Safety Manual.**
2. Make sure that all instructions in the MAINTENANCE section are followed.
3. Turn the master switch to the ON position.
4. Move the forward/reverse lever to NEUTRAL position, stop the machine.
5. Set the Emergency stop in the pulled-out position. The machine always starts in **Highspeed** mode.
6. Start the engine and allow it to warm up.
7. Move the forward/reverse lever to the NEUTRAL position.



8. **Operate the roller. The Forward/Reverse lever gives the required direction of travel. Use the accelerator carefully.**



9. **Test the brakes. Remember that the braking distance will be longer if the hydraulic fluid is cold.**

10. Check that the tires are thoroughly sprinkled when this is necessary.



11. **IN AN EMERGENCY:**
  - **Activate the brake pedal.**
  - **Press the EMERGENCY STOP.**
  - **Hold the steering wheel firmly.**
  - **Brace yourself for a sudden stop.**
12. When parking:
  - Move the forward/reverse lever to position "N".
  - Stop the engine and chock the wheels.
13. When lifting: - Refer to the relevant section in the Instruction Manual.
14. When towing: - Refer to the relevant section in the Instruction Manual.
15. When transporting: - Refer to the relevant section in the Instruction Manual.
16. When recovering - Refer to the relevant section in the Instruction Manual.



### Preventive maintenance

Complete maintenance is necessary for the machine to function satisfactorily and at the lowest possible cost.

The Maintenance section includes the periodic maintenance that must be carried out on the machine.

The recommended maintenance intervals assume that the machine is used in a normal environment and working conditions.

### Acceptance and delivery inspection

The machine is tested and adjusted before it leaves the factory.

On arrival, before delivery to the customer, delivery inspection must be conducted as per the check list in the warranty document.

Any transport damage must be immediately reported to the transport company.

### Warranty

The warranty is only valid if the stipulated delivery inspection and the separate service inspection have been completed as per the warranty document, and when the machine has been registered for starting under the warranty.








The warranty is not valid if damage has been caused by inadequate service, incorrect use of the machine, the use of lubricants and hydraulic fluids other than those specified in the manual, or if any other adjustments have been made without the requisite authorisation.



### Maintenance - Lubricants and symbols



Always use high-quality lubricants and the amounts recommended. Too much grease or oil can cause overheating, resulting in rapid wear.
















	ENGINE OIL	Air temperature -15°C - +50°C (5°F-122°F) Atlas Copco Engine 100 or equivalent.
	HYDRAULIC FLUID	Air temperature -15°C - +40°C (5°F-104°F) Hydraulic 300 or equivalent. Air temperature over +40°C (104°F) Shell Tellus T100 or equivalent.
	GREASE	Shell Retinax LX2, or equivalent.
	TRANSMISSION OIL	Air temperature -0°C - +40°C (32°F-104°F) Dynapac Gear Oil 300 or equivalent.
	FUEL	See engine manual.
	COOLANT	GlycoShell or equivalent (mixed 50/50 with water) Prevents freezing to around -37°C.
	BRAKE CIRCUIT OIL	Mobil DOT 3 or equivalent.



Other fuel and lubricants are required when operating in areas with extremely high or extremely low ambient temperatures. See the 'Special instructions' chapter, or consult Dynapac.


## Maintenance - Lubricants and symbols

### Maintenance symbols

	Engine, oil level		Air filter
	Engine, oil filter		Battery
	Hydraulic fluid tank, level		Sprinkler
	Hydraulic fluid, filter		Sprinkler water
	Lubricating oil		Recycling
	Coolant level		Fuel filter
	Air pressure		Transmission, oil level
			Sprinkler

## Maintenance - Maintenance schedule

### Service and maintenance points



**Fig. Service and maintenance points**

- |                             |                         |                            |
|-----------------------------|-------------------------|----------------------------|
| 1. Engine oil               | 8. Coolant              | 14. Battery                |
| 2. Oil filter               | 9. Air cleaner          | 15. Cab, air filter        |
| 3. Fuel filter              | 10. Refueling           | 16. Cab, AC                |
| 4. Hydraulic filter         | 11. Scraper             | 17. Lower pivot bearing    |
| 5. Hydraulic fluid level    | 12. Water tank, filling | 18. Upper pivot bearing    |
| 6. Hydraulic fluid, filling | 13. Sprinkling system   | 19. Pivot bearing          |
| 7. Hydraulic tank cap       |                         | 20. Driving axle           |
|                             |                         | 21. Oil pan                |
|                             |                         | 22. Propulsion pump filter |
|                             |                         | 23. Drive chain            |



## Maintenance - Maintenance schedule

### General

Periodic maintenance should be carried out after the number of hours specified. Use the daily, weekly etc. periods where number of hours cannot be used.



Remove all dirt before filling, when checking oils and fuel and when lubricating using oil or grease.



The manufacturer's instructions found in the engine manual also apply.

### Every 10 hours of operation (Daily)

Refer to the contents to find the page number of the sections referred to !

Pos. in fig	Action	Comment
	<b>Before starting up for the first time on that day</b>	
2	Check the engine oil level	Refer to the engine manual
8	Check the engine coolant level	
5	Check the hydraulic reservoir level	
10	Refuel	
12	Fill the water tanks	
13	Check the sprinkler system	
11	Check the scraper setting	
	Check emergency stop system pressure	

### After the FIRST 50 hours of operation

Refer to the contents to find the page number of the sections referred to !

Pos. in fig	Action	Comment
1, 2	Change the engine oil and oil filter	Refer to the engine manual
3	Change the fuel filter	Refer to the engine manual
4	Change the hydraulic fluid filter	Refer to 1000h.
17	Lubricate lower pivot bearing	
18	Lubricate upper pivot bearing	
20	Change the gear oil in the driving axle	
	Check air tank drain valve	
	Check emergency stop air tank pressure	

## Maintenance - Maintenance schedule

### Every 50 hours of operation (Weekly)

Refer to the contents to find the page number of the sections referred to !

Pos. in fig	Action	Comment
	Check the air intake system	
	Check the tire pressure	
	Retighten the wheel nuts	
	Inspect/clean the filter element in the air cleaner	Replace as required
	Draining the fuel prefilter	
	Inspect the air conditioning	Optional
17	Lubricate lower pivot bearing	
18	Lubricate upper pivot bearing	
	Check air-conditioner compressor belt	

### Every 250 hours of operation (Monthly)

Refer to the contents to find the page number of the sections referred to !

Pos. in fig	Action	Comment
8	Clean the hydraulic fluid cooler/water cooler	Or when required
	Check the AC	Optional
	Check the batteries condition.	
	Grease the pilot bearings and link bearings	
17	Lubricate lower pivot bearing	
18	Lubricate upper pivot bearing	
22	Change propulsion pump filter	
23	Drive chain maintenance	

## Maintenance - Maintenance schedule

### Every 500 hours of operation (Every three months)

Refer to the contents to find the page number of the sections referred to !

Pos. in fig	Action	Comment
1,2	Change the diesel engine oil and oil filter	Refer to the engine manual
3	Change the engine fuel filter	Refer to the engine manual
3	Change the engine pre-filter	
	Check bolted joints	
7	Check the hydraulic reservoir cover/breather	
17	Lubricate lower pivot bearing	
18	Lubricate upper pivot bearing	

### Every 1000 hours of operation (Every six months)

Refer to the contents to find the page number of the sections referred to !

Pos. in fig	Action	Comment
	Check engine valve clearances	Refer to the engine manual
	Check the engine belt drive system	Refer to the engine manual
9	Replace the air cleaner	
4	Change the hydraulic fluid filter	
15	Replace the air cleaner filter in the cab	
17	Lubricate lower pivot bearing	
18	Lubricate upper pivot bearing	
20	Change the oil in the wheel gear	
20	Check the oil level in the wheel gear	
22	Propulsion pump filter	
	Check and adjust emergency stop	

### Every 2000 hours of operation (Yearly)

Refer to the contents to find the page number of the sections referred to !

Pos. in fig	Action	Comment
6	Change the hydraulic fluid filter	
	Change hydraulic oil	
10	Drain and clean the fuel tank	
12	Drain and clean the water tank	
	Check the condition of the pilot bearings	
	Overhaul the air conditioning	Optional
	Changing the coolant	Refer to the engine manual
17	Lubricate lower pivot bearing	
18	Lubricate upper pivot bearing	
21	Change gear oil for oil pan	
22	Change propulsion pump filter	
23	Adjust drive chain	




## Maintenance - 10h



***Park the roller on a level surface.  
When checking and making adjustments to the roller, switch the engine off and make sure the Forward/Reverse lever is in the Neutral position.***



***Ensure that there is good ventilation (air extraction) if the engine is run indoors. Risk of carbon monoxide poisoning.***



1

***Fig. Engine compartment  
1. Dipstick***

### Diesel engine - Check oil level



***The dipstick is located under the engine hood.  
Take care not to touch any hot parts of the engine or the radiator when removing the dipstick.  
Risk of burns.***


The dipstick is located down on the left side of the engine.

Pull out the dipstick (1) and check that the oil level is between the upper and lower marks.

For further details, refer to the engine's instruction manual.



## Coolant level - Check



**Fig. Expansion tank**  
1. Filler cap  
2. Level marking  
3. Protective plate  
4. Bolt



**Observe great caution if the cap has to be opened while the engine is hot. Wear protective gloves and goggles.**

Fill with a mixture of 50% water and 50% anti freeze. See the lubrication specification in these instructions and the engine manual.



Flush the system every other year and change the coolant. Also check that the air has unobstructed passage through the reservoir.



## Brake fluid level - Check



**Fig. Brake fluid container**

Check every day that the fluid level is between the max/min marks.

Open the containers, which positioned on both front and rear of the frame.


Top up with hydraulic oil to the max mark on the container if the level is below the min mark.



## Fuel tank - Refueling



***Never refuel while the engine is running. Do not smoke and avoid spilling fuel.***



**Fig. Fuel tank**  
**1. Tank cap**  
**2. Filler pipe**

The filler pipe and tank cap are behind the operator platform on the left side of the frame.

Refuel the tank every day before starting work, or fill the tank at end of work. Unscrew the lockable tank cap (1) and fill fuel up to the lower edge of the filler pipe.

The tank holds 300 liters (79.1 gal) of fuel. Refer to the engine manual for information on diesel grade.



## Hydraulic reservoir - Check fluid level



**Fig. Hydraulic reservoir**


The filler pipe and sight glass are on the left side of the fan cover in the engine compartment.

Place the roller on a level surface and check that the oil level is between the max and min markings. Top up with the type of hydraulic fluid specified in the lubricant specification, if the level is too low.





## Water tank, Std - Filling



There are two filler caps on the top of the tank.




Unscrew the tank cap (1) and fill with clean water. Do not remove the strainer.

Fill the water tank; it holds 650 liters (167.6 gal).



Only additive: A small amount of environment-friendly antifreeze.

**Fig. Water tank**  
**1. Tank cap**



## Cleaning the coarse filter

To clean the coarse filter (1) open the drain cock (3) on the filter and allow any dirt to run out.

If necessary close the cock (2) and clean the filter and filter housing. Check that the rubber gasket in the filter housing is intact.

After inspecting and cleaning, reset and start the system to check that it works.

A drain cock (5) can be used to drain the tank and the pump system.


An extra pump (6) can be installed in case the standard water pump stops working. See section for emergency watering.

To drain the complete sprinkler system, see section for Watering system - Draining, 2,000 h.



**Fig. Pump system, front frame right side**

- 1. Coarse filter**
- 2. Stop cock**
- 3. Drain cock, filter**
- 4. Water pump**
- 5. Drain cock**



**Fig. Nozzle**  
1. Sleeve, nozzle, filter  
2. Packing

### Sprinkler system Cleaning of sprinkler nozzle

Dismantle the blocked nozzle by hand.


Blow the nozzle and fine filter (1) clean using compressed air. Alternatively, fit replacement parts and clean the blocked parts later on.

Nozzle	Colour	Ø (mm)	l/min (2.0 bar)	gal/min (40 psi)
Standard	yellow	0.8	0.63	0.20
Option	blue	1.0	1.00	0.31
Option	red	1.2	1.25	0.39
Option	brown	1.3	1.63	0.50

After inspecting and carrying out any necessary cleaning, start the system and check that it works.



***Wear protective goggles when working with compressed air.***



**Fig. Wheel rack**  
1. Water tank  
2. Sprinkler nozzle

### Sprinkler system - Check


Fill the tank with emulsion fluid, e.g. water mixed with 2% cutting fluid. Check that the sprinkler nozzles (2) are not blocked, and if necessary clean them and the filter. See under Sprinkler system, Check - Cleaning, for detailed instructions.



***Inspect the tire treads from time to time to ensure that no asphalt has stuck to the tires. This can happen before the tires have warmed up.***



***Fluids that are flammable or detrimental to the environment must not be used in the emulsion tank.***



**Fig. Sprinkler pump**

1. Valve
2. Hose
3. Coarse filter
4. Valve

## Sprinkler system - Freeze risk


Preventive measures when there is a risk of freezing.

### Draining the system.

- Close the valve (1)
- Separate the hose (2)
- Open the coarse filter (3)
- Loosen the intake to the pump by moving the plastic clamp to the left and pulling the white plastic adapter from the pump housing.
- Open the valves in the ends (4) of the sprinkler pipes.
- Allow the fluid to run out and run the sprinkler pump for about 10 seconds.

## Freeze protection

Freeze protection can also be achieved by connecting a separate container, after dividing the hose, with water mixed with glycol and running approx. 2 liters in the system.



## Check the emergency stop system pressure



**WARNING**


Place the roller on a level base. The engine must be switched off and the reserve/parking brake knob pushed in for all checking and adjustments on the roller unless otherwise specified.

Check by pressing the brake pedal. Air pressure should be 7.85 bar(114 psi). This is the maximum pressure.




**WARNING**


Do not move the roller before the system pressure has reached its specified operating level.



**Fig. Tire scrapers**  
1. Scraper blades  
2. Locking hook  
3. Adjusting screw  
1-2 mm



**Fig. Tire scrapers**  
1. Scraper blades  
2. Locking hook



**Fig. Scrapers**  
1. Pin  
2. Hairpin  
3. Locking hook  
4. Scraper attachment

## Wheel scrapers Control

Check that the tires and scrapers are worn evenly.

If there is uneven wear on the scraper, release the adjusting screw (3) on the back of the scraper attachment.

Pull down the scraper blade (1) so that it is flush with the tire.

Tighten the screws (3) again after adjusting.

The scrapers must hang free from the tires during transportation.

Lift up the scraper blades (1) and make sure that they are locked in raised position by the locking hooks (2).

To lower down the scrapers, lift the scraper slightly while pressing in the locking hook.

## Removing the scrapers

The scrapers can easily be removed for cleaning and inspection.

First secure the scraper in the locking hook (3), placed on the scraper attachment (4), to prevent the scraper dropping onto the ground.

Release the pin (1) on the hook-up axle by removing the hairpins (2) on each side of the pin. Grip the up-hook axle and pull it straight out.

When refitting after inspection etc., the scraper must first be hooked in the locking hook before the hook-up axle is put in position.

Refit the pin (1) and make sure that it is well secured by the hairpins (2).



## Maintenance - 50h



**Park the roller on a level surface.**  
**When checking and making adjustments to the roller, switch the engine off and make sure the Forward/Reverse lever is in the Neutral position.**



**Ensure that there is good ventilation (air extraction) if the engine is run indoors. Risk of carbon monoxide poisoning.**




### Air cleaner

#### Checking - Change the main air filter



Change the air cleaner main filter when the warning lamp on the control panel comes on when the engine is running at maximum speed.



**Fig. Air cleaner**

- 1. Clips**
- 2. Cover**
- 3. Main filter**
- 4. Backup filter**
- 5. Filter housing**
- 6. Dust valve**

Release the clips (1), pull off the cover (2), and pull out the main filter (3).

Do not remove the backup filter (4).

Clean the air cleaner if necessary, see section Air cleaner - Cleaning.

When replacing the main filter (3), insert a new filter and refit the air cleaner in the reverse order.

Check the condition of the dust valve (6); replace if necessary.


When refitting the cover, make sure that the dust valve is positioned downwards.



### Air cleaner - Cleaning

Wipe clean the inside of the cover (2) and the filter housing (5). See the previous illustration.

Wipe clean on both sides of the outlet pipe.



Inner edge of outlet pipe.

Outer edge of outlet pipe.

Wipe also both surfaces for the outlet pipe; see adjacent figure.



Check that the hose clamps between the filter housing and the suction hose are tight and that the hoses are intact. Inspect the entire hose system, all the way to the engine.




### Backup filter - Change

Change the backup filter with a new filter after every third replacement of the main filter.

To change the backup filter (1), pull the old filter out of its holder, insert a new filter and reassemble the air cleaner in the reverse order.

Clean the air cleaner if necessary, see section Air cleaner - Cleaning.



**Fig. Air filter**  
**1. Backup filter**



## Fuel filter - Draining



**Fig. Fuel filter**  
**1. Drain plug**


Unscrew the drain plug (1) at the bottom of the fuel filter.

With the aid of the secondary hand-operated pump, make certain that all sediment comes out. See Cummins service manual.

Tighten the drain plug as soon as uncontaminated fuel runs out.



Place in a suitable container and hand in to environment-friendly waste disposal station.



**1. Drain valve**

The air tank could also contain water due to condensation. The condensation water removes by the drain valve(1), which resets automatically when its loosening drain valve.

### CAUTION



If a lot of water is drained, the system must be inspected and faulty parts should be replaced.






## Air conditioning (Optional)

### - Inspection



**Park the roller on a level surface, chock the wheels and set the Forward/Reverse lever in the Neutral position.**



**Fig. Drying filter**  
1. Sight glass  
2. Filter holder

With the unit in operation, check using the sight glass (1) that bubbles are not visible on the drying filter.




**Make sure the Forward/Reverse lever is always in the Neutral position.**

The filter is located on the top of the rear part of the cab roof. If bubbles are visible through the sight glass, this is a sign that the refrigerant level is too low. Stop the unit to avoid risking damage. Fill up with refrigerant.



## Air conditioning (Optional)

### - Cleaning



**Fig. Cab**  
1. Condensor element

If there is a significant loss of cooling capacity, clean the condensor element (1) on the rear edge of the cab roof.




## Tires - Tire pressure

Check the tire pressure with a pressure gauge.


Make sure that the tires have the same pressure.

Recommended pressure: See Technical Specifications.

The figure shows the position of the air valve on the outer tires.



**Fig. Outer wheels**  
**1. Air valve**




**Fig. Inner wheels**  
**1. Air valve**


The figure shows the position of the air valve on the inner tires.



**Check the Safety Manual that accompanies the roller before filling the tires with air.**



## Upper/Lower Pivot bearing - Lubrication



**Fig. Pivot bearing**  
1. Lubrication nipple x1,  
upper pivot bearing  
2. Lubrication nipples x2,  
lower pivot bearing

Lubricate nipple (1) on upper pivot bearing and nipples (2) on lower pivot bearing with five pump strokes from hand-operated grease gun.

Use grease as specified in the lubricant specification.



## Driving axle - Oil change



**Take great care when draining the fluid. Wear protective gloves and goggles.**



Note: When filling and draining the gear oil and checking the level of gear oil, always park the roller on a level surface.



**Fig. Driving axle**  
1. Drain plug  
2. Filler plug

Place a receptacle that holds at least 20 liters (5.3 gal) under the drain plug.

Unscrew the drain plug (1) and filler plug (2) to evacuate air. Allow all the oil to drain out and refit the plug.



Deliver the drain oil to environmentally correct handling.

## Maintenance - 250h



***Park the roller on a level surface.  
When checking and making adjustments to the  
roller, switch the engine off and make sure the  
Forward/Reverse lever is in the Neutral position.***



***Ensure that there is good ventilation (air  
extraction) if the engine is run indoors. Risk of  
carbon monoxide poisoning.***



### Hydraulic fluid cooler Checking - Cleaning

The water and hydraulic fluid coolers are accessible when the cooler grill is removed.

Make sure that the air flow through the cooler is unobstructed. Dirty coolers are blown clean with compressed air or washed clean using a high-pressure water cleaner.




**Take care when using a high-pressure water jet.  
Do not hold the nozzle too near the cooler.**



**Fig. Cooler**



***Wear protective goggles when working with  
compressed air or high-pressure water jets.***



**Fig. Air conditioning**  
1. Refrigerant hoses  
2. Condensor element

### **Air conditioning (Optional)** **- Inspection**

Inspect refrigerant hoses and connections and make sure that there are no signs of an oil film that can indicate a refrigerant leakage.



**Fig. Batteries**

### **Battery** **- Check condition**

The batteries are sealed and maintenance-free.



***Make sure there is no open flame in the vicinity when checking the electrolyte level. Explosive gas is formed when the alternator charges the battery.***




**When disconnecting the battery, always disconnect the negative cable first. When connecting the battery, always connect the positive cable first.**

The cable shoes should be clean and tightened. Corroded cable shoes should be cleaned and greased with acid-proof Vaseline.

Wipe the top of the battery.



## Upper/Lower Pivot bearing - Lubrication




**Fig. Pivot bearing**

- 1. Lubrication nipple x1, upper pivot bearing
- 2. Lubrication nipples x2, lower pivot bearing


Lubricate nipple (1) on upper pivot bearing and nipples (2) on lower pivot bearing with five pump strokes from hand-operated grease gun.

Use grease as specified in the lubricant specification.



Filter

Change propulsion pump filter.




2

1

- 1. Compressor
- 2. Belt

Check the compressor belt.

**Drive chain maintenance (250 hours)**



When the machine working over 250 hours ,  
drive chain need to maintain.

Loosen the bolts (2) on the cover (1).

Gear oil used: Dynapac Gear Oil 100,  
rotating the rear wheel until the drive chain  
lubricate absolutely;

Repeat the procedure on the other side.

1. Cover

2. Bolt

## Maintenance - 500h



***Park the roller on a level surface.  
When checking and making adjustments to the  
roller, switch the engine off and make sure the  
Forward/Reverse lever is in the Neutral position.***



***Ensure that there is good ventilation (air  
extraction) if the engine is run indoors. Risk of  
carbon monoxide poisoning.***



### Diesel engine Oil change



**Fig. Drain plugs**

The engine's oil drain plug is delivered under the rotatory support on the front of the frame through the rubber tube. Unscrew the drain plug the engine oil could be changed.

Drain the oil when the engine is warm. Place a receptacle that holds at least 10 liters (11 qts) under the drain plugs.



***Take great care when draining engine oil. Wear  
protective gloves and goggles.***

Release the oil drain plug, allow all the oil to run out into a container.

Retighten the drain plug as soon as the engine oil run out.



**Deliver the drain oil for environmentally correct handling.**

Fill with fresh engine oil, see Lubricant specification or the engine manual for the correct grade of oil.

Fill with the requisite volume of engine oil. See technical specifications before starting the machine.



Check the dipstick to ensure that the engine oil level is correct. Refer to the engine manual for details. Top up with oil if necessary to the max mark on the dipstick.



### **Engine Replacing oil filter**



**Fig. Engine compartment  
Oil filter**

The oil filter (1) is located on the right side in the engine compartment.

See the engine manual for information about replacing the filter.



### The engine fuel filter - replacement/cleaning

The fuel filter is located in front of the accumulators on the left side in the engine compartment.

Unscrew the bottom and drain off any water, and then replace the filter unit.



**Fig. Engine compartment**  
**1. Prefilter**



**Fig. Engine compartment, right side**  
**1. Fuel filter**

Replace the fuel filter, located on the left side in the engine compartment.


Start the engine and check that the filter is well sealed.



### Hydraulic reservoir cap - Check

Unscrew and make sure that the reservoir cap is not clogged. Air must have unobstructed passage through the cap in both directions.

If passage in either direction is blocked, clean the filter with a little diesel oil and blow through with compressed air until the block is removed, or replace the cap with a new one.




1


**Fig. Left side of frame**  
**1. Tank cap**



***Wear protective goggles when working with compressed air.***




### Pivot bearing - Lubrication




Lubricate each nipple (1) with five strokes of a hand-operated grease gun.

Use grease as specified in the lubricant specification.

**Fig. Pivot bearing**  
**1. Lubrication nipples x 4**



### Upper/Lower Pivot bearing - Lubrication



Lubricate nipple (1) on upper pivot bearing and nipples (2) on lower pivot bearing with five pump strokes from hand-operated grease gun.

Use grease as specified in the lubricant specification.

**Fig. Pivot bearing**  
**1. Lubrication nipple x1, upper pivot bearing**  
**2. Lubrication nipples x2, lower pivot bearing**



## Maintenance - 1000h




**Park the roller on a level surface.**  
**When checking and making adjustments to the roller, switch the engine off and make sure the Forward/Reverse lever is in the Neutral position.**



**Ensure that there is good ventilation (air extraction) if the engine is run indoors. Risk of carbon monoxide poisoning.**



### Air filter - Changing



**Fig. Air cleaner**  
**1. Main filter**


Replace the air cleaner main filter (1) even if it has not been cleaned five times. See under the heading 'Every 50 hours of operation' for information on changing the filter.



If a blocked filter is not replaced, the exhaust fumes will be black and the engine will lose power. There is also a risk of severe damage to the engine.



### Backup filter - Change



**Fig. Air filter**  
**1. Backup filter**

Change the backup filter with a new filter after every fifth replacement or cleaning of the main filter.

The safety filter must not be cleaned.

To change the backup filter (1), pull the old filter out of its holder, insert a new filter and reassemble the air cleaner in the reverse order.



## Hydraulic filter Change

The hydraulic filters are located on the left side in the engine compartment, behind the battery disconnecter.



Remove the filter and hand in to waste disposal station. This is a disposable filter and cannot be cleaned.



**Fig. Hydraulic fluid filter**

Thoroughly clean the filter holder sealing surface.

Apply a thin coat of fresh hydraulic fluid to the rubber gasket on the new filter.

Screw the filter on by hand, firstly until the filter gasket makes contact with the filter base. Then rotate a further  $\frac{1}{2}$  turn.



1

**Fig. Hydraulic tank**  
**1. Sight glass**

Check the hydraulic fluid level in the sight glass (1) and top off as required. See under the heading 'Every 10 hours of operation' for more information.

Start the engine and check that the filter does not leak.




## Cab Fresh air filter - Replacing

There is one fresh air filter (1), placed on the front of the cab.


Remove the protective cover.

Undo the screws (2) and remove the complete holder. Remove the filter insert and replace with a new filter.

The filter may need to be changed more often if the machine is operated in a dusty environment.




**Fig. Cab, front**  
1. Fresh air filter (x1)  
2. Screw (x2)



## Upper/Lower Pivot bearing - Lubrication

Lubricate nipple (1) on upper pivot bearing and nipples (2) on lower pivot bearing with five pump strokes from hand-operated grease gun.

Use grease as specified in the lubricant specification.



**Fig. Pivot bearing**  
1. Lubrication nipple x1,  
upper pivot bearing  
2. Lubrication nipples x2,  
lower pivot bearing





## Wheel gear - Oil change



**Take great care when draining the fluid. Wear protective gloves and goggles.**




**Note:** When filling and draining the gear oil and checking the level of gear oil, always park the roller on a level surface.

Place a receptacle that holds at least 20 liters (5.3 gal) under the drain plug.

Unscrew the drain plug (1) and filler plug (2) to evacuate air. Allow all the oil to drain out and refit the plug.



Deliver the drain oil to environmentally correct handling.




**Fig. Wheel gear**  
1. Drain plug  
2. Filler plug

## Driving gear - Replenishing the oil

Move the machine so that the filler hole is correctly positioned. The hole should be just over the horizontal position to simplify filling.

Unscrew the filler plug (2). Unscrew the level plug (3) as well to evacuate air. Oil is filled from the filler well.



**Fig. Driving gearbox - Replenishing oil**  
2. Filler plug  
3. Level plug

Fill up with approx. 20 l (21 qts) of new oil. Use transmission oil, see lubricant specifications.


Move the machine so that the level plug (3) is in horizontal position.

Ensure that the oil level reaches up to the lower edge of the plug hole.

Clean and refit the plugs.



## Driving gear - Checking the oil level



3

**Fig. Level check - driving gear**  
**3. Level plug**


Move the machine so that the level plug (3) is in horizontal position.

Wipe clean the area around the level plug (3) and then undo the plug.

Ensure that the oil level reaches up to the lower edge of the plug hole.


Replenish the oil to the right level if the level is low. Use transmission oil, see lubricant specifications.

Clean and refit the plugs.



Filter

Change propulsion pump filter.



1. Adjust cam

2. Valve

Adjust the emergency stop.

Adjust the cams(1) as illustrated, Moving the brake shoes toward the drum.

Lift the wheels from the ground.

Screw the adjusting cams so that the brake shoes move away from the drum. Screw the right adjusting cam until the brake shoe lies against the drum. Screw back a quarter of a turn.

Repeat the procedure with the left adjusting cam.



## Maintenance - 2000h



***Park the roller on a level surface.  
When checking and making adjustments to the  
roller, switch the engine off and make sure the  
Forward/Reverse lever is in the Neutral position.***



***Ensure that there is good ventilation (air  
extraction) if the engine is run indoors. Risk of  
carbon monoxide poisoning.***



### Hydraulic reservoir Fluid change



***Take care when draining the hydraulic fluid. Wear  
protective gloves and goggles.***



***Fig. Hydraulic reservoir drain plug***

Hydraulic reservoir's drain plug is located on the left front side of the frame, under the hydraulic reservoir. Open the drain plug to run out oil inside the hydraulic reservoir.

Place a receptacle that holds at least 80 liters (21 gal) under the engine compartment.

Remove the plug on the end of the hose. Allow all the oil to run out. Reset by refitting the drain plug.



**Deliver the drained fluid to environmentally correct handling.**

Fill with fresh hydraulic fluid. Refer to the lubricants specification for grade information.

Replace the hydraulic filter. See section "Maintenance - 1000 hours".

Start the engine and operate the hydraulic functions. Check the level in the reservoir and top off as required.



### Fuel tank - Cleaning

It is easiest to clean the tank when it is almost empty.


Pump out any bottom sediment using a suitable pump, such as an oil drain pump.



Place in a suitable container and hand in to environment-friendly waste disposal station.



**Keep in mind fire risk when handling fuel.**



**Fig. Fuel tank**  
1. Oil drain pump



### Watering system - Draining



Remember that there is a risk of freezing during the winter. Empty the tank, pump, filter and lines, or mix antifreeze in the water.

There is a drain valve (2) in the area for the pump system on the water tank. This can be used to drain both the tank and parts of the pump system.



**Fig. Pump system**  
1. Filter housing  
2. Drain valve




## Water tank - Cleaning

Clean the tank with water and a suitable detergent for plastic surfaces.

Close the drain cock (1), fill with water and check for leaks.



The water tank is made of plastic (polyethylene) and can be recycled.



**Fig. Water tank**  
**1. Drain cock**



## Air conditioning (Optional) - Overhaul

Regular inspection and maintenance is necessary to ensure satisfactory long-term operation.


Clean all dust from the condenser element (1) using compressed air. Blow from above downwards.



The air jet can damage the element flanges if it is too powerful.



***Wear protective goggles when working with compressed air.***




**Fig. Cab**  
**1. Condensor element**  
**2. Drying filter**

Inspect the condenser element attachment.

Check the system hoses for chafing. Make sure that drainage from the cooling unit is unobstructed so that condensation does not accumulate inside the unit.

## Air conditioning (Optional) Drying filter - Inspection

With the unit in operation, check using the sight glass (1) that bubbles are not visible on the drying filter.



**Fig. Drying filter**  
1. Sight glass  
2. Filter holder



**Park the roller on a level surface, chock the wheels and set the Forward/Reverse lever in the Neutral position.**

The filter is placed at the top of the rear part of the cab roof.

If bubbles are visible through the sight glass, this indicates that the refrigerant level is too low. Stop the unit to avoid risking damage. Fill up with refrigerant.



**The refrigerant circuit is only to be worked on by authorized companies.**




## Engine Replacing the coolant

The drain plug for the coolant is located at the back on the right side of the machine. The drain plug can be accessed by opening the panel in front of the exhaust pipe.

Drain the coolant when the engine is warm. Place a container that holds at least 14 liters (15 qts) under the drain plugs.



**Observe caution when draining the coolant. Wear protective gloves and goggles.**



**Fig. Drain plugs**  
1. Hex nut  
2. Bulkhead elbow  
3. Hose  
4. Drain plug

Release the hex nut (1) as shown (2).

Pull out the hose (3) and release the drain plug (4) for the coolant. Allow all the coolant to run out into a container.

To refit, secure the plug (4) as shown and push in the hose.

Secure as shown and then tighten the hex nut (1).




**Hand in the drained coolant to an environment-friendly waste disposal station.**

Fill up with new coolant, refer to engine manual.

Fill with the requisite volume of coolant. See technical specifications before starting the machine. Allow the engine to idle for a few minutes, and then switch off the engine.

Check the dipstick to ensure that the engine oil level is correct. Refer to the engine manual for details. Top up with oil if necessary to the max mark on the dipstick.




**Fig. Pivot bearing**  
1. Lubrication nipple x1,  
upper pivot bearing  
2. Lubrication nipples x2,  
lower pivot bearing

### Upper/Lower Pivot bearing - Lubrication


Lubricate nipple (1) on upper pivot bearing and nipples (2) on lower pivot bearing with five pump strokes from hand-operated grease gun.

Use grease as specified in the lubricant specification.



Filter

Change the propulsion pump filter.



Gear oil outlet

Oil level outlet

Oil pan is located at the bottom of drive chain box. If gear oil overruns during the filling time, stop filling immediately. Use the gear oil outlet to drain gear oil when changing the oil, then fill with new gear oil.




### Drive chain -- Adjustment

When the machine working over 2000 hours, it needs to adjust the drive chain so that the rear wheels can rotate freely.

Loosen the lock nuts (2) on the adjusting bolt (1). Turn the adjusting bolt (1) while rotating the wheel until the increase in tension slows the wheel down. Check the distance: When pressing drive chain (3) by hand, it has 10 mm movement distance to obtain the right chain tension.


Tighten the lock nuts on the adjusting bolt (1)

Repeat the procedure on the other side.



### Hydraulic oil change (2000 hours or 1 year)

1. Open the air filter cap (1), drain the oil.
2. Add hydraulic oil (Hydraulic 300) to about 2/3 place of the level gauge (1).
3. Retighten the air filter cap (1).



***DYNAPAC***

Part of the Atlas Copco Group

Dynapac (China) Compaction & Paving Equipment Co., Ltd.  
No.38 QuanWang Road, WuQing High Tech Industrial Park, Tianjin, China