

# *Operating Instruction*

Original Operating Instructions

**DRP70D**

**Reversible plate**



S/N 101 924 62 1001>

DL8 203 86 EN

© 07/2018



## Table of contents

<b>1</b>	<b>Introduction.....</b>	<b>7</b>
1.1	Foreword.....	8
1.2	Machine type plate and engine type plate.....	10
<b>2</b>	<b>Technical data.....</b>	<b>11</b>
2.1	Noise and vibration data.....	13
2.1.1	Noise data.....	14
2.1.2	Vibration data.....	14
<b>3</b>	<b>Concerning your safety.....</b>	<b>15</b>
3.1	Basic prerequisites.....	16
3.1.1	General.....	16
3.1.2	Explanation of signal words used:.....	16
3.1.3	Personal protective equipment.....	17
3.1.4	Intended use.....	18
3.1.5	Improper use.....	18
3.2	Definition of responsible persons.....	20
3.2.1	Operating company.....	20
3.2.2	Expert / qualified person.....	20
3.2.3	Driver / operator.....	20
3.3	Basic safety regulations for safe operation.....	22
3.3.1	Remaining dangers, remaining risks.....	22
3.3.2	Regular safety inspections.....	22
3.3.3	Modifications and alterations to the machine.....	22
3.3.4	Damage, defects, misuse of safety devices.....	22
3.4	Handling fuels and lubricants.....	23
3.4.1	Preliminary remarks.....	23
3.4.2	Safety regulations and environmental protection regulations for handling diesel fuel.....	24
3.4.3	Safety regulations and environmental protection regulations for handling oil.....	25
3.4.4	Safety regulations and environmental protection regulations for handling hydraulic oil.....	26
3.4.5	Safety regulations and environmental protection regulations for handling battery acid.....	27
3.4.6	Safety regulations and environmental protection regulations when handling lubrication grease.....	28
3.5	Loading/transporting the machine.....	29
3.6	Start-up procedure.....	30
3.6.1	Prior to starting up.....	30
3.6.2	Starting the engine.....	30
3.7	Operation.....	31
3.7.1	Persons in the danger area.....	31
3.7.2	Operation.....	31
3.7.3	Parking the machine.....	31
3.8	Refuelling.....	32
3.9	Maintenance work.....	33
3.9.1	Preliminary remarks.....	33
3.9.2	Working on the engine.....	33
3.9.3	Maintenance work on electric components and battery.....	33

## Table of contents

3.9.4	Cleaning work.....	33
3.9.5	After maintenance work.....	34
<b>3.10</b>	<b>Repair.....</b>	<b>35</b>
<b>3.11</b>	<b>Signage.....</b>	<b>36</b>
<b>4</b>	<b>Indicators and control elements.....</b>	<b>41</b>
<b>4.1</b>	<b>Machine.....</b>	<b>42</b>
4.1.1	Handle.....	42
4.1.2	Throttle lever.....	42
4.1.3	Starter switch.....	42
4.1.4	Operating hour meter.....	43
4.1.5	Steering rod height adjustment.....	43
4.1.6	Locking pawl lever.....	43
<b>4.2</b>	<b>Engine.....</b>	<b>44</b>
4.2.1	Ventilation lever.....	44
4.2.2	Decompression lever.....	44
4.2.3	Crank handle.....	44
<b>5</b>	<b>Checks prior to start up.....</b>	<b>45</b>
<b>5.1</b>	<b>Notes on safety.....</b>	<b>46</b>
<b>5.2</b>	<b>Visual inspections and function tests.....</b>	<b>47</b>
<b>5.3</b>	<b>Checking the engine oil level.....</b>	<b>48</b>
<b>5.4</b>	<b>Checking the fuel level; topping up fuel.....</b>	<b>49</b>
<b>5.5</b>	<b>Checking the rubber buffers.....</b>	<b>50</b>
<b>6</b>	<b>Operation.....</b>	<b>51</b>
<b>6.1</b>	<b>Folding down the steering rod.....</b>	<b>52</b>
<b>6.2</b>	<b>Starting the engine.....</b>	<b>53</b>
<b>6.3</b>	<b>Operation.....</b>	<b>55</b>
<b>6.4</b>	<b>Parking the machine in secured condition.....</b>	<b>57</b>
<b>7</b>	<b>Loading / transporting the machine.....</b>	<b>59</b>
<b>7.1</b>	<b>Loading the machine.....</b>	<b>60</b>
<b>7.2</b>	<b>Lashing the machine to the transport vehicle.....</b>	<b>61</b>
<b>8</b>	<b>Maintenance.....</b>	<b>63</b>
<b>8.1</b>	<b>Preliminary remarks and safety notes.....</b>	<b>64</b>
<b>8.2</b>	<b>Preparations/concluding work.....</b>	<b>65</b>
8.2.1	Opening / closing the protection hood.....	65
8.2.2	Bleeding the fuel system.....	66
<b>8.3</b>	<b>Fuels and lubricants.....</b>	<b>68</b>
8.3.1	Engine oil.....	68
8.3.2	Fuel.....	68
8.3.3	Oil for exciter shaft housing.....	69
8.3.4	Mineral oil based hydraulic oil.....	69
<b>8.4</b>	<b>List of fuels and lubricants.....</b>	<b>71</b>
<b>8.5</b>	<b>Maintenance Table.....</b>	<b>72</b>
<b>8.6</b>	<b>Running-in instructions.....</b>	<b>73</b>
8.6.1	General.....	73
8.6.2	After 25 operating hours.....	73

<b>8.7 Weekly</b>	<b>74</b>
8.7.1 Checking, cleaning the air filter	74
8.7.2 Checking and cleaning the water separator	75
<b>8.8 Semi-annually</b>	<b>77</b>
8.8.1 Battery service	77
<b>8.9 Annually / every 250 operating hours</b>	<b>78</b>
8.9.1 Replacing the V-belt	78
8.9.2 Checking, adjusting the valve clearance	80
8.9.3 Changing engine oil and oil filter element	82
8.9.4 Replacing the fuel filter	84
8.9.5 Replacing the air filter	85
8.9.6 Changing the oil in the exciter housing	86
8.9.7 Checking the hydraulic oil level	88
8.9.8 Lubricating the machine	90
<b>8.10 Every 2 years / every 500 operating hours</b>	<b>91</b>
8.10.1 Changing the hydraulic oil	91
<b>8.11 As required</b>	<b>93</b>
8.11.1 Cleaning the machine	93
8.11.2 Cleaning the cooling fins and the cooling air intake openings	93
8.11.3 Servicing the V-belt	95
8.11.4 Checking the oil level in the exciter housing	96
8.11.5 Measures prior to extended shut-down period	97
<b>9 Troubleshooting</b>	<b>99</b>
9.1 Preliminary remarks	100
9.2 Emergency starting with crank handle	101
9.3 Starting the engine with jump leads	104
9.4 Fuse assignment	105
9.5 Engine malfunctions	106
9.6 Malfunctions during operation	108
<b>10 Disposal</b>	<b>109</b>
10.1 Final shut-down of machine	110





### 1.1 Foreword

These operating and maintenance instructions are part of your machine.

They provide necessary information to operate your machine safely and properly.

They also contain information on required operating, maintenance and repair measures.

Carefully read the operating and maintenance instructions before taking your machine into operation.

Please observe the safety regulations strictly and follow all instructions to ensure safe operation.

If you are not yet acquainted with the indicators and control elements on this machine, you should thoroughly read the corresponding chapter ↪ *Chapter 4 „Indicators and control elements“ on page 41.*

The description of the individual operating steps including the notes on safety to be followed can be found in chapter “Operation” ↪ *Chapter 6 „Operation“ on page 51.*

Before every start up, carry out all required visual inspections and function tests ↪ *Chapter 5 „Checks prior to start up“ on page 45.*

Ensure the compliance with the specified operating, maintenance and repair measures to maintain the functional safety of your machine.

A description of all necessary maintenance work, maintenance intervals as well as information on fuels and lubricants can be found in the chapter “Maintenance” ↪ *Chapter 8 „Maintenance“ on page 63.*

Do not service or repair your machine by yourself to avoid harming persons or damaging material or environment.

The machine must only be serviced and repaired by qualified and authorised personnel.

Contact our customer service to carry out the required maintenance work or necessary repairs.

In case of operating errors, inadequate maintenance or the use of unapproved fuels and lubricants all warranty claims will become null and void.

For your own personal safety you should only use original parts from Dynapac.

For your machine we offer service kits to make maintenance easier.

In the course of technical development we reserve the right for technical modifications without prior notification.

These operating and maintenance instructions are also available in other languages.

Apart from that, you can also order the spare parts catalogue against the serial number of your machine.

The above notes do not constitute an extension of the warranty and liability conditions specified in the general sales and delivery conditions of Dynapac GmbH.

We wish you successful work with your Dynapac machine.

1.2 Machine type plate and engine type plate




Fig. 1: Machine type plate (example)

Please enter here:	
Machine type (1):	
Serial number (2):	




Fig. 2: Engine type plate (example)

Please enter here:	
Engine type (1):	
Engine number (2):	



## Technical data

### Dimensions




Fig. 3

H	H <sub>1</sub>	H <sub>2</sub>	L	L <sub>1</sub>	W	W <sub>1</sub>	W <sub>2</sub>
Dimensions standard							
910	1180	1540	1890	980	650	800	950
(35.8)	(46.5)	(60.6)	(74.4)	(38.6)	(25.6)	(31.5)	(37.4)
Dimensions in millimetres							
(Dimensions in inch)							

Weights		
Operating weight (CECE) (W)	677 (1493)	kg (lbs)
Operating weight (CECE) (W <sub>1</sub> )	700 (1544)	kg (lbs)
Operating weight (CECE) (W <sub>2</sub> )	716 (1579)	kg (lbs)
Basic weight	695 (1532)	kg (lbs)
Crank handle ( <i>optional equipment</i> )	+ 3 (+ 7)	kg (lbs)

## Technical data – Noise and vibration data

Travel characteristics		
Max. working speed	28 (92)	m/min (ft/min)
Max. gradeability (depending on soil)	35	%

Drive		
Engine manufacturer	Hatz	
Type	1D90	
Cooling	Air	
Number of cylinders	1	
Rated power ISO 3046	10.3 (13.8)	kW (hp)
Rated speed	2600	min <sup>-1</sup>
Drive system	mechanical	

Exciter system		
Frequency	54 (3240)	Hz (vpm)
Centrifugal force	100 (22481)	kN (lbf)
Amplitude	2.70 (0.11)	mm (in)

Filling capacities		
Fuel (diesel)	10.0 (2.6)	l (gal us)

## 2.1 Noise and vibration data

The following noise and vibration data were determined in accordance with the following guidelines under equipment specific conditions and by using harmonized standards:

- EU Machine Directive edition 2006/42/EU
- Noise Emission Directive 2000/14/EU, Noise Protection Directive 2003/10/EU
- Vibration Protection Directive 2002/44/EU

## Technical data – Noise and vibration data

During operation these values may vary because of the prevailing operating conditions.

### 2.1.1 Noise data

**Sound pressure level at the operator's stand**

$L_{pA} = 96 \text{ dB(A)}$ , determined acc. to ISO 11201 and EN 500.



**WARNING!**

**Loss of hearing caused by too high noise burdens!**

- Wear your personal protective equipment (ear protection).

**Guaranteed sound power level**

$L_{WA} = 109 \text{ dB(A)}$ , determined acc. to ISO 3744 and EN 500

### 2.1.2 Vibration data

**Hand-arm vibration with comfort guide handle (*optional equipment*)**

Vector total of the weighted effective acceleration in three orthogonal directions:

**Total vibration value**  $a_{hv} \leq 2.5 \text{ m/s}^2$  on crushed rock determined acc. to ISO 5349 and EN 500.

**Associated uncertainty K** =  $0.5 \text{ m/s}^2$ , determined acc. to EN 12096.

Observe the daily vibration load (work safety acc. to 2002/44/EC).



### 3.1 Basic prerequisites

#### 3.1.1 General

This machine has been built in compliance with the latest technical standard and complies with the applicable regulations and technical rules.

However, dangers for persons and property may arise from this machine, if:

- it is used for purposes other than the ones it is intended for,
- it is operated by untrained personnel,
- it is changed or converted in an unprofessional way,
- the safety instructions are not observed.

Each person involved in the operation, maintenance and repair of the machine must therefore read and comply with these safety regulations. If necessary, the operating company must obtain the relevant signatures as confirmation.

Furthermore, the following obviously also applies:

- applicable accident prevention instructions,
- generally accepted safety and road traffic regulations,
- country/state specific safety regulations.

It is the duty of the operator to be acquainted with the safety regulations and to apply these accordingly. This also applies for local regulations and regulations concerning different types of handling activities. Should the recommendations in these instructions be different from the regulations valid in your country, you must comply with the safety regulations valid in your country.

#### 3.1.2 Explanation of signal words used:



##### **DANGER!**

##### **Danger to life if failing to comply!**

Sections marked accordingly indicate an extremely dangerous situation that could lead to fatal or severe injuries, if this warning is disregarded.



##### **WARNING!**

##### **Danger to life or danger of severe injuries if failing to comply!**

Sections marked accordingly indicate a dangerous situation that could lead to fatal or severe injuries, if this warning is disregarded.

## Concerning your safety – Basic prerequisites



### CAUTION!

#### Danger of injury if failing to comply!

Sections marked accordingly indicate a dangerous situation that could lead to fatal or severe injuries, if this warning is disregarded.



### NOTICE!

#### Danger of material damage if failing to comply!

Sections marked accordingly indicate possible dangers for machines or components.



*Sections marked accordingly indicate technical information or notes on using the machine or its components.*



### ENVIRONMENT!

#### Environmental damage if failing to comply!

Paragraphs marked accordingly indicate practices for safe and environment-friendly disposal of fuels and lubricants as well as replacement parts.

### 3.1.3 Personal protective equipment

Depending on the work to be carried out, personal protective equipment is required (to be provided by the operating company):



Working clothes

Tight fitting working clothes with low tear resistance, tight sleeves and without any projecting parts protect against being caught by moving components.



Safety shoes






To protect against heavy falling parts and slipping on slippery ground.



Protective gloves

To protect the hands against excoriation, punctures or deep injuries, against irritating and caustic substances as well as against burns.

## Concerning your safety – Basic prerequisites

	Safety goggles	To protect the eyes against airborne particles and squirting fluids.
	Face protection	To protect the face against airborne particles and squirting fluids.
	Hard hat	To protect the head against falling parts and to protect against injuries.
	Hearing protection	To protect hearing against excessive noise.
	Respiratory protection	To protect respiratory tracts against substances or particles.

### 3.1.4 Intended use

This machine must only be used for:

- Compaction of all types of soils
- Repair work on all types of soil
- Paving of walkways
- Work in trenches
- Underfilling and compaction of hard shoulders

Intended use also includes compliance with the specified operating, maintenance and repair measures.

### 3.1.5 Improper use

Dangers may arise from the machine when it is used for purposes other than the one it is intended for.

Any danger caused by improper use is the sole responsibility of the operating company or driver/operator, the manufacturer cannot be made liable.

## Concerning your safety – Basic prerequisites

Examples for improper use are:

- dragging the machine along as a measure of transportation
- throwing the machine off the transport vehicle
- attaching an additional weight to the machine

It is not permitted to stand on the machine while working.

Lifting tackle must be removed before starting work.

Starting and operating the machine in explosive environments and in underground mining is prohibited.

The lifting and lashing points specified in these instructions must be used. It is prohibited to use other lifting and lashing points (e.g. guide handle, steering rod).

### 3.2 Definition of responsible persons

#### 3.2.1 Operating company

The operating company is the natural or juridical person who uses the machine or in who's name the machine is used.

The operating company must make sure that the machine is only used for the purpose it is intended for and in strict compliance with the safety regulations mentioned in these operating and maintenance instructions.

The operating company must determine and assess the danger in its company. It must then take appropriate action to ensure health and safety at work for its employees and point out any remaining dangers.

The operating company must determine whether there are special operational hazards such as a toxic atmosphere or limiting soil conditions. Such conditions require special, additional measures to remove or reduce the hazard.

The operating company must make sure that all users read and understand the information concerning safety.

The operating company is responsible for the planning and professional execution of regular safety inspections.

#### 3.2.2 Expert / qualified person

An expert / qualified person is a person who, based on his/her professional education and experience, has profound knowledge in the field of construction equipment and the machine in question in particular.

This person is acquainted with the applicable governmental industrial safety regulations, accident prevention instructions, guidelines and generally acknowledged technical rules and regulations (standards, directives, technical rules of other member states of the European Union or other contractual states concerning the agreement about the European Economic Area) in as far as is necessary to be able to judge the safe condition of this machine.

#### 3.2.3 Driver / operator

This machine must only be operated by trained, instructed persons entrusted by the operating company aged 18 or more.

Observe your local laws and regulations.

Rights, obligations and rules of conduct for driver or operator:

The driver or operator must:

- be instructed about his rights and obligations,
- wear protective equipment as appropriate for the application,
- have read and understood the operating instructions,

## Concerning your safety – Definition of responsible persons

- have made himself familiar with the operation of the machine,
- be physically and psychologically able to drive and operate the machine.

Persons under the influence of alcohol, medication or drugs are not allowed to operate, service or repair the machine.

Maintenance and repair work requires specific knowledge and must therefore only be performed by trained specialists.

### 3.3 Basic safety regulations for safe operation

#### 3.3.1 Remaining dangers, remaining risks

Despite careful work and compliance with standards and regulations it cannot be ruled out that further dangers may arise when working with and handling the machine.

Both the machine as well as all other system components comply with the currently valid safety regulations. Nevertheless, remaining risks cannot be ruled out completely, even when using the machine for the purpose it is intended for and following all information given in the operating instructions.

A remaining risk can also not be excluded beyond the actual danger zone of the machine. Persons remaining in this area must pay particular attention to the machine, so that they can react immediately in case of a possible malfunction, an incident or failure etc.

All persons remaining in the area of the machine must be informed about the dangers that arise from the operation of the machine.

#### 3.3.2 Regular safety inspections

Have the machine inspected by an expert / qualified person as required for the conditions the machine is working under, but at least once every year.

#### 3.3.3 Modifications and alterations to the machine

Unauthorized changes to the machine are prohibited for safety reasons.

Original parts and accessories have been specially designed for this machine.

We wish to make explicitly clear that we have not tested or approved any parts or accessories not supplied by us.

The installation and/or use of such products may have an adverse effect on the active and/or passive safety.

#### 3.3.4 Damage, defects, misuse of safety devices

Machines which are not safe to operate or in traffic must be immediately taken out of service and shall not be used, until these deficiencies have been properly rectified.

Safety installations and switches must neither be removed nor must they be made ineffective.

### 3.4 Handling fuels and lubricants

#### 3.4.1 Preliminary remarks

The operating company must ensure that all professional users have read and follow the corresponding safety data sheets for the individual fuels and lubricants.

Safety data sheets provide valuable information about the following characteristics:

- name of substance
- possible dangers
- composition / information on constituents
- first-aid measures
- fire fighting measures
- measures in case of accidental release
- handling and storage
- limitation and monitoring of exposure / personal protective equipment
- physical and chemical properties
- stability and reactivity
- toxicological data
- environmental data
- notes on waste disposal
- information on transport
- legislation
- other data

### 3.4.2 Safety regulations and environmental protection regulations for handling diesel fuel




Fig. 4



#### **WARNING!**

##### **Danger of burning by ignited diesel fuel!**

- Do not allow diesel fuel to come into contact with hot components.
- Smoking and open fire is prohibited!
- Wear your personal protective equipment (protective gloves, protective clothing).



#### **CAUTION!**

##### **Health hazard caused by contact with diesel fuel!**

- Wear your personal protective equipment (protective gloves, protective clothing).
- Do not inhale any fuel fumes.
- Avoid contact.



#### **CAUTION!**

##### **Danger of slipping on spilled diesel fuel!**

- Immediately bind spilled diesel fuel with an oil-binding agent.



#### **ENVIRONMENT!**

##### **Diesel fuel is an environmentally hazardous substance!**

- Always keep diesel fuel in proper containers.
- Immediately bind spilled diesel fuel with an oil-binding agent and dispose of properly.
- Dispose of diesel fuel and fuel filters according to regulations.

### 3.4.3 Safety regulations and environmental protection regulations for handling oil




Fig. 5



#### **WARNING!**

##### **Danger of burning by ignited oil!**

- Do not allow oil to come into contact with hot components.
- Smoking and open fire is prohibited!
- Wear your personal protective equipment (protective gloves, protective clothing).



#### **CAUTION!**

##### **Health hazard caused by contact with oil!**

- Wear your personal protective equipment (protective gloves, protective clothing).
- Do not inhale any oil vapours.
- Avoid contact.



#### **CAUTION!**

##### **Danger of slipping on spilled oil!**

- Immediately bind spilled oil with an oil-binding agent.



#### **ENVIRONMENT!**

##### **Oil is an environmentally hazardous substance!**

- Always keep oil in proper containers.
- Immediately bind spilled oil with an oil-binding agent.
- Dispose of oil and oil filter according to regulations.

### 3.4.4 Safety regulations and environmental protection regulations for handling hydraulic oil




Fig. 6



#### **WARNING!**

**Danger of injury caused by escaping pressure fluid!**

- Always depressurize the hydraulic system before starting work in the hydraulic system.
- Wear your personal protective equipment (protective gloves, protective clothing, goggles).



*Should pressure fluid penetrate the skin, immediate medical help is required.*



#### **WARNING!**

**Danger of burning by ignited hydraulic oil!**

- Do not allow hydraulic oil to come into contact with hot components.
- Smoking and open fire is prohibited!
- Wear your personal protective equipment (protective gloves, protective clothing).



#### **CAUTION!**

**Health hazard caused by contact with hydraulic oil!**

- Wear your personal protective equipment (protective gloves, protective clothing).
- Do not inhale any oil vapours.
- Avoid contact.



#### **CAUTION!**

**Danger of slipping on spilled oil!**

- Immediately bind spilled oil with an oil-binding agent.



#### **ENVIRONMENT!**

**Oil is an environmentally hazardous substance!**

- Always keep oil in proper containers.
- Immediately bind spilled oil with an oil-binding agent.
- Dispose of oil and oil filter according to regulations.

### 3.4.5 Safety regulations and environmental protection regulations for handling battery acid




Fig. 7:



#### **WARNING!**

##### **Danger of cauterization with acid!**

- Wear your personal protective equipment (protective gloves, protective clothing, goggles).
- Do not allow clothes, skin or eyes to come into contact with acid.
- Rinse off spilled battery acid immediately with lots of water.



*Rinse acid off clothes, skin or eyes immediately with lots of clean water.*

*Immediately call for medical advice in case of cauterization.*



#### **WARNING!**

##### **Danger of injury caused by exploding gas mixture!**

- Remove the plugs before starting to recharge the battery.
- Ensure adequate ventilation.
- Smoking and open fire is prohibited!
- Do not lay any tools or other metal objects on the battery.
- Do not wear jewellery (watch, bracelets, etc.) when working on the battery.
- Wear your personal protective equipment (protective gloves, protective clothing, goggles).



#### **ENVIRONMENT!**

##### **Battery acid is an environmentally hazardous substance!**

- Dispose of battery and battery acid according to regulations.

### 3.4.6 Safety regulations and environmental protection regulations when handling lubrication grease




Fig. 8



#### **CAUTION!**

**Health hazard caused by contact with lubrication grease!**

- Wear your personal protective equipment (protective gloves, safety goggles, protective clothing).
- Avoid contact.



#### **CAUTION!**

**Danger of slipping on lubrication grease!**

- Collect and remove excess lubrication grease immediately.



#### **ENVIRONMENT!**

**Lubrication grease is an environmentally hazardous substance!**

- Always keep lubrication grease in proper containers.
- Collect excess lubrication grease and dispose of it according to regulations.
- Dispose of cloths soiled with lubrication grease according to regulations.

### 3.5 Loading/transporting the machine

Make sure that persons are not endangered by the machine tipping or sliding off.

Do not use damaged or in any other way impaired lashing points.

Always use appropriate lifting and lashing means on the lifting and lashing points.

Use lifting and lashing gear only in the prescribed direction of load application.

Lifting tackle must not be damaged by machine components.

Secure the machine on the transport vehicle against rolling, slipping and turning over.

Loads must only be attached and hoisted by an expert / capable person.

Use only lifting gear and lifting tackle with sufficient load bearing capacity for the weight to be loaded.

Fasten the lifting gear only at the specified lifting points.

Danger to the life of persons if they step or stand under a suspended load.

When lifting the machine avoid uncontrolled movements of the load. If necessary hold the load with guide ropes.

### 3.6 Start-up procedure

#### 3.6.1 Prior to starting up

Use only machines which are serviced at regular intervals.

Become acquainted with the equipment, the indicators and control elements, the working principle of the machine and the working area.

Use your personal protective equipment (hard hat, safety boots, if necessary also goggles and ear protection).

Do not take any loose objects with you or fasten them to the machine.

Before start up, check whether:

- persons or obstructions are beside or in front of the machine,
- the machine is free of oily and combustible materials,
- all safety elements are in place,
- all grips are free of grease, oils, fuel, dirt, snow and ice.

Before start up, carry out all required visual inspections and function tests.

If the following tests reveal damages or other faults, the machine must not be operated, until these deficiencies have been corrected.

Do not operate the machine with defective indicators and control elements.

#### 3.6.2 Starting the engine

Do not use any starting aids like start pilot or ether.

The machine must not be operated with damaged, missing or non-functional safety installations.

Before starting and moving the machine, make sure that there is nobody in the danger zone.

Always keep an eye on the machine when the engine is running and hold it by the steering bow.

Do not inhale exhaust fumes, because they contain toxic substances, which could cause damage to health, unconsciousness or even death.

Avoid operation in closed or partly closed rooms, or ensure adequate ventilation when working in trenches.

### 3.7 Operation

#### 3.7.1 Persons in the danger area

Before taking up work, also after breaks, you should always convince yourself that the danger zone is free of persons or obstructions.

Give warning signals, if necessary. Stop work immediately if persons remain in the danger zone, despite the warning.

#### 3.7.2 Operation

Operate the machine only with the steering rod folded down.

Only use the steering rod to steer the machine.

Guide the machine so that your hands do not hit against solid objects.

When reversing, steer the machine from the side using the steering handle.

Watch out for unusual noises and development of smoke. Perform trouble shooting and have the fault corrected.

Always keep a safe distance to excavation pit borders, embankments and edges.

Refrain from any work that could adversely affect the stability of the machine.

#### 3.7.3 Parking the machine

Park the machine on horizontal, level, firm ground.

Before leaving the machine:

- shut down the engine, pull off the ignition key,
- Secure the machine against accidental tipping over,
- Secure the machine against unauthorized use.

Mark machines, which could be in the way, with a clearly visible sign.

### 3.8 Refuelling

Do not inhale any fuel fumes.

Refuel only with the engine shut down.

Do not refuel in closed rooms.

No open fire, do not smoke.

Ultra-low sulphur diesel fuel poses a higher risk of combustion caused by the static charging than diesel fuel with a higher sulphur content.

Apply measures against electrostatic charging.

Do not spill any fuel. Catch running out fuel, do not let it seep into the ground.

Wipe off spilled fuel. Keep dirt and water away from the fuel.

A leaking fuel tank can cause an explosion. Ensure tight fit of the fuel tank cover, if necessary replace immediately.

### 3.9 Maintenance work

#### 3.9.1 Preliminary remarks

Adhere to the specified operating, maintenance and repair measures.

The machine must only be serviced by qualified personnel authorised by the operating company.

Keep unauthorised persons away from the machine.

Perform maintenance work only with the engine shut down.

Make sure that the engine cannot be accidentally started during maintenance work.

#### 3.9.2 Working on the engine

Drain the engine oil at operating temperature – danger of scalding!

Wipe off spilled oil, catch running out oil and dispose of environmentally.

When working on the air filter no dirt should fall into the air duct.

Do not work on the hot exhaust - danger of burning!

Store used filters and other oil contaminated materials in a separate, specially marked container and dispose of environmentally.

#### 3.9.3 Maintenance work on electric components and battery

Before starting to work on electric parts of the machine disconnect the battery and cover it with insulating material.

Do not use fuses with higher ampere ratings and do not bridge fuses.

When working on the battery, smoking or open fire is prohibited!

Do not lay any tools or other metal objects on the battery.

Do not wear jewellery (watch, bracelets, etc.) when working on the battery.

The connection cables of the battery must not touch or rub against machine parts.

#### 3.9.4 Cleaning work

Do not perform cleaning work while the motor is running.

Allow the engine to cool down before starting cleaning work.

Do not use gasoline or other easily inflammable substances for cleaning.

### **3.9.5 After maintenance work**

Reassemble all guards and protections.

### 3.10 Repair

Identify a defect machine with a warning sign.

Only operate the machine after it has been repaired.

When replacing safety relevant components, only original spare parts must be used.

Repairs must only be performed by an expert/qualified person.


When performing welding work on the machine you should cover the fuel tank with insulating material.

## Concerning your safety – Signage

### 3.11 Signage


Keep stickers and signage in good and legible condition and comply with their meaning.

Replace damaged and illegible stickers or signage immediately.




B-924-0027

Fig. 9




Warning sticker - Follow operating instructions

Fig. 10




Information sticker - Lashing point

Fig. 11



Information sticker - Lifting point


Fig. 12



Operation sticker - Travel lever


Fig. 13

Concerning your safety – Signage




Operation sticker - Throttle lever

Fig. 14




Instruction sticker - Wear ear protection / brief operating instructions

Fig. 15




Maintenance sticker

Fig. 16



Information sticker - Guaranteed sound capacity level

Fig. 17



Machine type plate (example)

Fig. 18





### 4.1 Machine

#### 4.1.1 Handle




Fig. 19

Shift forward	Forward travel
Pull back	Backward travel

#### 4.1.2 Throttle lever




Fig. 20

Position "STOP"	Engine off
Position "MIN"	Idle speed position
Position "I"	Medium load position
Position "II"	Full load position

#### 4.1.3 Starter switch




Fig. 21

Position "P"/"0"	Switch the ignition off Ignition key can be removed
Position "I"/"II"	Ignition on The warning buzzer sounds
Position "III"	Turn further against spring pressure, the engine starts Turn the ignition key back to position "I" when the engine starts



*The starter switch is designed with a re-start lock. The ignition key must first be turned back to position "0" before a new starting attempt can be made.*

### 4.1.4 Operating hour meter




Fig. 22

### 4.1.5 Steering rod height adjustment




Fig. 23

turn clockwise

lift the steering rod

turn anticlockwise

lower the steering rod

### 4.1.6 Locking pawl lever




Fig. 24

### 4.2 Engine

#### 4.2.1 Ventilation lever




Fig. 25

Press for approx.  
15 seconds

This will bleed the fuel system

#### 4.2.2 Decompression lever




Fig. 26

Position “closed”

Engine has compression

Normal operation

Position “open”

Engine has no compression

Only for emergency starting with crank  
handle (*optional equipment*) and mainte-  
nance



#### **NOTICE!**

##### **Danger of engine damage!**

Opening the decompression lever while the engine  
is running leads to engine damage.

- Never use the decompression lever for stop-  
ping the engine.

#### 4.2.3 Crank handle




Fig. 27



*Start the engine with the crank handle only if the  
battery is defective, empty or missing.*



*Optional equipment*



### 5.1 Notes on safety

If the following tests reveal damages or other defects, the machine must not be operated, until these deficiencies have been corrected.

Do not operate the machine with defective indicators and control elements.

Safety installations must not be removed or made ineffective.

Do not change any fixed settings.



#### **WARNING!**

##### **Health hazard caused by fuels and lubricants!**

- Safety regulations and environmental protection regulations must be followed when handling fuels and lubricants ↪ *Chapter 3.4 „Handling fuels and lubricants“ on page 23.*



#### **WARNING!**

##### **Danger of injury caused by rotating parts!**

- Before starting work on the machine make sure that the engine can not be started.

1. Park the machine safely ↪ *Chapter 6.4 „Parking the machine in secured condition“ on page 57.*
2. Open and secure the protection hood ↪ *Chapter 8.2.1.1 „Opening the protection hood“ on page 65.*
3. Close the protection hood again after work is completed ↪ *Chapter 8.2.1.2 „Closing the protection hood“ on page 66.*

## **5.2 Visual inspections and function tests**

1. Check fuel tank and lines for condition and leaks.
2. Check bolted connections for tight fit.
3. Check machine for contamination and damage.
4. Check the hydraulic oil cooler for dirt.

## Checks prior to start up – Checking the engine oil level

### 5.3 Checking the engine oil level




Fig. 28



#### NOTICE!

##### Danger of engine damage!

- +Use only oil of the permitted specification  
↳ Chapter 8.3.1 „Engine oil“ on page 68.

Protective equipment: ■ Working clothes  
■ Safety shoes  
■ Protective gloves




Fig. 29

1. Clean the area around the oil dipstick.
2. Pull the dipstick out, wipe it off with a lint-free, clean cloth and reinsert it to the end stop.
3. Pull the dipstick out again.  
⇒ The oil level must be between the “MIN” and “MAX” marks.



#### NOTICE!

##### Danger of engine damage!

- Do not fill in too much engine oil.

If the oil level is too low, top up engine oil to the “MAX” mark.

5. Push the dipstick in.

### 5.4 Checking the fuel level; topping up fuel




Fig. 30



#### NOTICE!

##### Danger of engine damage!

- Monitor the entire refuelling process.
- Contaminated fuel can cause malfunction or even damage of the engine. If necessary, fill in fuel through a screen filter.
- Use only fuel of the permitted specification  
↳ Chapter 8.3.2 „Fuel“ on page 68.

Protective equipment: ■ Working clothes  
■ Safety shoes  
■ Protective gloves




Fig. 31

1. Clean the area around the filling port.
2. Remove the cap and check the filling level visually.
3. If necessary, fill in fuel through a funnel with screen filter.
4. Close the cap.



*If the fuel tank has been completely emptied or when filling the fuel tank for the first time, the fuel system must be bled before starting* ↳ Chapter 8.2.2 „Bleeding the fuel system“ on page 66.

### 5.5 Checking the rubber buffers




Fig. 32

Protective equipment: ■ Working clothes  
■ Safety shoes  
■ Protective gloves

1. Park the machine safely ↗ *Chapter 6.4 „Parking the machine in secured condition“ on page 57.*
2. Allow the engine to cool down.
3. Check all rubber buffers for tight fit, cracks and tear-offs.
4. Replace damaged rubber buffers immediately.




Fig. 33



### 6.1 Folding down the steering rod




Fig. 34

1. Pull the locking pawl lever (2) and fold down the steering rod.  
⇒ The steering rod can swing freely.
2. Adjust the steering rod with the height adjustment (1) to the required height.

### 6.2 Starting the engine

Exhaust fumes contain toxic substances and can damage your health, cause unconsciousness or even death.



#### **WARNING!**

##### **Danger of poisoning by exhaust gases!**

- Do not inhale exhaust gases.
- Avoid operation in closed or partly closed rooms, or ensure adequate ventilation when working in trenches.



#### **WARNING!**

##### **Loss of hearing caused by too high noise burdens!**

- Wear your personal protective equipment (ear protection).

Protective equipment: ■ Working clothes  
■ Hearing protection  
■ Safety shoes




Fig. 35




Fig. 36

1. Set the throttle lever to position "MIN".

2. Set the handle to position "0".

## Operation – Starting the engine




Fig. 37




Fig. 38

3. Turn the ignition key to position “I”.  
⇒ The warning buzzer sounds.

4. **i** *The starter switch is designed with a re-start lock. The ignition key must first be turned back to position “0” before a new starting attempt can be made.*



### NOTICE!

#### Components may get damaged!

- Starting attempts should not exceed 30 seconds uninterrupted or max. 3 times for 10 seconds. Then allow the starter to cool down to ambient temperature.
- If the engine has not started after these attempts, determine the cause.

Turn the ignition key through position “II” to position “III”.

⇒ The starter cranks the engine.

The warning buzzer stops.



### NOTICE!

#### Danger of engine damage!

- Warm up engine for a short while before starting work. Do not operate the engine immediately under full load.

## 6.3 Operation

Operate the machine only with the steering rod folded down.

Use only the steering rod to steer the machine.

Guide the machine so that your hands do not hit against solid objects.

Keep feet clear of the vibrating base plate.



### CAUTION!

**Danger of injury caused by uncontrolled machine movement!**

- Always hold on to a running machine.
- Always keep an eye on a running machine.

Protective equipment: ■ Working clothes  
■ Hearing protection  
■ Safety shoes

1. Make sure that no persons are in the danger zone.

2.



### NOTICE!

**The centrifugal clutch may be damaged!**

- Operate the machine only with full throttle.

Set the throttle lever to position “I” or “II”.




Fig. 39




Fig. 40

3. Shift the handle forwards.

- ⇒ The machine vibrates forward with a speed which corresponds with the travel lever position.




Fig. 41




Fig. 42




Fig. 43

### Help if the machine gets stuck

4.



#### CAUTION!

**Danger of injury caused by the crushing of body parts!**

- When reversing, steer the machine from the side using the steering handle.

Pull the handle back.

- ⇒ The machine vibrates backwards with a speed which corresponds with the handle position.

5.

Move the handle back to position "0".

- ⇒ The machine stops and vibrates on the spot.

6.

For short work interruptions you should always return the throttle lever to "MIN" position (idle speed).

- ⇒ Vibration is switched off.

7.

For short work interruptions you should always park the machine in secured condition ↗ *Chapter 6.4 „Parking the machine in secured condition“ on page 57.*

1.

Park the machine safely ↗ *Chapter 6.4 „Parking the machine in secured condition“ on page 57.*

2.

Lift the machine, using suitable lifting and lashing tackle at the intended lifting points, until it becomes free ↗ *Chapter 7 „Loading / transporting the machine“ on page 59.*

### 6.4 Parking the machine in secured condition




Fig. 44




Fig. 45




Fig. 46




Fig. 47

1. Drive the machine onto level and firm ground.
2. Move the handle back to position "0".
  - ⇒ The machine stops and vibrates on the spot.

3. Set the throttle lever to "MIN" position (idle speed).
  - ⇒ Vibration is shut down.

4.



#### **NOTICE!** **Danger of engine damage!**

- Do not shut down the engine all of a sudden from full load speed, but let it idle for about two minutes.

Set the throttle lever to position "STOP".

⇒ The engine is shut down.

The warning buzzer sounds.

5. Turn the ignition key to position "0" and pull it out.
  - ⇒ The warning buzzer stops.





### 7.1 Loading the machine

Loads must only be attached and hoisted by an expert / qualified person.

Do not use damaged or in any other way impaired lifting points.

Use only lifting and lashing tackle with sufficient load bearing capacity for the weight to be loaded. Minimum load bearing capacity of lifting tackle: see operating weight ↗ *Chapter 2 „Technical data“ on page 11.*

Always use appropriate lifting and lashing tackle on the lifting and lashing points.

Use lifting tackle only in the prescribed direction of load application.

Lifting tackle must not be damaged by machine components.

When lifting the machine, avoid uncontrolled movements of the load. If necessary, hold the load with guide ropes.

Protective equipment: ■ Working clothes  
■ Protective gloves

1. Park the machine in secured condition ↗ *Chapter 6.4 „Parking the machine in secured condition“ on page 57.*
2. Allow the engine to cool down.
3. Make sure that the protection hood is fastened correctly ↗ *Chapter 8.2.1.2 „Closing the protection hood“ on page 66.*
4. Move the steering rod to an upright position and engage the locking pawl lever.




Fig. 48




Fig. 49

5. Attach the lifting tackle to the dedicated lifting eye.
- 6.



#### **DANGER!**

**Danger to life caused by suspended loads!**

- Do not step or stand under suspended loads.

Lift the machine carefully and lower it again at the intended location.

### 7.2 Lashing the machine to the transport vehicle

Do not use damaged or in any other way impaired lifting points.

Always use appropriate lifting and lashing tackle on the lifting and lashing points.

Use lifting tackle only in the prescribed direction of load application.

Lifting tackle must not be damaged by machine components.

Protective equipment: ■ Working clothes  
■ Protective gloves




Fig. 50




Fig. 51

1. Pull at least two suitable lashing belts crosswise across the marked lashing point.

2. Lash the machine securely to the transport vehicle as shown.





### 8.1 Preliminary remarks and safety notes



#### **DANGER!**

**Danger to life caused by an operationally unsafe machine!**

- The machine must only be serviced by qualified and authorized personnel.
- Follow the safety regulations for maintenance work ↪ *Chapter 3.9 „Maintenance work“ on page 33.*



#### **WARNING!**

**Health hazard caused by fuels and lubricants!**

- Safety regulations and environmental protection regulations must be followed when handling fuels and lubricants ↪ *Chapter 3.4 „Handling fuels and lubricants“ on page 23.*

Wear your personal protective equipment.

Do not touch hot components.

Park the machine on horizontal, level, firm ground.

Perform maintenance work only with the engine shut down.

Make sure that the engine cannot be accidentally started during maintenance work.

Thoroughly clean machine and engine before starting maintenance work.

Do not leave any tools or other objects, that could cause damage, in or on the machine.

After maintenance work has been completed, dispose of fuels and lubricants, filters, sealing elements and cleaning cloths in an environmentally friendly way.

After all maintenance work is completed reinstall all guards and safety installations.

### 8.2 Preparations/concluding work

Certain maintenance tasks require preparations and concluding activities.

This includes e.g. opening and closing maintenance flaps and maintenance doors as well as securing certain components.

After this work close all maintenance flaps and doors again and return all components to their operating condition.

#### 8.2.1 Opening / closing the protection hood

##### 8.2.1.1 Opening the protection hood

Protective equipment: ■ Working clothes  
■ Protective gloves




Fig. 52




Fig. 53

1. Remove the rear screws (2) on both sides of the machine.
2. Put the screws (2) and the matching washers to the side.
3. Loosen the front screws (1) on both sides.
4. Fold the protection hood forward.
5. Secure the protection hood against accidental closing.  
For this tighten the screw (1) on both sides.

### 8.2.1.2 Closing the protection hood

To fasten the protection hood, use only the prescribed original screws.

Always screw in and tighten all screws and their washers.

Protective equipment: ■ Working clothes  
■ Protective gloves




Fig. 54

1. Loosen the screw (1) on both sides.
2. Close the protection hood.




Fig. 55

3. Tighten the screw (1) on both sides.
4. Screw in screws (2) and washers on both sides and tighten them.

### 8.2.2 Bleeding the fuel system

The fuel shut-off valve automatically interrupts the engine's fuel supply if the oil pressure is too low.

This makes it necessary to bleed the fuel system in the following situations:

- After an engine shut-down due to an empty fuel tank.
- After filling the fuel tank for the first time.
- After using the crank handle without starting, e.g. when temperatures are low.
- After several unsuccessful starting attempts.
- After replacing the fuel filter.

Protective equipment: ■ Working clothes  
■ Safety shoes  
■ Protective gloves

1. Allow the engine to cool down.
2. Check the engine oil level, top up if necessary.



*The fuel tank must be full when bleeding.*

3. Check the fuel level, top up if necessary.
4. Press the ventilation lever for approx. 15 seconds against the spring.  
⇒ The engine is ready for starting.



*If the engine does not start after bleeding, contact our customer service department.*




Fig. 56

### 8.3 Fuels and lubricants

#### 8.3.1 Engine oil

##### 8.3.1.1 Oil quality

The following engine oil specifications are permitted:

- API CF/CH-4 or higher quality
- ACEA B3/E4 or higher quality

Avoid mixing engine oils.

##### 8.3.1.2 Oil viscosity




Fig. 57: Oil viscosity diagram

Since engine oil changes its viscosity with the temperature, the ambient temperature at the operating location of the engine is of utmost importance when choosing the viscosity class (SAE-class).

The temperature data of the SAE-class always refer to fresh oils. The engine oil ages during travel operation because of soot and fuel residues. This adversely affects the properties of the engine oil, especially at low ambient temperatures.

Optimal operating conditions can be achieved by using the oil viscosity chart as reference.

##### 8.3.1.3 Oil change intervals

Annually or every 250 operating hours.



*When changing to a higher alloyed oil quality after a longer period of operation, it is recommended to perform the first oil change of the higher quality oil already after 25 operating hours.*

#### 8.3.2 Fuel

##### 8.3.2.1 Fuel quality

The following fuel specifications are permitted:

- EN 590
- ASTM D975 Grade-No. 1-D and 2-D
- BS 2869 A1/A2

In order to fulfil national emission regulations one must strictly use the legally required fuels (e.g. sulphur content).

### 8.3.2.2 Winter fuel

For winter operation use only winter diesel fuel, to avoid clogging because of paraffin separation.

At very low temperatures disturbing paraffin separation can also be expected when using winter diesel fuel.

Diesel fuels suitable for temperatures down to -44 °C (-47 °F) are available for Arctic climates.



#### **NOTICE!**

##### **Danger of engine damage!**

- The admixture of petroleum and the addition of “flow enhancing additives” (fuel additives) is not permitted.

### 8.3.2.3 Storage

Even traces of zinc, lead and copper can cause deposits in the injection nozzles, especially in modern Common-Rail injection systems.

Zinc and lead coatings in refuelling systems and fuel lines are not permitted.

Copper containing materials (copper lines, brass items) should be avoided, because they can cause catalytic reactions in the fuel with subsequent depositing in the injection system.

### 8.3.3 Oil for exciter shaft housing

Use only engine oils according to the following specifications:

- API CI-4 or higher quality

Avoid mixing engine oils.



#### **NOTICE!**

##### **Components may get damaged!**

- Do not use low-ash engine oils for the exciter shaft housing.

### 8.3.4 Mineral oil based hydraulic oil

The hydraulic system is operated with hydraulic oil HV 32 (ISO) with a kinematic viscosity of 32 mm<sup>2</sup>/s at 40 °C (104 °F).

When refilling or changing oil, use only hydraulic oil type HVLP according to DIN 51524, part 3, or hydraulic oil type HV according to ISO 6743/4.

## Maintenance – Fuels and lubricants

The viscosity index must be at least 150 (observe information of manufacturer).

## 8.4 List of fuels and lubricants

Assembly group	Fuel or lubricant		Filling quantity
	Summer	Winter	Observe the level mark!
Engine oil	SAE 10W-40		1.9 l (0.5 gal us)
	Specification: ☞ Chapter 8.3.1 „Engine oil“ on page 68		
	SAE 15W-40		
	SAE 10W-30		
	SAE 30	SAE 10W	
Fuel	Diesel	Winter diesel fuel	10.0 l
	Specification: ☞ Chapter 8.3.2 „Fuel“ on page 68		(2.6 gal us)
Exciter shaft housing	SAE 10W-40		0.8 l (0.21 gal us)
	Specification: ☞ Chapter 8.3.3 „Oil for exciter shaft housing“ on page 69		
	SAE 15W-40		
	SAE 10W-30		
Steering rod	Hydraulic oil (ISO), HV 32		0.4 l (0.11 gal us)
	Specification: ☞ Chapter 8.3.4 „Mineral oil based hydraulic oil“ on page 69		

## Maintenance – Maintenance Table

### 8.5 Maintenance Table

No.	Maintenance works	Page
<b><i>Running-in instructions</i></b>		
8.6.1	<i>General</i>	73
8.6.2	<i>After 25 operating hours</i>	73
<b><i>Weekly</i></b>		
8.7.1	<i>Checking, cleaning the air filter</i>	74
8.7.2	<i>Checking and cleaning the water separator</i>	75
<b><i>Semi-annually</i></b>		
8.8.1	<i>Battery service</i>	77
<b><i>Annually / every 250 operating hours</i></b>		
8.9.1	<i>Replacing the V-belt</i>	78
8.9.2	<i>Checking, adjusting the valve clearance</i>	80
8.9.3	<i>Changing engine oil and oil filter element</i>	82
8.9.4	<i>Replacing the fuel filter</i>	84
8.9.5	<i>Replacing the air filter</i>	85
8.9.6	<i>Changing the oil in the exciter housing</i>	86
8.9.7	<i>Checking the hydraulic oil level</i>	88
8.9.8	<i>Lubricating the machine</i>	90
<b><i>Every 2 years / every 500 operating hours</i></b>		
8.10.1	<i>Changing the hydraulic oil</i>	91
<b><i>As required</i></b>		
8.11.1	<i>Cleaning the machine</i>	93
8.11.2	<i>Cleaning the cooling fins and the cooling air intake openings</i>	93
8.11.3	<i>Servicing the V-belt</i>	95
8.11.4	<i>Checking the oil level in the exciter housing</i>	96
8.11.5	<i>Measures prior to extended shut-down period</i>	97

### 8.6 Running-in instructions

#### 8.6.1 General

The following maintenance work must be performed when running in new machines or overhauled engines.

#### 8.6.2 After 25 operating hours

1. Change the engine oil ↗ *Chapter 8.9.3 „Changing engine oil and oil filter element“ on page 82.*
2. Check the valve clearance, adjust if necessary ↗ *Chapter 8.9.2 „Checking, adjusting the valve clearance“ on page 80.*
3. Check engine and machine for leaks.
4. Retighten the fastening screws on air filter, exhaust and other attachments.
5. Retighten the bolted connections on the machine.
6. Check the V-belt ↗ *Chapter 8.11.3 „Servicing the V-belt“ on page 95.*
7. Check the oil level in the exciter shaft housing ↗ *Chapter 8.11.4 „Checking the oil level in the exciter housing“ on page 96.*

### 8.7 Weekly

#### 8.7.1 Checking, cleaning the air filter




Fig. 58



#### NOTICE!

##### Danger of engine damage!

- Do not start the engine after having removed the air filter.
- If necessary, the air filter may be cleaned up to six times.
- Cleaning does not make sense if the air filter element is covered with a sooty deposit.
- Do not use gasoline or hot fluids to clean the filter element.
- After cleaning, the air filter must be inspected for damage using a torch.
- Do not continue to use a damaged air filter element. If in doubt use a new air filter.

Protective equipment:

- Working clothes
- Safety shoes
- Protective gloves
- Safety goggles




Fig. 59

1. Park the machine safely ↗ Chapter 6.4 „Parking the machine in secured condition“ on page 57.
2. Allow the engine to cool down.
3. Remove the cap (1).
4. Pull out the air filter.
5. Clean the cover.
- 6.



#### NOTICE!

##### Danger of engine damage!

- Prevent dirt from getting into the air intake opening.
- Do not clean the air filter housing with compressed air.

Clean the filter housing with a clean, lint-free cloth.




Fig. 60




Fig. 61

## 8.7.2 Checking and cleaning the water separator




Fig. 62

7.



### CAUTION!

**Danger of eye injuries caused by particles flying around!**

- Wear your personal protective equipment (safety gloves, protective working clothes, goggles).

Blow the air filter out with dry compressed air (max. 5 bar (73 psi)) from inside to outside by moving the gun up and down inside the element, until it is free of dust.

8. Examine the air filter with a torch for cracks and holes.
9. Replace the air filter if it is damaged.
10. Slide the air filter (2) carefully into the filter housing.
11. Check the sealing face (3) on the cover.
- 12.



### NOTICE!

**Danger of engine damage!**

- Ensure correct fit of cover and seal.

Close the cap (1).



*The service intervals for the water separator depend on the water content in the fuel and can therefore not be determined precisely.*

*After taking the engine into operation you should check for signs of water and dirt initially every day.*




Fig. 63

Protective equipment: ■ Working clothes  
■ Safety shoes  
■ Protective gloves

1. Park the machine safely ↪ *Chapter 6.4 „Parking the machine in secured condition“ on page 57.*
2. Place the transparent container under the drain plug.
3. Loosen the drain plug and collect escaping fluid.
4. Drain the fuel off until there is no water left.

**i**

*If the fuel tank has been completely emptied, bleed the fuel system before starting.  
↪ Chapter 8.2.2 „Bleeding the fuel system“ on page 66*

5. Screw the drain plug back on tightly. Ensure leak tightness.
6. Dispose of collected fluid in line with environmental regulations.

## 8.8 Semi-annually

### 8.8.1 Battery service




Fig. 64



*Maintenance free batteries also need care. Maintenance free only means that the fluid level does not need to be checked.*

*Every battery has a self-discharge, which may, if not checked occasionally, even cause damage to the battery as a result of exhaustive discharge.*

*Exhausted batteries (batteries with formation of sulphate on the plates) are not covered under warranty!*

- Protective equipment:
- Working clothes
  - Safety shoes
  - Protective gloves
  - Safety goggles




Fig. 65


1. Park the machine safely Chapter 6.4 „Parking the machine in secured condition“ on page 57.
2. Remove the bracket (1) of the battery.
3. Remove the battery (2) and the vibration damping mats (3).
4. Check the condition of the vibration insulation mats, replace if necessary.
5. Clean the outside of the battery.
6. Clean the battery poles and terminals and grease them with pole grease (Vaseline).
7. On serviceable batteries check the acid level, if necessary top up to the filling mark with distilled water.
8. Install battery and vibration insulation mats.
9. Install the bracket of the battery.

## **8.9 Annually / every 250 operating hours**


### **8.9.1 Replacing the V-belt**

Protective equipment: ■ Working clothes  
■ Protective gloves


1. Park the machine in secured condition ↗ *Chapter 6.4 „Parking the machine in secured condition“ on page 57.*
2. Allow the engine to cool down.
3. Unscrew the V-belt guard (1).



*Fig. 66*



*Fig. 67*



*Fig. 68*

4. Unscrew the guard (1).
5. Unscrew the V-belt pulley (1).
6. Replace the V-belt (3).
7. If necessary, reassemble the spacers (2) that may have been removed.
8. Fasten the V-belt pulley.




Fig. 69

9. Check the centre distance (x) between the centrifugal clutch (1) and the V-belt pulley (2).

⇒ **Nominal value:**  $424 \pm 1$  mm



*If the centre distance is incorrect, contact our customer service.*




Fig. 70

10. Fasten the guard (1), tightening torque: 15 Nm (11 ft·lbf).




Fig. 71

11. Fasten the V-belt guard (1).

### 8.9.1.1 Checking the frequency of the base plate

Keep feet and hands clear of the vibrating base plate.



#### **CAUTION!**

**Danger of injury caused by uncontrolled machine movement!**

- Always hold on to a running machine.
- Always keep an eye on a running machine.

## Maintenance – Annually / every 250 operating hours

Protective equipment: ■ Working clothes  
■ Hearing protection  
■ Safety shoes

Special tool: ■ Sirometer

1. Park the machine on a rubber mat.
2. Start the engine ↗ *Chapter 6.2 „Starting the engine“ on page 53.*
3. Run the machine at maximum speed for one minute.
4. Check the base plate's frequency with a suitable measuring instrument (e.g. Sirometer).  
⇒ **Nominal value:** ↗ *Chapter 2 „Technical data“ on page 11*
5. Park the machine safely ↗ *Chapter 6.4 „Parking the machine in secured condition“ on page 57.*
6. If frequency incorrect:
  - Check the engine speed.
  - Check the V-belt.
  - If necessary, contact our customer service.

### 8.9.2 Checking, adjusting the valve clearance



#### NOTICE!

##### **Danger of engine damage!**

We recommend to have this work carried out by trained personnel or our after sales service.

- Before checking the valve clearance let the engine cool down.

#### Preparations

Protective equipment: ■ Working clothes  
■ Protective gloves

1. Park the machine in secured condition ↗ *Chapter 6.4 „Parking the machine in secured condition“ on page 57.*
2. Let the engine cool down to ambient temperature.




Fig. 72




Fig. 73

### Checking the valve clearance




Fig. 74

3. Check the position of the decompression lever, if necessary move it to the initial position.

4. Remove the valve cover with the seal.

#### Valve clearance:

Intake valve (IN)	0.30 mm (0.012 in)
Exhaust valve (EX)	0.30 mm (0.012 in)

1. Crank the engine, until the exhaust valve (EX) is fully open.
2. Check the valve clearance on the intake valve (IN) with a feeler gauge (1), adjust if necessary.
3. Crank the engine further, until the intake valve is fully open.
4. Check the valve clearance on the exhaust valve, adjust if necessary.

### Adjusting the valve clearance




Fig. 75

1. Loosen screw (3) on the rocker arm.
2. Adjust the screw (2), until the feeler gauge (1) can be inserted and pulled out with a barely noticeable resistance after the hexagon nut (3) has been tightened.

### Final work




Fig. 76

1. Install the valve cover with a new seal and tighten the screws evenly.
2. After a short test run check the valve cover for leaks.

### 8.9.3 Changing engine oil and oil filter element



#### NOTICE!

##### Danger of engine damage!

- Change the oil only with the engine at operating temperature.
- Use only oil of the permitted specification  
↳ Chapter 8.3.1 „Engine oil“ on page 68.
- Filling quantity: ↳ Chapter 8.4 „List of fuels and lubricants“ on page 71

Protective equipment: ■ Working clothes  
■ Protective gloves  
■ Safety goggles

1. Park the machine in secured condition ↗ *Chapter 6.4 „Parking the machine in secured condition“ on page 57.*

### Draining off engine oil




Fig. 77




Fig. 78

### Changing the oil filter element




Fig. 79

2. Clean the area around the dipstick and pull the dipstick out.

3. Clean the area around the drain hose.



#### **WARNING!**

##### **Danger of burning on hot components!**

- Wear your personal protective equipment (protective gloves, protective clothing).
- Avoid touching hot components.

4. Unscrew the drain plug and collect any oil running out.
5. Clean the drain plug and screw it in, tightening torque: 20 Nm (15 ft·lbf).
6. Clean the area around the cover.
7. Unscrew the cover and change the oil filter element.
8. Clean the sealing face on the engine.
9. Insert the new filter oil filter element with the recess facing downwards.
10. Check the seal ring on the cover for damage, replace if necessary.
11. Slightly lubricate the seal ring.
12. Screw the cap on.

### Filling in engine oil




Fig. 80

### Concluding work

13. Fill in fresh engine oil through the filler opening.
14. Push the dipstick in.
15. After a short test run, check the oil level on the dipstick, top up oil if necessary.

16. Check oil filter and drain plug for leaks.
17. Dispose of oil and oil filter insert in an environmentally friendly way.

### 8.9.4 Replacing the fuel filter



#### NOTICE!

##### Danger of engine damage!

- Ensure strict cleanliness! Thoroughly clean the area around the fuel tank beforehand.
- Never operate the engine after having removed the fuel filter.

Protective equipment: ■ Working clothes  
■ Protective gloves




Fig. 81

1. Park the machine in secured condition ↗ *Chapter 6.4 „Parking the machine in secured condition“ on page 57.*
2. Use a suitable vessel to collect running out fuel.
3. Drain the fuel.
4. Clean the area around the fuel filter.
5. Unscrew the hose clamp from the holding fixtures.
6. Pull the fuel filter with the fuel lines out of the hose clamps.
7. Pull the fuel lines off the fuel filter.
8. Replace the fuel filter.
9. Plug on the fuel lines.



*Observe the flow direction of the new fuel filter.*

10. Insert the fuel filter with the fuel lines into the hose clamps.
11. Screw the hose clamps to the holding fixtures.

12. Fill the fuel tank.
13. Bleed the fuel system before starting ↗ *Chapter 8.2.2 „Bleeding the fuel system“ on page 66.*
14. After a short test run check fuel filter and fuel lines for leaks.
15. Dispose of fuel and fuel filter in an environmentally friendly way.

### 8.9.5 Replacing the air filter



#### NOTICE!

##### Danger of engine damage!

- Do not start the engine after having removed the air filter.

Protective equipment: ■ Working clothes  
■ Protective gloves




Fig. 82

1. Park the machine in secured condition ↗ *Chapter 6.4 „Parking the machine in secured condition“ on page 57.*
2. Allow the engine to cool down.
3. Remove the cap (1).
4. Pull out the air filter.
5. Clean the cover.
- 6.



#### NOTICE!

##### Danger of engine damage!

- Prevent dirt from getting into the air intake opening.
- Do not clean the air filter housing with compressed air.

Clean the filter housing with a clean, lint-free cloth.




Fig. 83

7. Replace the air filter.
8. Slide the air filter (2) carefully into the filter housing.
9. Check the sealing face (3) on the cover.
- 10.



#### NOTICE!

##### Danger of engine damage!

- Ensure correct fit of cover and seal.

Close the cap (1).

### 8.9.6 Changing the oil in the exciter housing



#### NOTICE!

##### Components may get damaged!

- Use only oil of the permitted specification  
↳ *Chapter 8.4 „List of fuels and lubricants“ on page 71.*
- Do not use low-ash engine oils for the exciter shaft housing.

Protective equipment: ■ Working clothes  
■ Safety shoes  
■ Protective gloves




Fig. 84




Fig. 85

1. Park the machine on level ground.
2. Park the machine safely ↳ *Chapter 6.4 „Parking the machine in secured condition“ on page 57.*
3. Clean the area around the bleeding screw (1) and filling/drain plug (2).
4. Tilt the machine slightly towards the oil drain side and secure it properly.
5. Unscrew the bleeding screw.
6. Unscrew the filling/drain plug and collect any oil running out.
7. Tilt the machine to the opposite side and secure it properly.
8. Fill in new oil.

## Maintenance – Annually / every 250 operating hours




Fig. 86

9. Stand the machine horizontally and check the oil level.  
⇒ **Nominal value:** Bottom edge of filling/drain bore.
10. Clean the bleed screw (1) and filling/drain plug (2) and screw them in with a low-strength sealing agent (e.g. spare parts number: DL 009 700 16).
11. Dispose of oil in line with environmental regulations.

### 8.9.7 Checking the hydraulic oil level

Protective equipment: ■ Working clothes  
■ Protective gloves

1. Park the machine in secured condition ↗ *Chapter 6.4 „Parking the machine in secured condition“ on page 57.*
2. Adjust the steering rod with height adjustment so that the area with the filler screw is horizontal.
3. Unscrew the filler screw.




Fig. 87




Fig. 88




Fig. 89

**Fill in hydraulic oil, bleed the system**

4. Press the handle forward against the stop and secure it using suitable means.

5. The oil level must reach the mark on the steering rod head, if necessary, fill in hydraulic oil.

**Mark:** approx. 40 mm (1.6 in) below the filler opening



#### **NOTICE!**

**Components may get damaged!**

- Use only oil of the permitted specification.




Fig. 90




Fig. 91




Fig. 92

### Concluding work




Fig. 93

6. Press the handle forward against the stop and secure it using suitable means.

7. Place a cloth underneath the bleeding screw to collect leaking oil.
8. Slacken the bleeding screw.
9. Wait until all air has escaped and then tighten the bleeding screw.

10. Fill in hydraulic oil up to the mark on the steering rod head.

11. Screw in the filler screw.

### 8.9.8 Lubricating the machine

Protective equipment: ■ Working clothes  
■ Safety shoes  
■ Protective gloves

1. Park the machine safely ↗ *Chapter 6.4 „Parking the machine in secured condition“ on page 57.*
2. Unscrew the four fastening screws (1) and remove the cover (2).




Fig. 94




Fig. 95

3.



**NOTICE!**

**Inadequate lubrication will cause damage to components!**

- Use only grease of the permitted specification.  
(Spare parts number of lubrication grease: DL 009 960 17)

Grease the mechanical parts between the fork head (1), lever (2) and bolt (3).

4. Fasten the cover (2) with four fastening screws, tightening torque: 10 Nm (7.5 ft·lbf).





Fig. 96

## **8.10 Every 2 years / every 500 operating hours**


### **8.10.1 Changing the hydraulic oil**

Protective equipment: ■ Working clothes  
■ Protective gloves


1. Park the machine in secured condition ↗ *Chapter 6.4 „Parking the machine in secured condition“ on page 57.*
2. Adjust the steering rod with height adjustment so that the area with the filler screw is horizontal.
3. Unscrew the filler screw.



*Fig. 97*



*Fig. 98*



*Fig. 99*

4. Press the handle forward against the stop and secure it using suitable means.
5. Unscrew the bleeding screw and collect any oil running out.
6. Screw in the bleeding screw.

## Maintenance – Every 2 years / every 500 operating hours




Fig. 100




Fig. 101




Fig. 102




Fig. 103

7.



### NOTICE!

Components may get damaged!

- Use only oil of the permitted specification.

Fill in hydraulic oil up to the mark on the steering rod head.

**Mark:** approx. 40 mm (1.6 in) below the filler opening

8.

Slacken the bleeding screw.

9.

Wait until all air has escaped and then tighten the bleeding screw.

10.

Fill in hydraulic oil up to the mark on the steering rod head.

11.

Screw in the filler screw.

12.

Dispose of oil in an environmentally friendly way.

## 8.11 As required

### 8.11.1 Cleaning the machine

Protective equipment: ■ Working clothes  
■ Safety shoes  
■ Protective gloves

1. Park the machine safely ↗ Chapter 6.4 „Parking the machine in secured condition“ on page 57.
2. Allow the engine to cool down for at least 30 minutes.




Fig. 104: Cleaning the machine (example)



#### NOTICE!

**Electric components can be damaged by water entering into the system!**

- Do not guide the water jet directly into the openings of the crank handle, into the air filter or onto electrical equipment.

Clean the machine from the outside and inside with a water jet.

4. Warm up the engine for a while to avoid corrosion.

### 8.11.2 Cleaning the cooling fins and the cooling air intake openings



*How dirty the cooling fins and cooling air intake openings are depends very much on the daily operating conditions; clean daily if necessary.*

Protective equipment: ■ Working clothes  
■ Protective gloves  
■ Safety goggles

1. Park the machine in secured condition ↗ Chapter 6.4 „Parking the machine in secured condition“ on page 57.
2. Allow the engine to cool down.
3. Remove dried dirt with a suitable brush from all cooling fins and cooling air intake openings.




Fig. 105



#### CAUTION!

**Danger of eye injuries caused by particles flying around!**

- Wear your personal protective equipment (safety gloves, protective working clothes, goggles).

Blow out the cooling fins and cooling air intake openings with compressed air.

## Maintenance – As required

5. In case of damp or oily contamination you should consult our customer service department.

## 8.11.3 Servicing the V-belt

### Preparations

Protective equipment: ■ Working clothes  
■ Protective gloves

1. Park the machine in secured condition ↗ *Chapter 6.4 „Parking the machine in secured condition“ on page 57.*
2. Allow the engine to cool down.
3. Unscrew the V-belt guard (1).




Fig. 106

### Checking the V-belt




Fig. 107

1. Check condition and tension of V-belt.  
⇒ **Compression measurement:** 15 - 20 mm (0.6 - 0.8 in).
2. Tension the V-belt if the compression measurement is exceeded.
3. Replace the V-belt if damaged ↗ *Chapter 8.9.1 „Replacing the V-belt“ on page 78.*

### Tightening the V-belt




Fig. 108

1. Loosen the threaded pins.




Fig. 109

2. Turn the outer V-belt pulley with the suitable tool, until the required belt tension is achieved.



*Counter the inner V-belt pulley with a suitable tool.*

3. Retighten the threaded pins, tightening torque: 10 Nm (7.4 ft·lbf).

### Concluding work




Fig. 110

1. Fasten the V-belt guard (1).

### 8.11.4 Checking the oil level in the exciter housing



#### NOTICE!

#### Components may get damaged!

- Use only oil of the permitted specification  
↳ Chapter 8.4 „List of fuels and lubricants“ on page 71.
- Do not use low-ash engine oils for the exciter shaft housing.

Protective equipment: ■ Working clothes  
■ Safety shoes  
■ Protective gloves

1. Park the machine on level ground.
2. Park the machine safely ↳ Chapter 6.4 „Parking the machine in secured condition“ on page 57.
3. Allow the machine to cool down.




Fig. 111

4. Clean the area around the bleeding screw (1) and filling/drain plug (2).
5. Unscrew the bleeding screw.
6. Unscrew the filling/drain plug and check the oil level; top up if necessary.  
⇒ **Nominal value:** Bottom edge of filling/drain bore.
7. Clean the bleed screw and filling/drain plug and screw them in with a low-strength sealing agent (e.g. spare parts number: DL 009 700 16).

### 8.11.5 Measures prior to extended shut-down period

#### 8.11.5.1 Measures before shutting down

If the machine is shut down for a longer period of time, e.g. winter season, the following work must be carried out:

1. Clean the machine thoroughly.
2. Clean the water separator.
3. Fill the fuel tank with diesel fuel, to prevent the formation of condensation water in the tank.
4. Change engine oil and oil filter if the oil change had been carried out more than 300 operating hours ago.
5. Change the fuel filter.
6. After shutting down store the machine under cover in a dry and well ventilated room.
7. Protect the cooled down engine against dust and moisture.

#### 8.11.5.2 Battery service during prolonged machine downtimes



#### **WARNING!**

**Danger of injury caused by exploding gas mixture!**

- Remove the plugs before starting to recharge the battery.
- Ensure adequate ventilation.
- Smoking and open fire is prohibited!
- Do not lay any tools or other metal objects on the battery.
- Do not wear jewellery (watch, bracelets, etc.) when working on the battery.
- Wear your personal protective equipment (protective gloves, protective clothing, goggles).

Protective equipment: ■ Working clothes  
■ Protective gloves  
■ Safety goggles

1. Switch off all consuming devices (e.g. ignition, light).
2. Measure the open-circuit voltage of the battery at regular intervals (at least 1 x per month).  
⇒ Reference values: 12.6 V = fully charged; 12.3 V = discharged to 50%.
3. Recharge the battery immediately after an open-circuit voltage of 12.25 V or less is reached. Do not perform boost charging.  
⇒ The open-circuit voltage of the battery occurs approx. 10 hours after the last charging process or one hour after the last discharge.
4. Switch off the charging current before removing the charging clamps.
5. After each charging process allow the battery to rest for one hour before taking it into service.
6. For standstill periods of more than one month you should always disconnect the battery. Do not forget to perform regular open-circuit voltage measurements.

### 8.11.5.3 Measures before restarting

1. Replace the fuel filter.
2. Replace the air filter.
3. Change the engine oil and clean the oil filter.
4. Check cables, hoses and lines for cracks and leaks.
5. Start the engine and run it for 15 to 30 minutes with idle speed.
6. Check the oil levels.
7. Clean the machine thoroughly.



### 9.1 Preliminary remarks

Malfunctions are frequently caused by incorrect operation of the machine or insufficient maintenance. Whenever a fault occurs you should therefore thoroughly read these instructions on correct operation and maintenance.

If you cannot locate the cause of a fault or rectify it yourself by following the trouble shooting chart, you should contact our customer service department.

### 9.2 Emergency starting with crank handle



*Start the engine with the crank handle only if the battery is defective, empty or missing.*



*Optional equipment*

Exhaust fumes contain toxic substances and can damage your health, cause unconsciousness or even death.



#### **WARNING!**

##### **Danger of poisoning by exhaust gases!**

- Do not inhale exhaust gases.
- Avoid operation in closed or partly closed rooms, or ensure adequate ventilation when working in trenches.



#### **WARNING!**

##### **Loss of hearing caused by too high noise burdens!**

- Wear your personal protective equipment (ear protection).

Protective equipment:

- Working clothes
- Hearing protection
- Safety shoes




Fig. 112

1. Set the throttle lever to position "MIN".

## Troubleshooting – Emergency starting with crank handle




Fig. 113

2. Set the handle to position "0".




Fig. 114

3. Turn the ignition key to position "I".  
⇒ The warning buzzer does not sound.



*With the ignition key in position "I" the battery is charged when the engine is running, as long as the battery voltage is at least 9 V.*




Fig. 115

4. Pull the decompression lever in direction of arrow to the end stop.  
⇒ The decompression lever clicks noticeably into place.




Fig. 116

5. Open the cover.
6. Remove the crank handle from the bracket and insert it.
7. Stand in the correct position parallel to the machine.

## Troubleshooting – Emergency starting with crank handle




Fig. 117

8. Grip the crank handle with both hands as shown.
9. Turn the crank handle with both hands slowly in the direction of the arrow until it engages.



### CAUTION!

**Danger of injury caused by uncontrolled machine movement!**

- Always hold on to a running machine.
- Always keep an eye on a running machine.

10. Then turn the crank handle with increasing speed, until the engine starts.



*Ensure a positive connection between crank handle and engine by turning it quickly.*

*Do not interrupt the starting process under any circumstances.*

*When the decompression lever closes and engages (after five revolutions), the highest speed must be reached.*

11. As soon as the engine starts, pull out the crank handle.
12. If the engine does not start during the first attempt, repeat the starting process.
  - ⇒ Always open the decompression lever when repeating the starting procedure.



### NOTICE!

**Danger of engine damage!**

- Warm up engine for a short while before starting work. Do not operate the engine immediately under full load.




Fig. 118

13. Hook the crank handle into the bracket.
14. Close the cover.



### NOTICE!

**Danger of engine damage!**

- Warm up engine for a short while before starting work. Do not operate the engine immediately under full load.

### 9.3 Starting the engine with jump leads



#### NOTICE!

**A wrong connection will cause severe damage in the electric system.**

- Bridge the machine only with a 12 Volt auxiliary battery.




Fig. 119

1. Open the protection hood and secure it to prevent unintended closing.
2. Remove the bracket of the battery.
3. First connect the plus pole of the external battery to the plus pole of the starter battery using the first jump lead.
4. Next, connect the second jump lead to the minus pole of the energizing external battery and then to the minus pole of the starter battery.
5. Start the engine ↪ *Chapter 6.2 „Starting the engine“ on page 53.*
6. After starting disconnect the minus poles first and the plus poles after.
7. Install the bracket of the battery.
8. Close the protection hood.

### 9.4 Fuse assignment

**WARNING!**

**Danger of injury by fire in the machine!**

- Do not use fuses with higher ampere ratings and do not bridge fuses.




Fig. 120

Pos.	Amperage	Designation
1	25 A	Main fuse

## Troubleshooting – Engine malfunctions

### 9.5 Engine malfunctions

Fault	Possible cause	Remedy
The engine is hard to start or does not start at all	Fuel tank empty	Check the fuel level, top up if necessary
	Fuel filter clogged	Check the fuel filter, replace if necessary
	Fuel lines leaking	Check the fuel lines
	The fuel shut-off valve has triggered automatically	Check the engine oil level, top up if necessary. Check the fuel level, top up if necessary. If necessary, check other causes for triggering. Bleed the fuel system by means of the ventilation lever on the fuel shut-off valve.
	Incorrect valve clearance	Check the valve clearance, adjust if necessary
	Wear on cylinder or piston rings	Have it checked by qualified expert personnel
	Injection nozzle out of order	Have it checked by qualified expert personnel
Engine does not start or starts poorly at low temperatures	Fuel filter clogged by paraffin separation	Change the fuel filter, use winter fuel
	Engine oil with wrong SAE viscosity class	Changing the engine oil
	Insufficiently charged battery	Check the battery, charge if necessary
Engine ignites, but does not run	Fuel filter clogged	Check the fuel filter, replace if necessary
The starter does not switch on or the engine does not crank.	Main fuse broken	Replace main fuse
	Battery or other cables not connected correctly	Check
	Battery defective or not charged	Check the battery, charge or replace if necessary
	Starter defective	Replace the starter
Engine stops	Fuel tank empty	Check the fuel level, top up if necessary
	Fuel filter clogged	Replacing the fuel filter
	Tank ventilation blocked	Ensure sufficient ventilation of the tank
	Air in the fuel system	Check the fuel system for air entry. Check the ventilation valve.

## Troubleshooting – Engine malfunctions

Fault	Possible cause	Remedy
	The fuel shut-off valve has triggered automatically	Check the engine oil level, top up if necessary. Check the fuel level, top up if necessary. If necessary, check other causes for triggering. Bleed the fuel system by means of the ventilation lever on the fuel shut-off valve.
	Mechanical defect	Have checked by qualified expert personnel.
Engine loses power and speed	Fuel tank empty	Check the fuel level, top up if necessary
	Fuel system clogged	Replacing the fuel filter
	Tank ventilation blocked	Ensure sufficient ventilation of the tank
	Air in the fuel system	Check the fuel system for air entry. Check the ventilation valve.
	Too much oil in exciter housing.	Drain the oil from the exciter housing
Engine loses power and speed, black exhaust smoke	Air filter dirty	Clean the air filter, replace if necessary.
	Incorrect valve clearance	Check the valve clearance, adjust if necessary
	Injection nozzle out of order	Have it checked by qualified expert personnel
Engine overheats	Engine oil level too high	Check the engine oil level, drain off engine oil if necessary
	Air filter dirty	Clean the air filter, replace if necessary.
	Lack of cooling air	Clean the cooling fins and the cooling air intake openings. Check air guide plates and ducts for completeness and good sealing.
Engine runs with high speed, but no vibration	Centrifugal clutch defective	Have it checked by qualified expert personnel
	V-belt torn	Replacing the V-belt

### 9.6 Malfunctions during operation

Fault	Possible cause	Remedy
The machines vibrates forward with a strongly reduced speed	Air in the hydraulic system of the steering rod	Release pressure from the steering rod
	The oil level in the exciter shaft housing is too high	Check the oil level in the exciter shaft housing

#### Release pressure from the steering rod




Fig. 121

Protective equipment: ■ Protective gloves

1. Park the machine in secured condition Chapter 6.4 „Parking the machine in secured condition“ on page 57.
2. Press the handle forward against the end stop and hold it in this position.
3. Carefully loosen the filler screw (1).  
⇒ The air makes a slight hissing sound when escaping.
4. Wait until all air has escaped and then tighten the filler screw.



### 10.1 Final shut-down of machine

If the machine can no longer be used and needs to be finally shut down you must carry out the following work and have the machine disassembled by an officially recognized specialist workshop.



#### **WARNING!**

##### **Health hazard caused by fuels and lubricants!**

- Safety regulations and environmental protection regulations must be followed when handling fuels and lubricants → *Chapter 3.4 „Handling fuels and lubricants“ on page 23.*

Protective equipment:

- Working clothes
- Safety shoes
- Protective gloves
- Safety goggles

1. Remove the batteries and dispose of in compliance with legal regulations.
2. Empty the fuel tank.
3. Drain engine oil from engine and exciter housing.
4. Drain off hydraulic oil.



