


DYNAPAC
CP142
SPARE PARTS
CATALOGUE
SCP142-1EN3



DYNAPAC

Rua Georg Schaeffler, 430, Sorocaba/SP, Brasil
Phone: +55 (15) 3011-8800, Fax: +55 (15) 3011-8849
www.dynapac.com

Pneumatic Tire Roller CP142

Spare Parts Catalogue SCP142-1EN3

*Valid from roller serial number: *2163BR3000* -*

Diesel engines: CUMMINS QSB 3.3

Published catalogue issues valid for these rollers:

<i>Catalogue</i>	<i>Issue date</i>	<i>Valid for serial numbers</i>
<i>SCP142-1EN0.5</i>	<i>2004-06</i>	<i>Replaced by SCP142-1EN1</i>
<i>SCP142-1EN1</i>	<i>2004-07</i>	<i>Replaced by SCP142-1EN2</i>
<i>SCP142-1EN2</i>	<i>2005-05</i>	<i>Replaced by SCP142-1EN3</i>
<i>SCP142-1EN3</i>	<i>2010-01</i>	<i>* 2163BR3000* -</i>



RESERVDELSBESTÄLLNING

Följande uppgifter ska lämnas vid beställning av reservdelar för att undvika leveransfel:

1. Maskintyp.
2. Vältensserienummer.
3. Antal av önskad reservdel.
4. Reserdelens artikelnummer.
5. Reservdelens benämning.
6. Måttuppgifter vid beställning av metervara.

ORDERING SPARE PARTS

To avoid errors in delivery, please give the following information when ordering spare parts:

1. Type of machine.
2. Roller serial number.
3. Quantity required.
4. Part number.
5. Parts denomination.
6. Dimensions when ordering per length.

ERSATZTEILBESTELLUNG

Zur Vermeidung von Fehllieferungen sind bei der Bestellung von Ersatzteilen folgende Angaben zu machen:

1. Maschinentyp.
2. Herstellungsnummer.
3. Bestellmenge. (Quantity)
4. Ersatzteilnummer. (Part N°)
5. Ersatzteilbenennung. (Denomination)
6. Massangaben bei Bestellung von Meterware.

ORDINI DI RICAMBI

Per evitare errori nelle consegne di ricambi, Vi preghiamo di comunicarci le seguenti informazioni al momento dell'ordinazione:

1. Tipo di macchina.
2. Numero di serie della macchina.
3. Quantità dei pezzi desiderati. (Quantity)
4. Numero di codice del pezzo. (Part N°)
5. Descrizione del pezzo di ricambio. (Denomination)
6. Misura, in caso di ordine per metro.

PEDIDO DE RECAMBIOS

Para evitar errores en las entregas, deberán indicarse los siguientes datos al hacer un pedido de recambios:

1. Tipo de máquina.
2. Número de serie.
3. Cantidad de piezas deseadas. (Quantity)
4. Número de artículo de la pieza de recambio. (Part N°)
5. Denominación de la pieza. (Denomination)
6. Indíquese la medida al solicitar un artículo que se expide por metros.

COMMANDE DE PIÉCES DE RECHANGE

Les indications suivantes doivent être fournies lors de la commande de pièces de rechange, afin d'éviter toute erreur de livraison:

1. Type de machine.
2. Numéro de série.
3. Quantité désirée de pièce de rechange. (Quantity)
4. Numéro de la pièce de rechange. (Part N°)
5. Dénomination de la pièce de rechange. (Denomination)
6. Longueur en cas de commande au mètre.

YOUR AGENT/DEALER:

The text pages is structured as the picture on the right.

- | DYNAPAC | | Metso Dynapac AB | |
|----------------|----------|------------------|----------------------|
| Cooling system | | | |
| Ref. No. | Part No. | Rem. | Qty Description Code |
| 1 | 223047 | | 1 Water cooler ③ C |
| 2 | 935852 | | 1 Radiator cap D |
| 3 | 935851 | ① | ② Cock |
| 4 | 373263 | A | 1 Radiator hose D |
| 5 | 313009 | | 6 Clamp |
| 6 | 205058 | B | 1XL Rubber cloth |
| 7 | 373261 | C | 1 Radiator hose D |
| 8 | | | 1 Oil cooler D |
| 9 | 223289 | | 1 Plate |
| 10 | 902166 | D | 1XL Edge trim |
| 11 | 223287 | E | 1 Holder |
| 12 | 223288 | F | 1 Holder |
| 13 | 908168 | | 1 Fan guard |
| 14 | 908170 | | 1 Fan shroud |
| 15 | 908171 | | 2 Mounting bar |
| 16 | 908169 | | 1 Fan guard |
| 17 | 500021 | | 14 Screw |
| 18 | 902286 | | 14 Nut |
| 19 | 600006 | | 14 Washer |
| 20 | 313102 | | 2 Cable strap |
- A) Upper
 B) L=060MM
 C) Lower
 D) L=2280MM
 E) Left
 F) Right

[illegible]

Notes

Notes

[illegible]

PÄRMETIKETT

För att undvika fel vid reservdelsbeställning finns här nedan två etiketter som passar i fickorna på pärmarnas ryggar. På dessa kan man se från vilket vältnummer av aktuell maskin reservdelskatalogen gäller. Gör så här:

1. Tag denna sida ur pärmen.
2. Klipp ut etiketten till **VÄNSTER** (1) och sätt in den i fickan på **DENNA** pärmens rygg.
3. Finns det en etikett till **HÖGER** (2), kan denna användas på pärmen för **FÖREGÅENDE** utgåva av denna katalog.
4. Kasta detta papper.

KATALOG-BESCHRIFTUNG

Zur Vermeidung von Fehlern bei der Ersatzteilbestellung benutzen Sie bitte die unteren Beschriftungen, um die Kataloge auf der Rückseite zu kennzeichnen. Auf der Beschriftung ist angegeben, für welche Maschinennummern der jeweilige Katalog gültig ist. Ablauf:

1. Nehmen Sie dieses Blatt aus dem Katalog.
2. Schneiden Sie die **LINKE** Beschriftung (1) aus. Schieben Sie die Beschriftung in die tasche auf **DEM** Katalogrücke.
3. Sollte die Beschriftung unten **RECHTS** (2) mitgeliefert werden, kennzeichnen Sie damit bitte die **ÄLTERE** Ausführung dieses Kataloges.
4. Den Rest dieses Blattes bitte vernichten.

ETIQUETA PARA LA CARPETA

Para evitar errores al pedir repuestos utilicen las etiquetas abajo descritas para identificar los catálogos en la parte trasera de la carpeta. En la etiqueta se ven los números de referencia de la serie para la cual es válido el catálogo. Instrucciones:

1. Quitar esta página de la carpeta.
2. Corta la etiqueta **IZQUIERDA** (1) y ponerla en **ESTA** carpeta en la parte trasera.
3. Si hay una etiqueta en la parte **DERECHA** (2) se puede utilizar en la carpeta para el catálogo que **PRECEDE** a esta.
4. Tirar esta hoja.

BINDER LABEL

To avoid errors when ordering spare parts use the labels below to identify the catalogues on the back of the binder. The label contain the serial number range for which the catalogue is valid. Do like this:

1. Remove this page from the binder.
2. Cut out the **LEFT** label (1) and put it on **THIS** binders back.
3. If there is a label to the **RIGHT** (2), it can be used on the binder for **PRECEDING** issue of this catalogue.
4. Throw away this paper.

ETICHETTAPOSTASULRACCOGLITORE

Per evitare errori quando ordinate pezzi di ricambio, usate le etichette in calce che servono ad identificare i cataloghi sul retro del raccoglitore. L'etichetta indica il numero di matricola delle macchine prese in considerazione nel catalogo.

1. Rimuovete questa pagina dal raccoglitore.
2. Ritagliate l'etichetta posta a **SINISTRA** (1) e ponetela sul retro **DEL** raccoglitore.
3. Se trovate anche un'etichetta sulla **DESTRA** (2), ritagliatela e ponetela sul raccoglitore relativo alla **PRECEDENTE** edizione del catalogo.
4. Distruggete questo foglio.

ETIQUETAGE DU CATALOGUE

Afin d'éviter des erreurs lors de commandes de pièces de rechange, nous vous conseillons d'apposer les marquages ci-dessous à l'arrière du classeur, pour identifier les catalogues. Ce marquage indique les numéros de série pour lesquels le catalogue est adapté. Il convient de procéder de la façon suivante:

1. Retirez cette page du classeur.
2. Découpez l'étiquette de **GAUCHE** (1), et apposez-la à l'arrière de **CE** catalogue.
3. Si il y a une étiquette à **DROITE** (2), vous pourrez l'apposer sur le classeur de l'édition **PRECEDENTE** du catalogue.
4. Détruire cette feuille.

1.



TABLE OF CONTENTS

Page

CP142 Tier3 SN 2163BR3000	2
Service kits	4
4812100391 Service kit, Cummins 50 h	6
4812100392 Service kit, Cummins 250 h	8
Frame	10
Frame and Ballast	12
Hood and covers	14
Scrapers	16
Scrapers and mat	18
Sprinkler system one pump	20
Sprinkler system two pumps	22
Suspension	26
Front suspension	28
Rear Suspension	30
Wheel	32
Engine	34
Engine filters	36
Engine module	38
Engine module	40
Cooling system	42
Air cleaner	44
Fuel system	46
Exhaust system	48
Hydraulic system	50
Propulsion system	52
Hydraulic oil tank	54
Hydraulic filters	56
Drain system	58
Speed system	60
Hydraulic steering	62
Electrical equipment	64
Electrical equipment	66
Driving lights	70
Working lights	72
Drivers platform	74
Drivers platform	76
Handrail	78
Drivers seat	80
Forward and reverse control handle	82
Decals	84
Decals	86
Standard equipment	88
Standard equipment	90
Optional equipment	92
Canopy	94
Rotating beacon	96
Tool equipment	98

CP142 Tier3 SN 2163BR3000

CP142 Tier3 SN 2163BR3000

Item	Part No	Rem Qty	Description	Code
5		1	Service kits (Page 4)	
10		1	Frame (Page 10)	
20		1	Suspension (Page 26)	
30		1	Engine (Page 34)	
50		1	Hydraulic system (Page 50)	
60		1	Electrical equipment (Page 64)	
70		1	Drivers platform (Page 74)	
80		1	Decals (Page 84)	
90		1	Standard equipment (Page 88)	
91		1	Optional equipment (Page 92)	


Service kits

Service kits

Item	Part No	Rem Qty	Description	Code
10	4812100391	1	Service kit, Cummins (Page 6)	50 h
20	4812100392	1	Service kit, Cummins (Page 8)	250 h

4812100391 Service kit, Cummins 50 h

4812100391




4812100391 Service kit, Cummins 50 h

Item	Part No	Rem Qty	Description	Code
1	4700939068	1	Oil filter	
2	4700950302	1	Fuel filter	
3	950301	1	Pre-fuel filter	
4	372229	2	Hydraulic oil filter element	

4812100392 Service kit, Cummins 250 h

4812100392



4812100392 Service kit, Cummins 250 h


Item	Part No	Rem Qty	Description	Code
1	4700939068	1	Oil filter	
2	4700950302	1	Fuel filter	
3	950301	1	Pre-fuel filter	

Frame

Frame

Item	Part No	Rem Qty	Description	Code
10		1	Frame and Ballast (Page 12)	
15		1	Hood and covers (Page 14)	
20		1	Scrapers (Page 16)	
25		1	Scrapers and mat (Page 18)	
30		1	Sprinkler system one pump (Page 20)	
35		1	Sprinkler system two pumps (Page 22)	

Frame and Ballast
CP142100100010




Frame and Ballast

Item	Part No	Rem	Qty	Description	Code
1	388896		1	Frame	
5	193591		8	Scraper	
6	904559		16	Washer	25x45x8
7	570016		8	Nut	M24
8	388939	A	2	Step	
9	193557	B	6	Ballast box	
10	193580		8	Plate	
11	904232		16	Washer	17x30x3
12	500134		16	Screw	M16x60

A) Only in use together with 6 or less ballast boxes

B) STD = 6 ballast boxes, Option = 8 ballast boxes


Hood and covers
CP142200100015



Hood and covers

Item	Part No	Rem Qty	Description	Code
1	170618	1	Guard, right	
2	170619	1	Guard, left	
3	388910	1	Grid, left	
4	388921	1	Grid, right	
5	170617	1	Engine hood	
6	170621	1	Cover	
7	198096	1	Catch	
8	928041	2	Hinge	
9	170654	2	Shim	
10	170620	1	Cover	
11	388932	1	Cover	
12	904230	12	Washer	M10 10,5x22x2
13	500027	10	Screw	M10-1,55x22 8.8
14	513008	4	Screw	M6 X 016H 10.9
15	202056	NC	Edge trim	
16	202056	NC	Edge trim	
17	202056	NC	Edge trim	
18	904640	23	Washer	M08-8,4x22x3
19	500021	23	Screw	M8-1,25x25 8.8
20	570005	2	Hexagon nut	M8-1,25 8
21	500505	1	Screw	M8x20 8.8
22	499162	1	Wing screw	
23	904639	6	Washer	6,7x14x1,5
24	500014	6	Screw	M6x22H 8.8
25	904228	6	Washer	M6-6,4x12x1,5
26	570004	6	Hexagon nut	M6
27	902166	1	Edge trim	
28	4812100297	1	Pawl	
29	904874	1	Grab handle	
30	902166	NC	Edge trim	
31	902166	NC	Edge trim	
32	902166	NC	Edge trim	
33	902166	NC	Edge trim	
34	902166	NC	Edge trim	
35	902166	NC	Edge trim	
36	4812100308	1	Threaded plate	
37	500013	2	Screw	M6-1x16 8.8
38	4812100306	1	Lock	
39	904557	2	Washer	10,5x22x4
40	586018	2	Lock nut	M10
41	500030	2	Screw	M10-1,5x35 8.8
42	4812100348	1	Safe locking	
43	904229	8	Washer	M8-8,4x16x1,5
44	586003	3	Lock nut	M8
45	500068	2	Screw	M8X65 8.8
46	4812100299	1	Safe lock	

Scrapers
16140




Scrapers

Item	Part No	Rem	Qty	Description	Code
1	193590		9	Bracket	
2	193591		9	Scraper	
3	194149		5	Bracket	
4	194080	A	5	Bracket	
5	194092	B	23	Retaining ring	
	152001	C	23	Retaining ring	
6	500046		8	Screw	M12x30H 8,8 FZB
7	600009		14	Washer	
8	194079		2	Bearing housing	
9	500047		18	Screw	M8-1,25x35 8.8
10	600006		36	Washer	8,4x17x1,6
11	586003		18	Lock nut	M8
12	194083		1	Shaft	
13	629019		2	Expanding pin	
14	500046		2	Screw	M12x30H 8,8 FZB
15	194082		1	Lock	
16	194081	A	1	Lever	
17	192828		1	Handle	
18	193592		2	Bracket	
19	570007		4	Hexagon nut	
20	194150		4	Bracket	
21	194018		4	Bracket	
22	570006		4	Hexagon nut	M10-1,5 8.
23	252793		4	Bushing	
24	600008		16	Washer	
25	500030		4	Screw	M10-1,5x35 8.8
26	194078		4	Hook	
27	630008		8	Cotter pin	
28	251729		4	Shaft	

- A) New design has grooves and is used together with 152001, item 5
 B) In use together with the old design of item 4 and 16, which doesn't have any grooves
 C) Only in use together with the new design of item 4 and 16

Scrapers and mat
16141




Scrapers and mat

Item	Part No	Rem	Qty	Description	Code
1	193590		18	Bracket	
2	193591		18	Scraper	
3	194019		5	Bracket	
4	194080	A	5	Bracket	
5	194092	B	23	Retaining ring	
	152001	C	23	Retaining ring	
6	500046		8	Screw	M12x30H 8,8 FZB
7	600009		14	Washer	
8	194079		2	Bearing housing	
9	500047		36	Screw	M8-1,25x35 8.8
10	600006		72	Washer	8,4x17x1,6
11	586003		36	Lock nut	M8
12	194083		1	Shaft	
13	629019		2	Expanding pin	
14	500046		2	Screw	M12x30H 8,8 FZB
15	194082		1	Lock	
16	194081	A	1	Lever	
17	192828		1	Handle	
18	193592		2	Bracket	
19	570007		4	Hexagon nut	
20	193586		4	Bracket	
21	194018		4	Bracket	
22	570006		4	Hexagon nut	M10-1,5 8.
23	252793		4	Bushing	
24	600008		16	Washer	
25	500030		4	Screw	M10-1,5x35 8.8
26	194078		4	Hook	
27	630008		8	Cotter pin	
28	251729		4	Shaft	
29	313041		72	Cable ties	L=186mm
30	193600		9	Mat	

- A) New design has grooves and is used together with 152001, item 5
 B) In use together with the old design of item 4 and 16, which doesn't have any grooves
 C) Only in use together with the new design of item 4 and 16

Sprinkler system one pump
CP142100100030




Sprinkler system one pump

Item	Part No	Rem	Qty	Description	Code
1	333228		1	Cap	
2	358846		1	Strainer	
3	194093		1	O-ring	
4	193571		2	Clamp	
5	297018	A	1	Rubber strip	
6	193472		1	Tank	
7	813422		1	Plug	
8	375569		1	Nipple	
9	904501		1	Ball valve	
10	313002		26	Hose clamp	
11	904502		1	Connection	
12	244054	B	N	Hose reinforced	0,66M
13	923734		2	Hose connection	
	923734		2	Hose connection Up to 2163BR2341	
	904926		2	Hose connector From 2163BR2342	
14	248491		2	Reducing nipple Up to 2163BR2341	
15	927568		2	Clamp Up to 2163BR2341	
	374584	K	2	Spacer Up to 2163BR2341	
16	570004		2	Hexagon nut Up to 2163BR2341	M6
17	248513		1	Water filter	
	393272		1	Water filter From 2163BR2342	
	500189		2	Screw From 2163BR2342	
18	500075		2	Screw Up to 2163BR2341	M6-1x25 8.8
19	380784		1	Bracket Up to 2163BR2341	
	199475		1	Bracket From 2163BR2342	
20	904698		2	Washer	4,3x8x0,8
21	500002		2	Screw	M4-0,7x12H 8.8
22	506019		4	Lock nut	
23	904231		4	Washer	13x24x2
24	244054	C	N	Hose reinforced	0,66M
25	500075		2	Screw	M6-1x25 8.8
26	383697		1	Water pump	
27	904228		4	Washer	M6-6,4x12x1,5
28	570004		2	Hexagon nut	M6
29	901432		2	Hose connection	
30	287713		1	Solenoid valve	
31	194088		2	Tee-connector	
32	194087		2	Plug	
33	244054	D	N	Hose reinforced	0,66M
34	194018		9	Bracket	
35	194085		6	Sprinkler	
36	244054	E	N	Hose reinforced	0,66M
37	901175		3	Nozzle body	
38	244054	F	N	Hose reinforced	0,66M
39	244054	G	N	Hose reinforced	0,66M
40	903541		9	Strainer with valve	
41	904116		9	Gasket	
42	923679		9	Nozzle	
43	923681		9	Quick Coupling, black	
44	244054	H	N	Hose reinforced	0,66M
45	313041		7	Cable ties	L=186mm

- A) L= 4,33 m
 B) L= 900 mm
 C) L= 180 mm
 D) L= 3,5 m
 E) L= 2,22 m
 F) L= 65,00 mm
 G) L= 290 mm
 H) L= 1,5 m
 K) L= Not illustrated

Sprinkler system two pumps
CP142100100040




Sprinkler system two pumps

Item	Part No	Rem	Qty	Description	Code
1	333228		1	Cap	
2	358846		1	Strainer	
3	194093		1	O-ring	
4	193571		2	Clamp	
5	297018	A	1	Rubber strip	
6	193472		1	Tank	
7	813422		1	Plug	
8	375569		1	Nipple	
9	904501		1	Ball valve	
10	313002		36	Hose clamp	
11	904502		1	Connection	
12	244054	B	N	Hose reinforced	0,66M
13	923734		6	Hose connection	
14	248491		2	Reducing nipple	
15	927568		2	Clamp	
	374584	P	2	Spacer	
16	570004		2	Hexagon nut	M6
17	248513		1	Water filter	
18	500075		2	Screw	M6-1x25 8.8
19	380784		1	Bracket	
20	904698		2	Washer	4,3x8x0,8
21	500002		2	Screw	M4-0,7x12H 8.8
22	506019		4	Lock nut	
23	904231		4	Washer	13x24x2
24	244054	C	N	Hose reinforced	0,66M
25	500075		4	Screw	M6-1x25 8.8
26	383697		2	Water pump	
27	904228		6	Washer	M6-6,4x12x1,5
28	570004		4	Hexagon nut	M6
29	901432		2	Hose connection	
30	287713		1	Solenoid valve	
	384326		1	Cable harness	
31	194088		4	Tee-connector	
32	194087		4	Plug	
33	244054	D	N	Hose reinforced	0,66M
34	194018		9	Bracket	
35	194085		6	Sprinkler	
36	244054	E	N	Hose reinforced	0,66M
37	901175		3	Nozzle body	
38	244054	F	N	Hose reinforced	0,66M
39	244054	G	N	Hose reinforced	0,66M
40	903541		9	Strainer with valve	
41	904116		9	Gasket	
42	923679		9	Nozzle	
43	923681		9	Quick Coupling, black	
44	244054	H	N	Hose reinforced	0,66M
45	313041		7	Cable ties	L=186mm
46	244054	I	N	Hose reinforced	0,66M

- A) L= 4,33 m
- B) L= 900 mm
- C) L= 180 mm
- D) L= 3,5 m
- E) L= 2,22 m
- F) L= 65 mm
- G) L= 290 mm
- H) L= 1,5 m
- I) L= 100 mm
- P) Not illustrated

Sprinkler system two pumps
CP142100100040



Sprinkler system two pumps

Item	Part No	Rem	Qty	Description	Code
47	244054	J	N	Hose reinforced	0,66M
48	244054	K	N	Hose reinforced	0,66M
49	380785		1	Bracket	
50	244054	Q	N	Hose reinforced	0,66M
J)	L= 230 mm				
K)	L= 250mm				
Q)	L= 400 mm				


Suspension

Suspension

Item	Part No	Rem Qty	Description	Code
10		1	Front suspension (Page 28)	
15		1	Rear Suspension (Page 30)	
20		1	Wheel (Page 32)	

Front suspension


CP142100200015



Front suspension

Item	Part No	Rem Qty	Description	Code
1	500082	44	Screw	M16x70
2	904232	44	Washer	17x30x3
3	192831	1	Bearing	
4	193487	1	Guide ring	
5	193512	1	Shaft	
6	310037	3	Grease nipple	
7	259211	1	Snap plate	
8	904231	2	Washer	13x24x2
9	500035	2	Screw	
10	193459	1	Front suspension	
11	264488	2	Shaft	
12	193513	2	Snap plate	
13	500075	19	Screw	M6-1x25 8.8
14	904228	19	Washer	M6-6,4x12x1,5
15	193520	2	Shaft	
16	264486	4	Spacer	
17	193521	5	Spacer	
18	928351	5	Seal ring	
19	116009	5	Bearing	
20	193469	5	Wheel nut	
21	193886	20	Screw	
22	630008	20	Cotter pin	
23	193887	20	Wheel lock Up to 2163BR2007	
	198195	20	Wheel lock From 2163BR2008	
24	192424	20	Wheel nut	
25	924696	5	Bearing	
26	193517	5	Spacer	
27	136010	5	Washer	
28	135010	5	Nut	
29	193465	5	Bearing cover	

Rear Suspension
CP142100200020




Rear Suspension

Item	Part No	Rem Qty	Description	Code
1	376123	2	Hydraulic motor	
	198247	2	Seal kit	
2	927479	20	Screw	
3	193467	2	Hub	
4		4	See section "Wheel"	
5	193573	2	Air hose	
6	921058	2	Clamp	
7	586002	2	Lock nut	M6
8	500185	2	Screw	
9	921058	2	Clamp	
10	193886	12	Screw	
11	194011	12	Nut	
12	193565	2	Spacer	
13	630008	12	Cotter pin	
14	193887	12	Wheel lock Up to 2163BR2007	
	198195	12	Weel lock From 2163BR2008	
15	192424	12	Wheel nut	
16	600011	20	Washer	17x30x3
17	195214	2	Valve	

Wheel

CP142100200030



Wheel

Item	Part No	Rem	Qty	Description	Code
1	376578		9	Wheel, cpl Up to 2163BR2007	
	198329		9	Wheel, cpl From 2163BR2008	
2	194308		1	. Rim	
	198330		1	. Rim From 2163BR2008	
4	194325		1	. Rim liner	
5	374474		1	. Inner tube	
6	194265	A	1	. Tyre	
7	195214		1	Valve	
A)	14 ply				



Engine

Engine

Item	Part No	Rem Qty	Description	Code
5		1	Engine filters (Page 36)	
10		1	Engine module (Page 38)	
15		1	Engine module (Page 40)	
20		1	Cooling system (Page 42)	
25		1	Air cleaner (Page 44)	
30		1	Fuel system (Page 46)	
35		1	Exhaust system (Page 48)	

Engine filters


CP142200300005



Engine filters

Item	Part No	Rem Qty	Description	Code
1	4700939068	1	Oil filter	
2	4700950302	1	Fuel filter	


Engine module
CP142200300010



Engine module

Item	Part No	Rem Qty	Description	Code
7	170599	1	Hydraulic pump bracket	
9	170632	2	Engine bracket	
10	170631	2	Engine bracket	
11	372983	2	Shock absorber	
12	370984	2	Shock absorber	
13	347512	4	Washer	
14	370258	2	Spacer washer	
15	500228	4	Screw	M20-2,5x120 8,8
16	586022	4	Lock nut	M20-8
17	904638	16	Washer	12x22x2
18	500194	10	Screw	M12x40
19	586019	8	Lock nut	M12-1,75 8.
25	904230	24	Washer	M10 10,5x22x2
26	500029	8	Screw	M10-1,5x30 8.8
27	904231	8	Washer	13x24x2
28	500046	8	Screw	M12x30H 8,8 FZB
29	500028	8	Screw	M10-1,5x25 8.8
30	904213	2	Washer	13x30x4
32	904637	12	Washer	10x18x2
33	508029	12	Screw	M10-1,5x30H 8,8
35	170695	1	Bracket	


Engine module
CP142200300011



Engine module

Item	Part No	Rem Qty	Description	Code
2	240154	1	Connector	
3	813435	1	Elbow 90G	
4	813422	1	Plug	
5	199491	1	Diesel engine	QSB3.3T3 CUMMINS
6	370229	1	Coupling	
7	950302	1	Fuel filter	
8	378205	1	Hydraulic pump	
20	170683	1	Fan adapter	
21	390047	1	Fan	
22	170633	1	Bracket	
23	384821	1	Connector	
24	384822	1	Connector	
25	904230	2	Washer	M10 10,5x22x2
29	500028	2	Screw	M10-1,5x25 8.8
31	500030	8	Screw	M10-1,5x35 8.8
34	170688	1	Bracket	
36	508006	4	Screw	M8x70 8.8
37	904230	4	Washer	M10 10,5x22x2
38	500029	4	Screw	M10-1,5x30 8.8
39	379480	1	Reducer	
40	4812100307	1	Thermal protection	
41	396543	1	Protection cover	
42	904228	2	Washer	M6-6,4x12x1,5
43	500012	2	Screw	M6-1,0x12 8.8
44	330333	1	Copper washer	
45	191808	1	Hose	
46	267465	1	Hollow screw	
47	330331	1	Seal gasket	18,2x23,9x1,5
48	904557	2	Washer	10,5x22x4
49	5086018	2	Lock nut	M10
50	500031	2	Screw	M10-1,5x40 8.8

Cooling system
CP142200300020




Cooling system

Item	Part No	Rem Qty	Description	Code
1	388922	1	Expansion tank	
2	903714	1	Cooler cup	
3	390524	2	Threaded plate	
4	904229	10	Washer	M8-8,4x16x1,5
5	500020	4	Screw	M8-1,25x22 8.8
6	199504	1	Cooler	
7	4812100301	2	Fan guard	
8	170655	1	Hose	
9	170656	1	Hose	
10	170643	1	Hose	
11	170644	1	Hose	
12	384822	1	Connector	
13	384821	1	Connector	
14	313022	4	Hose clamp	
15	904550	1	Hose connector	
16	198548	1	Hose	
17	198548	1	Hose	
18	500053	6	Screw	M8-1,25x20 8.8
19	313001	4	Hose clamp	
20	904557	4	Washer	10,5x22x4
21	500029	4	Screw	M10-1,5x30 8.8
22	313010	3	Hose clamp	
23	313008	1	Hose clamp	
24	205027	1	Hose	
25	313035	2	Hose clamp	
26	234958	1	Straight connector	
27	334156	1	Adapter	
28	234243	1	T-connector	
29	234667	1	Reducer	
30	334135	1	T-connection with nut	
31	334197	1	Elbow 90G with nut	

Air cleaner

CP142200300030




Air cleaner

Item	Part No	Rem Qty	Description	Code
1	392677	1	Air filter	
2	392088	1	Primary element	
3	392089	1	Secondary element	
4	170680	1	Hose	
5	170681	1	Hose	
6	313033	3	Hose clamp	
7	313038	1	Hose clamp	
8	170642	1	Tube	
9	170682	1	Rain cap	
10	390836	1	Pipe	
11	390835	1	Nut	
12	390830	1	Service indicator	
13	392091	1	Bracket	
14	904734	2	Washer	8,4x26x4
15	500023	2	Screw	M8-1,25x40 8.8
16	904556	2	Washer	8,4x16x3,0
17	570005	2	Hexagon nut	M8-1,25 8

Fuel system

CP142200300040




Fuel system

Item	Part No	Rem	Qty	Description	Code
1	388879		1	Fuel tank	
2	246069	A	1	Fuel hose	
3	195593		1	Cap	
4	925966		1	Rubber sealing	
5	193527		2	Pipe	
6	374764		1	Plug	
7	194312		2	Shim	
8	194311		2	Shim	
9	330330		2	Seal ring	
10	297018	B	1	Rubber strip	
11	191824		2	Clamp, cpl	
12	904231		4	Washer	13x24x2
13	586019		4	Lock nut	M12-1,75 8.
14	385436		1	Fuel hose	
15	901434		1	Fuel hose	
16	313001		4	Hose clamp	
19	246057	C	1	Hose	
20	950301		1	Pre-fuel filter	
21	330171		3	Hollow screw	
22	313041			Cable ties	L=186mm
23	162024		6	Saling washer	

- A) L=
- B) L=1640 mm
- C) L=1300 mm

Exhaust system
CP142200300060



Exhaust system

Item	Part No	Rem Qty	Description	Code
1	170639	1	Exhaust tube	
2	194287	1	Flexible pipe	
3	390340	1	Muffler	
4	170640	1	Exhaust tube	
5	904359	3	Pipe clamp	
6	378644	1	V-band clamp	
7	170641	1	Exhaust tube	
8	313036	1	Pipe clamp	
9	170673	1	Bracket	
10	904231	3	Washer	13x24x2
11	500051	3	Screw	M12-0,25H 8.8
12	379184	2	Washer	
13	904229	8	Washer	M8-8,4x16x1,5
14	500021	4	Screw	M8-1,25x25 8.8
15	570005	4	Hexagon nut	M8-1,25 8
16	4812100302	1	Thermal protection	
17	904230	4	Washer	M10 10,5x22x2
18	500028	2	Screw	M10-1,5x25 8.8
19	570006	2	Hexagon nut	M10-1,5 8.





Hydraulic system

Hydraulic system

Item	Part No	Rem Qty	Description	Code
10		1	Propulsion system (Page 52)	
11		1	Hydraulic oil tank (Page 54)	
12		1	Hydraulic filters (Page 56)	
15		1	Drain system (Page 58)	
20		1	Speed system (Page 60)	
25		1	Hydraulic steering (Page 62)	

Propulsion system


CP142200500030



Propulsion system

Item	Part No	Rem Qty	Description	Code
1	193773	1	Connection-T	
2	923384	2	Flange half	
3	813429	1	O-ring	
5	313102	1	Cable ties	
9	376123	2	Hydraulic motor	
10	813443	4	O-ring	
11	923384	8	Flange half	
12	813443	4	O-ring	
13	343732	2	Hose clamp	
14	904230	4	Washer	M10 10,5x22x2
15	500077	2	Screw	
16	335914	1	Cover plate	
17	570006	2	Hexagon nut	M10-1,5 8.
18	349933	1	Flange coupling	
19	904005	1	O-ring	
20	232222	1	Plug	
22	380168	1	Accumulator	
23	904640	2	Washer	M08-8,4x22x3
24	500021	2	Screw	M8-1,25x25 8.8
25	334139	1	Straight connector	
26	234810	1	Elbow 90, O-ring	
27	334138	1	Adapter with o-ring	
28	234243	1	T-connector	
29	792135	1	Elbow 90° with o-ring	
30	234900	1	T-connector	
31	891953	1	Nipple with O-ring	
32	334155	4	Connector elbow 90°	
33	334155	1	Connector elbow 90°	
34	910162	2	Measuring nipple	
35	4812100211	1	Hydraulic hose	
36	4812100211	1	Hydraulic hose	
37	482391	1	Hydraulic hose	
38	483414	1	Hydraulic hose	
39	483414	1	Hydraulic hose	
40	483299	1	Hydraulic hose	
41	482980	1	Hydraulic hose	
42	482182	1	Hydraulic hose	


Hydraulic oil tank
CP142200500035



Hydraulic oil tank

Item	Part No	Rem Qty	Description	Code
1	170529	1	Hydraulic oil tank	
2	170693	1	Cover	
3	170694	1	Gasket	
4	989151	1	Oil level glass	
5	357138	1	Breather	
7	234958	2	Straight connector	
8	814251	1	Elbow 90G	
9	334174	1	Elbow 90G	
10	923294	1	Tee-connector	
11	234909	1	Straight connector	
12	904638	4	Washer	12x22x2
13	500051	4	Screw	M12-0,25H 8.8
14	234667	1	Reducer	
15	902520	12	Screw	
16	334264	1	Reducing	

Hydraulic filters
CP142200500045




Hydraulic filters

Item	Part No	Rem Qty	Description	Code
1	4700372229	2	Hydraulic oil filter element	

Drain system


CP142200500070



Drain system

Item	Part No	Rem Qty	Description	Code
1	813499	1	Elbow 90G with O-ring	
2	334121	2	Straight connector	
3	234909	1	Straight connector	
4	482041	1	Hydraulic hose	
5	334156	1	Adapter	
6	233304	1	Ball valve	
7	232039	1	Plug	G3/4
8	4812100314	1	Bracket	
9	921050	1	Clamp	
10	586003	1	Lock nut	M8
11	500053	1	Screw	M8-1,25x20 8.8
12	904230	1	Washer	M10 10,5x22x2
13	500028	1	Screw	M10-1,5x25 8.8
14	904229	2	Washer	M8-8,4x16x1,5
15	234662	1	Elbow 45°	
16	170692	1	Hydraulic hose	
17	483148	1	Hydraulic hose	
18	482841	1	Hydraulic hose	
19	482247	1	hydraulic hose	
20	170691	1	hydraulic hose	

Speed system
CP142200500080



Speed system

Item	Part No	Rem Qty	Description	Code
1	192833	1	Reversing valve	
2	234349	3	Connector	
3	334234	1	Tee-connector	
4	334524	1	Elbow 90G with nut	
5	500079	2	Screw	M6-1x50 8.8
6	904228	2	Washer	M6-6,4x12x1,5
7	570004	2	Hexagon nut	M6
8	234233	2	Adapter	
9	892446	1	Plug	
11	483069	1	Hydraulic hose	
12	482497	1	Hydraulic hose	
13	483419	1	Hydraulic hose	
14	483420	1	Hydraulic hose	

Hydraulic steering

Item	Part No	Rem Qty	Description	Code
1	376545	1	Hydraulic pump	
2	904557	2	Washer	10,5x22x4
3	502035	2	Screw	3/8"-16UNCx1 8.8
4	313102	N	Cable ties	
7	193807	1	Steering cylinder (S)	
9	801198	2	Elbow 90G	
10	813499	1	Elbow 90G with O-ring	
11	334124	1	Connector	
12	193774	1	Connector	
13	910161	1	Measuring nipple	
14	170691	1	hydraulic hose	
15	482669	1	Hydraulic hose	
16	482880	1	Hydraulic hose	
17	482896	1	Hydraulic hose	
18	482669	1	Hydraulic hose	


Electrical equipment

Electrical equipment

Item	Part No	Rem	Qty	Description	Code
10			1	Electrical equipment (Page 66)	
15			1	Driving lights (Page 70)	
20			1	Working lights (Page 72)	

Electrical equipment

CP142200600010




Electrical equipment

Item	Part No	Rem Qty	Description	Code
1	388934	1	Holder plate	
2	470029	1	Battery	
3	193574	1	Shim	360x45 mm
4	193575	1	Shim	360x180 mm
5	193569	1	Battery holder	
6	264650	2	Screw	3/8-16UNC
7	903640	1	Battery switch	
8	904448	1	Relay	12V 75A
9	903631	1	Temperature sensor / Hydraulic	1/2-NPTF 40-120C
10	791129	1	Fuel level sender	
11	945777	1	Gasket	
12	904698	8	Washer	4,3x8x0,8
13	500258	5	Screw	M4-0,7x20 8.8
14	900798	1	Back-up alarm	
15	901766	1	Connector	2-POL
16	960273	2	Terminal	
17	904281	6	Washer	M05-5,3x10x1
18	500087	2	Screw	M05-2,5 8.8
19	586001	2	Lock nut	M5
20	500040	2	Screw	M6-1x20 8.8
21	586002	5	Lock nut	M6
22	904228	10	Washer	M6-6,4x12x1,5
23	348902	1	Bracket	
24	999027	1	Horn	
25	904229	12	Washer	M8-8,4x16x1,5
26	586003	3	Lock nut	M8
27	500053	1	Screw	M8-1,25x20 8.8
28	374545	4	Cover	
29	904696	16	Screw	M5x14
30	903632	1	Temperature sensor / Engine	1/2-NPTF 40-120C
31	500022	4	Screw	M8-1,25x30 8.8
32	4812100303	1	Bracket	
33	388946	1	Hood	
34	500013	3	Screw	M6-1x16 8.8
35	570004	4	Hexagon nut	M6
36	791532	1	Fuse box	
37	791557	2	Fuse	125A (Green)
38	378745	1	Control unit	
39	904036	1	Fuse holder	
40	791183	2	Relay	12V 100A
41	500012	4	Screw	M6-1,0x12 8.8
42	500004	2	Screw	M5-0,8x12 8.8
43	791185	1	Fuse box	
44	901227	2	Fuse	10A (Red)
45	901225	1	Fuse	5A (Tan)
46	901767	4	Screw	ST3,5x9,5 Black
47	792414	1	Switch	3 position RPM
48	791582	1	Switch	2 position Parking brake
49	392996	1	Display panel	
50	394061	1	Decal	
51	791578	1	Switch	2 position Horn
52	791657	1	Switch	2 position Horn
53	791579	1	Switch	3 position RPM
54	791588	6	Panel plug	
55	238158	1	Ignition switch	
56	792319	1	Pilot lamp	Yellow
57	792435	1	Pilot lamp	Red
58	792318	1	Switch	3 position
59	792317	1	Switch	2 position
60	791647	1	Emergency stop	
61	385599	1	Buzzer	

Electrical equipment

CP142200600010




Electrical equipment

Item	Part No	Rem Qty	Description	Code
62	4812100294	1	Cable harness panel	
63	4812100295	1	Cable harness engine	
64	4812100296	1	Cable harness front	
65	792314	2	Connector	
66	792313	1	Connector	
67	792432	1	Contact block	Red
68	792315	1	Contact block	Yellow
69	792091	1	Fuse box	
70	901228	1	Fuse	15A (Blue)
71	791520	1	Connection cable, coarse	
72	904919	1	Battery cable	
73	904748	1	Battery cable negative	
74	791518	1	Connection cable, coarse	
75	791518	1	Connection cable, coarse	
76	904750	1	Connection cable, coarse	
77	901851	1	Electrical cable	
78	500021	6	Screw	M8-1,25x25 8.8
79	904230	2	Washer	M10 10,5x22x2
80	571003	2	Hexagon nut	3/8-16 UNC
81	570005	6	Hexagon nut	M8-1,25 8
82	500075	3	Screw	M6-1x25 8.8
83	792083	1	Protective plug	
84	902223	3	Screw	ST4,8x9,5

Driving lights


CP142200600011



Driving lights

Item	Part No	Rem Qty	Description	Code
1	380824	1	Holder plate, Right	
2	380825	1	Holder plate, Left	
3	791583	1	Switch	3 position RPM
4	791584	1	Switch	2 position HORN
5	792413	1	Switch	3 position RPM
6	903741	1	Fuse	20A (Yellow)
7	901227	1	Fuse	10A (Red)
8	904989	1	Relay	
9	791138	1	Relay	12V 30A
10	904229	4	Washer	M8-8,4x16x1,5
11	500053	4	Screw	M8-1,25x20 8.8
12	902066	2	Head light	
13	904315	1	Direction lamp	front left side
14	904316	1	Direction lamp	front right side
15	904317	1	Direction lamp	
16	904318	1	Direction lamp	
17	904792	4	Rubber cap	
18	928502	6	Bulb	21w
19	985014	4	Bulb	5w
20	904315	1	Direction lamp	front left side
21	904698	8	Washer	4,3x8x0,8
22	533013	8	Screw	M4x20
23	904316	1	Direction lamp	front right side
24	904317	1	Direction lamp	
25	904318	1	Direction lamp	
26	902066	2	Head light	
27	902227	2	Work light	
28	900790	2	Bulb	60/55w H4
29	928502	6	Bulb	21w
30	985014	4	Bulb	5w
31	901369	2	Bulb	55w H3
32	904792	4	Rubber cap	

Working lights
CP142100600020



Working lights


Item	Part No	Rem Qty	Description	Code
1	791587	1	Switch	2 position work lightning
2	903741	1	Fuse	20A (Yellow)
3	791138	1	Relay	12V 30A
4	902227	4	Work light	
5	901369	4	Bulb	55w H3
6	904792	4	Rubber cap	

Drivers platform

Drivers platform

Item	Part No	Rem Qty	Description	Code
10		1	Drivers platform (Page 76)	
15		1	Handrail (Page 78)	
20		1	Drivers seat (Page 80)	
25		1	Forward and reverse control handle (Page 82)	

Drivers platform
CP142200700010




Drivers platform

Item	Part No	Rem Qty	Description	Code
1	378335	1	Steering column	
2	378633	1	Instrument panel	
3	901123	1	Steering column	
4	170597	1	Steering valve	
5	355869	2	Spacer sleeve	
6	372964	1	Steering wheel, cpl	
7	387226	1	Column cover	
8	928830	1	Rubber washer	
9	904230	12	Washer	M10 10,5x22x2
10	500048	2	Screw	M10-1,5x20 8.8
11	500031	2	Screw	M10-1,5x40 8.8
12	500029	4	Screw	M10-1,5x30 8.8
13	500505	2	Screw	M8x20 8.8
14	813444	4	Elbow 90, O-ring	
15	902166	1	Edge trim	
16	500028	4	Screw	M10-1,5x25 8.8
17	387683	1	Distribution control plate	
18	903782	4	Thread rolling screw	

Handrail


CP142200700015



Handrail

Item	Part No	Rem Qty	Description	Code
1	381006	1	Handrail	
2	170678	1	Handrail	
3	170675	1	Handrail	
4	381008	1	Hand rail	
5	193738	2	Clamp	
6	500022	16	Screw	M8-1,25x30 8.8
7	629019	3	Expanding pin	

Drivers seat
CP142200700025



Drivers seat

Item	Part No	Rem Qty	Description	Code
1	170591	1	Floor assy	
2	193736	1	Tool box	
3	377518	1	Seat	
4	927026	6	Screw with washer	
5	904231	2	Washer	13x24x2
6	500037	2	Screw	M12-1,75x35 8.8
7	391060	1	Forward / Reverse control	
8	170657	1	Bracket	
9	904230	6	Washer	M10 10,5x22x2
10	500029	2	Screw	M10-1,5x30 8.8
11	170601	1	Cover	
12	500021	2	Screw	M8-1,25x25 8.8
13	904556	2	Washer	8,4x16x3,0
14	508019	2	Screw	M8x025H 8.8
15	904228	2	Washer	M6-6,4x12x1,5
16	904281	8	Washer	M05-5,3x10x1
17	500060	4	Screw	M5x020H
18	586001	4	Lock nut	M5
19	586003	6	Lock nut	M8
20	586018	2	Lock nut	M10
21	904229	4	Washer	M8-8,4x16x1,5
22	383705	1	Instruction book holder	
23	791226	4	Screw	4,2x13
24	573003	1	Nut	M6
25	904557	2	Washer	10,5x22x4
26	570005	2	Hexagon nut	M8-1,25 8
27	500023	2	Screw	M8-1,25x40 8.8

Forward and reverse control handle

Item	Part No	Rem Qty	Description	Code
1	4700945407	1	Lever, cpl	
2	4700940374	1	. Handle kit, cpl	
		1	. . Handle	
	4700945729	1	. . . Push-button switch	
		1	. . . Cable	
		1	. . Lock fluid	
		1	. . Service information	
3		1	. . Washer	
4		2	. . Washer	
5		1	. . Connector, receptable	
6		1	. . Lock wedge	
7		2	. . Pin	
8		1	. . Rod	
9		1	. . Nut	
10	4700377018	1	. . Protection plug	
11	4700378759	1	. . Handle top	
12	4700391379	1	. Lever	
13	4700377009	1	. Bellows	
14	4700570004	2	. Nut	M6 X 1,00 8 A2K
15	4700377015	2	. Set screw	
16	4700391381	1	Bushing	
17	4700391382	1	Potentiometer with cable	
18	4700377016	1	Spring loaded pin	
20	4700377010	1	Bracket	
21	4700903945	1	Connector, plug	
22	4700903946	1	Lock wedge	
23	4700508068	1	Screw	
24	4700904563	1	Lock nut	M6
25	4700927233	1	Nut	
26	4700391383	1	Screw	
27	4700903947	3	Pin	
28		1	Cable	
29	4700377011	1	Spacer	
30	4700377012	1	Friction washer	
31	4700391380	1	Cam washer	
33	4700377014	1	Spring washer	
34	4700586019	1	Lock nut	
36	4700391386	1	Spirol pin	


Decals

Decals

Item	Part No	Rem Qty	Description	Code
1		1	Decals (Page 86)	

Decals

CP142100800010



Decals

Item	Part No	Rem	Qty	Description	Code
		A	1		
2	791915		2	Decal "CP142"	
3	388449		1	Decal "Engine coolant fill"	
4	192985		1	Decal "OIL FILTER"	
5	991657		1	Decal "WATER"	
6	588176		2	Decal, "LIFT POINT"	
7	991658		1	Decal, "FUEL"	
8	383859		2	Reflector, yellow	
9	929076		2	Reflector, red	
10	383860		2	Reflector, white	
11		A	1	Documentation	
12		A	1	Documentation	
14	272372		1	Decal, "HYDRAULIC OIL"	
15	991650		1	Decal "DIRECTION"	
16	193882		1	Decal "ENGINE OIL LEVEL"	
17	373363		1	Slip protection	
18	386084XX		1	Plate "Don't leave platform"	
19	903422		2	Decal "SAFETY"	
20	903424		2	Decal "HOT SURFACE"	
21	903423		1	Decal "SAFETY"	
22	903459		2	Decal "SAFETY"	
23	960787		1	Decal, identification decal "Dynapac"	
24	904895		1	Safety decal	"Brake release"
25	904870		2	Lifting sign	
26		A	1	Padlock	
27	378529		4	Decal "TYRE PRESSURE"	
28	904093		3	Decal, Svedala Dynapac	L= 1010 mm
30	904095		1	Decal "DYNAPAC"	L=880 mm
31	903425		1	Decal "SAFETY MANUAL"	
32	624015		24	Blind rivet	4,0x8,5
33	908229		2	Decal "SAFETY"	
34	382751		4	Decal "TIE DOWN POINT"	
35	904835		1	Decal "BATTERY POWER"	
36	348331		1	Seat cover	
37	384154		1	Loading/Unloading instruction	
38	624017		2	Blind rivet	
39	791275		1	Decal "Sound power level"	105dB
	791275		1	Decal "Sound power level"	105dB
	791275		1	Decal "Sound power level"	105dB
	791275		1	Decal "Sound power level"	105dB

A) See section: Standard equipment


Standard equipment

Standard equipment

Item	Part No	Rem	Qty	Description	Code
10			1	Standard equipment (Page 90)	

Standard equipment

CP1421009000100



Standard equipment

Item	Part No	Rem Qty	Description	Code
1		1	Missing description	OMS142xx
		1	. Warranty registration card	
		1	. Operating instruction	O142xx
		1	. Maintenance instruction	
		1	. Spare parts catalogue	SCP142xxxx
2		1	. Operating / maintenance instruction	OM142xx
3		1	. Safety manual	RSAFExx
4		3	. Padlock	


Optional equipment

Optional equipment

Item	Part No	Rem	Qty	Description	Code
10			1	Canopy (Page 94)	
15			1	Rotating beacon (Page 96)	
20			1	Tool equipment (Page 98)	

Canopy

CP142100910010




Canopy

Item	Part No	Rem	Qty	Description	Code
1	261152		1	Canopy	
2	198190	A	1	Frame	
3	450089		4	Shock absorber	
4	615044		4	Conical spring washer	
5	570006		4	Hexagon nut	M10-1,5 8.
6	900235		8	Screw	M18x120
7	904793		16	Washer	19x34x3
8	925206		8	Nut	M18

A) With 4 lower mounting holes on side instead of the 2 illustrated


Rotating beacon
CP142100910020



Rotating beacon

Item	Part No	Rem Qty	Description	Code
1	389577	1	Rotating beacon	
2	904228	1	Washer	M6-6,4x12x1,5
3	500013	1	Screw	M6-1x16 8.8
4	500021	2	Screw	M8-1,25x25 8.8
5	904229	2	Washer	M8-8,4x16x1,5
6	358452	1	Lamp holder	
7	372674	1	Spacer	
8	374398	1	Cable harness	

Tool equipment
17687



Tool equipment

Item	Part No	Rem Qty	Description	Code
1	196029	1	Tool kit	
2	485011	1	. Adjustable wrench	
3	268964001	1	. Screw driver	1/8" x 3"
	268964002	1	. Screw driver	1/8" x 5"
	268964003	1	. Screw driver	1/4" x 8"
	268964004	1	. Screw driver	3/8" x 12"
4	926040	1	. Wheel nut spanner	24/27MM
5	268964017	1	. Ball pan hammer	
6	485075	1	. Strap wrench	
7	485060	1	. Air pressure gauge	
8	904809	1	. Spanner	16/17MM
	904810	1	. Spanner	18/19MM
9	485183	1	. Spanner	10MM
	485186	1	. Spanner	13MM
10	311016	1	. Hand-operated pump	
11	277992	1	. Tool bag	

